

DISASSEMBLY

1. REMOVE BELT GUIDES

Remove the 8 screws and 3 belt guides.

2. REMOVE CENTER ARMREST

- (a) Remove the 2 nuts and center armrest assembly.
- (b) Remove the 2 screws and center armrest door.

3. REMOVE SEATBACK COVER

- (a) Remove the 3 bolts and center headrest.
- (b) Remove the 4 headrest supports.
- (c) Remove the hog rings and seatback frame from the seatback cover with pad.
- (d) Remove the hog rings and seatback cover from the seatback pad.

4. REMOVE SEAT CUSHION COVER

- (a) Remove the hog rings and seat cushion frame from the seat cushion cover with pad.
- (b) Remove the hog rings and seat cushion cover from the seat cushion pad.