

HOW TO PROCEED WITH TROUBLESHOOTING

HINT:

- Use this procedure to troubleshoot the power mirror control system with memory function.
- The intelligent tester II should be used in steps 3 and 5.

1 VEHICLE BROUGHT TO WORKSHOP

2 CUSTOMER PROBLEM ANALYSIS CHECK AND SYMPTOM CHECK (See page 05-2079)

3 INSPECT COMMUNICATION FUNCTION OF LARGE-SCALE MULTIPLEX COMMUNICATION SYSTEM (BEAN)

- (a) Use the intelligent tester II to check for normal function of the multiplex communication system.
- (1) (ECU unconnected, communication line malfunctioning) Without code outputs, proceed to A.
 - (2) (ECU unconnected, communication line malfunctioning) With code outputs, proceed to B.

B

Go to MULTIPLEX COMMUNICATION SYSTEM (See page 05-3128)

A

4 PROBLEM SYMPTOMS TABLE (See page 05-2080)

- (a) If the fault is not listed on the problem symptoms table, proceed to A.
- (b) If the fault is listed on the problem symptoms table, proceed to B.

B

Go to step 6

A

5 OVERALL ANALYSIS AND TROUBLESHOOTING

- (a) DATA LIST/ACTIVE TEST (see page 05-2089).
- (1) Inspection with the intelligent tester II (DATA LIST).
 - (2) Inspection with the intelligent tester II (ACTIVE TEST).
- (b) Terminals of ECU (see page 05-2081).
- (c) Inspection (see page 70-39).

6 ADJUSTMENT, REPAIR OR REPLACE

| | |
|---|-------------------|
| 7 | CONFIRMATION TEST |
|---|-------------------|



| |
|-----|
| END |
|-----|