

DIAGNOSTIC TROUBLE CODE CHART

If a DTC is displayed, check the circuit for that code listed in the table below. For the details of each code, refer to the "See page" column for the respective DTC No. in the DTC chart.

DTC No. (See Page)	Detection Item	Trouble Area
B2602 (05-696)	Key un-lock warning switch circuit malfunction	<ul style="list-style-type: none"> • Un-lock warning switch assy • Un-lock warning switch circuit • Transponder key ECU *1 (Steering lock ECU *2) • Multiplex tilt & telescopic ECU
B2610 (05-701)	Tilt position sensor or tilt motor circuit malfunction	<ul style="list-style-type: none"> • Power tilt motor (w/ tilt position sensor) • Actuator power source circuit • Tilt position sensor or tilt motor circuit • Multiplex tilt & telescopic ECU
B2611 (05-707)	Telescopic position sensor or telescopic motor circuit malfunction	<ul style="list-style-type: none"> • Power telescopic motor (w/ telescopic position sensor) • Actuator power source circuit • Telescopic position sensor or telescopic motor circuit • Multiplex tilt & telescopic ECU
B2620 (05-713)	ECU power source circuit malfunction	<ul style="list-style-type: none"> • Battery • ECU power source circuit • Multiplex tilt & telescopic ECU
B2621 (05-717)	Communication interruption	<ul style="list-style-type: none"> • Multiplex communication system • Driver side J/B • Position control ECU & switch assy (Driver seat ECU) • Turn signal switch assy • Steering column assy (Steering lock ECU) • Multiplex tilt & telescopic ECU

*1: w/o Smart key

*2: w/ Smart key