

CHECK FOR INTERMITTENT PROBLEMS

HINT:

Intelligent Tester II only:

Inspect the vehicle's ECM using check mode. Intermittent problems are easier to detect when the Intelligent Tester II is in check mode. In check mode, the Intelligent Tester II uses 1 trip detection logic, which has a higher sensitivity to malfunctions than normal mode (default), which uses 2 trip detection logic.

- (a) Clear the DTCs (see page 05-26).
- (b) Set the check mode (see page 05-27).
- (c) Perform a simulation test.
- (d) Check the connector and terminal (see page 01-44).
- (e) Wiggle the harness and the connector (see page 01-44).