



REMOVAL

1. REMOVE REAR WHEEL
2. REMOVE TOE CONTROL LINK
 - (a) Remove the nut.



- (b) Using SST, disconnect the toe control link from the axle carrier.
SST 09610-20012



- (c) Place matchmarks on the cam plate and rear suspension member.
 - (d) Remove the nut, toe adjust plate, toe adjust cam and toe control link.