

RTC Based Alarm Clock : USER MANUAL

A. Set Clock Time:

- step 1. Press Hour Button to set Hour
- step 2. Press Minute Button to set Minute

B. Set Alarm Time:

- step 1. Press Config_Alarm button to enter configuration mode
- step 2. Press Hour Button to set alarm hour
- step 3. Press Minute Button to set alarm minute
- step 4. Press Config_Alarm button to exit configuration mode

C. Turn On Alarm:

- step 1: Press Alarm ON/OFF button [screen will display 'ON']

D. Turn Off Alarm:

- step 1: Press Alarm ON/OFF button [screen will display 'OFF']