




WRO 2017

Advanced Robotic Challenge

Solution Program Introduction

Made by *Alex Tkachenko*



TETRIS LabVIEW Project

VI's you need are listed below

Move arm

Close robot connection

Open robot connection, Initialize

Push Robot to the border

Go to the line



Move robot


Find next object and pick it up

MAIN Program, Run it

Put the object into the stacking form


MAIN program






Move the robot


Input / Output	Value
KNR in/out, error in/out	Connect to other blocks.
mode	Movement type. Right click -> Create -> constant/control. Type enum. Values are <straight, turn left, turn right>.
speed	Movement speed in centimeters (cm) per second. Any value in range [0, 50] . Example: 0 – stop, 10 – slow, 50 – fast.
DST	In <i>straight</i> mode – distance in centimeters (cm) to travel. In <i>turn</i> mode – turn degree. Only one wheel is moving. Example: 180 - turn around Negative (-) value means another direction.



Move arm




Input / Output	Value
KNR in/out, error in/out	Connect to other blocks.
X,Y	X,Y coordinate in the robot coordinate system in (cm). Arm would be moved there.
fg	Final absolute position of the <i>fingers</i> . <i>Ex: 0 – horizontal (as on picture).</i> <i>Ex: -90 – look down</i>



Move till light sensor detects a **black** line



Input / Output	Value
KNR in/out, error in/out	Connect to other blocks.
Forward?	TRUE – move forward FALSE – move backward




Moves, detects the object and picks it up

Input / Output	Value
KNR in/out, error in/out	Connect to other blocks.
FinalY	In the end raises the object to the desired level in the <i>stacking from coordinate system (Discussed further)</i>
Drove	The distance the robot travelled to find the objects. Is used to calculate the way back.

Opens/ closes connection




Input / Output	Value
KNR in/out, error in/out	Connect to other blocks.
Battery	Battery charge level




Puts the object into the stacking form

Stacking form coordinate system



Input / Output	Value
KNR in/out, error in/out	Connect to other blocks.
X,Y	X and Y coordinate in the <i>stacking form coordinate system</i>



Pushes the robot to the border


Input / Output	Value
KNR in/out, error in/out	Connect to other blocks.
Homing v	Power on the motors (out of 100%).

Troubleshooting

1. Robot **turns** not exactly 90°

Your wheel base might be slightly different.
Wheelbase – distance between wheels.
Turns too much? Decrease value
Turns not enough? Increase value

Move.vi




2. Robot **finger** position is not calibrated

Calibrated fingers work as follows:
Middle RC position (1500) means fingers are aligned parallel with the arm shoulder
However, this value may not be exactly 1500, set your own value there.

Arm XY to Motor Angles.vi

```
p3 = max(min(p3, 16.5), 3.4) - 3.3;  
p4 = max(min(p4, 16), 6) - 5.9;  
float64 rev3 = p3 * 2.5;  
float64 rev4 = p4 * 2.5;  
  
ulInt16 fgout = 1476 + (1600/180)* (-270-fg+(alpha+beta)*180/pi);  
fgout = max(min(fgout, 2300), 700);
```





3. Light sensor has problems detecting the line


Different light sensors may have different sensitivity.
At first, try to change black threshold.
If this doesn't help, try to check setup values. First number is the voltage on white, second – range from white to black.

Also check the connection at the analog port.


Line.vi



4. Robot doesn't put the object in the right position at the stacking form



After we found the **line**, there is a starting offset (in cm) between the **current position** and the center of the **first cell** in the *stacking form coordinate system*. This value may differ, if your stacking form is slightly misaligned with the central **black line**.



More at
<http://www.knrrobotics.com>



Made by *Alex Tkachenko*