

EC2x&EG9x&EG25-G Series

QuecOpen FTP Service

User Guide

LTE Standard Module Series

Rev. EC2x&EG9x&EG25-G_Series_QuecOpen_FTP_Service_User_Guide_
V1.0

Date: 2020-07-17

Status: Released

Our aim is to provide customers with timely and comprehensive service. For any assistance, please contact our company headquarters:

Quectel Wireless Solutions Co., Ltd.

Building 5, Shanghai Business Park Phase III (Area B), No.1016 Tianlin Road, Minhang District, Shanghai 200233, China

Tel: +86 21 5108 6236

Email: info@quectel.com

Or our local office. For more information, please visit:

<http://www.quectel.com/support/sales.htm>

For technical support, or to report documentation errors, please visit:

<http://www.quectel.com/support/technical.htm>

Or email to: support@quectel.com

GENERAL NOTES

QUECTEL OFFERS THE INFORMATION AS A SERVICE TO ITS CUSTOMERS. THE INFORMATION PROVIDED IS BASED UPON CUSTOMERS' REQUIREMENTS. QUECTEL MAKES EVERY EFFORT TO ENSURE THE QUALITY OF THE INFORMATION IT MAKES AVAILABLE. QUECTEL DOES NOT MAKE ANY WARRANTY AS TO THE INFORMATION CONTAINED HEREIN, AND DOES NOT ACCEPT ANY LIABILITY FOR ANY INJURY, LOSS OR DAMAGE OF ANY KIND INCURRED BY USE OF OR RELIANCE UPON THE INFORMATION. ALL INFORMATION SUPPLIED HEREIN IS SUBJECT TO CHANGE WITHOUT PRIOR NOTICE.

COPYRIGHT

THE INFORMATION CONTAINED HERE IS PROPRIETARY TECHNICAL INFORMATION OF QUECTEL WIRELESS SOLUTIONS CO., LTD. TRANSMITTING, REPRODUCTION, DISSEMINATION AND EDITING OF THIS DOCUMENT AS WELL AS UTILIZATION OF THE CONTENT WITHOUT PERMISSION ARE FORBIDDEN. OFFENDERS WILL BE HELD LIABLE FOR PAYMENT OF DAMAGES. ALL RIGHTS ARE RESERVED IN THE EVENT OF A PATENT GRANT OR REGISTRATION OF A UTILITY MODEL OR DESIGN.

Copyright © Quectel Wireless Solutions Co., Ltd. 2020. All rights reserved.

About the Document

Revision History

Version	Date	Author	Description
1.0	2020-07-17	Mike ZHOU/ Tinker SUN	Initial

Contents

About the Document	2
Contents	3
Table Index	4
Figure Index	5
1 Introduction	6
1.1. Applicable Modules	6
2 FTP Service.....	7
2.1. Overview	7
2.2. Startup Methods	7
2.2.1. Startup Through Shell Command Line.....	8
2.2.2. Startup Through init.d Service.....	8
2.2.3. Startup Through inetd Service	9
2.3. FTP Service Verification And Use	11
3 Appendix A Reference.....	13

Table Index

Table 1: Applicable Modules..... 6

Table 2: Terms and Abbreviations 13

Figure Index

Figure 1: FTP Usage Help Information	7
Figure 2: Start FTP Service Through Shell Command Line.....	8
Figure 3: Start or Stop FTP Service Through init.d Service	9
Figure 4: Start or Stop FTP Service Through inetd Service.....	11
Figure 5: Client Connects to FTP Server	12
Figure 6: Access FTP Server Through A Browser	12

1 Introduction

Quectel LTE Standard EC2x&EG9x&EG25-G series modules support QuecOpen® solution. This document mainly guides you to start, verify and use the FTP service of these modules.

1.1. Applicable Modules

Table 1: Applicable Modules

Module Series	Module
EC2x series	EC25 series
	EC21 series
	EC20 R2.1
EG9x series	EG95 series
	EG91 series
EG25-G	EG25-G

2 FTP Service

2.1. Overview

FTP (File Transfer Protocol) is a TCP-based protocol that uses a client/server mode. Through the protocol, users can upload or download files on the FTP server.

The FTP service of Quectel EC2x&EG9x&EG25-G series QuecOpen modules is a built-in service provided by Busybox. It is not started by default and can be started as described in **Chapter 2.2**.

Execute the following command in the shell command line of the module to view the FTP usage help information, as shown in the following figure.

ftpd

```
root@mdm9607-perf:~# ftpd
BusyBox v1.23.1 (2018-02-06 08:15:29 UTC) multi-call binary.

Usage: ftpd [-wvS] [-t N] [-T N] [DIR]

Anonymous FTP server

ftpd should be used as an inetd service.
ftpd's line for inetd.conf:
    21 stream tcp nowait root ftpd ftpd /files/to/serve
It also can be ran from tcpsvd:
    tcpsvd -vE 0.0.0.0 21 ftpd /files/to/serve

-w    Allow upload
-v    Log errors to stderr. -vv: verbose log
-S    Log errors to syslog. -SS: verbose log
-t,-T Idle and absolute timeouts
DIR   Change root to this directory
```

Figure 1: FTP Usage Help Information

2.2. Startup Methods

EC2x&EG9x&EG25-G series QuecOpen modules support three methods to start FTP service (through shell command line, init.d service or inetd service). You can choose any of them according to the actual situation. This chapter mainly introduces these three methods and their startup steps.

2.2.1. Startup Through Shell Command Line

Start FTP service through the following shell command line.


```
tcpsvd -vE 0.0.0.0 21 ftpd -w /data
```

0.0.0.0 Indicates IP address.

21 Indicates FTP port.

-w Indicates that FTP has the permission to upload file.

/data Indicates FTP directory.



```
root@mdm9607-perf:~# tcpsvd -vE 0.0.0.0 21 ftpd -w /data
tcpsvd: listening on 0.0.0.0:21, starting
```

Figure 2: Start FTP Service Through Shell Command Line

2.2.2. Startup Through init.d Service

To start the FTP service through the init.d service, the module needs to integrate the FTP service startup script *start_ftpd_le*. Currently the startup script is not integrated in the module by default and you need to upload it to directory */etc/init.d* of the module (or directory *ql-ol-rootfs/etc/init.d* in SDK package) before you can start FTP service through the init.d service.

1. Upload the startup script *start_ftpd_le* to directory */etc/init.d*. An example of the file contents is as follows:

```
#!/bin/sh
#
# Copyright (c) 2009-2020 @ Quectel Wireless Solutions Co., Ltd. All Rights Reserved.
#
# FTP Server init.d script to start the busybox FTP daemon

DAEMON=/bin/tcpsvd
IP=0.0.0.0
PORT=21
PATH=/data

set -e

case "$1" in
    start)
        echo -n "Starting Busybox FTP Server: "
        /sbin/start-stop-daemon -S -b -a $DAEMON -- -vE $IP $PORT /sbin/ftpd -w $PATH
        echo "done"
```

```

;;
stop)
    echo -n "Stopping Busybox FTP Server: "
    /sbin/start-stop-daemon -K -x $DAEMON
    echo "done"
;;
restart)
    $0 stop
    $0 start
;;
*)
    echo "Usage $0 { start | stop | restart}" >&2
    exit 1
;;
esac

exit 0


```

2. Execute the following command in shell environment of the module to start FTP service.

```
/etc/init.d/start_ftpd_le start
```

Executing the following command in shell environment of the module can stop FTP service.

```
/etc/init.d/start_ftpd_le stop
```



```

root@mdm9607-perf:~#
root@mdm9607-perf:~# /etc/init.d/start_ftpd_le start
Starting Busybox FTP Server: done
root@mdm9607-perf:~# /etc/init.d/start_ftpd_le stop
Stopping Busybox FTP Server: stopped /bin/tcpsvd (pid 2152)
done
root@mdm9607-perf:~#

```

Figure 3: Start or Stop FTP Service Through init.d Service

2.2.3. Startup Through inetd Service

1. Modify `/etc/init.d/inetd.busybox` file in the module and an example of the file contents is as follows:

```

#!/bin/sh
#
# start/stop inetd super server.

INETD_DAEMON=/sbin/inetd

```

```
if ! [ -x $INETD_DAEMON ]; then
    exit 0
fi

case "$1" in
    start)
        echo -n "Starting internet superserver:"
        echo -n " inetd" ; start-stop-daemon -S -x $INETD_DAEMON > /dev/null
        echo "."
        ;;
    stop)
        echo -n "Stopping internet superserver:"
        echo -n " inetd" ; start-stop-daemon -K -x $INETD_DAEMON > /dev/null
        echo "."
        ;;
    restart)
        echo -n "Restarting internet superserver:"
        echo -n " inetd "
        killall -HUP inetd
        echo "."
        ;;
    *)
        echo "Usage: /etc/init.d/inetd {start|stop|restart}"
        exit 1
        ;;
esac

exit 0
```

2. Add the following contents to the */etc/inetd.conf* configuration file.

```
21 stream    tcp    nowait    root    ftpd    ftpd -w /data
```

21 Indicates FTP port.

/data Indicates FTP directory.

An example of the configuration file contents is as follows:

```
# /etc/inetd.conf:  see inetd(8) for further informations.
#
# Internet server configuration database
#
# If you want to disable an entry so it isn't touched during
# package updates just comment it out with a single '#' character.
```


```
#  
# <service_name> <sock_type> <proto> <flags> <user> <server_path> <args>  
#  
#:INTERNAL: Internal services  
21      stream  tcp   nowait  root    ftpd    ftpd -w /data
```

3. Execute the following command in the shell environment to start FTP service.

```
/etc/init.d/inetd.busybox start
```

Executing the following command in the shell environment can stop FTP service.

```
/etc/init.d/inetd.busybox stop
```



```
root@mdm9607-perf:~# /etc/init.d/inetd.busybox start  
Starting internet superserver: inetd.  
root@mdm9607-perf:~# /etc/init.d/inetd.busybox stop  
Stopping internet superserver: inetd.  
root@mdm9607-perf:~#
```

Figure 4: Start or Stop FTP Service Through inetd Service

2.3. FTP Service Verification And Use

Perform the following steps to verify the FTP service connection and use the service.

1. Connect FTP client to FTP server.

After starting the FTP service, the FTP client connects to the FTP server, and the username and password must be the same as that of logging in to the module through the debug UART. The example is shown in the figure below (taking Windows operating system as an example, where the username for connection is root and the password is quectel123). You can use FTP service only after the connection is successful.


```

PS C:\Users\Mike\Desktop> ftp 192.168.22.106
Connected to 192.168.22.106.
220 Operation successful
530 Login with USER and PASS
User (192.168.22.106:(none)): root
331 Please specify password
Password:
230 Operation successful
ftp> ls
200 Operation successful
150 Directory listing
802.1avb.txt
alsaucm_test
atfwd_pipe
ipth_dme_urc
psm_aware_cmd
psm_aware_urc
ringtone1.wav
time
voc_svr
226 Operation successful
ftp: 117 bytes received in 0.01Seconds 7.80Kbytes/sec.
ftp>

```

Figure 5: Client Connects to FTP Server (Windows Operating System)

- After the FTP service is successfully connected, access the FTP service through a browser.



Name	Size	Modified Date
802.1avb.txt	41 B	2018/1/8 PM 9:56:00
alsaucm_test	0 B	2018/1/6 AM 8:04:00
atfwd_pipe	0 B	2018/1/6 AM 8:04:00
ipth_dme_urc	0 B	2018/1/6 AM 8:04:00
psm_aware_cmd	0 B	1970/1/1 AM 8:00:00
psm_aware_urc	0 B	2018/1/6 AM 8:04:00
ringtone1.wav	973 kB	2018/1/6 AM 8:04:00
time/		1970/1/1 AM 8:00:00
voc_svr	0 B	2018/1/6 AM 8:04:00

Figure 6: Access FTP Server Through A Browser (Windows Operating System)

3 Appendix A Reference

Table 2: Terms and Abbreviations

Abbreviation	Description
FTP	File Transfer Protocol
IP	Internet Protocol
LTE	Long Term Evolution
SDK	Software Development Kit