

EC2x-Quecopen 9x07

USB Audio Class Sound Card Testing Method

LTE Standard Module Series

Rev. EC2x-Quecopen_9x07_USB_Audio_Class_Sound_Card_Testing_

Method_V1.1

Date: 2019-04-30

Status: Preliminary

Our aim is to provide customers with timely and comprehensive service. For any assistance, please contact our company headquarters:

Quectel Wireless Solutions Co., Ltd.

7th Floor, Hongye Building, No.1801 Hongmei Road, Xuhui District, Shanghai 200233, China

Tel: +86 21 5108 6236

Email: info@quectel.com

Or our local office. For more information, please visit:

<http://www.quectel.com/support/sales.htm>

For technical support, or to report documentation errors, please visit:

<http://www.quectel.com/support/technical.htm>

Or email to: support@quectel.com

GENERAL NOTES

QUECTEL OFFERS THE INFORMATION AS A SERVICE TO ITS CUSTOMERS. THE INFORMATION PROVIDED IS BASED UPON CUSTOMERS' REQUIREMENTS. QUECTEL MAKES EVERY EFFORT TO ENSURE THE QUALITY OF THE INFORMATION IT MAKES AVAILABLE. QUECTEL DOES NOT MAKE ANY WARRANTY AS TO THE INFORMATION CONTAINED HEREIN, AND DOES NOT ACCEPT ANY LIABILITY FOR ANY INJURY, LOSS OR DAMAGE OF ANY KIND INCURRED BY USE OF OR RELIANCE UPON THE INFORMATION. ALL INFORMATION SUPPLIED HEREIN IS SUBJECT TO CHANGE WITHOUT PRIOR NOTICE.

COPYRIGHT

THE INFORMATION CONTAINED HERE IS PROPRIETARY TECHNICAL INFORMATION OF QUECTEL WIRELESS SOLUTIONS CO., LTD. TRANSMITTING, REPRODUCTION, DISSEMINATION AND EDITING OF THIS DOCUMENT AS WELL AS UTILIZATION OF THE CONTENT ARE FORBIDDEN WITHOUT PERMISSION. OFFENDERS WILL BE HELD LIABLE FOR PAYMENT OF DAMAGES. ALL RIGHTS ARE RESERVED IN THE EVENT OF A PATENT GRANT OR REGISTRATION OF A UTILITY MODEL OR DESIGN.

Copyright © Quectel Wireless Solutions Co., Ltd. 2019. All rights reserved.

About the Document

History

| Revision | Date | Author | Description |
|----------|------------|----------------------------|--|
| 1.0 | 2018-10-11 | Will SHAO/ Zichar ZHANG | Initial |
| 1.1 | 2019-04-30 | Zichar ZHANG | Updated the supported sample rate and related data |

Contents

| | |
|--|----------|
| About the Document..... | 2 |
| Contents..... | 3 |
| 1 9x07 USB Audio Class Sound Card Testing Method..... | 4 |
| 1.1. Open USB Sound Card Interface | 4 |
| 1.2. Send AT Command and Open USB Voice..... | 4 |
| 1.3. Set USB Audio Mode | 5 |
| 1.4. Test in Windows7 | 5 |
| 1.5. Test in Linux | 7 |

1 9x07 USB Audio Class Sound Card Testing Method

1.1. Open USB Sound Card Interface

UAC (USB Audio Class) function is not open by default. If it needs to be enabled, please configure the USB configuration file.

Modify Line 207 of configuration file 9025.

Add audio to functions, see details below.

After that, execute sync and reboot the module

```
root@mdm9607-perf:~# vi /sbin/usb/compositions/9025
root@mdm9607-perf:~# sync
root@mdm9607-perf:~# reboot
```

```
echo QTI,BAM_DMUX > /sys/class/android_usb/android0/f_rmnet/transport
echo BAM_DMUX > /sys/class/android_usb/android0/f_usb_mbim/mbim_transport
echo $USB_FUNC,ffs,audio > /sys/class/android_usb/android$num/functions
echo 1 > /sys/class/android_usb/android$num/remote_wakeup
echo 1 > /sys/class/android_usb/android$num/f_rndis/wceis
```

1.2. Send AT Command and Open USB Voice

```
AT+QPCMV=<enable>,<port>
```

enable: 1 Open USB Voice, 0 Close USB Voice

port: 0 USB NEMA interface, 1 UART interface, 2 USB Audio Class

Send the following command to open UAC. After that, it will close EC20 Codec and switch to USB Voice.

```
AT+QPCMV=1,2
```

OK

Send the following command to close UAC. After that, it will switch to EC20 Codec.

AT+QPCMV=0,2

OK

In UAC Mode, it supports 8KHz sample rate with data length of 16 bits and mono channel by default.

1.3. Set USB Audio Mode


Playing USB voice in default mode will produce some noise. Please send the following AT command and switch to USB Voice mode.

AT+QAUDMOD=3


OK

1.4. Test in Windows7

After executing **Chapter 1.1**, insert USB. The UAC sound card will appear in Windows7.



Set it as the default sound card.



Send AT Command **AT+QPCMV=1,2**. Open USB Voice.

Send AT Command **AT+QAUDMOD=3** to switch to USB Voice Audio mode.

Send the command to dial the cellphone number and answer it through via EC20 AT interface.

Play music in the Windows via certain music player (QQ Player, KUWO, Netease cloud music). The music played in the Windows can be heard on the cellphone.

Open the recording program in the Windows (Accessories->Recorder). All the sound sent from the cellphone terminal can be recorded.

1.5. Test in Linux

Users can play music via tinyply, however, EC20 UAC only supports 8KHz sample rate with data length of 16 bits and mono channel. Therefore, the audio file needs to be played at 8KHz sample rate with data length of 16 bits and mono channel.

```
tinyply music.wav -D x -d 0
```

Here “x” is the device number of EC20 UAC sound card, which should be the actual device number of the sound card in the system.

```
pi@NanoPi-M1-Plus:~$ ./tinyply record_sample.wav -D 4 -d 0 -r 8000 -c 1  
playing 'record_sample.wav': 1 ch, 8000 hz, 16 bit
```

Record with tinycap.

```
tinycap rec.wav -D x -d 0 -c 1 -r 16000
```

```
pi@NanoPi-M1-Plus:~$ ./tinycap rev.wav -D 4 -d 0 -r 8000 -c 1  
Capturing sample: 1 ch, 8000 hz, 16 bit
```