

Bootloader

The bootloader is installed using an ICSP programmer

The X-Controller uses the standard Arduino UNO bootloader which is **optiboot_atmega328.hex** There is a link to it on this [web page](#) .

The fuses are....

Low Byte: 0xFF

High Byte: 0xD6

Extended: 0xFD

Lock bits are all off.

Here is a screenshot of one programmer to show the fuses.

