

## MiniRef - Bold Words

<b>Tempo:</b>	w1	<b>Live:</b>	.1+.5
<b>Pitch:</b>	w2	<b>Program:</b>	.5+.1-.4
<b>Duration:</b>	w3 ↓ mutes	<b>Mixer:</b>	5+w1-w4 (transient)
<b>Envelope:</b>	w4 0.4	<b>Demo:</b>	1+on
<b>Swing:</b>	w5		
<b>Mod:</b>	5+w5 ↓ off	<b>LDR Pitch:</b>	.2+.3 w2 to revert, LM
<b>Voice:</b>	.1-.4, .5=sine	<b>Set Voices:</b>	1- 4+w1 0.14, LM
<b>Sequence Parts:</b>  1- 4+w1-w4 ↓ off, ↑ ref, PM			
<b>Scale:</b>  1+w5 0.8; any  1- 4 works, PM			
0:Chrom 1:M 2:m 3:M3 4:m3 5:M5 6:m5 7:Blu6 8:Har.m			
<b>Scale Shift Up:</b>  3+.4... <b>Down:</b>  4+.3... 15.0..15, PM			

<b>Song Shift Up:</b>  1+.2... <b>Down:</b>  2+.1... 15.0..15, PM			
<b>Save Song:</b>	1- 4+ 5	Hold 3s, 4*R, LM	
<b>Load Song:</b>	1- 4	Hold 3s, 4*Y, LM	
<b>Load Mult:</b>	1+ 2- 4	Hold 3s, 4*Y, song 1 editable, LM	
<b>Midi Voice:</b>	1- 4+w2 0.127, ↓percussion (midi 10)		
<b>Set Midi:</b>	2+on	Rotates: 3*Y = off, 3*R = 31250bps, 3*RY = 115200bps, persists	
<b>LDR Tripwire:</b>	.3+.4 3*R, calibrates 5s both high and low light, 3*Y; turn any wheel to exit, LM		
<b>Low Battery:</b>	6*RY		

+ = "together", | = hold, . = press, w = wheel, x-y = "choose one of", .x... = repeated presses, ↑/↓ = full up/down

0.n..m = LED binary display, N\*R/Y = N red/yellow flashes, LM/PM = live-/program-mode only

Voice = waveform, part = sequence+voice+etc, song = all parts and settings except tempo and swing

Compiled by Benjamin Holt – Shared under the MIT License

## MiniRef - Bold Actions

<b>Tempo:</b>	<b>w1</b>	<b>Live:</b>	<b>.1+.5</b>
<b>Pitch:</b>	<b>w2</b>	<b>Program:</b>	<b>.5+.1-.4</b>
<b>Duration:</b>	<b>w3 ↓ mutes</b>	<b>Mixer:</b>	<b> 5+w1-w4 (transient)</b>
<b>Envelope:</b>	<b>w4 0.4</b>	<b>Demo:</b>	<b> 1+on</b>
<b>Swing:</b>	<b>w5</b>		
<b>Mod:</b>	<b> 5+w5 ↓ off</b>	<b>LDR Pitch:</b>	<b>.2+.3 w2 to revert, LM</b>
<b>Voice:</b>	<b>.1-.4, .5=sine</b>	<b>Set Voices:</b>	<b> 1- 4+w1 0.14, LM</b>
<b>Sequence Parts:</b>  1- 4+w1-w4 ↓ off, ↑ ref, PM			
<b>Scale:</b>  1+w5 0.8; any  1- 4 works, PM			
0:Chrom 1:M 2:m 3:M3 4:m3 5:M5 6:m5 7:Blu6 8:Har.m			
<b>Scale Shift Up:</b>  3+.4... <b>Down:</b>  4+.3... 15.0..15, PM			

<b>Song Shift Up:</b>  1+.2... <b>Down:</b>  2+.1... 15.0..15, PM			
<b>Save Song:</b>	1- 4+ 5	Hold 3s, 4*R, LM	
<b>Load Song:</b>	1- 4	Hold 3s, 4*Y, LM	
<b>Load Mult:</b>	1+ 2- 4	Hold 3s, 4*Y, song 1 editable, LM	
<b>Midi Voice:</b>	1- 4+w2 0.127, ↓percussion (midi 10)		
<b>Set Midi:</b>	2+on	Rotates: 3*Y = off, 3*R = 31250bps, 3*RY = 115200bps, persists	
<b>LDR Tripwire:</b>	.3+.4 3*R, calibrates 5s both high and low light, 3*Y; turn any wheel to exit, LM		
<b>Low Battery:</b>	6*RY		

+ = "together", | = hold, . = press, w = wheel, x-y = "choose one of", .x... = repeated presses, ↑/↓ = full up/down

0.n..m = LED binary display, N\*R/Y = N red/yellow flashes, LM/PM = live-/program-mode only

Voice = waveform, part = sequence+voice+etc, song = all parts and settings except tempo and swing

Compiled by Benjamin Holt – Shared under the MIT License