


Welcome to Teensy® 3.6

32 Bit Arduino-Compatible Microcontroller


To begin using Teensy, please visit the website & click Getting Started.

www.pjrc.com/teensy



Teensy[®] 3.6 Back Side

Additional pins and features available on the back side



Cut to separate VIN from VUSB, if using a battery charger or external power.

Teensy 3.6 pins are
not 5 volt tolerant.
Do not apply more
than 3.3 volts.

For solutions to the most common issues
and technical support, please visit:

www.pjrc.com/help

Teensy 3.6 System Requirements:

PC computer with Windows 7, 8, 10 or later
or Ubuntu Linux 12.04 or later
or Macintosh OS-X 10.7 or later
USB Micro-B Cable

