

Zone ID	Zone Type	Upstream PD	Downstream PD	Max Fault		Reference kV	Coordination Status	Amp Range		Condition
				Type	Amp			From	To	
Bus6	Bus	CB4	CB8	L-G	12353	0.48	Pass	322.3	7309	Devices are coordinated between amp range of 322.3 A to 7309A @ 0.48 kV
			CB9	3Ph	13047	0.48	Pass	50.1	1239	Devices are coordinated between amp range of 50.1 A to 1239A @ 0.48 kV
				L-G	12353	0.48	Pass	50.2	1242	Devices are coordinated between amp range of 50.2 A to 1242A @ 0.48 kV
			CB10	3Ph	13047	0.48	Pass	50.1	1239	Devices are coordinated between amp range of 50.1 A to 1239A @ 0.48 kV
				L-G	12353	0.48	Pass	50.2	1242	Devices are coordinated between amp range of 50.2 A to 1242A @ 0.48 kV
			CB11	3Ph	13047	0.48	Pass	50.1	1239	Devices are coordinated between amp range of 50.1 A to 1239A @ 0.48 kV
				L-G	12353	0.48	Pass	50.2	1242	Devices are coordinated between amp range of 50.2 A to 1242A @ 0.48 kV
			CB12	3Ph	12761	0.48	Pass	157.9	3726	Devices are coordinated between amp range of 157.9 A to 3726A @ 0.48 kV
				L-G	12353	0.48	Pass	160.6	3790	Devices are coordinated between amp range of 160.6 A to 3790A @ 0.48 kV