

Zone ID	Zone Type	Upstream PD	Downstream PD	Max Fault		Reference kV	Coordination Status	Amp Range		Condition
				Type	Amp			From	To	
Bus6	Bus	CB4	CB13	3Ph	13055	0.48	Pass	40.1	991.5	Devices are coordinated between amp range of 40.1 A to 991.5A @ 0.48 kV
				L-G	12353	0.48	Pass	40.2	993.5	Devices are coordinated between amp range of 40.2 A to 993.5A @ 0.48 kV
			CB14	3Ph	13055	0.48	Pass	40.1	991.5	Devices are coordinated between amp range of 40.1 A to 991.5A @ 0.48 kV
				L-G	12353	0.48	Pass	40.2	993.5	Devices are coordinated between amp range of 40.2 A to 993.5A @ 0.48 kV
			CB15	3Ph	13088	0.48	Pass	40.1	991.5	Devices are coordinated between amp range of 40.1 A to 991.5A @ 0.48 kV
				L-G	12353	0.48	Pass	40.1	991.8	Devices are coordinated between amp range of 40.1 A to 991.8A @ 0.48 kV
			CB25	3Ph	13094	0.48	Pass	50.1	1239	Devices are coordinated between amp range of 50.1 A to 1239A @ 0.48 kV
				L-G	12353	0.48	Pass	50.1	1239	Devices are coordinated between amp range of 50.1 A to 1239A @ 0.48 kV