

VIDEO TUTORIAL



Important!

This replacement procedure can be used for:

BMW X5 (E70) xDrive 35 i, BMW 3 Touring (E91) 325i 3.0, BMW 5 Saloon (F10) 520i 2.0, BMW 6 Convertible (F12) 640i 3.0, BMW 6 Coupe (F13) 640i 3.0, BMW 1 Hatchback (F20) 125i 2.0, BMW 7 (F01, F02, F03, F04) 730i 3.0, BMW 1 Coupe (E82) M, BMW X1 (E84) xDrive 28 i, BMW X3 (F25) xDrive 28 i, BMW 5 Saloon (F10) 535i xDrive 3.0, BMW 5 Saloon (F10) 528i 2.0, BMW 5 Saloon (F10) 528i xDrive 2.0, BMW 5 Saloon (F10) 530i 3.0, BMW 5 Saloon (F10) ActiveHybrid, (+ 219)

The steps may slightly vary depending on the car design.

REPLACEMENT: ENGINE OIL AND FILTER – BMW E92. TOOLS YOU MIGHT NEED:



- All-purpose cleaning spray
- Drive socket # 17
- Oil filter cup socket 86-16F
- Ratchet wrench
- Torque wrench
- Flat Screwdriver
- Funnel
- Oil drain pan
- Microfibre towel
- Fender cover

BUY TOOLS

Replacement: engine oil and filter – BMW E92. AUTODOC recommends:

- Replace the oil filter every time when changing motor oil.
- Use only new O-rings during installation.
- Wear gloves to prevent contact with hot liquid.
- Please note: all work on the car – BMW E92 – should be done with the engine switched off.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:


1

Open the hood.




2

Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.




3 Unscrew the oil filler plug.




4 Unscrew the filter housing cap together with the old filter element. Use the 86-16F socket. Use a ratchet wrench.




5 Prepare a container for the old oil filter.



6 Remove the oil filter.



7 Put the old oil filter in the container.




Replacement: engine oil and filter – BMW E92. AUTODOC experts recommend:

- Move up the container. The oil starts to drain out of the drainage hole immediately after you have removed the oil filter.


8

Cover the oil filter housing with a microfibre towel to prevent dirt and foreign objects from getting into the system.



9

Lift the car using a jack or place it over an inspection pit.



Replacement: engine oil and filter – BMW E92. Tip:

- The vehicle must be on even keel, and if it is at an angle, the drain plug must be at the lowest point.
- All work should be done with the engine stopped.

10

Unscrew the fastener of the drain plug access panel. Use a flat screwdriver.


- 11 Remove the drain plug access panel.




- 12 Put a waste oil container with at least 7 l capacity under the drainage hole.



- 13 Unscrew the drain plug. Use a drive socket #17. Use a ratchet wrench.



- 14 Drain the used oil.




Replacement: engine oil and filter – BMW E92. AUTODOC experts recommend:

- Caution! The oil may be hot.
- Wait until the oil has completely drained from the drainage hole.


15

Clean the area of the oil pan drainage hole.



16

Screw in the new drainage plug and tighten it. Use a drive socket #17. Use a torque wrench. Tighten it to 30 Nm torque.



17


Clean the area of the oil pan drainage hole. Use all-purpose cleaning spray.




- 18 Install the drain plug access panel.



- 19 Screw in the fastener of the drain plug access panel. Use a flat screwdriver.




- 20 Lower the car.



- 21 Detach the oil filter from the filter cover.




- 22 Remove old o-rings from the oil filter cover. Use a flat screwdriver.



23

Clean the oil filter housing cap. Use all-purpose cleaning spray.



24

Install new O-rings and a new oil filter to their mounting seats on the filter cover.




Please note!

- Make sure to install the filter correctly. Don't mix up the sides of the part.

25

Remove the microfibre towel from the oil filter housing.



26

Lubricate the rubber seal of the new filter with a little amount of fresh oil.



27

Screw the new filter into its place.




28

Install a new oil filter housing cover and tighten it. Use the 86-16F socket. Use a torque wrench. Tighten it to 25 Nm torque.




29

Remove the oil filler cap. Insert the funnel.



30

Pour oil into the engine through the filler. Required amount of oil: 6.5 l.



Replacement: engine oil and filter – BMW E92. AUTODOC recommends:

- Use the oil recommended by the manufacturer.