

STM32 ISI Firmware update

Revision 1

2020.06.29

dani@connect-ex.com

[Prerequisites](#)

[Hardware](#)

[Software](#)

[Installation](#)

[STLink V2](#)

[\(alternative\) STLink embedded in nucleo boards](#)

[U10](#)

[Programming the board](#)

Prerequisites

Hardware

FT-Click 6050

RS232 or UART to send the binary

Software

The software requires windows (tested in windows 10)

STM32CubeIDE version 1.1.0 or above

Installation

Download the code from the repository: <https://bitbucket.org/connectexteam/userlibs/src/master/>

Open STM32CubeIDE

Create a workspace. This workspace must be outside the git repository folder so you don't mix your workspace settings with the repo files (the projects will be imported to your workspace)

Compile the code using STM32CubeIDE, the project location inside the repository is `firmware\mikroe_r1_01\` , please read `Doc/FtClick Application Examples.pdf` section 5 to import the project. When project is imported press build button.

Connect the FT-click to the PC using the UART device.

Use utility `firmware_updater` located in `utilities\firmware_updater\Updater.exe`

- `Updater.exe COM`
`../../firmware/mikroe_r1_01/Debug/mikroe_r1_01_shortstack_ccp.bin`