

[SOLVED] Intel NIC e1000e hardware unit hang

md127 · Mar 5, 2022

Home > Forums > Proxmox Virtual Environment > Proxmox VE: Installation and configuration



md127

New Member



Mar 5, 2022

 #1

This has been discussed many times, is there a solution/workaround yet, as the specified steps are not working for me?
I've the following in /etc/network/interfaces

Code:

```
auto lo
iface lo inet loopback

iface eno1 inet manual
    offload-gso off
    offload-gro off
    offload-tso off
    offload-rx off
    offload-tx off
    offload-rxvlan off
    offload-txvlan off
    offload-sg off
    offload-ufo off
    offload-lro off

auto vmbr0
iface vmbr0 inet static
    address xxx
    gateway xxx
    bridge-ports eno1
    bridge-stp off
    bridge-fd 0
```

Syslog:

Code:

```
Mar 05 09:38:22 snuc2 kernel: e1000e 0000:00:1f.6 eno1: Detected Hardware Ur
    TDH                <3b>
    TDT                <59>
    next_to_use         <59>
    next_to_clean       <3a>
buffer_info[next_to_clean]:
    time_stamp          <1000bb386>
    next_to_watch       <3b>
```

```

jiffies                <1000bb5e0>
next_to_watch.status  <0>
MAC Status             <40080083>
PHY Status             <796d>
PHY 1000BASE-T Status <3800>
PHY Extended Status    <3000>
PCI Status             <10>
Mar 05 09:38:24 snuc2 kernel: e1000e 0000:00:1f.6 eno1: Detected Hardware Ur
TDH                    <3b>
TDT                    <59>
next_to_use            <59>
next_to_clean          <3a>
buffer_info[next_to_clean]:
time_stamp             <1000bb386>
next_to_watch          <3b>
jiffies                <1000bb7d8>
next_to_watch.status  <0>
MAC Status             <40080083>
PHY Status             <796d>
PHY 1000BASE-T Status <3800>
PHY Extended Status    <3000>
PCI Status             <10>
Mar 05 09:38:26 snuc2 kernel: e1000e 0000:00:1f.6 eno1: Detected Hardware Ur
TDH                    <3b>
TDT                    <59>
next_to_use            <59>
next_to_clean          <3a>
buffer_info[next_to_clean]:
time_stamp             <1000bb386>
next_to_watch          <3b>
jiffies                <1000bb9c8>

```



oguz

Proxmox Retired Staff

Retired Staff



Mar 14, 2022

#2

hi,

md127 said: ↻

This has been discussed many times, is there a solution/workaround yet, as the specified steps are not working for me?

where did you find those steps?

could you install `ethtool` and check your interface like: `ethtool -k eno1 | grep offload` to see if they're really disabled?

if not then please check the workaround in the post here [0] (the original linked thread is [1] but quite a long one to go through), using `ethtool` to set those options off.

if none of that works, post the requested information from my first post on thread [0]

[0]: <https://forum.proxmox.com/threads/trap-error-on-e1000-network-adapter.105758>
[1]: <https://forum.proxmox.com/threads/e1000-driver-hang.58284/page-4#post-302307>

Best regards,
Oguz

Do you already have a Commercial Support Subscription? - If not, [Buy now](#) and read the [documentation](#)



md127

New Member



Mar 14, 2022

#3

oguz said:

could you install `ethtool` and check your interface like: `ethtool -k eno1 | grep offload` to see if they're really disabled?

@oguz That's a great tip as although I had them disabled in the interface file (see below), the offloading got enabled automatically! Do we need to setup a cron job to periodically disable this?

Code:

```
auto lo
iface lo inet loopback






iface eno1 inet manual
    offload-gso off
    offload-gro off
    offload-tso off
    offload-rx off
    offload-tx off
    offload-rxvlan off
    offload-txvlan off
    offload-sg off
    offload-ufo off
    offload-lro off

auto vmbr0
iface vmbr0 inet static
    address 192.168.1.158/24
    gateway 192.168.1.1
    bridge-ports eno1
    bridge-stp off
    bridge-fd 0
```



Mar 14, 2022

#4

<div>oguz</div> <div>Proxmox Retired Staff</div> <div>Retired Staff</div> <div>▼</div>	<div>md127 said: ↻</div> <div>! Do we need to setup a cron job to periodically disable this?</div> <div>check the linked post [0], you can add a <code>post-up</code> directive in your network configuration file as described there (that will basically rerun the workaround when the interface is up)</div> <div>Best regards, Oguz</div> <div>Do you already have a Commercial Support Subscription? - If not, Buy now and read the documentation</div>
<div></div> <div>md127</div> <div>New Member</div> <div></div> <div>▼</div>	<div>Mar 14, 2022</div> <div>↻ #5</div> <div>oguz said: ↻</div> <div>check the linked post [0], you can add a <code>post-up</code> directive in your network configuration file as described there (that will basically rerun the workaround when the interface is up)</div> <div>Thanks! Apply them to the vmbr0 interface as well? And reboot PVE?</div>
<div></div> <div>oguz</div> <div>Proxmox Retired Staff</div> <div>Retired Staff</div> <div>▼</div>	<div>Mar 14, 2022</div> <div>↻ #6</div> <div>md127 said: ↻</div> <div>Apply them to the vmbr0 interface as well? And reboot PVE?</div> <div>yes and yes. you can also install <code>ifupdown2</code> and do <code>ifreload -a</code> instead of rebooting</div> <div>Best regards, Oguz</div> <div>Do you already have a Commercial Support Subscription? - If not, Buy now and read the documentation</div>
<div></div> <div>md127</div> <div>New Member</div> <div></div> <div>▼</div>	<div>Mar 14, 2022</div> <div>↻ #7</div> <div>Awesome! thanks again. Will try and mark this as a "solution" if it works Last question (for the time being): only gso/tso off? What about the others? Right now I've switched off a lot more options in the interfaces file shared above, which gives me this:</div> <div>Code:</div>

```
root@snuc2:~# ethtool -k eno1|grep offload
tcp-segmentation-offload: off
generic-segmentation-offload: off
generic-receive-offload: off
large-receive-offload: off [fixed]
rx-vlan-offload: off
tx-vlan-offload: off
l2-fwd-offload: off [fixed]
hw-tc-offload: off [fixed]
esp-hw-offload: off [fixed]
esp-tx-csum-hw-offload: off [fixed]
rx-udp_tunnel-port-offload: off [fixed]
tls-hw-tx-offload: off [fixed]
tls-hw-rx-offload: off [fixed]
macsec-hw-offload: off [fixed]
hsr-tag-ins-offload: off [fixed]
hsr-tag-rm-offload: off [fixed]
hsr-fwd-offload: off [fixed]
hsr-dup-offload: off [fixed]
```

**oguz**

Proxmox Retired Staff

Retired Staff



Mar 15, 2022

#8

md127 said:

Last question (for the time being): only gso/tso off? What about the others?

try the options as posted before: `ethtool -K eno1 gso off gro off tso off tx off rx off`

if it doesn't solve your issue please report

Best regards,
OguzDo you already have a Commercial Support Subscription? - If not, [Buy now](#) and read the [documentation](#)**md127**

New Member



Mar 19, 2022

#9

@oguz guess that's it! I don't see any more hardware hangs. Thanks much for helping debug the issue and provide the workaround.
Is it possible to disable rx-vlan/tx-vlan offload in that script as well?**Code:**

```
root@snuc2:~# ethtool -k eno1|grep offload
tcp-segmentation-offload: off
generic-segmentation-offload: off
generic-receive-offload: off
```

```
large-receive-offload: off [fixed]
rx-vlan-offload: off
tx-vlan-offload: off
l2-fwd-offload: off [fixed]
hw-tc-offload: off [fixed]
esp-hw-offload: off [fixed]
esp-tx-csum-hw-offload: off [fixed]
rx-udp_tunnel-port-offload: off [fixed]
tls-hw-tx-offload: off [fixed]
tls-hw-rx-offload: off [fixed]
macsec-hw-offload: off [fixed]
hsr-tag-ins-offload: off [fixed]
hsr-tag-rm-offload: off [fixed]
hsr-fwd-offload: off [fixed]
hsr-dup-offload: off [fixed]
```

haarm123

You must log in or register to reply here.

Share:  

 > Forums > Proxmox Virtual Environment > Proxmox VE: Installation and configuration

About

The Proxmox community has been around for many years and offers help and support for Proxmox VE, Proxmox Backup Server, and Proxmox Mail Gateway.

We think our community is one of the best thanks to people like you!

Quick Navigation

[Home](#)

[Get Subscription](#)

[Wiki](#)

[Downloads](#)

[Proxmox Customer Portal](#)

[About](#)

Get your subscription!

The Proxmox team works very hard to make sure you are running the best software and getting stable updates and security enhancements, as well as quick enterprise support. Tens of

thousands of happy customers have a Proxmox subscription. Get your own in 60 seconds.

 **Buy now!**

[Proxmox Support Forum - Light Mode](#)

[Contact us](#)

[Terms and rules](#)

[Privacy policy](#)

[Help](#)

[Home](#)



Community platform by XenForo® © 2010-2023 XenForo Ltd.



This site uses cookies to help personalise content, tailor your experience and to keep you logged in if you register.
By continuing to use this site, you are consenting to our use of cookies.

 **Accept**

[Learn more...](#)