


Kirk-Rudy, Inc.

**Instruction
and Parts Manual
The QC System**



Manufactured by Kirk-Rudy, Inc.

Before using this machine, all operators must study this manual to understand and follow the Safety Warnings and Instructions. Keep these instructions with the machine for future reference. If you have any questions, contact your local Kirk-Rudy, Inc. Distributor.

Manual

Table of Contents

1	Important Safety Instructions	3
2	Introduction	4
2.1	Physical Specifications.....	4
2.2	Electrical Power Requirements	4
3	System Components	5
3.1	5	
4	Installation	6
4.1	Hardware Installation.....	6
4.1.1	Light Adjustment	6
4.1.2	Installing USB Ethernet Adapter	8
4.1.3	Configuring USB Ethernet Adapter	14
4.2	Software Installation	18
5	Software Operation	23
5.1	Introduction.....	23
5.2	Startup Procedure	23
5.3	User Interface	24
5.4	Job Files	27
5.5	Barcode Quality.....	27
5.6	Analyzing Barcodes.....	29
5.6.1	Preview	29
5.6.2	Job	30
5.6.3	User Interface	30
5.7	Wizard Mode	33
5.7.1	Introduction	33
5.7.2	Job	34
5.7.3	Align	35
5.7.4	Trigger	36
5.7.5	Run	39
5.7.6	Report	40
5.8	Normal Mode.....	41
5.8.1	Job	41
5.8.2	Setup	41
5.8.3	Run	42
5.9	Reports.....	43
6	Appendix.....	44
6.1	Appendix A Troubleshooting	44
7	Index.....	45
8	Notes	47
9	Software License Agreement.....	48
10	Warranty and Service	50

1 Important Safety Instructions

Intended Use Statement: The KRQC Barcode Checker is a quality control checking tool for analyzing barcode quality and suggesting improvements. Usage for other purposes may lead to an unsafe condition.

SAVE THESE INSTRUCTIONS. Read all instructions before using this product.



WARNING

* NEVER OPERATE THE MACHINE WITHOUT ALL GUARDS OR SAFETY DEVICES IN PLACE.

2 Introduction



WARNING

Read and follow all Safety Instructions, Page 4 before proceeding.

2.1 Physical Specifications

Height: 15-3/8"

Width: 10-1/2"

Length: 36"

2.2 Electrical Power Requirements

120VAC, 1A, 60HZ

3 System Components



WARNING

Read and follow all Safety Instructions, Page 4 before proceeding.

3.1

546690-05 ASSY, COGNEX CAMERA SYSTEM

546694-01 ASSY, CONTROL BOX LIGHT

4 Installation



WARNING

Read and follow all Safety Instructions, Page 4 before proceeding.




4.1 Hardware Installation

4.1.1 Light Adjustment

In the case where the LED light has moved or needs to be installed, the LED light must be adjusted so that it is at the best angle for most reliable results.

To adjust the LED light:

1. Gently loosen the screws on the side of the light.
2. Start the QC software, load/start a job.
3. Switch to Normal Mode.
4. Make sure the software is in the Setup step and auto refresh is selected.
5. Place a blank product until the camera sensor.
6. Adjust the angle of the light until the brightest spot is at the center of the image.
7. Examples are on the next page.

To Low**Too High****Perfect**


4.1.2 Installing USB Ethernet Adapter

Windows XP


1. Plug the small USB to Ethernet converter into a free USB 2.0 slot.
2. If you see the following screen, select “**No, not at this time**” and click **Next**. Otherwise, skip to step 3.



3. Select “Install from a list or a specific location” and click **Next**.




4. In the following screen select “**Search for the best driver in these locations**” and only select “**Include this location in the search.**” Enter **D:\winxp** in the field, or if the CDROM drive is another letter, replace D with the CDROM’s drive letter. Click **Next**.



5. Click “Continue Anyway”



6. Installation is complete. Click “Finish.”




Windows 2000

1. Plug the small USB to Ethernet converter into a free USB 2.0 slot.
2. When the following screen is displayed, select “**Search for a suitable driver for my device**” and click **Next**.



3. Select “Specify a location” and click **Next**.



4. In the *Copy manufacturer's files from:* field enter **D:\win2000** then click OK. If the CD-ROM drive is not D, replace D with the CD-ROM's drive letter.
5. The following *Driver Files Search Results* screen will appear. Click “Next”




6. If the following screen is displayed, click **Yes**.



7. Click **Finish** then remove the driver CD from the CD-ROM drive.


4.1.3 Configuring USB Ethernet Adapter

1. Open Network Connections
 - a. **Windows XP:** Click Start – All Programs – Accessories – Communications – Network Connections
 - b. **Windows 2000:** Click Start – Programs – Accessories – Communications – Network and Dial-Up Connections.
2. Find the interface that uses the **Linksys USB 2.0 Network Adapter ver.2**
3. Right click on the interface icon, click rename, type in 'QC' then click enter.
4. Right click on the interface icon and click **Properties**.
5. Put a check in the box near the bottom next to “**Show icon in notification area when connected.**”
This is an optional visual indicator in the system tray that displays the camera's connection to the PC.




6. Scroll down the list of items under the section “**This connection uses the following items.**” Click once on **Internet Protocol (TCP/IP)** and then click **Properties**.


7. Select the option “**Use the following IP address.**”



8. Enter the IP address 192.168.100.1 in the field **IP address**




9. Click in the field **Subnet mask** so that it is filled automatically with 255.255.255.0.




10. Click **OK**.
11. Click **Close**.
12. The USB Ethernet interface is now configured and ready to communicate with the camera sensor.

4.2 Software Installation


1. Insert the QC System Installation CD into the CD-ROM drive.
2. Run Setup from the CD.
3. If the .NET 2.0 Framework is not installed, the following message will be displayed. Click **Accept**. If the .NET 2.0 Framework is already installed, skip to step 6.




4. Allow several minutes for the .NET Framework 2.0 to install.




5. Click "Yes" to reboot the system.




6. After the PC reboots the QC System installer should automatically start. If the installer does not start, run Setup from the CD again. Click **Next**.




7. Click **Next**.



8. Click **Next**.



9. Installation is complete. Click **Close**.



10. A link has been created on the desktop and a program group has been created.

5 Software Operation

5.1 Introduction

The QC System is designed to be a tool for reporting barcode quality in such a way that an operator can quickly identify quality problems for a barcode and fix them before starting a job. Detailed barcode quality metrics allow an operator to tweak a printer's output so that the printer prints barcodes at the highest quality level possible. The QC system uses both DMM and MERLIN specifications for determining thresholds, and its graphical display makes it easy to make sure barcode measurements are in the middle of allowed limits.


The QC System provides

- Detailed barcode quality metrics
- Audible alarm for failure condition
- Report generation


5.2 Startup Procedure

1. Power on the PC if it is turned off.
2. Power on the camera sensor.
3. Wait 30 seconds.
4. Start The Quality Checker System software.


The QC System splash screen




5. If the sensor is not detected, click "**Retry**". Either the software was started before the camera was fully initialized, or the USB Ethernet interface is not configured correctly.



5.3 User Interface






Menu


The menu has two dropdown items, **File** and **Help**.

Menu -File



Command	Description
New	Creates a new job.
Open	Opens an existing job from disk.
Save	Saves the current job to disk using the current job name.
Save As	Allows saving the current job to a different file on disk.
Mode	<ul style="list-style-type: none"> • Wizard – Switches software to wizard mode. • Normal – Switches software to normal mode.
Exit	Closes the application.

Menu -Help




Command	Description
Online Help	Displays this manual in a browser
Zip to Desktop	<ul style="list-style-type: none"> • Logs – Zips all software logs and saves them to the desktop in a zip file. • Decode Failure Images – Zips all images, where the barcode was unable to be decoded, to the desktop. For diagnostic and reporting purposes only.
About	Displays The QC System software information


Step

The **Step** bar allows switching between different steps in the software. The ideal progression is left to right. However, steps can be skipped if the user wishes to do so.

Wizard Mode:



Normal Mode:



5.4 Job Files







Job files provide a way to save settings for a particular job as well as result stats. Due to portability and size constraints, job files do not save all result data for each product. Result data for each product is lost when the application closes. Jobs are automatically saved when the software closes. The following information is stored in a job file:


Item	Description
Invert	Whether or not the image is inverted.
Scan Type	Barcode position (below, above, between text)
Stop Percentage	The percentage at which an alarm condition will be raised.
Stop Count	The number of recent products for determining the failure percentage for the alarm condition.
Passed	Number of products that passed analysis.
Failed	Number of products that failed analysis.

5.5 Barcode Quality

To reduce the probability of failing MERLIN, printers should produce barcodes that are in the middle of allowed specifications. The QC System analyzes many aspects of a barcode's quality, some of which are displayed graphically. The graphical display makes it easy to identify when a barcode is of high quality or when it will risk failure. The following table provides an overview of the different quality checks The QC System performs when analyzing a barcode. All measurements are in inches.

Quality Metrics	
Item	Description

Code	Barcode must decode. Code 323260280806
Checksum	Check digit verification Checksum OK
Bars	Bar count must be either 32, 52, or 62.  Bars 54
Void	VOIDS due to missing jets. A small amount of void will result in a warning, but if a void is more than the MERLIN specification maximum, the barcode will count as a failure.  Void 0.015
Extraneous Ink	Extra ink in and around barcode. This condition will not cause a failure of a barcode in The QC System, but can cause a warning. Voids can cause this warning to occur.  Extraneous Ink WARNING
Connected Bars	Two or more bars are connected. If bars are too wide, there is smearing from the print head, or there is excess overspray, this condition can occur.  Connected Bars Bad
Clearance	Barcode is too close to address/text. The QC System makes sure that a barcode has sufficient clearance above, below, left, and right.  Clearance Bad
Width	Full barcode width; maximum and minimum. Depending on the postnet type, the overall width of the barcode must be within a certain range for it to meet the DMM and MERLIN pitch specifications.  Width
Height	Full barcode height, maximum and minimum. The overall height of the barcode must be within DMM and MERLIN specifications.



5.6 Analyzing Barcodes

The QC System provides real-time reporting of barcode quality. The **Run** step is where barcodes are analyzed and results and statistics displayed. There are two modes for analyzing barcodes: **Preview** and **Job**.

Mode Overview	
Preview	Job
Results are not saved	Result stats saved with job
Displays all barcodes	Displays failed barcodes
100 results before warning	Exportable results
	Unlimited # of results
	Ability to raise alarm condition

5.6.1 Preview


The purpose of **Preview** mode is to allow an operator to see each barcode that is being analyzed and the corresponding quality measurements. In **Preview** mode the analysis results are not saved or counted towards a job. This mode is a means for improving barcode quality until the quality is

sufficient to run a job. For all quality measurements that are displayed using a colored gauge, the ideal quality measurement is in the center of the high and low limits, as shown in the following image:

Good:



Bad:



Even if The QC System reports a barcode as passing, if the quality results are near a failure condition the probability of failing MERLIN increases. **Preview** mode allows the operator to make any printing changes necessary to get quality results in the center of the limits so as to *reduce the probability* of MERLIN or QC System failure.


5.6.2 Job





The purpose of **Job** mode is to keep track of barcode quality for the duration of a print job. The results for each barcode are stored in memory until either the 'clear' button is clicked or the software closes. However, the total number of pass/fails for a job is stored in the job file. This allows a job to be resumed another day. Images of barcodes that pass the QC System quality checking are not displayed on the screen. Only images of warning or failed barcodes are displayed. This means that during the run of a job, the image displayed will always be the most recent bad quality barcode.





5.6.3 User Interface

The **Run** step is nearly identical in both the wizard mode and normal mode. The only difference is that **Preview** mode does not keep track of total stats and reports cannot be generated. The Run step has several user interface items:

1. Go/Stop/Clear
2. Barcode image display
3. Preview/Job mode selection (tabs)
4. Barcode quality history
5. Results display
6. Report generation (**Job** mode only)



Item	Description
Go/Stop/Clear	 <ul style="list-style-type: none"> Go – Puts the camera in online mode, ready to analyze barcodes. Stop – Stops the camera from analyzing barcodes Clear – Clears all results for the current mode (Preview or Job)
Barcode Display	<p>Displays the most recent image of a product passing under the camera sensor. In Preview mode, all images are displayed. In Job mode, only the most recent failure or warning barcode is displayed.</p> <ul style="list-style-type: none"> Red Box – The red box is displayed during setup, and it is the actual field of view for analyzing barcodes. This Barcode Display is the same area and same field of view as the red box during setup. Green Box – The green box is the ideal field of view for barcodes. If a barcode is outside the green box, analysis of a barcode may result in error or failure condition. Blue Box – The blue box is the QC's way of displaying where it has identified a barcode. 
Run Mode	<p>Allows switching between Preview and Job mode.</p> 
Barcode Quality History	 <p>Allows a user to select any analysis result that is still in memory. The results for the selection are automatically displayed in the Results Display. In Job mode, if the result is a failure or a warning, there will be a corresponding image that will also be displayed for that result. In Preview mode, all results have a corresponding image.</p> <p>Note: The image history is limited to 100 images. Older images are automatically deleted as newer ones are created.</p>


Results Display	Results	Fail: 26 Pass: 38/64 59.38%	Displays the quality measurements. If the barcode passes, all items are green. If the barcode fails or is a warning, the corresponding item(s) will be yellow for warning or red for failure. In Job mode, run stats are displayed at the top.	
	Code	323260280806		
	Checksum	OK		
	Bars	62		
	Void	0.000		
	Extraneous Ink	OK		
	Connected Bars	OK		
	Clearance	OK		
	Width			
	Height			
Report Generation	Bar Width		Allows the failed items in the result history to be exported to PDF. (Only available in Job mode)	
	Space Width			
Auto Scroll	<input type="button" value="Generate Report"/>			
	<input checked="" type="checkbox"/> Auto Scroll	When enabled, the History and Result Display will automatically scroll and update as new barcodes are analyzed. When disabled, the user is able to browse the history and select a result to see the corresponding detailed results.		

5.7 Wizard Mode

5.7.1 Introduction

The user interface wizard is designed to walk users through the process of setting up and running a job. Each step has a pass light that indicates if the current step was completed correctly. A 5 second delay is displayed using a progress bar before the wizard automatically moves to the next step.

Pass light off:




Pass light on:



5.7.2 Job

When the QC software is first started, no job is loaded. All features in the software are disabled until a job is created or opened. There are 3 ways to start a job:

1. Create a **new** job.
2. Open the most **recent** job that was loaded.
3. Open an **existing** job from disk.




Once a job is loaded, the wizard will automatically move to the next step, which is **Alignment**.

5.7.3 Align

The purpose of the alignment step is to make sure the barcode is vertically centered on the screen as the product moves under the camera. The camera sensor has the ability to physically slide forward or backward. Moving the camera forward (away from the operator) will make a barcode move down on the screen. Moving the camera back will make a barcode move up on the screen.

The steps to vertically align the barcode on the screen are as follows:


1. Print an 11 digit postnet barcode
2. Allow the product to travel slowly down the table using a slow belt speed and/or jogging until the barcode is horizontally centered under the camera sensor. If the barcode is not horizontally centered on the screen (it traveled too far or not far enough), it can be horizontally aligned in the next wizard step.
3. If the barcode is upside down, click the blue label '**here**' in step 3 in the wizard. The image will be rotated 180 degrees.
4. Slide the camera sensor forward or back until the barcode is vertically centered in the green box.
5. If the barcode is a floating barcode and will not remain in one position, move the camera sensor accordingly such that all positions of the barcode will be in the green box.
6. Move the beam switch to a position such that it is as close to the leading/trailing edge of the product as possible while still getting a reflection. This makes the next wizard step easier.
7. If the barcode is vertically centered, but not horizontally centered, the **Pass** light will not turn on. As long as the barcode is vertically centered on the screen, proceed to the next step (**Trigger**). The **Trigger** step will align the barcode horizontally.




5.7.4 Trigger

The trigger step is for adjustment of the location of the beam switch so that when a product triggers the camera sensor, the barcode is horizontally aligned on the screen. The steps to horizontally align the barcode on the screen are as follows:


1. Print 11 digit postnet barcodes as the print job's expected belt speed (Or use existing printed items from the job).
2. As the product moves down the belt, the leading or trailing edge of the product (depending on the beam switch mode) will trigger the camera and the screen will be updated.
3. If the barcode is horizontally and vertically centered on the screen, the Pass light will light up and the software will automatically move to the next step **Run**.
4. If the barcode is too far left, demonstrated in the following image, then the beam switch must be moved to the right.



5. If the barcode is too far right, demonstrated in the following image, then the beam switch must be moved to the left.



6. A barcode that is both horizontally and vertically aligned on the screen looks like the following:



5.7.5 Run

Step 1: Use the height lever to make sure the camera sensor is the proper distance above the product. The lever should be able to touch the product and still be able to perform a full swing over the product. **Failure to set the proper camera sensor height will result in incorrect measurements.**

Step 2: Choose the barcode position for the current job. This option is for determining which type of scan the camera will make to find the barcode. If the incorrect option is selected, the barcode may not be able to be identified. **Below address** offers the best performance, but **Between text** should find the barcode in any position.

Quality Checker

File Help Job Align Trigger **Run** Report

Run Job

Note: Use height lever to ensure proper distance from product.

Select barcode position:

- ☒ Below address
- ☐ Above address
- ☐ Between Text

Choose a mode for barcode analysis:

- ☒ Preview
- ☐ Job

To begin, click [GO](#)

Go Stop Clear

Preview Job

History		Results	
	Code		
		Code	
		Checksum	
		Bars	
		Void	
		Extraneous Ink	
		Connected Bars	
		Clearance	
		Width	
		Height	
		Bar Width	
		Space Width	

Auto Scroll

Current Job: TestJob

Step 3: Choose **Preview** mode and analyze a job's product to make sure the printer is printing high quality barcodes. Once the printer is producing high quality barcodes the system is ready to analyze them in **Job** mode which will keep track of pass/fail stats and allow a report to be generated.

Step 4: Choose **Job** mode and select the alarm condition percentage and product count. The software is now ready to run a job and keep track of stats.

Using the results that are displayed on the screen, if necessary the operator should adjust the barcode parameters in their ink-jet software until their printed barcodes are in the center of the DMM specifications. This 'centering' will produce the highest quality barcode and reduce the probability of printing barcodes that fail MERLIN due to low quality.

5.7.6 Report

The Report step allows a user to generate a PDF report. Reports contain only failed items due to size constraints.

Quality Checker

File Help Job Align Trigger Run **Report**

Report

Products analyzed: 80
To continue running the job, click [GO](#)
To clear job results, click [Clear](#)

- To generate a report, click [Generate](#)
- To save the job, click File -> [Save](#)
- To start a new job, click File -> [New](#)

Go
Stop
Clear

Preview Job

History	
	Code
46	323260280806
47	323260280806
48	323260280806
49	323260280806
50	323260280806
51	323260280806
52	323260280806
53	323260280806
54	323260280806
55	323260280806
56	323260280806
57	323260280806
58	323260280806
59	323260280806
60	323260280806

Results	
	Fail: 26 Pass: 54/80 67.50
Code	323260280806
Checksum	OK
Bars	62
Void	0.000
Extraneous Ink	OK
Connected Bars	OK
Clearance	Bad
Width	
Height	
Bar Width	
Space Width	

Generate Report ☐ Auto Scroll

Current Job: TestJob


5.8 Normal Mode

5.8.1 Job





Other than the wizard panel, the Job step is identical in Normal Mode as the Job step in Wizard mode.

5.8.2 Setup

The **Setup** step allows the system to be configured and set up from one screen.



Item	Description
------	-------------

Height Adjustment	<p>Note: Use height lever to ensure proper distance from product.</p> <p>Use the height lever to make sure the camera sensor is the proper distance above the product. The lever should be able to touch the product and still be able to perform a full swing over the product. Failure to set the proper camera sensor height will result in incorrect measurements.</p>
Camera Trigger	 <ul style="list-style-type: none"> • Auto refresh – This option puts the camera in a state where it automatically takes pictures at regular intervals. This allows the barcode to be vertically aligned. • Beam Switch – This option puts the camera in a state where it takes a picture only when the beam switch is triggered. This allows the barcode to be horizontally centered by moving the beam switch left or right. • Invert – If a barcode is upside down, this option allows it to be flipped to be right side up.
Vertical Alignment	 <p>A graph that displays a barcode's vertical position. This is used to center the barcode vertically when in Auto refresh mode.</p>
Barcode Position	 <p>Choose the barcode position for the current job. This option is for determining which type of scan the camera will make to find the barcode. If the incorrect option is selected, the barcode may not be able to be identified. Below address offers the best performance, but Between text should find the barcode in any position.</p>
Alarm Condition	 <p>Specifies the condition at which the system will raise an alarm. The pass percentage is calculated using the number of most recent results specified.</p>

5.8.3 Run

Other than the wizard panel, the Run step is identical in Normal Mode as the Run step in Wizard mode

5.9 Reports

Quality analysis results can be exported to a PDF file. Due to size constraints, reports contain only failed items. A report displays all of the same measurements as the **Result Display** except in the report numbers are used instead of graphs. Failure items are indicated in red, and warnings are indicated in yellow.

Sample PDF Report:

Kirk-Rudy, Inc. QC Report													
Tuesday, March 21, 2006 10:16:04 AM Fail: 26 Pass:54/80 Readability: 67.00%													
Product	Code	Check Digit	Bars	Voids (0.0156)	Extraneous Ink	Connected Bars	Clearance	Width	Height	Max Bar (0.025)	Min Bar (0.015)	Max Space(0.040)	Min Space(0.012)
13	323260280806	OK	62	0.000	WARNING	OK	Bad	2.745	0.116	0.023	0.020	0.023	0.021
14	323260280806	OK	62	0.000	WARNING	OK	Bad	2.745	0.116	0.024	0.020	0.023	0.021
24	323260280806	OK	62	0.000	OK	OK	Bad	2.745	0.116	0.024	0.020	0.023	0.021
25	323260280806	OK	62	0.000	OK	OK	Bad	2.745	0.116	0.023	0.020	0.023	0.021
26	323260280806	OK	62	0.000	OK	OK	Bad	2.745	0.116	0.024	0.020	0.023	0.021
29	323260280806	OK	62	0.000	OK	OK	Bad	2.745	0.117	0.024	0.020	0.023	0.021
30	323260280806	OK	62	0.000	WARNING	OK	Bad	2.744	0.116	0.024	0.020	0.023	0.021
31	323260280806	OK	62	0.000	WARNING	OK	Bad	2.744	0.117	0.024	0.020	0.023	0.021
32	323260280806	OK	62	0.000	WARNING	OK	Bad	2.744	0.117	0.024	0.020	0.023	0.021
33			61	0.000			Bad	2.744	0.117	0.044	0.019	0.023	0.020
34	323260280806	OK	60	0.000			Bad	2.744	0.117	0.023	0.019	0.023	0.021
35	323260280806	OK	61	0.000			Bad	2.745	0.116	0.024	0.020	0.023	0.021
36			62	0.000	WARNING	OK	Bad	2.744	0.117	0.024	0.018	0.029	0.020
37	323260280806	OK	62	0.000	WARNING	OK	Bad	2.744	0.117	0.024	0.020	0.023	0.021
38	323260280806	OK	62	0.000	WARNING	OK	Bad	2.745	0.117	0.024	0.020	0.023	0.021
39	323260280806	OK	62	0.000	OK	OK	Bad	2.745	0.116	0.024	0.020	0.023	0.021
40			62	0.000	WARNING	OK	Bad	2.744	0.117	0.024	0.020	0.023	0.021
41			62	0.000	WARNING	OK	Bad	2.744	0.117	0.024	0.020	0.024	0.021
42	323260280806	OK	62	0.000	WARNING	OK	Bad	2.744	0.117	0.024	0.020	0.023	0.021
43	323260280806	OK	62	0.000	WARNING	OK	Bad	2.745	0.117	0.024	0.019	0.026	0.020
44	323260280806	OK	62	0.000	WARNING	OK	Bad	2.745	0.117	0.024	0.020	0.023	0.021
45	323260280806	OK	62	0.000	WARNING	OK	Bad	2.745	0.116	0.024	0.020	0.023	0.021
46	323260280806	OK	62	0.000	WARNING	OK	Bad	2.745	0.116	0.024	0.020	0.023	0.021
47	323260280806	OK	62	0.000	WARNING	OK	Bad	2.745	0.116	0.024	0.020	0.023	0.021
51	323260280806	OK	62	0.000	OK	OK	Bad	2.745	0.116	0.024	0.020	0.023	0.021
52	323260280806	OK	62	0.000	OK	OK	Bad	2.745	0.116	0.024	0.020	0.023	0.021

6 Appendix

6.1 Appendix A Troubleshooting

Problem: Unable to detect sensor

1. Power off the sensor.
2. Power on the sensor.
3. Wait 30 seconds.
4. Restart the QC system software to try to reconnect.
5. If no connection is established, repeat 1-4 up to 5 times.

Problem: Barcode is unable to be decoded

1. Ensure the barcode is centered
2. Make sure the barcode is not too close to the edge of the screen.
3. Try to print a higher quality barcode.

Problem: Barcode metrics are not being read correctly

1. Ensure the barcode is centered
2. Make sure the barcode is not slanted too much.
3. Make sure camera height is correct by using the Height lever.

7 Index

Alarm Condition, 41
Align, 34
Auto refresh, 41
Auto Scroll, 32
Bar Width, 28
Barcode Display, 31
Barcode Position, 41
Bars, 27
Beam Switch, 41
Below address, 41
Between text, 41
Camera Trigger, 41
Centering Rectangle, 25
Checksum, 27
Clear, 31
Clearance, 27
Code, 27
Connected Bars, 27
Electrical Power Requirements, 4
Extraneous Ink, 27
Go, 31
Height, 28
Height Adjustment, 41
History, 31
Intended Use Statement, 3
Invert, 41
Job, 33
Job Files, 26
Online Help, 25
PDF Report, 42
Physical Specifications, 4
Preview, 29
Print Imager Mount, 5
Report Generation, 32
Reports, 42
Results, 32
Run, 38
Run Mode, 31
Safety Instructions, 3
Space Width, 28
Step, 26
Stop, 31
Stop Count, 26
Stop Percentage, 26
System Description and Components, 4
Trigger, 35
Troubleshooting, 43
Void, 27
Width, 27
Wizard Mode, 32
Zip to Desktop, 25

[illegible]

9 Software License Agreement

KIRK-RUDY INC. SOFTWARE FOR BARCODE QUALITY CHECKING

PAGE 1 OF 2

LICENSE AGREEMENT FOR SOFTWARE DOWNLOADED, INSTALLED, AND /OR OPERATED FROM THE KIRK-RUDY WEBSITE OR INSTALLATION MEDIA.

NOTICE: BY DOWNLOADING, INSTALLING, AND /OR OPERATING SOFTWARE ACCESSED FROM THIS WEBSITE OR INSTALLATION MEDIA, YOU INDICATE YOUR ACCEPTANCE OF THE TERMS AND CONDITIONS OF THIS LICENSE AGREEMENT. IF YOU DO NOT AGREE TO THESE TERMS, YOU WILL NOT BE PERMITTED TO INSTALL OR DOWNLOAD SOFTWARE FROM THIS SITE.

FILES YOU WISH TO DOWNLOAD FROM THIS WEBSITE CONTAIN SOFTWARE PROGRAMS AND ELECTRONIC DATA OWNED BY KIRK-RUDY INC. (KR) OR OBTAINED BY KR FOR SUBLICENSE (COLLECTIVELY, THE SOFTWARE) IN RETURN FOR RIGHT TO DOWNLOAD, INSTALL, AND OPERATE THE SOFTWARE YOU AGREE TO THE FOLLOWING TERMS:

1. USE OF SOFTWARE. YOU ARE GRANTED A NON EXCLUSIVE RIGHT TO DOWNLOAD THE SOFTWARE, INSTALL THE SOFTWARE USE THE SOFTWARE ON ONE KR COMPUTER SERVER IN CONJUNCTION WITH A KR PRINTER, TYPESETTER, FILM RECORDER OTHER KR OUTPUT DEVICE. KR RESERVES ALL RIGHTS NOT GRANTED TO YOU UNDER THIS AGREEMENT.
2. PROPRIETARY RIGHTS AND OBLIGATIONS. YOU AGREE THAT THE SOFTWARE IS THE VALUABLE PROPERTY OF KR AND ITS SUPPLIERS. YOU WILL NOT MAKE YOURSELF, OR ALLOW ANYONE ELSE TO MAKE ANY COPIES OF THE SOFTWARE DOCUMENTATION, OR ANY PORTION THEREOF, EXCEPT ONE 1 COPY SOLELY FOR A BACKUP PURPOSES. ANY COPIES OF SOFTWARE SHALL CONTAIN THE SAME PROPRIETY NOTICES, WHICH APPEAR ON OR IN THE SOFTWARE. YOU AGREE NOT MODIFY, ADAPT TRANSLATE, REVERSE, ENGINEER, DECOMPILE, DISASSEMBLE, OR CREATE DERIVATIVE WORKS BASED ON THE SOFTWARE. THIS AGREEMENT DOES NOT GIVE YOU THE RIGHT TO USE ANY TRADEMARKS OR TRADE NAMES OF KR.
3. TRANSFER. YOU MAY ASSIGN YOUR RIGHTS UNDER THIS LICENSE AGREEMENT TO A THIRD PARTY PROVIDED: (i) THEY AGREE IN WRITING TO BE BOUND BY THIS AGREEMENT PRIOR TO THE ASSIGNMENT AND (ii) THAT YOU TRANSFER ALL COPIES OF SOFTWARE TO THEM OR DESTROY ANY COPIES NOT TRANSFERRED. EXCEPT AS SET FORTH ABOVE, YOU MAY NOT ASSIGN YOUR RIGHTS UNDER THIS LICENSE AGREEMENT. YOU AGREE THAT THE SOFTWARE WILL NOT BE SHIPPED, TRANSFERRED, EXPORTED INTO ANY COUNTRY OR USED IN ANY MANNER PROHIBITED BY THE UNITED STATES EXPORT ADMINISTRATION ACT.
4. NO OTHER RIGHTS KR AND ITS SUPPLIERS RETAIN TITLE AND OWNERSHIP OF THE SOFTWARE, THE MEDIA ON WHICH THE SOFTWARE IS RECORDED, AND ALL COPIES OF THE SOFTWARE. IF YOU USE OF THE SOFTWARE IS FOUND TO INFRINGE ON INTELLECTUAL PROPERTY RIGHTS OF ANY THIRD PARTY, YOU WILL CEASE SUCH USE OR YOU WILL SECURE THE RIGHTS NECESSARY FOR SUCH USE. ALL TRADEMARKS REMAIN THE PROPERTY OF THEIR RESPECTIVE OWNERS.
5. TERM. THE LICENSE IS EFFECTIVE UNTIL TERMINATED. KR HAS THE RIGHT TO TERMINATE IMMEDIATELY IF YOU FAIL TO COMPLY WITH ANY TERM OF THIS LICENSE AGREEMENT. UPON ANY SUCH TERMINATION YOU WILL DESTROY THE ORIGINAL AND ANY COPIES OF THE SOFTWARE AND RELATED DOCUMENTATION AND CEASE ALL USE.
6. NO WARRANTY. KR HEREBY DISCLAIMS ALL WARRANTIES WHETHER IMPLIED EXPRESS OR STATUTORY WITH RESPECT TO THE SOFTWARE INCLUDING ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR PARTICULAR PURPOSE, NON INFRINGEMENT AND THE LIKE, AND ANY WARRANTY COVERING COMPUTER VIRUSES. THE SOFTWARE IS PROVIDED AS IS WITH ALL FAULTS, KR DOES NOT WARRANT THE PERFORMANCE OR RESULTS YOU MAY OBTAIN

BY USING THE SOFTWARE. SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES OR LIMITATIONS ON THE DURATION OF IMPLIED WARRANTIES, SO THE LIMITATIONS MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOUR JURISDICTION MAY GIVE YOU OTHER RIGHTS.

7. LIMIT OF LIABILITY. IN NO EVENT WILL KR BE LIABLE TO YOU FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES (INCLUDING DAMAGES FROM LOSS OF BUSINESS PROFITS OR SAVINGS, BUSINESS INTERRUPTION LOSS OF BUSINESS INFORMATION, AND THE LIKE) OR FOR CLAIM BY ANY PART ARISING OUT OF THE USE OR INABILITY TO USE THE SOFTWARE EVEN IF KR HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. IF THE JURISDICTION WHERE YOU INCIDENTAL OR CONSEQUENTIAL DAMAGES TO THE ABOVE MAY NOT APPLY TO YOU.
8. INDEMNIFICATIONS. YOU AGREE TO INDEMNIFY AND HOLD KR HARMLESS FROM AND AGAINST ANY CLAIMS OR DAMAGES, WHICH MAY RESULT FROM YOUR USE OF THE SOFTWARE OR BREACH OF THIS AGREEMENT.
9. GOVERNING LAW, VENUE. THE LAWS OF THE STATE OF GEORGIA U.S.A WILL GOVERN THIS LICENSE AGREEMENT. DISPUTES RELATED TO THIS LICENSE WILL BE LITIGATED IN THE STATE OF GEORGIA. THIS LICENSE AGREEMENT WILL NOT BE GOVERNED BY THE UNITED NATIONS CONVENTIONS ON CONTRACTS FOR THE INTERNATIONAL SALE OF GOODS, THE APPLICATION OF WHICH IS EXPRESSLY EXCLUDED.
10. GOVERNMENT END USERS. IF THIS PRODUCT IS ACQUIRED UNDER THE TERMS OF GSA CONTRACT, THE SOFTWARE AND DOCUMENTATION ARE PROVIDED WITH RESTRICTED RIGHTS. USE, DUPLICATION, OR DISCLOSURE BY THE GOVERNMENT IS SUBJECT TO RESTRICTIONS AS SET FORTH IN SUBPARAGRAPH © (1) (ii) OF THE RIGHTS IN TECHNICAL DATA AND COMPUTER SOFTWARE CLAUSE AT DFARS 252.227-7013 OR SUBPARAGRAPHS © (1) AND (2) OF THE COMMERCIAL COMPUTER SOFTWARE RESTRICTED RIGHTS AT 48 CFR 52.227-19, AS APPLICABLE. CONTRACTOR/ MANUFACTURER IS KIRK-RUDY, INC., 125 LORRAINE PARKWAY, WOODSTOCK, GA 30188.

IF YOU HAVE ANY QUESTIONS CONCERNING THIS LICENSE AGREEMENT, OR IF YOU DESIRE TO CONTACT KR FOR ANY REASONS PLEASE WRITE TO KIRK-RUDY, INC., 125 LORRAINE PARKWAY, WOODSTOCK, GA 30188.

DO YOU AGREE TO THE TERMS OF THE KIRK-RUDY SOFTWARE LICENSE AGREEMENT?

YES | NO

10 Warranty and Service

WARRANTY

Warranty: Kirk-Rudy, Inc., warrants to the original retail purchaser that this product is free from defects in the material and workmanship, and agrees to repair or replace, at Kirk-Rudy's option, any defective product within (90) days from the date of purchase. This warranty is not transferable. It covers damage resulting from defects in material or workmanship, and it does not cover conditions or malfunctions resulting from normal wear, neglect, abuse or accident.

THIS WARRANTY IS IN LIEU OF ALL OTHER EXPRESSED WARRANTIES ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR ANY IMPLIED WARRANTY ARISING OUT OF A COURSE OF DEALING, CUSTOM, OR USAGE OF TRADE.

Limitation of Remedies: If product is proven to be defective within the warranty period stated above, THE EXCLUSIVE REMEDY, AT KIRK-RUDY'S OPTION, SHALL BE TO REFUND THE PURCHASE PRICE OF OR TO REPAIR OR REPLACE THE DEFECTIVE PRODUCT, provided that the defective product is, at Kirk-Rudy's choice, returned immediately to Kirk-Rudy or authorized service representative designated by Kirk-Rudy, or made available at user's premises in a location suitable for servicing.

Limitation of Liability: Kirk-Rudy shall not otherwise be liable for any losses or damages, whether direct, indirect, special, incidental, or consequential, regardless of the legal or equitable theory asserted, including contract, negligence, warranty, or strict liability.

To obtain replacement parts and service, contact an Authorized Kirk-Rudy Dealer. Use Kirk-Rudy part numbers when ordering.

USE ONLY GENUINE KIRK-RUDY REPLACEMENT PARTS

KIRK-RUDY, INC.
125 LORRAINE PARKWAY
WOODSTOCK, GA. 301448844
770-427-4203
FAX 770-427-4036
WWW.KIRKRUDY.COM