

Naval Systems, Inc. (NSI) Capabilities List CAGE 5A0V7 8551 Westside Industrial Drive Jacksonville, FL 32219 Phone (904)248-4300 FAX (904)248-4301 Contact Stephanie Winters or Karl Hunnicutt swinters@n-s-i.us or khunnicutt@n-s-i.us FAA repair station NY4R405M. EASA certificate EASA.145.6372 Certified to ISO 9001, AS 9100, AS 9110, and AS 9120. ITAR certified				
<u>NSN</u>	<u>Nomenclature</u>	<u>P/N</u>	<u>Alternate P/N</u>	<u>Notes</u>
6610-00-612-7144	DC SELSYN POSITION INDICATOR	8T39BAL1	5462981	
6695-00-903-1047	Accelerometer	656310	24108-9, 24523T9	
1660-00-562-3898	Temperature Controller	25730028-04	7667750-523	
1660-00-719-6885	Temperature Controller	25730028-03		
5826-00-081-8325	Bearing Distance Heading Indicator (BDHI)	DSB357	ID-663	
5826-00-168-8308	Bearing Distance Heading Indicator (BDHI)	1000	ID-663/U	
5826-00-952-3709	Bearing Distance Heading Indicator (BDHI)	196716	ID-1103	
5826-00-952-3709	Bearing Distance Heading Indicator (BDHI)	1166-8	ID-1103/ARN	
5826-00-961-7185	Bearing Distance Heading Indicator (BDHI)	101580	ID-663A/U	
5826-01-029-8005	Bearing Distance Heading Indicator (BDHI)	27900		
5826-01-029-8005	Bearing Distance Heading Indicator (BDHI)	276000	ID-663	
6130-00-913-4114	Power Supply	MS 18103-1	28VS50Y	
6608-00-893-7892	Liquid Quantity Indicator, Oxygen	1649602-1	29316-4L-C1	
6610-00-039-5020	Altimeter Indicator, Pressure	AAU-31/A	3252010-1101	
6610-00-061-7882	Attitude Indicator	137521-01-02		
6610-00-086-1632	Attitude Indicator	113150	ID-1329A/A	
6610-00-086-3840	Altimeter Ind, Counter-Drum Pointer/Servoed Ctl	3252001-0101	AAU-19/A	
6610-00-106-7552	Altimeter Indicator, Pressure	112234-1	AAU-24A	
6610-00-134-1323	Attitude Indicator	E25-8034-2	ID-1329A	
6610-00-134-1824	Altimeter Indicator, Pressure	3252010-0101	AAU-31/A	
6610-00-147-4225	Amplifier, Electronic Control (ECA)	352-020-001	7821745-515	
6610-00-150-6897	Altimeter Indicator, Pressure	AAU-24A	B41552-10-002	
6610-00-159-1119	Attitude Indicator	520 1045 001		
6610-00-165-5827	Attitude Indicator, Remote	112940	MS17401-1	
6610-00-167-9800	Altitude Encoding Altitude Computer	1620644-5	CPU66/A22	
6610-00-167-9800	Altitude Encoding Altitude Computer	31103-A22		
6610-00-169-1526	Attitude Indicator	142000-01-01	ID-1329A	
6610-00-169-1594	Attitude Indicator	3571442-3001	ID-1329A	
6610-00-169-1594	Attitude Indicator	DSA335		
6610-00-169-1595	Attitude Indicator, Remote	103700	ID-1329A/A	
6610-00-179-5086	Altimeter Ind, Counter-Drum Pointer/Servoed Ctl	A413222-10-003	AAU-19/A	
6610-00-181-1746	Accelerometer, Counting Transducer	24108-1		
6610-00-181-1750	Accelerometer, Counting Transducer	24108-4	MIL-A-22145	
6610-00-181-1750	Accelerometer, Counting Transducer	MS 25447-4		
6610-00-244-2816	Attitude Indicator	3571540-9003	DSA309	
6610-00-445-1033	Altimeter Indicator, Pressure (Cabin Pressure Indicator)	34500-C1-A1A1	A27397-10-004	
6610-00-580-9562	Attitude Indicator	131400-01	ARU-13/A	
6610-00-580-9563	Attitude Direction Indicator (ADI)	27360	ARU-13/A	
6610-00-585-0990	Attitude Direction Indicator (ADI)	127123-01	ARU-13/A	
6610-00-590-8270	Attitude Indicator	118769-01		
6610-00-597-3095	Accelerometer, Counting Indicator	3422-5C-A1		
6610-00-605-8296	Rate of Climb Indicator (ROC, VSI, VVI)	A27407-10-004		
6610-00-629-1883	Attitude Indicator	4003G	131941-01	
6610-00-674-6073	Attitude Direction Indicator (ADI)	29993	ARU-13/A	
6610-00-703-3519	Altimeter Indicator, Pressure (Cabin Pressure Indicator)	A27397-10-004	34500-C1-A1A1	
6610-00-729-6479	Position Indicator, Pitch Trim	1200A-C1A-1-A2	3571810-4001	
6610-00-732-0035	Accelerometer, Counting Transducer	24523T1		
6610-00-732-0036	Accelerometer, Counting Transducer	24523T4		
6610-00-761-2330	Accelerometer, Counting Transducer	261-7	24108-7	
6610-00-776-2137	Position Indicator, Flap	1300A-C1A-1A2		
6610-00-778-9039	Position Indicator, Nose Trim	1201A-C2A-1-A2		
6610-00-781-4198	Attitude Direction Indicator (ADI)	101700	ARU-13/A	
6610-00-841-6505	Accelerometer, Counting Transducer	24108-7	261-7	
6610-00-841-6509	Accelerometer, Counting Transducer	24108-6		
6610-00-855-9349	Attitude Direction Indicator (ADI)	136600-01-03	ARU-13/A	
6610-00-866-5509	Attitude Direction Indicator (ADI)	ARU-13/U	138093-01-01	
6610-00-872-0454	Altimeter Ind, Counter-Drum Pointer/Servoed Ctl	10180-A	AAU-19A/A	
6610-00-886-6518	Rate of Climb Indicator (ROC, VSI, VVI)	1665-6AU-6A-1		
6610-00-887-2068	Altimeter Ind, Counter-Drum Pointer/Servoed Ctl	34500-C1A-1A1	AAU-19/A	
6610-00-887-2068	Altimeter Ind, Counter-Drum Pointer/Servoed Ctl	A41322-10-002	AAU19A	
6610-00-903-1046	Accelerometer, Counting Transducer	24523T7	261-7	
6610-00-903-1047	Accelerometer, Counting Transducer	24108-9		
6610-00-930-9158	Position Indicator, Flap	1301A-C1A-1-A2		

6610-00-933-5950	Attitude Indicator	102500	MS17401-1	
6610-00-933-5951	Attitude Indicator	102300	MS17400-1	
6610-00-933-8790	Attitude Indicator, Remote	MS 18028(AS)	ID-1329A	
6610-00-954-6156	Attitude Direction Indicator (ADI)	138093-01-02	ARU-13/U	
6610-00-954-6156	Attitude Indicator	MIL-I-25592	MM3A	
6610-00-976-3337	Accelerometer, Counting Transducer	261-4		
6610-00-976-3340	Accelerometer, Counting Transducer	24523T1	261-1	
6610-01-039-5020	Altimeter Indicator, Pressure	AAU-31/A-1	3252010-1101	
6610-01-091-3702	Altimeter Indicator, Pressure	10450-31327	22964	
6610-01-142-8323	Altitude Encoding Altitude Computer	31103-A22A	CPU66/A22A	
6610-01-158-6540	Accelerometer, Counting Indicator	MIL-A-22145	MS25448	
6610-01-180-5544	Attitude Indicator, Remote	276111	E25-8034-2	
6610-01-655-5827	Attitude Indicator	112940		
6620-00-085-2881	Tachometer, Electric Indicator	8DJ81LAA4	ERU-5A/A	
6620-00-085-2908	Tachometer, Electric Indicator	8DJ81LCA4	ERU-5A/A	
6620-00-181-2605	Tachometer, Electric Indicator	3571260-4002	ERU-5A	
6620-00-182-7569	Tachometer, Electric Indicator	3571261-7001	ERU-5A/A	
6620-00-553-8862	Tachometer, Electric Indicator	34101-C1E-7-1C1	MIL-I-25863	
6620-00-553-8862	Tachometer, Electric Indicator	8DJ81LAA1	ERU-5/A, -5A/A	
6620-00-987-9242	Tachometer, Electric Indicator	408981-2	ERU-5A/A	
6620-00-987-9242	Tachometer, Electric Indicator	8DJ81LAA2		
6620-01-025-8503	Tachometer, Electric Indicator	3571280-4002	ERU-5/A	
6620-01-060-5430	Tachometer, Electric Indicator	3571281-7001	ERU-5A/A	
6680-00-425-1762	Liquid Quantity Indicator	211-003-001	7821745-503	
6680-00-425-1763	Liquid Quantity Indicator, Fuel	200-017-001		
6680-00-425-1823	Liquid Quantity Indicator	200-018-001	7821745-501	
6680-00-684-2236	Liquid Quantity Indicator, Oxygen	29316-4C-H1		
6680-00-723-1934	Liquid Quantity Indicator, Oxygen	29316-4FA1		
6680-00-871-0590	Liquid Quantity Indicator, Fuel	B118-135		
6680-00-944-5784	Liquid Quantity Indicator	B353-20		
6680-00-945-2416	Liquid Quantity Indicator	B118-266		
6680-00-950-9619	Amplifier, Electronic Control (ECA)	B478-32		
6610-00-087-2434	Attitude Direction Indicator (ADI)	41550	ARU-13/A	
6610-00-167-9699	Attitude Indicator	144700-01-01	4003AF	
6610-00-764-6627	Attitude Direction Indicator (ADI)	101700	ARU-13/A	
6610-00-764-6627	Attitude Direction Indicator (ADI)	102630	MIL-I-27710	
5826-00-032-7024	Bearing Distance Heading Indicator (BDHI)	18-1686-2	ID-663	
5826-00-679-3205	Bearing Distance Heading Indicator (BDHI)	331C4A	ID-663U	
5826-00-679-3205	Bearing Distance Heading Indicator (BDHI)	522-0974-003	ID663/U	
5826-00-812-8606	Bearing Distance Heading Indicator (BDHI)	520-1046-001	C45-9813-02	
5826-00-812-8606	Bearing Distance Heading Indicator (BDHI)	9813-02		
5826-00-829-9045	Bearing Distance Heading Indicator (BDHI)	9813-06	ID-663U	
5826-00-912-3285	Bearing Distance Heading Indicator (BDHI)	102200	ID-663BU	
5826-00-912-3285	Bearing Distance Heading Indicator (BDHI)	587981	2033250-01	
5826-00-953-9298	Bearing Distance Heading Indicator (BDHI)	522-2377-003	331C4F	
5826-00-953-9464	Bearing Distance Heading Indicator (BDHI)	182774	ID-663/U	
5826-00-689-9780	Bearing Distance Heading Indicator (BDHI)	10124	ID-663A/U	
5826-00-882-1203	Bearing Distance Heading Indicator (BDHI)	ID-663/U	37604-1E5A1	
5826-00-953-9298	Bearing Distance Heading Indicator (BDHI)	ID-663/U	QB400434	
5826-01-147-3098	Bearing Distance Heading Indicator (BDHI)	ID-663C/U	276200	
6610-00-133-7868	Accelerometer, Counting Indicator	24110	MIL-A-22145	
6610-00-780-3065	Air Speed Transmitter	892495-00-000	A24950-00-001	
5826-00-089-7912	Bearing Distance Heading Indicator (BDHI)	104470	ID-663C/U	
5826-00-788-5273	Bearing Distance Heading Indicator (BDHI)	ID-663BV	37612-1H5A1	
5826-00-953-9465	Bearing Distance Heading Indicator (BDHI)	101200	ID-663U	
6610-00-179-2655	Attitude Indicator	501-1049-01	ID-1481A	
6610-01-088-2352	Attitude Indicator	501-1277-01	ID-1791A/A	
6610-00-140-1719	Attitude Indicator	44615	ID-1448/A, B185	
6610-00-435-8932	Rate of Climb Indicator (ROC, VSI, VVI)	RC-60-V1L	41304-2	
6610-00-531-2345	Altimeter Indicator, Counter Pointer Pressure	A29534-04-001	A29534-10-004	
6610-00-531-2345	Altimeter Indicator, Counter Pointer Pressure	MS 28074-2		
6610-00-732-0037	Accelerometer, Counting Indicator	2231B1	262	
6610-00-732-0037	Accelerometer, Counting Indicator	2231B2	MS 25448-1	
6610-00-736-4376	Altimeter Indicator, Counter Pointer Pressure	B29534-04-001	B29534-10-004	
6610-00-866-4348	Attitude Indicator	137000-01-01	4012D	
6610-00-912-5033	Attitude Indicator	42659	ID1448/A	
6610-00-937-0527	Altimeter Indicator, Counter Pointer Pressure	C003124101	MC2	
6610-00-937-9721	Attitude Indicator	43010	ID1448/A	
6610-00-976-3341	Accelerometer, Counting Indicator	262	MS25448-1	
6610-00-999-1528	Attitude Indicator	18507-1EA1	1493892	
6620-00-904-1596	Altimeter Indicator, Pressure	18-1487	HE432-5004-0001	
6610-00-089-4358	Attitude Indicator	501-1022-01	ID-1481A	
6610-00-089-4358	Attitude Indicator	507-1009	AI-803A	

6610-00-115-6782	Attitude Indicator	11500	ID1448A/A	
6610-00-115-6800	Attitude Indicator	501-1099-01	ID-1791A	
6610-00-165-5838	Attitude Indicator	501-1059-51	ID-1481A/A	
6610-00-179-2655	Attitude Indicator	AI-803D		
6610-01-034-5226	Attitude Indicator	501-1099-02	ID-1791A	
6610-01-123-2204	Attitude Indicator	501-1278-01	ARU-48/A	
6610-01-341-6041	Attitude Indicator	501-1664-01	ARU-70/A	
6610-01-343-2609	Attitude Indicator	501-1665-01	ARU-71/A	
6610-01-357-4345	Attitude Indicator	501-1492-02	ARU-69/A	
6610-01-358-1161	Attitude Indicator	501-1492-01	ARU-65/A	
6605-01-221-5384	Horizontal Situation Indicator (HSI)	126610		
6605-01-221-5384	Horizontal Situation Indicator (HSI)	AQU-6A/A	MIL-I-83034	
6605-01-398-0032	Horizontal Situation Indicator (HSI)	126610-3		
6605-01-183-2220	Horizontal Situation Indicator (HSI)	3809283-2		
5825-01-328-0196	Compass Indicator, Radio Magnetic (RMI)	RMI-36	622-2506-003	
5841-01-014-1674	Altimeter Indicator, Radar	339H4	622-1204-003	
6610-00-134-5625	Altimeter Indicator, Encoder	B45152-10-002	AAU-32/A	
6610-00-167-9699	Attitude Indicator	104-384022-3	ARU-13/A	
6610-00-764-6627	Attitude Direction Indicator (ADI)	104-384022-3		
6610-00-883-1034	Attitude Direction Indicator (ADI)	ARU-13/A	MIL-I-27710	
6610-01-055-0468	Altimeter Indicator, Encoder	3252011-0101	C44202-10-002	
6610-01-080-2117	Accelerometer, Counting Indicator	104-384016-1	MS 28025	
6610-01-176-9314	Altimeter Indicator, Encoder	101450-31243		
	Accelerometer, Counting Indicator	2117-812		
	Volt Ammeter Indicator	521915	90-384023-1	
5826-01-370-9328	Compass Indicator, Radio Magnetic (RMI)	RMI-30	622-4938-007	
6610-01-005-9151	Altimeter Indicator, Encoder	3252013-0101	AAU-31/A	
6610-01-294-5633	Altimeter Indicator, Encoder	570-23932-414		
6610-01-323-1077	Rate of Climb Indicator (ROC, VSI, VVI)	100-384054-1	7130C-44	
6615-01-217-6219	Horizontal Situation Indicator (HSI)	066-3046-01	KI 525A	
	Turn and Slip Indicator	100-384078-1	2800(6930NIL)	
	Air Speed Indicator	100-384083-5	AW2829AFO1	
	Turn and Slip Indicator	5550-7070-1	104-384018-1	
6680-00-580-1248	Liquid Quantity Indicator	JG402A4	695797-5	
6680-00-585-5444	Liquid Quantity Indicator	JG412A3	675797-11	
6680-00-585-5859	Liquid Quantity Indicator	JG412A2		
6680-01-056-1779	Liquid Quantity Indicator	JG402A52		
6680-01-060-5228	Liquid Quantity Indicator	JG402A-53	695797-25	
6685-00-148-8247	Temperatue Indicator, Thermocouple	9A375	MIL-I-27552	
6130-01-123-2274	Inverter, Power Static	501-1243-01		
6610-01-167-6617	Attitude Direction Indicator (ADI)	112790-1	ARU-39A	
6605-00-797-0134	Horizontal Situation Indicator (HSI)	AQU-2A	522-1785-003	
6680-00-728-8764	Liquid Quantity Indicator	B118-191	3B90018-101	
6680-00-728-8765	Liquid Quantity Indicator	B118-192M	3B90018-103	
6680-00-728-8765	Liquid Quantity Indicator	3B90018-275		
6605-00-992-3096	Horizontal Situation Indicator (HSI)	101000	104500	
6605-00-992-3096	Horizontal Situation Indicator (HSI)	AQU-4/A	MIL-I-27848	
6605-01-194-3611	Horizontal Situation Indicator (HSI)	277666	AQU-4/A	
6605-00-034-2500	Horizontal Situation Indicator (HSI)	100524	AQU-2A	
6605-00-034-2500	Horizontal Situation Indicator (HSI)	AQU-2/A	MIL-I-26889	
6680-01-382-9162	Tachometer Indicator, Turbine	30B367-3	50-380034-3	
6620-00-450-3952	Tachometer Indicator	D31527-10-008	107E2982-7	
6620-01-029-4777	Tachometer Indicator	D31527-10-015	107E2982-9	
5841-00-957-6694	HEIGHT INDICATOR (AN/APN-141)	3158656	S101975, 1494073, ID1015AAPN141V	
6615-00-858-4472	DIRECTIONAL GYROSCOPE	8KD3AD2		
5821-01-038-7301	COMMUNICATION RADIO	622-1396-002	RT-5048/ARC-511(V)	
6605-00-979-9200	ACCELEROMETER, ELECTRICAL	602110-4		
6615-00-884-1900	DISPLACEMENT GYROSCOPE	42565		
6610-00-558-0399	Turn and Slip Indicator	266-004-001	A51A9055-1	
6610-00-817-8771	Position Indicator	8DJ49LAM2		
6610-00-817-8772	Position Indicator	8DJ49LAN2		
6610-01-172-3705	Air Speed Indicator	2154	MS17264-1	
6610-01-242-9674	Airspeed Indicator	3250002-0201	3250002-201	
6605-01-018-2184	Horizontal Situation Indicator (HSI)	75500000-1		
6605-01-058-0975	Horizontal Situation Indicator (HSI)	126460	AQU13/A/A	
6605-01-094-3627	Horizontal Situation Indicator (HSI)	118550M	AQU-13A/A	
1660-01-030-2821	Temperature Controller	10088A200-505	673163-107	
1660-01-037-8700	Temperature Controller	10088A200-507	673163-109	
4920-00-993-7859	Position Indicator	142550-01-01	2718A	
5821-00-100-7931	Radio, UHF Communication ARC-159	622-0356-001	AN/ARC-159	
5821-00-140-1775	Radio, UHF Communication ARC-159	622-1524-021	AN/ARC-159	
5821-00-140-1776	Radio, UHF ARC-159	622-1524-022	AN/ARC-159(V)1	
5821-00-140-1785	Frequency Indicator	ID-1972	622-1624-001	

5821-00-140-1817	Indicator, Frequency Channel p/o ARC-159	622-1624-002	ID-1972/ARC-159V	
5821-00-140-1824	Radio, UHF Communication ARC-159	622-0356-003	AN/ARC-159	
5821-00-180-8264	Translator-Modulator, 1A2 p/o ARC-159	617-9621-002	AN/ARC-159	
5821-00-566-2980	Translator-Modulator, 1A2 p/o ARC-159	617-9621-004	617-9621-006	
5821-00-567-4544	Chassis 1A7 p/o ARC-159	622-1495-002		
5821-01-018-4238	Control Panel	C-9816/ARC-159(V)	622-2287-002	
5821-01-018-4240	Radio, UHF Communication ARC-159	622-1365-001	RT-1150/ARC-159	
5821-01-020-3970	Radio, UHF Communication ARC-159	622-0356-002	AN/ARC159	
5821-01-020-8384	Radio, UHF Communication ARC-159	622-1366-001	RT-1124/ARC-159	
5821-01-021-3503	Control Panel	C-9815/ARC-159(V)	622-2287-001	
5821-01-022-9499	Control Panel	C-9818/ARC-159(V)	622-2287-004	
5821-01-023-9318	Guard receiver, 1A4 p/o ARC-159	608-9419-003		
5821-01-023-9813	Guard Receiver 1A4	608-9613-003		
5821-01-025-5020	Control Panel	C-9817/ARC-159(V)	622-2287-003	
5821-01-029-4786	Connector Board 1A6A1A2 p/o C-9815/ARC-159	628-2137-001		
5821-01-029-5098	Front Plate 1A6A1 p/o C-9815/ARC-159	628-2138-001		
5821-01-349-7085	Radio, UHF Communication ARC-159	622-1524-001	AN/ARC-159	
5826-00-117-4629	Bearing Indicator	104840	ID-1540/A	
5831-00-008-5602	Intercommunications Set Control AIC-14	227-3000	C-2645D/AIC-14A	
5831-00-008-5602	Intercommunications Set Control AIC-14	227-4906		
5831-00-008-5604	Intercommunications Set Control AIC-14	277-4000	C-2648B/AIC-14	
5831-00-050-8617	Intercommunications Set Control AIC-14	1000850	106D7011-1	
5831-00-050-8617	Intercommunications Set Control AIC-14	106C7000-1	220344-2	
5831-00-050-8617	Intercommunications Set Control AIC-14	264-4000-2	C-2647A/AIC-14	
5831-00-050-8618	Intercommunications Set Control AIC-14	1000800	C-2642A/AIC-14	
5831-00-050-8618	Intercommunications Set Control AIC-14	106D2006-1	MIL-I-22352B	
5831-00-060-0026	Intercommunications Set Control AIC-14	1000630	C-2648B/AIC-14	
5831-00-060-0026	Intercommunications Set Control AIC-14	106D8006-1	220340-2	
5831-00-806-7834	Intercommunications Set Control AIC-14	117D700-1	C-2647/AIC-14	
5831-00-806-7835	Intercommunications Set Control AIC-14	117D600-1	C-2648A/AIC-14	
5831-00-806-7836	Intercommunications Set Control AIC-14	106E5005-1	C-2645A/AIC-14	
5831-00-806-7836	Intercommunications Set Control AIC-14	117E100-2	C-2645B/AIC-14	
5831-00-824-9153	Intercommunications Set Control AIC-14	117D600-2	C-2648/AIC-14	
5831-00-824-9365	Intercommunications Set Control AIC-14	117D700-2	C-2647/AIC-14	
5831-00-933-2825	Intercommunications Set Control AIC-14	C-2645D/AIC-14A	122-4500	
5831-00-989-8978	Intercommunications Set Control AIC-14	1000700	C-2645C/AIC-14	
5831-00-989-8978	Intercommunications Set Control AIC-14	106C5019-1		
5831-00-989-8978	Intercommunications Set Control AIC-14	106E5005-1C	117E300-1	
5831-00-989-8978	Intercommunications Set Control AIC-14	106C5019-1	227-4905	
5831-01-372-3708	Intercommunications Set Control AIC-14	1974AS7000-1	C-2645D/AIC-14A	
5831-01-396-7324	Intercommunications Set Control AIC-14	C-2645C/AIC-14	1794A7100	
5841-00-989-8978	Intercommunications Set Control AIC-14	C-2645/AIC-14		
5895-00-567-4548	ARC-159	622-1391-003		
5895-00-567-4549	Amplifier RF, ARC-159	622-1394-002		
5895-01-017-5383	Control 1A6 p/o ARC-159	618-7241-004		
5996-01-025-8697	Circuit Card, ARC-159	608-9420-003		
5998-01-027-8667	ALC/Control 1A6 p/o RT-1194/ARC-159	601-3718-001		
5998-01-236-4916	Memory Circuit 1A6A3 p/o ARC-159	637-2576-001	637-2576-002	
6605-00-076-0611	Bearing Distance Heading Indicator (BDHI)	512-31-000	ID-956A	
6605-00-226-0596	Bearing Distance Heading Indicator (BDHI)	189003-000	ID-956A	
6605-00-226-0597	Bearing Distance Heading Indicator (BDHI)	512-30-000	ID-956/ASN30A	
6605-00-824-4735	Bearing Distance Heading Indicator (BDHI)	569-3-000	ID-956A	
6605-00-878-8275	Bearing Distance Heading Indicator (BDHI)	512-30-000	ID-956A/ASN-30	
6610-00-007-1030	Accelerometer, Counting Indicator	2119-500		
6610-00-020-2854	Rate of Climb Indicator (ROC, VSI, VVI)	C2536310002	88253623000	
6610-00-050-8806	Attitude Direction Indicator (ADI)	1784163-901		
6610-00-050-8808	Attitude Direction Indicator (ADI)	1510698		
6610-00-055-8535	Attitude Direction Indicator (ADI)	139001-01-01		
6610-00-056-3092	Rate of Climb Indicator (ROC, VSI, VVI)	C25363-10-021	MIL-I-18804	
6610-00-056-7276	Rate of Climb Indicator (ROC, VSI, VVI)	RCS-60-1L0		
6610-00-058-9527	Attitude Direction Indicator (ADI)	9819-08		
6610-00-065-7276	Rate of Climb Indicator (ROC, VSI, VVI)	RCS-60-IL0	MIL-I-18804	
6610-00-068-3464	Attitude Direction Indicator (ADI)	4055K	139602-01-01	
6610-00-070-3374	Altimeter Indicator, Pressure	MIL-I-81403		
6610-00-078-9002	Attitude Direction Indicator (ADI)	139800-01-01	ARU-13/A	
6610-00-078-9002	Attitude Direction Indicator (ADI)	MIL-I-27710	ARU-13/A	
6610-00-084-1128	Position Indicator	8DJ49LAS2	7000043	
6610-00-084-1129	Position Indicator	8DJ49LAR2	4062044	
6610-00-087-2434	Attitude Direction Indicator (ADI)	MIL-I-27710	ARU-13/A	
6610-00-087-6303	Position Indicator	8DJ49LAV2		
6610-00-110-3368	Altimeter Indicator, Pressure	Type AAU-31/A	MIL-A-81851	
6610-00-115-2405	Altimeter Indicator, Encoder	Type AAU32A	MILA81852	
6610-00-121-4679	Altitude Encoding Altitude Computer	31103-A1	1620644-1	

6610-00-131-8817	Attitude Direction Indicator (ADI)	109090		
6610-00-148-7180	Attitude Direction Indicator (ADI)	156578-01-01	4003AU	
6610-00-150-6785	Attitude Direction Indicator (ADI)	501-1086-01		
6610-00-160-0905	Attitude Direction Indicator (ADI)	501-1098-01		
6610-00-168-0797	Altitude Indicator, Encoder	B4154210003		
6610-00-179-2535	Altitude Encoding Altitude Computer	31103-A25	CPU66/A25	
6610-00-179-9035	Attitude Indicator	148700-01-01		
6610-00-186-8229	Attitude Direction Indicator (ADI)	152560-01-01		
6610-00-200-8742	Attitude Direction Indicator (ADI)	501-1131-02		
6610-00-200-8832	Attitude Direction Indicator (ADI)	501-1131-01		
6610-00-224-1278	Altitude Indicator, Pressure	AN5760-2A	671K03	
6610-00-224-1284	Altitude Indicator, Pressure	AN5760-2	671CK010	
6610-00-224-1843	Altitude Indicator, Pressure	AN5760L2	671CKL010	
6610-00-232-9470	Altitude Indicator, Pressure	AN5760L4B	671CKL018	
6610-00-232-9472	Altitude Indicator, Pressure	671CK010	AN5760L4B	
6610-00-232-9473	Altitude Indicator, Pressure	671CKL010	AN5760L4B	
6610-00-232-9479	Altitude Indicator, Pressure	AN5760L4B	671BU010	
6610-00-232-9485	Altitude Indicator, Pressure	671BK011	C-16	
6610-00-251-0366	Altitude Indicator, Pressure	AN5760T2A	671CPU19-015	
6610-00-301-6365	Altitude Indicator, Pressure	671CK-010		
6610-00-301-6365	Altitude Indicator, Pressure	AN5760-2	C63110ISSUEA	
6610-00-365-4194	Attitude Direction Indicator (ADI)	501-1153-01		
6610-00-405-6461	Altitude Indicator	88415422001		
6610-00-410-2866	Attitude Indicator	149250-01-01		
6610-00-424-8740	Attitude Direction Indicator (ADI)	139001-01-04		
6610-00-474-2286	Attitude Direction Indicator (ADI)	1784163		
6610-00-477-6691	Rate of Climb Indicator (ROC, VSI, VVI)	1675-6BD-A6-1	MS28075-2B	
6610-00-514-4175	Altitude Indicator, Pressure	AN5760L4B	671BK03	
6610-00-514-4181	Altitude Indicator	1845LU-4-02BUE		
6610-00-514-5651	Altitude Indicator, Pressure	AN5760L2A	671BU010	
6610-00-514-5651	Altitude Indicator, Pressure	MS280441	8000	
6610-00-514-6156	Position Indicator	8DJ48CAD1	EA323-1	
6610-00-530-3953	Altitude Indicator, Pressure	2240LU-4-02	5760L4U	
6610-00-530-3955	Altitude Indicator, Pressure	671BK010	C-12	
6610-00-531-4582	Rate of Climb Indicator (ROC, VSI, VVI)	A25363-10-002	MS28075-1	
6610-00-531-4587	Rate of Climb Indicator (ROC, VSI, VVI)	A25753-10-001	MS28075-1	
6610-00-620-3802	Turn and Slip Indicator	A1620	MD-4A	
6610-00-620-3802	Turn and Slip Indicator	MS 28041-2A	M3500-9	
6610-00-625-6035	Turn and Slip Indicator	A1605	MD-1B	
6610-00-663-7749	Altitude Indicator, Pressure	AN5760-2A	671CP19-017	
6610-00-663-8706	Air Speed Indicator	739CU-4-034		
6610-00-663-8716	Air Speed Indicator	1296U4-0202		
6610-00-663-8722	Air Speed Indicator	1296U40206		
6610-00-719-8446	Attitude Direction Indicator (ADI)	501-1096-01		
6610-00-722-2795	Attitude Direction Indicator (ADI)	139001-01-02		
6610-00-758-2385	Attitude Indicator	141400-01-01	4005AB	
6610-00-783-5470	Attitude Direction Indicator (ADI)	136000-01-01		
6610-00-787-7652	Attitude Indicator	501-1032-01	ID-1481A	
6610-00-787-7652	Attitude Indicator	AI-803B		
6610-00-817-8769	Position Indicator	8DJ48LAA2		
6610-00-821-2635	Attitude Direction Indicator (ADI)	ARU-2B/A		
6610-00-833-3315	Attitude Direction Indicator (ADI)	136910-01-01		
6610-00-933-9262	Attitude Direction Indicator (ADI)	139001-01-03		
6610-00-939-5237	Attitude Direction Indicator (ADI)	102379		
6610-00-963-5783	Altitude Indicator, Pressure	C28934-101007	671BU10	
6610-00-970-9111	Rate of Climb Indicator (ROC, VSI, VVI)	1667-6AEA6-1	128SCAV108-1	
6610-00-975-1699	Horizontal Situation Indicator (HSI)	522-4706-001		
6610-01-038-2081	Altitude Indicator, Pressure	B4515210003		
6610-01-044-1860	Attitude Direction Indicator (ADI)	77600000-3		
6610-01-045-6372	Attitude Direction Indicator (ADI)	501-1190-02		
6610-01-070-9411	Attitude Direction Indicator (ADI)	161815-01-01		
6610-01-084-9562	Altitude Indicator, Encoder	3252011-1101		
6610-01-091-3701	Altitude Indicator, Pressure	B4420210002	B44202-10-002	
6610-01-092-9846	Attitude Direction Indicator (ADI)	77600000-4		
6610-01-101-1883	Horizontal Situation Indicator (HSI)	622-4298-001		
6610-01-101-1927	Attitude Indicator	622-3374-002	ADI-55A	
6610-01-105-7880	Turn and Slip Indicator	A1605	MD-1B	
6610-01-130-8885	Altitude Encoding Altitude Computer	31103-A28	CPU66/A28	
6610-01-132-1898	Attitude Direction Indicator (ADI)	135070		
6610-01-134-5625	Altitude Indicator, Encoder	B451521002		
6610-01-148-2181	Altitude Encoding Altitude Computer	31103-A28A	CPU66/A28A	
6610-01-182-9481	Attitude Direction Indicator (ADI)	501-1230-01		
6610-01-259-0251	Altitude Indicator, Encoder	518-28007-204	28007-204	

6610-01-264-3953	Altimeter Indicator, Encoder	101450-41883	
6610-01-282-3207	Altimeter Indicator, Encoder	3252011-0301	
6610-01-286-0880	Altimeter Indicator, Pressure	3252010-1100-01	lite mod
6610-01-296-0880	Altimeter Indicator, Pressure	10450-31875	23557
6610-01-296-0880	Altimeter Indicator, Pressure	AAU-31A-2	MIL-A-81851
6610-01-314-2480	Attitude Direction Indicator (ADI)	112790	
6610-01-390-6925	Attitude Direction Indicator (ADI)	109090-3	
6610-01-394-8294	Attitude Direction Indicator (ADI)	160C180238-1	
6610-01-406-4983	Altimeter Indicator, Pressure	B44202-10-042	lite mod
6610-01-406-4985	Altimeter Indicator, Pressure	3252010-1101-01	
6610-01-468-3489	Altimeter Indicator, Pressure	B4515210042	AAU-32/A-2
6620-00-148-8307	Tachometer Indicator	8DJ81CAN4	
6620-00-543-2534	Tachometer Indicator	34102C2B3-2D1	MS 21971-1
6620-00-543-2534	Tachometer Indicator	8DJ81CAN2	F15597-10-003
6620-00-557-0350	Pressure Indicator, Pneumatic	SR-4A	18-1102
6620-00-557-0362	Pressure Indicator, Pneumatic	SR-3A	18-1104
6620-00-557-0363	Pressure Indicator, Pneumatic	SR-4B/D	18-1103
6620-00-557-0816	Pressure Indicator, Pneumatic	SR-8B/P	18-1112
6620-00-717-1900	Pressure Indicator, Oil	18-1118	18-1118W
6620-00-761-9292	Tachometer Indicator	8DJ67AAC1	107E2081-1
6620-00-765-5139	Tachometer Indicator	8DJ81LCA2	ERUSAA
6620-00-928-0216	Torquemeter Indicator	B709-4	620865-103
6620-01-038-5801	Torquemeter Indicator	201-004-001	
6620-01-151-9590	Flowmeter Indicator	8DJ88LAB1, -2, -3	
6620-01-228-1571	Tachometer Indicator	78035-11119	
6620-01-230-0197	Tachometer Indicator	78035-01118	
6625-00-189-9607	Position Indicator	142550-02-01	2718C
6655-00-458-1363	Magnetic Distortion Recorder	58206-301	RO-32/ASQ
6655-00-473-5280	Magnetic Distortion Recorder	654BM104	RO-32/ASQ
6655-00-720-2679	Magnetic Distortion Recorder	58206	RO-32/ASQ10
6655-00-999-2597	Magnetic Distortion Recorder	58206-1	RO-32/ASQ10
6680-00-358-1306	Liquid Oxygen Quantity Indicator	9A1021	MIL-I-81387A Type II
6680-00-358-1306	Liquid Oxygen Quantity Indicator	9A860	
6680-00-728-8767	Liquid Quantity Indicator	B118-194	3B90018-107
6680-00-728-8768	Liquid Quantity Indicator	B118-195	3B90018-109
6680-00-762-0454	Liquid Quantity Indicator	118-999-20	561281
6680-00-762-0454	Liquid Quantity Indicator	B118-193	3B90018-105
6680-00-887-6763	Accelerometer, Counting Indicator	602110-5	CN-793/ASN-42
6680-01-103-3419	Fuel Quantity Indicator	472964-001	68-580104-235
6680-01-137-3784	Fuel Quantity Indicator	JG4C1	
6685-00-148-7296	Temperatue Indicator, Thermocouple	354-012-006	354-012-006
6685-00-148-7296	Temperatue Indicator, Thermocouple	A51A9011-15	
6685-00-161-8995	Temperatue Indicator, Thermocouple	354-012-001	354-012-004
6685-00-183-0351	Temperatue Indicator, Thermocouple	9A400	MS24569-1
6685-00-557-0215	Pressure Indicator, Pneumatic	SR-7A	18-1105
6685-00-663-8832	Altimeter Indicator, Pressure	254BK8-045	
6685-00-690-8905	Pressure Indicator, Oil	18-1157	EGU-1/A
6685-00-801-7587	Temperatue Indicator, Thermocouple	DST-17-1	MS24569
6685-00-882-8127	Altimeter Indicator, Pressure	18-1169	MS 25470-7
6685-00-906-4720	Temperatue Indicator, Thermocouple	502BL3B	
6685-00-979-6257	Altimeter Indicator, Pressure	18-1199-01	
6685-01-177-3442	Temperatue Indicator, Thermocouple	DST497-2	
6685-01-506-8079	Temperature Indicator, Thermocouple	9A550	MS24569-1
6615-00-628-6363	Link Force Assembly	RG79A1	
1280-00-475-6858	Control Monitor	60A95D1	DCU-77/A
1660-00-019-1515	Temperature Controller	1378-1C	
1660-00-870-0497	Temperature Controller	1378-1A	860-1
1660-00-921-8441	Temperature Controller	1378-1F	
1660-00-939-0460	Temperature Controller	1378-1B	
5826-00-505-2218	Course Indicator	7202-1A4B1	ID-249A/ARN52
5826-00-505-3141	Course Indicator	ID-351/ARN	140313
5826-00-799-3716	Azimuth Range Indicator (Drift Angle-Ground Speed)	ID-863/A	T8513-11A
5841-00-102-8684	Control Indicator	588K0001G1 /G2	C-7683/APN-182
5841-00-756-3975	Azimuth Range Indicator (Drift Angle-Ground Speed)	ID-862	T8605-22NMD1
5841-00-799-3715	Azimuth Range Indicator (Drift Angle-Ground Speed)	ID-862A/A	T8605-22N
6210-00-676-7874	Advisory Panel	965-9015-008	S6155-61551-018
6220-00-760-4332	Tachometer Indicator, Triple	212-070-108-3	3571371-6001
6610-00-075-1501	Attitude Indicator, Remote	118930-01-23	
6610-00-607-8292	Attitude Indicator, Remote	118930-01	4005H
6610-00-929-8968	Attitude Indicator	142640-01-01	S6145-61315-101
6610-00-986-0031	Rate of Climb Indicator (ROC, VSI, VVI)	A10352-1	A10352-2
6620-00-165-5777	Tachometer Indicator, Triple	3571371-8001	MS 18099-3
6620-00-165-5777	Tachometer Indicator, Triple	MIL-I-23832	2274655

6620-00-612-7743	Torquemeter Indicator	393059-01897	21C1596-46	
6620-00-760-4332	Tachometer Indicator, Triple	8DJ131LAE1	212-070-108-3	
6620-00-797-2591	Torque Meter Indicator, Percent	3571320-0010	6300C49A155B1	
6620-00-797-2591	Torque Meter Indicator, Percent	S6145-61044-001		
6620-00-809-4480	Tachometer, Electric Indicator	8831522-0001	C31527-10008	
6620-00-895-9774	Tachometer, Electric Indicator	B31521-10-008		
6620-00-938-9571	Cruise Guide Indicator	1122	TYPE 23L	
6620-00-938-9571	Cruise Guide Indicator	196897	65450-01025-101	
6620-00-940-9292	Tachometer Indicator, Triple	8DJ131AAB1	S6147-61051-003	
6620-00-946-2677	Torque Meter Indicator, Percent	3571320-0007	6300C38A155B1	
6620-00-946-2677	Torque Meter Indicator, Percent	S6145-61044		
6625-00-895-3980	Temperatue Indicator, Thermocouple	152B8	MJ2	
6680-00-191-0538	Liquid Quantity Indicator, Fuel	393004-093	S6145-61391-002	
6680-00-703-6812	Liquid Quantity Indicator, Fuel	393004-01648	S6145-61391-1	
6680-00-733-8432	Liquid Quantity Indicator, Fuel	393004-01970		
6680-00-868-9810	Liquid Quantity Indicator, Fuel	393004-01699		
6680-00-948-3837	Liquid Quantity Indicator, Fuel	393004-01794	S6145-61390-001	
6685-00-530-3614	Temperatue Indicator, Thermocouple	152B4	152B44	
6685-00-530-3614	Temperatue Indicator, Thermocouple	MJ1		
6685-00-557-5910	Temperatue Indicator, Thermocouple	152B2	152B2A	
6685-00-557-5910	Temperatue Indicator, Thermocouple	152B22	157800	
6685-00-603-3913	Temperatue Indicator, Thermocouple	163B2	EHU18A	
6685-00-603-3913	Temperatue Indicator, Thermocouple	163B2C	163B2D	
1680-01-279-8193	Controller Grip Assembly	70450-21905-102	707-3407	
1680-01-347-4628	Control Panel	70450-81012-043		
6605-01-327-0253	Control Panel	70450-81012-041		
6680-00-159-0815	Fluid Quantity Indicator, Hydraulic	358-002-001	65450-01426-101	
6680-01-020-8149	Fluid Quantity Indicator, Hydraulic	358-002-002	65450-01426-102	
6610-01-175-9045	Position Indicator	70450-21953-101	3809487-1	
6610-00-353-9990	Position Indicator, Roll Trim	3571812-4001	673146-101	
6610-00-639-3615	Rate of Climb Indicator (ROC, VSI, VVI)	1652-6AJ-B6-1	1652-6AJ-BG-1	
6610-00-639-3615	Rate of Climb Indicator (ROC, VSI, VVI)	1652-6AJ-C6-1	MS28075-1	
1680-01-164-4123	Temperature Control Panel	70450-21801-101	783235-1	
1680-01-164-4126	Blade Deice Control Panel	70902-01099-043		
1680-01-175-8968	Caution Advisory Panel	844182-2	70550-21900-102	
1680-01-240-5509	Blade Deice Control Panel	70902-01099-044		
1680-01-274-7060	Rescue Hoist Control Panel Assy	70850-22111-113	EC-10000-30	
1680-01-317-4563	Caution Advisory Panel	844182-4	70550-21900-105	
1680-01-330-6729	Caution Advisory Panel	844182-3	70550-21900-104	
1680-01-330-6729	Caution Advisory Panel	ABU-35A		
1680-01-346-8274	Temperature Control Panel	801676-1	70450-21801-102	
1680-01-346-8299	Rescue Hoist Control Panel Assy	70850-22111-121	EC-10000-60	
1680-01-347-4626	Blade Deice Control Panel	70902-01099-046		
1680-01-348-5144	Caution Advisory Panel	844182-8	70550-21900-109	
1680-01-353-9292	Fault Function Indicator Panel	70550-82605-042		
1680-01-361-1051	Caution Advisory Panel	844182-15	70550-21900-113	
1680-01-361-1051	Caution Advisory Panel	ABU-26B/A		
1680-01-393-6859	Caution Advisory Panel	844182-16	70550-21900-118	
1680-01-434-1979	Caution Advisory Panel	844182-14	70550-21900-115	
5895-01-313-6476	Recording Set Control	70600-81815-101	2010566-001	
6220-01-115-9237	Power Supply, Strobe Light	70553-05002-107	60-2977-3	
6220-01-211-6790	Power Supply, Strobe Light	70553-05002-110	60-2977-5	
6610-01-164-4329	Rate of Climb Indicator (ROC, VSI, VVI)	70450-21988-101	30260-1164	
6610-00-454-0284	VERTICAL VELOCITY INDICATOR	1684-6BDA6-1		
5895-00-930-2656	INDICATOR CONTROL	G7148-001-01	183305-000, C4418BAPN153V	
1660-00-760-0622	Selector and Indicator	588530-3		
1660-00-918-6727	Temperature Controller	588531-5		
1660-01-097-8733	Selector and Indicator	588530-5	670596-105	
1660-01-097-8747	Temperature Controller	588531-7	670587-107	
1680-01-174-1962	SASP Control Panel	C-11104/A	969063-101	
4920-00-867-1424	Temperature Indicator, Turbine Inlet (TIT)	H153B		
4920-01-166-5020	Temperature Indicator, Turbine Inlet (TIT)	H153C		
5826-00-117-4629	Bearing Indicator	671353-101		
5831-00-438-4654	Intercommunications Set Control AIC-22	655355-7	C-8242V/AIC-22V	
5831-00-438-4654	Intercommunications Set Control AIC-22	671675-117		
5831-00-802-8947	Intercommunications Set Control AIC-22	449204-1	C-4164V/AIC-22V	
5831-00-987-1815	Intercommunications Set Control AIC-22	449201 - 6 Mod 2	616297-57	
5831-00-987-1815	Intercommunications Set Control AIC-22	616297-57	C-4162/AIC-22V	
5831-00-987-1815	Intercommunications Set Control AIC-22	449201-6		
5831-01-190-7804	Intercommunications Set Control AIC-22	655355-10	C-8242AV/AIC-22V	
5831-01-190-7804	Intercommunications Set Control AIC-22	671675-127	C8242A/AIC22(V)	
5935-00-987-1903	Intercommunications Set Control AIC-22	178D000-3		
5935-00-987-1903	Intercommunications Set Control AIC-22	616291-3	AM3364/AIC22(V)	

6610-00-641-3015	Attitude Indicator	14602-1JA1M		
6610-00-663-8812	Attitude Indicator	678901	NAF 1308-1	
6610-00-663-8813	Attitude Indicator	613937	NAF 1308-1	
6610-00-663-8815	Attitude Indicator	673191		
6610-00-759-7170	True Air Speed Computer	510414-3-2	A24G-9	
6620-00-148-7313	Torque Meter Indicator	B-709-7J	620865-107	
6620-00-151-5363	Torque Meter Indicator	B-709-7		
6620-00-151-5363	Torque Meter Indicator	B-709-7A	MS 90323-6	
6620-00-236-5004	Tachometer Indicator	8DJ81LBZ2	MIL-I-22596	
6620-00-369-0618	Tachometer Indicator	8DJ81LBZ4	3237K35	
6620-00-761-9290	Tachometer Indicator	B31521-10-007	107E2982-1	
6620-00-860-1626	Tachometer Indicator	34101C2C7-2E1	1496049	
6620-01-018-7440	Tachometer Indicator	B31521-10-015	107E2982-8	
6620-01-063-9054	Torquemeter Indicator	472592		
6680-00-815-7282	Liquid Quantity Indicator, Fuel	393007-07869	624407-1	
6680-00-815-7284	Liquid Quantity Indicator, Fuel	393065-01858	624408-1	
6680-00-815-7285	Liquid Quantity Indicator, Fuel	393007-07870		
6685-00-234-7118	Temperatue Indicator, Thermocouple	309-001-001	670785-109	
6685-00-319-1685	Temperature Indicator, Electrical	JG165A2	626175-1	
6685-00-887-9302	Rate of Climb Indicator (ROC, VSI, VVI)	A26877-10-001	620536-1	
6685-00-887-9303	Altimeter Indicator, Pressure	SRD9B	626150-1	
5831-00-118-9016	Intercommunications Set Control AIC-22	449202-9	C-4163AV/AIC-22V	
5831-00-118-9016	Intercommunications Set Control AIC-22	616296-121	173AS352	
6615-00-719-5849	Stall Warning Computer	C-35206-2		
6685-00-919-2188	Temperatue Indicator, Thermocouple	670785-101	BH183R58	
6685-01-047-8368	Temperatue Indicator, Thermocouple	4SE01104-1		
6685-01-069-3964	Temperature Indicator	100004-001		
6685-01-143-2704	Temperatue Indicator, Thermocouple	10004-001	670785-107	
6685-01-176-3649	Temperature Indicator, Turbine Inlet (TIT)	10004-001A	670785-111	
5985-00-990-5198	ANTENNA	AS1350APN153V	G6779-001-01	REPLACED WITH 5985-00-930-2657
6130-00-815-3516	POWER SUPPLY (PP-2058A/ULA-2)	1150186	PP2058ULA2, PL20517LA2	REPLACED WITH 6130-00-179-4692.
6625-00-815-3593	PULSE ANALYZER INDICATOR	1150188	IP471ULA2	REPLACED WITH 6130-00-179-4693.
6610-00-844-1195	AIRSPPEED INDICATOR	1701BX8-04		REPLACED WITH 6610-01-067-0228.
6615-00-876-4987	DISPLACEMENT GYROSCOPE	119001-01-45		REPLACED WITH 6615-00-181-2334.
6615-00-832-6601	DISPLACEMENT GYROSCOPE	MS17398-1	119001-01-47	REPLACED WITH 6615-00-181-2334.
6615-00-986-8995	VERTICAL GYRO	15885-1B		REPLACED WITH 6615-00-182-7698.
6620-00-927-6176	Flowmeter Indicator	8DJ97LAK1		REPLACED WITH 6620-00-345-1474.
6620-00-900-3986	LOW LEVEL FUEL CONTROL ASSEMBLY	B478-33M		REPLACED WITH 6620-00-351-9949.
5998-00-836-3633	Modulator Assembly	99971EE207-1		
1680-00-424-6612	Fault Function Indicator Panel	837171-5	673134-111	
1680-01-378-3339	Fault Function Indicator Panel	837171-8	673134-117	
6610-00-038-1115	Rate of Climb Indicator (ROC, VSI, VVI)	A25753-04-001		
6610-00-070-8067	Rate of Climb Indicator (ROC, VSI, VVI)	843-67-1A	128SCAV108-1	
6610-00-070-8461	Rate of Climb Indicator (ROC, VSI, VVI)	843-67-2A	MIL-I-18804	
6610-00-168-0564	Rate of Climb Indicator (ROC, VSI, VVI)	843-67-1		
6610-00-179-5175	Rate of Climb Indicator (ROC, VSI, VVI)	843-67-2	MS28075-2B	
6610-00-183-0664	Rate of Climb Indicator (ROC, VSI, VVI)	843-67-3		
6610-00-454-0284	Rate of Climb Indicator (ROC, VSI, VVI)	1684-6BDA6-1		
6610-00-462-3879	Rate of Climb Indicator (ROC, VSI, VVI)	1685-6BDA6-1		
6610-00-473-5046	Rate of Climb Indicator (ROC, VSI, VVI)	MS28075-1B	35160-0124	
6610-00-522-7669	Position Indicator, Flap	3571820-4001	673152-101	
6610-00-633-4260	Horizontal Situation Indicator (HSI)	522-1393-003	Type AFA24J1	
6610-00-663-8798	Attitude Indicator	14602-1JD1	MIL-I-5133B	
6610-00-663-8800	Attitude Indicator	14602-1JF1	MIL-I-5133B	
6610-00-799-8315	Horizontal Situation Indicator (HSI)	522-2411-003	331D2	
6610-00-799-8315	Horizontal Situation Indicator (HSI)	629318-5		
6610-00-816-3621	Rate of Climb Indicator (ROC, VSI, VVI)	1655-6AEB6-1	MIL-I-18804	
6610-00-816-3621	Rate of Climb Indicator (ROC, VSI, VVI)	1655-6AEB6-1SD		
6610-01-012-0517	Position Indicator, Pitch Trim	3571812-5005	673148-109	
6610-01-012-0517	Position Indicator, Pitch Trim	ALU-11/A		
6620-00-020-6096	Temperature Indicator	BH183M13		
6620-00-075-5861	Torquemeter Indicator	B709-1	123SCAV345-3	
6620-00-738-5996	Temperature Indicator	BH183R16	622273-103	
6620-00-895-0976	Tachometer, Electric Indicator	8DJ82CAS1	282206	
6680-00-294-6289	Liquid Quantity Indicator	219-004-002	694965-101	
6680-00-294-6291	Liquid Quantity Indicator	215-002-002	694966-101	
6680-00-554-4336	Liquid Quantity Indicator	219-004-003	694965-103	
6685-01-047-8368	Temperatue Indicator, Thermocouple	670785-105	BH183R58A	
6615-00-900-6853	DISPLACEMENT GYROSCOPE	42281	MIL-G-25597, MD1	
6610-00-887-9308	SINGLE POSITION TRANSMITTER ASSEMBLY	4564-5A6-1	1267519-1	
6610-00-976-3338	ACCELEROMETER, COUNTING	261-6		SUPERCEDED BY 6610-00-841-6509.
6220-01-004-1643	Assembly)	41775A-121	41775A-121-7079-24	
6610-00-167-9801	Altitude Encoding Altitude Computer	31103-A24	CPU66/A24	

6610-00-585-1355	Accelerometer, Counting Indicator	2119-001-2		
6610-00-585-5929	Accelerometer, Counting Indicator	2119-001	Type MA1	
6610-00-684-1666	Accelerometer, Counting Indicator	2119-001-3	MIL-A-25719	
6610-00-686-1554	Altimeter Indicator, Counter Pointer Pressure	B003124101	MC2	
6610-00-719-5228	Position Indicator	SRL92B		
6610-01-285-4673	Altitude Encoding Altitude Computer	31103-A24A	CPU66/A24A	
6620-00-345-1474	Flow Indicator	9807-27		
6620-00-659-0950	Landing & Taxi Light Assembly	G-4710A-11		
6620-00-716-3305	Assembly)	41775A-21	41775A-21-7079-24	
6620-00-903-5053	Altimeter Indicator, Pressure	18-1488	HE432-5003-0001	
6620-00-903-5054	Altimeter Indicator, Pressure	18-1486	HE432-5005-0001	
6620-00-908-7497	Flow Indicator, Fuel	25622-B41A-40-A3	3571210-7001	
6620-00-908-7497	Flow Indicator, Fuel	HE432-5002-0001		
6680-00-623-6015	Liquid Quantity Indicator	118-999-38	B118C38	
6680-00-623-6016	Liquid Quantity Repeater Indicator, Fuel	B353-6	353-999-6	
6680-00-943-5179	Liquid Quantity Repeater Indicator, Oxygen	1649602-2	29119-6H-A1	
6680-00-966-6340	Liquid Quantity Indicator	B118-325	HE432-9001-001	
6680-00-966-6423	Liquid Quantity Indicator	B353-32	HE432-9002-001	
6685-00-134-1851	Temperatue Indicator, Thermocouple	9A1091	ST4325014HE0002	
6685-00-455-9941	Temperatue Indicator, Thermocouple	502B29	ST4325014HE0001	
6130-01-124-9886	Power Supply, Strobe Light	60-1750-3		
6610-01-152-2821	Attitude Indicator	501-1197-08		
	Temperature & Pressure Indicator, Oil	9019	104-384059-5	
	Temperature Indicator, Turbine Inlet (TIT)	521673	104-384009-3	
	Pressure Indicator, Oil	0213-004	104-384059-3	
	Position Indicator, Flap	104-384008-1	19-20-187	
	Volt Ammeter Indicator	104-384020-1	9021-1004	
	Pressure Indicator, Oil	104-384059-3	9036-1019	
	Altimeter Indicator, Encoding (FC)	104-384064-1	570-36920-001	
	Strobe Assembly	30-1331-3		
	Strobe Assembly	30-1467-1		
	Strobe Assembly	30-1467-5		
	Pressure Indicator, Differential	50-380046-3	3000J.21	
	Power Supply, Strobe Light	60-1750-1		
6605-00-775-3253	Horizontal Situation Indicator (HSI)	1783960	AQU-2/A	
5945-00-475-9117	Strobe Light Power Supply	60-2693-1	1680EG035-7	
6130-01-069-2087	Power Supply, Strobe Light	60-2694-1	1680EG035-5	
6615-00-992-3850	ACCELEROMETER, ELECTRICAL	611480-1		Alternate 6605-00-923-2965.
5841-00-930-2659	RECIEVER-TRANSMITTER (RT680BAPN153B)	183302-000	RT680AAPN153V	Replaced with 5841-00-087-6089.
6230-01-105-6580	SEARCHLIGHT	45-0189-7	70553-01007-103	Alternate for 6230-01-206-1585.
6605-00-323-7649	AMPLIFIER	107062-01		
1560-00-717-5525	ADVISORY PANEL ASSEMBLY	F638-1A		
1660-00-077-1834	SELECTOR	588530-1		
1660-00-019-1515	TEMPERATURE CONTROL BOX	1378-1C		
5310-00-172-6136	ICS RELAY BOX	173AS800		
5340-00-209-9328	ATTITUDE INDICATOR	118769-01-02		
5381-00-069-3555	INTERCOM SET CONTROL	655355-4		
5821-01-130-3162	RADIO RECIEVER	622-1239-012		
5826-00-505-3091	Course Deviation Indicator	ID-249/ARN	11200	
5826-00-887-1942	Converter, Navigation Set ARN-87	101217-1	616277-7	
5826-00-887-1942	Converter, Navigation Set ARN-87	CV-2059/ARN-87(V)	2086412-1	
5826-00-887-1942	Converter, Navigation Set ARN-87	NVA-22A	101-000-217	
5826-01-120-5991	RADIO RECIEVER	622-1239-001		
5826-01-135-1943	Bearing Distance Heading Indicator (BDHI)	276200-001	ID-663D/U	
5826-01-136-7853	Radio, VHF Communications Control	313N-4B		
5826-01-136-7886	RADIO RECIEVER	622-1239-027		REPLACED WITH 5826-01-486-8271.
5826-01-147-3098	BEARING DISTANCE HEADING INDICATOR	276200		
5826-01-188-4128	Bearing Distance Heading Indicator (BDHI)	ID-663D/U	276200-001	
5826-01-202-7420	RADIO RECIEVER	622-1239-011		
5826-01-216-7985	RADIO RECIEVER	622-1239-001	123SCAV6010-1	
5826-01-482-4504	RADIO RECIEVER	622-1239-201		
5826-01-482-4505	RADIO RECIEVER	622-1239-211		
5826-01-486-8271	RADIO RECIEVER	622-1239-007		
5826-01-487-7615	RADIO RECIEVER	622-1239-227	R-2217/ARN-140	
5831-00-029-9124	SPEAKER MUTING CONTROL	173AS380		
5831-00-029-9173	INTERCOM SET CONTROL	173AS368		
5831-00-032-3342	INTERCOM SET CONTROL	173AS390		
5831-00-038-0024	SECURE RADIO/ICS DISCONNECT PANEL	173AS300		
5831-00-095-6431	INTERCONNECTING CONTROL BOX	173AS353		
5831-00-118-9016	Intercommunications Control Box AIC-22	C-4163AV/AIC-22 (V)	616296-121	
5831-00-118-9016	Intercommunications Control Box AIC-22	449202-9	C-4163AV/AIC-22 (V)	
5831-00-135-0827	INTERCOM SET CONTROL	655355-1		
5831-00-168-8789	Amplifier, Jack Box	AM4964/AIC-22 (V)	178D700-3	

5831-00-168-8789	Amplifier, Jack Box	671496-103	AM4964/AIC-22 (V)	
5831-00-675-8786	Intercommunication Junction Box	J-1013/AIC14		
5831-00-802-8945	Intercommunications Control Box AIC-22	C-4165/AIC-22 (V)	449203-1	
5831-00-803-6365	Intercommunications Control Box AIC-22	C-4163V/AIC-22 (V)	449202-5	
5831-01-190-7774	Intercommunications Control Box AIC-22	C-4164A/AIC-22 (V)	616294-101	
5831-01-190-7774	Intercommunications Control Box AIC-22	449204-2	974831-101	
5835-00-703-3601	Recorder Control	121AV12032-1		
5841-00-087-6089	RECIEVER-TRANSMITTER (RT680BAPN153B)	G7092-001-01		
5841-00-753-7657	HEIGHT INDICATOR (AN/APN-141)	1073640-1		Alternate NSN 5841-00-937-3083.
5841-00-761-4084	HEIGHT INDICATOR (AN/APN-141)	1272-2700	ID1304APN141V	
5841-00-900-8005	HEIGHT INDICATOR (AN/APN-141)	3158965	33807C1B1A2, ID1304APB141V	
5841-00-937-3083	HEIGHT INDICATOR (AN/APN-141)	1270-0001		
5841-00-937-3084	HEIGHT INDICATOR (AN/APN-141)	1271-0001	ID1015AAPN141V	
5895-00-657-0345	AZIMUTH-RANGE INDICATOR	T8605-11N		
5895-00-930-2657	ANTENNA (AS 1350APN153)	AS1350APN153V	183304-000	
5895-00-990-5215	ANTENNA	AS1350APN153V	G6777-001-01	
5965-00-858-4852	Loudspeaker	AM3365/AIC-22 (V)	178D100-1	
5965-00-858-4852	Loudspeaker	616292-1		
5965-01-101-1852	Loudspeaker	587-1	674155-101	
5985-00-930-2655	ANTENNA (AS 1349APN153)	18330-001-000	AS1349APN153V	
5990-00-821-0102	ATTITUDE INDICATOR	ST12M		
5990-00-821-0103	ATTITUDE INDICATOR	ST12N		
5996-00-167-4225	ELECTRONIC CONTROL AMPLIFIER	352-020-001		
5996-00-617-0426	ELECTRONIC CONTROL AMPLIFIER	522-1394-003		
5999-01-487-6103	RADIO RECIEVER	622-1239-212		
6110-00-323-7662	MOTOR CONTROL	107064-01		
6130-00-179-4692	POWER SUPPLY (PP-2058A/ULA-2)	SCDL451302B		
6130-00-928-9532	AIRCRAFT STATIC POWER INVERTER	HE464-5002-0001		
6130-01-083-1520	Power Supply, Strobe Light	60-2667-1		
6130-01-217-5880	REMOTE POWER SUPPLY	915-38106-001	38106-001	
6210-00-032-2559	SECURE STATUS PANEL	173AS890		
6210-00-676-7874	LIGHT INDICATOR PANEL	965-9015-008	S6155-61551-018	
6210-00-690-9724	ADVISORY PANEL ASSEMBLY	F638-1E		
6220-00-945-2342	ADVISORY PANEL ASSEMBLY	F638-1K	S6155-61551-015	
6220-01-104-5604	ADVISORY PANEL ASSEMBLY	F638-1		
6230-01-206-1585	SEARCHLIGHT	45-0189-9		
6230-01-350-4661	SEARCHLIGHT	45-0241-5		
6340-00-672-5700	Stall Warning Shaker	35A509	C35102-3	
6340-00-719-4503	Lift Transducer	C-35207		
6340-00-955-5899	FIRE DETECTING CONTROL UNIT	892165-0350-01		
6605-00-087-0628	DIRECTIONAL GYROSCOPE	126091-02-01		
6605-00-591-2330	INDUCTION COMPASS INDICATOR	18-1138	MS28094-1	
6605-00-604-5662	DIRECTIONAL GYROSCOPE	126091-01		REPLACED WITH 6615-00-087-0628.
6605-01-119-0832	Horizontal Situation Indicator (HSI)	AQU13/A/A	126460	
6610-00-012-4624	Turn and Slip Indicator	RC30V		
6610-00-023-6073	Attitude Indicator	148700-03-01		
6610-00-038-3423	Air Speed Indicator	724DU4-016		
6610-00-086-2853	ANGLE OF ATTACK INDICATOR	30-1020		
6610-00-116-4020	FLIGHT DIRECTOR INDICATOR	105010		
6610-00-134-1322	Attitude Indicator	E25-8034-1	ID-1329A	
6610-00-134-1458	AIRSPPEED INDICATOR	MS28089-2		
6610-00-179-9033	AIRSPPEED INDICATOR	1701DX8-04		
6610-00-180-5544	Attitude Indicator	DSA335-1	ID-1329A	
6610-00-190-1414	Rate of Climb Indicator (ROC, VSI, VVI)	1636-6A-B1		
6610-00-244-9142	AIRSPPEED INDICATOR	AN5862-1		
6610-00-388-0048	ATTITUDE INDICATOR	14602-1JA1		
6610-00-388-0049	ATTITUDE INDICATOR	14602-1JB1		
6610-00-390-8437	AIRSPPEED INDICATOR	739CU4-034		
6610-00-390-8441	ATTITUDE INDICATOR	14602-1JC1		
6610-00-405-0513	Turn and Slip Indicator	91-380019-1		
6610-00-405-6461	Altimeter Indicator, Encoder	C41542-10-003	AAU-21/A	
6610-00-451-1155	Turn and Slip Indicator	20B380-1	91-380018-1	
6610-00-462-3879	INDICATOR,VERTICAL VELOCITY	1685-6BDA6-1		
6610-00-469-8148	ATTITUDE INDICATOR	149250-01-02	209-070-277-1	
6610-00-473-5046	RATE OF CLIMB INDICATOR	MS28075-1B	35160-0124	
6610-00-477-6691	INDICATOR,VERTICAL VELOCITY	1675-6BDA6-1		
6610-00-514-5611	AIRSPPEED INDICATOR	724DU4-012		
6610-00-514-5612	AIRSPPEED INDICATOR	724CU4-012		
6610-00-515-5824	ATTITUDE INDICATOR	686531		
6610-00-526-4798	AIRSPPEED INDICATOR	724CU5-03M		
6610-00-526-7944	AIRSPPEED INDICATOR	724DX4-012		
6610-00-526-7960	AIRSPPEED INDICATOR	AN5862W2	GA4065, S-65-KS	
6610-00-526-7967	Rate of Climb Indicator (ROC, VSI, VVI)	716BU4-052		

6610-00-527-8356	ANGLE OF ATTACK INDICATOR	SLZ9028D		
6610-00-530-0028	Rate of Climb Indicator (ROC, VSI, VVI)	RC-60		
6610-00-530-1363	Rate of Climb Indicator (ROC, VSI, VVI)	D0716304052		
6610-00-531-4160	AIRSPED INDICATOR	1701CX8-04		
6610-00-531-4296	AIRSPED INDICATOR	724CU8-011		
6610-00-557-3030	Attitude Indicator	116595-01	4005A	
6610-00-561-9375	DUAL POSITION TRANSMITTER	4562-5A7-1	1267003-1	
6610-00-585-4132	ANGLE OF ATTACK INDICATOR	MS28067-1	932579-101, 937579-103	
6610-00-585-4931	AIRSPED INDICATOR	1701DX4-04		
6610-00-598-2751	AIRSPED/ MACH INDICATOR	1451-51C-A51-1		
6610-00-601-2313	Attitude Indicator	ID-811/AJB-3A	471764-1	
6610-00-620-7888	ANGLE OF ATTACK INDICATOR	SLZ9028E		REPLACED WITH 6610-01-004-5856.
6610-00-622-6227	Position Indicator	12050		
6610-00-652-2403	ANGLE OF ATTACK INDICATOR	27400C1A1A2		REPLACED WITH 6610-00-086-2853.
6610-00-663-4138	Rate of Climb Indicator (ROC, VSI, VVI)	1636-6H-B1		
6610-00-663-4148	Rate of Climb Indicator (ROC, VSI, VVI)	1648-6U-A6-1		
6610-00-663-4156	Rate of Climb Indicator (ROC, VSI, VVI)	716-BU8-036		
6610-00-663-8723	Air Speed Indicator	1214CX8-05		
6610-00-671-3437	Accelerometer, Counting Indicator	7200	TRU-3/A	
6610-00-703-0781	Position Indicator, Wheel/Flap	8DJ26AA51		
6610-00-716-5240	Altimeter Monitor, C-8836	121PE15512-3		
6610-00-719-6001	DC SELSYN POSITION INDICATOR	8TJ39BAL2		
6610-00-734-6053	ACCELEROMETER, COUNTING	24523T6		REPLACED WITH 6610-00-841-6509.
6610-00-738-6203	Attitude Indicator	134799-01-02	ID-811AJB3A	
6610-00-759-7170	TRUE AIR SPEED COMPUTER	510414-3-2	CPK-281A24G-9	
6610-00-790-2735	ANGLE OF ATTACK TRANSDUCER	19910		
6610-00-794-7267	ANGLE OF ATTACK TRANSDUCER	815572		
6610-00-805-8011	Accelerometer, Counting Indicator	TRU-3/A	MIL-T-27330	
6610-00-809-0978	Attitude Indicator	138094-01-01	4005N	
6610-00-811-6070	ANGLE OF ATTACK INDICATOR	SLZ9028G		REPLACED WITH 6610-01-004-5856.
6610-00-841-8221	Attitude Indicator	ID-811AJB3A	471764-1	
6610-00-845-4674	Accelerometer, Counting Indicator	TRU-3/A	18-1151	
6610-00-854-9166	Attitude Indicator	ARU-14A	MM-4	
6610-00-864-9759	Rate of Climb Indicator (ROC, VSI, VVI)	SLZ9066		
6610-00-866-3234	Attitude Direction Indicator (ADI)	136601-01-03	ARU-14A	
6610-00-866-3234	Attitude Direction Indicator (ADI)	4005F	MM-4A	
6610-00-886-6515	TRUE AIR SPEED TRANSMITTER	A2495000005	A24950-00-005	
6610-00-887-9301	AIRSPED INDICATOR	A33971-10-005	622275-7	
6610-00-898-2112	Turn and Slip Indicator	1734-1BNA1-2		
6610-00-929-1614	PRESSURE INDICATOR	F0739310067	S-65-KS	
6610-00-933-8790	Attitude Indicator	DSA335-1	ID-1329A	
6610-00-937-0527	PRESSURE ALTIMETER	C003124101	MS28704-2	
6610-00-954-5068	Attitude Indicator	471764-1	ID811AJB3A	
6610-00-972-0869	Altimeter Ind, Counter-Drum Pointer/Servoed Ctl	10180A		
6610-00-990-9825	Attitude Indicator	138094-01-02		
6610-00-991-0770	AIRSPED INDICATOR	538088-0-2		
6610-00-994-7839	AIRSPED INDICATOR	AW2812AH08	S40KAW	
6610-01-004-5856	ANGLE OF ATTACK INDICATOR	SLZ9696		
6610-01-023-6073	Attitude Indicator	148700-03-01		
6610-01-067-0228	AIRSPED INDICATOR	1701DX10-04	MIL-I-5392-6	
6610-01-079-8804	ANGLE OF ATTACK TRANSDUCER	815572-10		
6610-01-083-1439	Accelerometer, Counting Indicator	2094-7		
6610-01-125-0726	Rate of Climb Indicator (ROC, VSI, VVI)	RC30V10		
6610-01-192-2467	Attitude Indicator	501-1239-51	ARU-55A	
6610-01-192-2467	Attitude Indicator	75J808000-101		
6610-01-192-6478	ANGLE OF ATTACK INDICATOR	SLZ9517-2	75J878001-101, ID-2276/A	
6610-01-253-9180	POSITION INDICATOR	265-039-001	A55A9016-7	
6610-01-255-1433	Altitude Encoding Altitude Computer	31103-A25A	CPU66/A25A	
6610-01-263-1400	AIRSPED INDICATOR	532-38105-202		
6610-01-264-2663	Turn and Bank Standard AIRD	TS300-1A		
6610-01-286-2306	AIRSPED INDICATOR	2154-2	21285-1139	
6610-01-287-8559	ANGLE OF ATTACK INDICATOR	SLZ9517-8	75J878001-103	
6610-01-323-1076	Turn and Slip Indicator	50-380023-1		
6610-01-357-5955	POSITION INDICATOR	265-039-002	A55A9016-17	
6610-01-359-9809	Turn and Slip Indicator	101-500053-7	270-2424-010	
6615-00-087-0629	DISPLACEMENT GYROSCOPE	107063-01-02		
6615-00-098-5309	DISPLACEMENT GYROSCOPE	107063-01		
6615-00-137-6038	RATE GYROSCOPE	501-1027-02		
6615-00-181-2334	DISPLACEMENT GYROSCOPE	44270		
6615-00-182-7698	VERTICAL GYRO	15885-1C		
6615-00-531-6389	DIRECTIONAL GYROSCOPE	8KD3AC3	9893250G4	
6615-00-602-0806	DISPLACEMENT GYROSCOPE	119001-01		REPLACED WITH 6615-00-181-2334.
6615-00-659-5201	Altitude Control	PG10D1		

6615-00-663-8694	DIRECTIONAL GYROSCOPE	8KD3AC2	9893250G2	
6615-00-663-8699	DIRECTIONAL GYROSCOPE	8KD3AA2		REPLACED WITH 6615-00-531-6389.
6615-00-676-0855	Controller, Roll Stabilization	15753-1-A		
6615-00-676-2675	Compass Interconnection Box	DR45A1		
6615-00-717-5267	Force Link Actuator	RG79A2		
6615-00-717-6094	Common & Yaw Axis Amplifier	BG102D2		
6615-00-717-6157	Control Panel	CG80A2		
6615-00-787-3770	Wheel Control (Pilot)	CG79C1		
6615-00-787-3771	Wheel Control (CoPilot)	CG79D1		
6615-00-794-7239	Air Speed Compensator	PG7007B24		
6615-00-796-7343	Actuator, Servo	MG70A13		
6615-00-903-4414	DISPLACEMENT GYROSCOPE	42520	MD1	
6615-00-933-6037	DISPLACEMENT GYROSCOPE	124623-01-14		
6620-00-030-1867	Tachometer, Electric Indicator	751CU-4-02	AN5530-3A-12	
6620-00-244-8020	Tachometer, Electric Indicator	751CU-4-02	AN5530-3A-12	
6620-00-257-1133	Tachometer Indicator, Propeller	8DJ81AAK1		
6620-00-351-9949	LOW LEVEL FUEL CONTROL ASSEMBLY	352-011-001	7822701-1	
6620-00-551-1270	RATE OF FLOW INDICATOR	8DJ72GAB1	8DJ72GAB	
6620-00-551-2631	RATE OF FLOW INDICATOR	8DJ72GAB1		
6620-00-630-8812	PRESSURE RATIO TRANSDUCER	24094-0-3		
6620-00-662-4211	Tachometer, Electric Indicator	751CU-4-02	AN5530-3A-12	
6620-00-716-0001	Pressure Indicator, Oil	SR94F		
6620-00-760-4332	Tachometer Indicator, Triple	3571371-6001		
6620-01-285-4685	Suction Gauge Indicator	09007-0168	101-384133-1	
6620-01-328-2971	Altimeter Indicator, Pressure	206-075-675-001	9016-3018	
6620-01-359-9363	Tachometer Indicator, Propeller	50-380035-1	5610-01	
6620-01-513-4140	Temperature Indicator, Engine Oil	169P910-5LBW5		
6625-00-179-4693	PULSE ANALYZER INDICATOR	IP471CULA2V		
6625-00-179-4693	PULSE ANALYZER INDICATOR	SCDL4511300C		
6625-01-513-5012	Load Meter	169P909-1LBW5		
6655-00-458-1363	MAGNETIC DISTORTION RECORDER	58206-301		
6680-00-597-8859	Flow Indicator, Fuel	25104-B16C-3A1		
6680-00-684-5927	Liquid Quantity Indicator, Fuel	JG130A63		
6680-00-871-0591	ELECTRONIC CONTROL AMPLIFIER	B478-2		
6680-01-491-8863	Liquid Quantity Indicator, Fuel	169P910-22LBW5		
6685-00-027-5619	TEMPERATURE INDICATOR	588-10-1		
6685-00-557-7006	Temperature Indicator	152BL2C	MIL-I-25852	
6685-00-585-4133	Temperature Indicator	77B203B	AN5792-2	
6685-00-871-0594	INDICATOR	34800-C1A-1-A2		
6685-00-887-1971	PRESSURE TRANSMITTER	ST109C	626151-1	
6685-01-097-9188	Temperature Indicator, Cabin	50-380026-1	562-806	
	Temperature Indicator, Turbine Inlet (TIT)	521692	104-384009-1	
	Pressure Indicator, Oil	522082	101-384122-5	
	Pressure Indicator, Oil	0213-005	104-384059-5	
	Rate of Climb Indicator (ROC, VSI, VVI)	100-384053-3		
	Position Indicator, Flap	100-384053-7		
	Pressure Indicator, Oil	100-384058-7		
	Tachometer Indicator, Propeller	100-384079-3	3941231-9003	
	Pressure Indicator, Oil	100-384082-5	522315	
	Indicator	100-384088-5	55035-1138	
	Rate of Climb Indicator (ROC, VSI, VVI)	100-384091-1	35060-1152	
	Pressure Indicator, Pneumatic	100-384092-3	78020-1114	
	Position Indicator, Flap	100-384093-1	8001-3003	
	Temperature & Pressure Indicator, Oil	101-320255-5	521594	
	Indicator	101-380030-1	509-003-901	
	Indicator	101-380030-3	509-003-903	
	Torque Meter Indicator	101-384008-3	SR2AM	
	Voltage Indicator, AC	101-384078-1	570-518	
	Voltage Indicator, DC	101-384106-1	562-898/MD106-5	
	Voltage Indicator, DC	101-384106-3	562-898/MD106-3	
	Voltage Indicator, DC	101-384106-5	MD106-5	
	Voltage Indicator, DC	101-384106-7	563-110/MD106-7	
	Voltage Indicator, DC	101-384106-9	563-124/MD106-9	
	Voltage Indicator, AC	101-384107-3	570-531	
	Altimeter Indicator, Encoder	101-420-01223		
	Tachometer Indicator, Propeller	104-384010-3	30B369-3	
	Temperature & Pressure Indicator, Oil	104-384014-3	9019-1015	
	Temperature & Pressure Indicator, Oil	104-384014-5	9019-1016	
	Temperature & Pressure Indicator, Oil	104-384014-9	9019-1014	
	Torque Meter Indicator	104-384017-3	SR-C2AQ	
	Torque Meter Indicator	104-384017-5	SR-C2AS	
	Position Indicator, Flap	104-384066-3	559-3	
	Accelerometer	104-384168-1		

	Accelerometer	104-384168-3		
	Rate of Climb Indicator (ROC, VSI, VVI)	30030-1137	100-384075-1	
	Tail Strobe	30-1125-1		
	Voltage Indicator, AC	570-524	100-384095-1	
	Turn and Slip Indicator	6930N1L		
	Rate of Climb Indicator (ROC, VSI, VVI)	7200C57	104-384019-1	
	Position Indicator, Flap	8001-3003	100-384093-1	
	Marker Beacon Receiver	R-666C/ARN-32		
	Turn and Slip Indicator	100-500053-7	270-2424-010	
	ITT Indicator	104-384009-3	521673	
	Torquemeter Indicator	104-384012-3	SR-C2AQ	
	Accelerometer	104-384016-1	2117-812	
	Turn and Slip Indicator	104-384018-1	5550-7070	
	Volt Ammeter Indicator	104-384020-1	MD-67-1	
	Oil Pressure Indicator	104-384059-5	0213-005	
	Altimeter, Encoding	104-384064-1	570-36920-001	
	Altimeter, Barometric	104-384065-1	570-36930-001	
	Altimeter, Barometric	325010-0901		
	Altimeter, Barometric	325011-0801		
	Differential Pressure Indicator	50-380046-3	3000J.21	
	Slave, Accessory	522-2644-011		
	RMI	622-0555-010		
	Transponder	622-1270-001		
	RMI	622-3046-001		
	DME 40A	622-3177-001		
	Gyroscope	792-6694-001		
	Radar Altimeter Indicator	622-1204-003	339H4	
	Volt Ammeter Indicator	90-384023-1	621915	
	Altimeter, Barometric	C44202-10-002	B0020	
	Altimeter, Encoding	C45152-10-002	B0020	
	INDICATOR	B0020-14110	B0020	
	INDICATOR	B0020-14201		
	INDICATOR	B0020-14211	B0020	
	INDICATOR	B0020-14211F	B0063	
	INDICATOR	B0020-81105	B0063	
	ALTIMETER	B0063-81101	B0063	
	ALTIMETER	B0063-81103	B0063	
	ALTIMETER	B0063-81104	B0063	
	ALTIMETER	B0063-81106	B0063	
	ALTIMETER	B0063-81107	B0063	
	ALTIMETER	B0063-81108	B0063	
	ALTIMETER	B0063-81109	B0063	
	ALTIMETER	B0063-81110	B0063	
	ALTIMETER	B0063-81114	B0063	
	ALTIMETER	B0063-82103	B0090	
	ALTIMETER	B0063-82109	B0090	
	ALTIMETER	B0090-81101	B0090	
	ALTIMETER	B0090-81102	B0090	
	ALTIMETER	B0090-81104	B0090	
	ALTIMETER	B0090-81105	B0090	
	ALTIMETER	B0090-81106	B0090	
	ALTIMETER	B0090-81107	B0090	
	ALTIMETER	B0090-81108	B0090	
	ALTIMETER	B0090-81109	B0090	
	ALTIMETER	B0090-81110	B0090	
	ALTIMETER	B0090-81111	B0090	
	ALTIMETER	B0090-81112	B0090	
	ALTIMETER	B0090-81113	B0090	
	ALTIMETER	B0090-81114	B0090	
	ALTIMETER	B0090-81115	B0090	
	ALTIMETER	B0090-81116	B0090	
	ALTIMETER	B0090-81128	B0090	
	ALTIMETER	B0090-82113	B0200	
	ALTIMETER	B0090-82114	B0200	
	INDICATOR	B0200-81104	B0200	
	INDICATOR	B0200-81105	B0200	
	INDICATOR	B0200-81108	B0200	
	INDICATOR	B0200-81110	B0200	
	INDICATOR	B0200-81111	B0200	
	INDICATAOR	B0200-81127	B0200	
	INDICATAOR	B0200-81137	B0243	
	INDICATOR	B0200-81908	B0243	
	INDICATOR	B0243-71101	B0243	

	INDICATOR	B0243-81102	B0243	
	INDICATOR	B0243-81103	B0243	
	INDICATOR	B0243-81104	B0243	
	INDICATOR	B0243-81106	B0243	
	INDICATOR	B0243-81107	B0243	
	INDICATOR	B0243-81108	B0243	
	INDICATOR	B0243-81110	B0243	
	INDICATOR	B0243-81113	B0243	
	INDICATOR	B0243-81120	B0243	
	INDICATOR	B0243-81122	B0243	
	INDICATOR	B0243-81124	B0243	
	INDICATOR	B0243-81126	B0243	
	INDICATOR	B0243-81128	B0243	
	INDICATOR	B0243-81129	B0243	
	INDICATOR	B0243-81131	B0243	
	INDICATOR	B0243-81132	B0243	
	INDICATOR	B0243-81135	B0243	
	INDICATOR	B0243-81145	B0243	
	INDICATOR	B0243-81911	B0243	
	INDICATOR	B0243-81921	B0243	
	INDICATOR	B0243-81923	B0243	
	INDICATOR	B0243-81925	B0243	
	INDICATOR	B0243-81937	B0243	
	INDICATOR	B0243-81953	B0243	
	INDICATOR	B0243-82104	B0243	
	INDICATOR	B0243-82105	B0243	
	INDICATOR	B0243-82128	B0245	
	INDICATOR	B0243-84112	B0245	
	INDICATOR	B0245-81101	B0245	
	INDICATOR	B0245-81104	B0245	
	INDICATOR	B0245-81107	B0245	
	INDICATOR	B0245-81108	B0245	
	INDICATOR	B0245-81110	B0247	
	INDICATOR	B0245-82107	B0247	
	INDICATOR	B0247-81101	B0247	
	INDICATOR	B0247-81105	B0247	
	INDICATOR	B0247-81106	B0248	
	INDICATOR	B0247-81107	B0248	
	INDICATOR	B0248-81105	B0248	
	INDICATOR	B0248-81901	B0600	
	INDICATOR	B0248-81903	B0650	
	ALTIMETER	B0600-71104	B0650	
	ALERT	B0650-71107-1	B0650	
	ALERT	B0650-71107-2	B0650	
	ALERT	B0650-71109-1	B0651	
	ALERT	B0650-71110	B0651	
	ALERT	B0651-71102	B0651	
	ALERT	B0651-71104	B0651	
	ALERT	B0651-71106	B0651	
	ALERT	B0651-71107	B0652	
	ALERT	B0651-72104	B0652	
	ALERT	B0652-71104	B0690	
	ALERT	B0652-71113	B0690	
	ISOLATION PANEL	B0690-10004	B0690	
	ISOLATION PANEL	B0690-10005	B0690	
	ISOLATION PANEL	B0690-10006	B0690	
	ISOLATION PANEL	B0690-10007	B0690	
	ISOLATION PANEL	B0690-10009	B0690	
	ISOLATION PANEL	B0690-10010	B0690	
	ISOLATION PANEL	B0690-10011	B0690	
	ISOLATION PANEL	B0690-10012	B0700	
	ISOLATION PANEL	B0690-10013		
	O.L.S.	B0700-10001	B0704	
	O.L.S.	B0700-10002	B0704	
	O.L.S.	B0704-10004	B0704	
	O.L.S.	B0704-10006	B0704	
	O.L.S.	B0704-10008	B0704	
	O.L.S.	B0704-10009	B0704	
	O.L.S.	B0704-10010	B0704	
	O.L.S.	B0704-10011	B0704	
	O.L.S.	B0704-10012	B0704	
	O.L.S.	B0704-10016	B0704	
	O.L.S.	B0704-10018	B0704	

	O.L.S.	B0704-10019	B0704	
	O.L.S.	B0704-10020	B0704	
	O.L.S.	B0704-10023	B0704	
	O.L.S.	B0704-10024	B0704	
	O.L.S.	B0704-10025	B0704	
	O.L.S.	B0704-10026	B0704	
	O.L.S.	B0704-10029	B0704	
	O.L.S.	B0704-10032	B0704	
	O.L.S.	B0704-10033	B0704	
	O.L.S.	B0704-10034	B0704	
	O.L.S.	B0704-10036	B0704	
	O.L.S.	B0704-10037	B0704	
	O.L.S.	B0704-10038	B0704	
	O.L.S.	B0704-10042	320316-01-01	
	O.L.S.	B0704-10043	314087-01-01	
	O.L.S.	B0704-10046	B0704	
	O.L.S.	B0704-10048	B0704	
	O.L.S.	B0704-10049	B0705	
	O.L.S.	B0704-10051	B0706	
	O.L.S.	B0705-10001	B0706	
	O.L.S.	B0706-10001	B0706	
	O.L.S.	B0706-10002	B0706	
	O.L.S.	B0706-10003	B0706	
	O.L.S.	B0706-10004	B0706	
	O.L.S.	B0706-10005	B0706	
	O.L.S.	B0706-10007	B0707	
	O.L.S.	B0706-10011	B0707	
	O.L.S.	B0707-10001	B0707	
	O.L.S.	B0707-10003	B0707	
	O.L.S.	B0707-10006	B0707	
	O.L.S.	B0707-10007	B0707	
	O.L.S.	B0707-10008	B0707	
	O.L.S.	B0707-10010	B0707	
	O.L.S.	B0707-10011	B0707	
	O.L.S.	B0707-10012	B0707	
	O.L.S.	B0707-10013	B0707	
	O.L.S.	B0707-10018	B0707	
	O.L.S.	B0707-10020	B0709	
	O.L.S.	B0707-10030	B0709	
	O.L.S.	B0709-10001	B0709	
	O.L.S.	B0709-10002	B0711	
	O.L.S.	B0709-10004	B0711	
	O.L.S.	B0711-24101	B1200	
	O.L.S.	B0711-24102	B1800	
	ALT.XDUCER	B1200-90001	B1800	
	ALTIMETER	B1800-81103	B1811	
	ALTIMETER	B1800-81108	C0245	
	ALTIMETER	B1811-90001	C0245	
	INDICATOR	C0245-81101	DG120	
	INDICATOR	C0245-81910	DG120	
	ADAPTER	DG120A1	DG120	
	ADAPTER	DG120A10	DG120	
	ADAPTER	DG120A11	DG120	
	ADAPTER	DG120A119	DG120	
	ADAPTER	DG120A120	DG120	
	ADAPTER	DG120A13	DG120	
	ADAPTER	DG120A138	DG120	
	ADAPTER	DG120A14	DG120	
	ADAPTER	DG120A15	DG120	
	ADAPTER	DG120A16	DG120	
	ADAPTER	DG120A17	DG120	
	ADAPTER	DG120A2	DG120	
	ADAPTER	DG120A3	DG120	
	ADAPTER	DG120A4	DG120	
	ADAPTER	DG120A5	DG120	
	ADAPTER	DG120A6	DG120	
	ADAPTER	DG120A7	DG120	
	ADAPTER	DG120A701	DG120	
	ADAPTER	DG120A702	DG120	
	ADAPTER	DG120A8	DG120	
	ADAPTER	DG120A800	DG120	
	ADAPTER	DG120A801	HG180	
	ADAPTER	DG120A9	HG180	

	ADC	HG180A1	HG180	
	ADC	HG180B1	HG180	
	ADC	HG180B2	HG180	
	ADC	HG180B3	HG180	
	ADC	HG180R11	HG180	
	ADC	HG180R12	HG180	
	ADC	HG180R19	HG180	
	ADC	HG180R20	HG180	
	ADC	HG180R22	HG180	
	ADC	HG180R23	HG180	
	ADC	HG180R24	HG180	
	ADC	HG180R25	HG180	
	ADC	HG180R26	HG180	
	ADC	HG180R5	HG180	
	ADC	HG180R8	HG180	
	ADC	HG180U1	HG180	
	ADC	HG180U201	HG180	
	ADC	HG180U202	HG180	
	ADC	HG180U203	HG180	
	ADC	HG180U204	HG180	
	ADC	HG180U205	HG180	
	ADC	HG180U206	HG180	
	ADC	HG180U207	HG180	
	ADC	HG180U208	HG180	
	ADC	HG180U209	HG180	
	ADC	HG180U210	HG180	
	ADC	HG180U211	HG180	
	ADC	HG180U212	HG180	
	ADC	HG180U213	HG180	
	ADC	HG180U215	HG180	
	ADC	HG180U216	HG180	
	ADC	HG180U217	HG180	
	ADC	HG180U218	HG180	
	ADC	HG180U219	HG180	
	ADC	HG180U220	HG180	
	ADC	HG180U221	HG180	
	ADC	HG180U222	HG180	
	ADC	HG180U223	HG180	
	ADC	HG180U224	HG180	
	ADC	HG180U226	HG180	
	ADC	HG180U227	HG180	
	ADC	HG180U228	HG180	
	ADC	HG180U229	HG180	
	ADC	HG180U230	HG180	
	ADC	HG180U231	HG180	
	ADC	HG180U232	HG180	
	ADC	HG180U233	HG180	
	ADC	HG180U234	HG180	
	ADC	HG180U235	HG180	
	ADC	HG180U236	HG180	
	ADC	HG180U237	HG180	
	ADC	HG180U238	HG180	
	ADC	HG180U239	HG180	
	ADC	HG180U241	HG180	
	ADC	HG180U243	HG180	
	ADC	HG180U244	HG180	
	ADC	HG180U245	HG180	
	ADC	HG180U246	HG180	
	ADC	HG180U247	HG180	
	ADC	HG180U248	HG180	
	ADC	HG180U249	HG180	
	ADC	HG180U250	HG180	
	ADC	HG180U251	HG180	
	ADC	HG180U251	HG180	
	ADC	HG180U252	HG180	
	ADC	HG180U253	HG180	
	ADC	HG180U255	HG180	
	ADC	HG180U256	HG180	
	ADC	HG180U258	HG180	
	ADC	HG180U259	HG180	
	ADC	HG180U260	HG180	
	ADC	HG180U261	HG180	
	ADC	HG180U262	HG180	

	ADC	HG180U263	HG180	
	ADC	HG180U264	HG180	
	ADC	HG180U265	HG180	
	ADC	HG180U266	HG180	
	ADC	HG180U267	HG180	
	ADC	HG180U268	HG180	
	ADC	HG180U269	HG180	
	ADC	HG180U270	HG180	
	ADC	HG180U271	HG180	
	ADC	HG180U272	HG180	
	ADC	HG180U273	HG180	
	ADC	HG180U274	HG180	
	ADC	HG180U275	HG180	
	ADC	HG180U276	HG180	
	ADC	HG180U277	HG180	
	ADC	HG180U277DLH	HG180	
	ADC	HG180U277DLH1	HG180	
	ADC	HG180U278	HG180	
	ADC	HG180U279	HG180	
	ADC	HG180U280	HG180	
	ADC	HG180U281	HG180	
	ADC	HG180U282	HG180	
	ADC	HG180U283	HG180	
	ADC	HG180U284	HG180	
	ADC	HG180U285	HG180	
	ADC	HG180U286	HG180	
	ADC	HG180U288	HG180	
	ADC	HG180U289	HG180	
	ADC	HG180U290	HG180	
	ADC	HG180U291	HG180	
	ADC	HG180U293	HG180	
	ADC	HG180U294	HG180	
	ADC	HG180U295	HG180	
	ADC	HG180U296	HG180	
	ADC	HG180U299	HG180	
	ADC	HG180U301	HG180	
	ADC	HG180U303	HG180	
	ADC	HG180U304	HG180	
	ADC	HG180U307	HG180	
	ADC	HG180U309	HG180	
	ADC	HG180U312	HG180	
	ADC	HG180U313	HG180	
	ADC	HG180U314	HG180	
	ADC	HG180U315	HG180	
	ADC	HG180U316	HG180	
	ADC	HG180U317	HG180	
	ADC	HG180U318	HG180	
	ADC	HG180U319	HG180	
	ADC	HG180U320	HG180	
	ADC	HG180U323	HG180	
	ADC	HG180U326	HG180	
	ADC	HG180U344	HG180	
	ADC	HG180U345	HG180	
	ADC	HG180U346	HG180	
	ADC	HG180U347	HG180	
	ADC	HG180U400	HG180	
	ADC	HG180U401	HG180	
	ADC	HG180U403	HG180	
	ADC	HG180U404	HG180	
	ADC	HG180U410	HG180	
	ADC	HG180U51	HG180	
	ADC	HG180U52	HG180	
	ADC	HG180U53	HG180	
	ADC	HG180U54	HG180	
	ADC	HG180U55	HG180	
	ADC	HG180U56	HG180	
	ADC	HG180U57	HG180	
	ADC	HG180U58	HG180	
	ADC	HG180U59	HG180	
	ADC	HG180U60	HG180	
	ADC	HG180U61	HG180	
	ADC	HG180U62	HG180	
	ADC	HG180U63	HG180	

	ADC	HG180U64	HG180	
	ADC	HG180U65	HG180	
	ADC	HG180U66	HG180	
	ADC	HG180U67	HG180	
	ADC	HG180U68	HG180	
	ADC	HG180U69	HG180	
	ADC	HG180U70	HG180	
	ADC	HG180U701	HG180	
	ADC	HG180U702	HG180	
	ADC	HG180U703	HG180	
	ADC	HG180U704	HG180	
	ADC	HG180U705	HG180	
	ADC	HG180U706	HG180	
	ADC	HG180U707	HG180	
	ADC	HG180U708	HG180	
	ADC	HG180U709	HG180	
	ADC	HG180U71	HG180	
	ADC	HG180U710	HG180	
	ADC	HG180U711	HG180	
	ADC	HG180U712	HG180	
	ADC	HG180U713	HG180	
	ADC	HG180U714	HG180	
	ADC	HG180U715	HG180	
	ADC	HG180U716	HG180	
	ADC	HG180U717	HG180	
	ADC	HG180U718	HG180	
	ADC	HG180U719	HG180	
	ADC	HG180U720	HG180	
	ADC	HG180U721	HG180	
	ADC	HG180U722	HG180	
	ADC	HG180U723	HG180	
	ADC	HG180U724	HG180	
	ADC	HG180U725	HG180	
	ADC	HG180U726	HG180	
	ADC	HG180U727	HG180	
	ADC	HG180U729	HG180	
	ADC	HG180U73	HG180	
	ADC	HG180U732	HG180	
	ADC	HG180U733	HG180	
	ADC	HG180U737	HG180	
	ADC	HG180U738	HG180	
	ADC	HG180U739	HG180	
	ADC	HG180U74	HG180	
	ADC	HG180U742	HG180	
	ADC	HG180U746	HG180	
	ADC	HG180U747	HG180	
	ADC	HG180U749	HG180	
	ADC	HG180U75	HG180	
	ADC	HG180U750	HG180	
	ADC	HG180U751	HG180	
	ADC	HG180U754	HG180	
	ADC	HG180U756	HG180	
	ADC	HG180U757	HG180	
	ADC	HG180U759	HG180	
	ADC	HG180U76	HG180	
	ADC	HG180U77	HG180	
	ADC	HG180U79	HG180	
	ADC	HG180U80	HG180	
	ADC	HG180U800	HG180	
	ADC	HG180U801	HG180	
	ADC	HG180U802	HG180	
	ADC	HG180U803	HG180	
	ADC	HG180U804	HG180	
	ADC	HG180U805	HG180	
	ADC	HG180U806	HG180	
	ADC	HG180U807	HG180	
	ADC	HG180U808	HG180	
	ADC	HG180U809	HG180	
	ADC	HG180U81	HG180	
	ADC	HG180U810	HG180	
	ADC	HG180U811	HG180	
	ADC	HG180U812	HG180	
	ADC	HG180U813	HG180	

	ADC	HG180U814	HG180	
	ADC	HG180U815	HG180	
	ADC	HG180U816	HG180	
	ADC	HG180U817	HG180	
	ADC	HG180U82	HG180	
	ADC	HG180U83	HG180	
	ADC	HG180U84	HG180	
	ADC	HG180U85	HG180	
	ADC	HG180U850	HG180	
	ADC	HG180U851	HG180	
	ADC	HG180U86	HG180	
	ADC	HG180U87	HG180	
	ADC	HG180U88	HG180	
	ADC	HG180U89	HG180	
	ADC	HG180U90	HG180	
	ADC	HG180U91	HG180	
	ADC	HG180U92	HG180	
	ADC	HG180U93	HG180	
	ADC	HG180U94	HG180	
	ADC	HG180U94LM1	HG180	
	ADC	HG180U95	HG180	
	ADC	HG180U96	HG180	
	ADC	HG180U97	HG180	
	ADC	HG180U98	HG180	
	ADC	HG180U99	HG180	
	ADC	HG180UABB4321	HG180	
	ADC	HG180V1	HG180	
	ADC	HG180V2	HG180	
	ADC	HG180V3	HG180	
	ADC	HG180V5	KS200	
	ADC	HG180V8	KS200	
	ADC	KS200-101	KS200	
	ADC	KS200-102	KS200	
	ADC	KS200-103	KS200	
	ADC	KS200-104	KS200	
	ADC	KS200-105	KS200	
	ADC	KS200-107	KS200	
	ADC	KS200-108	KS200	
	ADC	KS200-109	KS200	
	ADC	KS200-110	KS200	
	ADC	KS200-111	KS200	
	ADC	KS200-112	KS200	
	ADC	KS200-113	KS200	
	ADC	KS200-114	KS200	
	ADC	KS200-115	KS200	
	ADC	KS200-116	KS200	
	ADC	KS200-117	KS200	
	ADC	KS200-118	KS200	
	ADC	KS200-119	KS200	
	ADC	KS200-120	KS200	
	ADC	KS200-121	KS200	
	ADC	KS200-123	KS200	
	ADC	KS200-124	KS200	
	ADC	KS200-125	KS200	
	ADC	KS200-126	KS200	
	ADC	KS200-127	KS200	
	ADC	KS200-128	KS200	
	ADC	KS200-129	KS200	
	ADC	KS200-130	KS200	
	ADC	KS200-131	KS200	
	ADC	KS200-132	KS200	
	ADC	KS200-133	KS200	
	ADC	KS200-134	KS200	
	ADC	KS200-135	KS200	
	ADC	KS200-136	KS200	
	ADC	KS200-137	KS200	
	ADC	KS200-138	KS200	
	ADC	KS200-139	KS200	
	ADC	KS200-140	KS200	
	ADC	KS200-151	KS200	
	ADC	KS200-152	KS200	
	ADC	KS200-153	KS200	
	ADC	KS200-154	KS200	

	ADC	KS200-155	KS200	
	ADC	KS200-156	KS200	
	ADC	KS200-157	KS200	
	ADC	KS200-158	KS200	
	ADC	KS200-199	KS200	
	ADC	KS200-200	KS200	
	ADC	KS200-201	KS200	
	ADC	KS200-301	KS200	
	ADC	KS200-302	KS200	
	ADC	KS200-303	LG14	
	ADC	KS200-99	LG14	
	XDUCER	LG14A14	LG14	
	XDUCER	LG14C11	LG14	
	XDUCER	LG14C12	LG14	
	XDUCER	LG14C13	LG14	
	XDUCER	LG14C14	LG14	
	XMITTER	LG14C20	LG14	
	XDUCER	LG14C7	LG45	
	XDUCER	LG14C8	LG45	
	XDUCER	LG45A3	LG80	
	XDUCER	LG45A4	LG80	
	XMITTER	LG80A11	LG80	
	XMITTER	LG80A12	LG80	
	XMITTER	LG80A18	LG80	
	XMITTER	LG80A2	LG80	
	XMITTER	LG80A3	LG80	
	XMITTER	LG80A4	LG80	
	XMITTER	LG80A6	LG80	
	XMITTER	LG80A7	LG80	
	XMITTER	LG80A9	PG12	
	XMITTER	LG80E1	PG12	
	XDUCER	PG12A-1	PG12	
	XDUCER	PG12A12	PG12	
	XDUCER	PG12A14	PG12	
	XDUCER	PG12A7	PG12	
	XDUCER	PG12A9	PG60	
	XDUCER	PG12B14	PG60	
	XMITTER	PG60A10	PG60	
	XMITTER	PG60A18	PG60	
	XMITTER	PG60A6	PG60	
	XMITTER	PG60A8	B0707	
	XMITTER	PG60A9	B0707	
	SENSOR	B0707-10005	B0707	
	SENSOR	B0707-10009	B0707	
	SENSOR	B0707-10016	B0707	
	SENSOR	B0707-10017	B0707	
	SENSOR	B0707-10019	B0707	
	SENSOR	B0707-10021	B0707	
	SENSOR	B0707-10025	B0707	
	SENSOR	B0707-10026	B0707	
	SENSOR	B0707-10027		
	SENSOR	B0707-10028		