

Operating the A/V system in Central Plant

Selecting the video source:

In the cabinet on the bottom shelf above the VCR is a StarView video switch box for selecting the component you wish to view.

Push the corresponding button below the label to select. CPU2 is connected to the VGA wall plate on the west wall. Connect the VGA extension cable to the wall and to the visiting notebook computer. CPU1 is the computer in the cabinet.

Selecting the audio source:

Power on the Sony receiver on the top shelf, left side and select the component you listen to by pressing the silver buttons on the front. The inputs are labeled on the receiver display.

Video1 is the VCR, Video3 is the Front input. AUX is the computer in the cabinet.

Keyboard/Mouse

The wireless keyboard and mouse should "just work" as long as they are in range of the Logitech receiver. If they do not operate, press the connect button on the Logitech receiver in the cabinet in front of the computer and then the connect buttons on the underside of the keyboard and mouse.

Remotes:

The silver Sony remote can control all the functions of the DVD, CD, and VCR. It also controls the receiver and volume. Press the corresponding button for the component that you want to control, then issue the command. Play, pause and stop are in the middle of the remote. Volume is bottom right.

If you have quiet content and have to turn up the sound level, please remember to turn it back down when you're done. The next person's content might not be at the same levels as yours.

The grey Interlink remote is used to control the projector. Only the power and blank buttons need to be used. Press the power button to turn on the projector. It should chime to indicate it's powering on. The Blank button projects a black screen instead of the time consuming task of powering off and back on the projector if you need to hide the display.

To power off the projector, you need to press power and then power again when prompted. This prevents accidental power off. It also means you have to pay attention and press power quickly enough afterwards to make it register. It will chime when it is powering off successfully.

WHEN YOU ARE FINISHED WITH THE PROJECTOR, PLEASE TURN IT OFF.

Lamps are expensive and do not last forever. Never just pull the power cord from a projector.