

Allegro® X Layout Editor Design Parameters Reference

**Product Version 23.1
September 2023**

© 2023 Cadence Design Systems, Inc. All rights reserved.

Portions © Apache Software Foundation, Sun Microsystems, Free Software Foundation, Inc., Regents of the University of California, Massachusetts Institute of Technology, University of Florida. Used by permission. Printed in the United States of America.

Cadence Design Systems, Inc. (Cadence), 2655 Seely Ave., San Jose, CA 95134, USA.

Allegro X PCB Editor contains technology licensed from, and copyrighted by: Apache Software Foundation, 1901 Munsey Drive Forest Hill, MD 21050, USA © 2000-2005, Apache Software Foundation. Sun Microsystems, 4150 Network Circle, Santa Clara, CA 95054 USA © 1994-2007, Sun Microsystems, Inc. Free Software Foundation, 59 Temple Place, Suite 330, Boston, MA 02111-1307 USA © 1989, 1991, Free Software Foundation, Inc. Regents of the University of California, Sun Microsystems, Inc., Scriptics Corporation, © 2001, Regents of the University of California. Daniel Stenberg, © 1996 - 2006, Daniel Stenberg. UMFPACK © 2005, Timothy A. Davis, University of Florida, (davis@cise.ulf.edu). Ken Martin, Will Schroeder, Bill Lorensen © 1993-2002, Ken Martin, Will Schroeder, Bill Lorensen. Massachusetts Institute of Technology, 77 Massachusetts Avenue, Cambridge, Massachusetts, USA © 2003, the Board of Trustees of Massachusetts Institute of Technology. All rights reserved.

Trademarks: Trademarks and service marks of Cadence Design Systems, Inc. contained in this document are attributed to Cadence with the appropriate symbol. For queries regarding Cadence's trademarks, contact the corporate legal department at the address shown above or call 800.862.4522.

Open SystemC, Open SystemC Initiative, OSCI, SystemC, and SystemC Initiative are trademarks or registered trademarks of Open SystemC Initiative, Inc. in the United States and other countries and are used with permission. All other trademarks are the property of their respective holders.

Restricted Permission: This publication is protected by copyright law and international treaties and contains trade secrets and proprietary information owned by Cadence. Unauthorized reproduction or distribution of this publication, or any portion of it, may result in civil and criminal penalties. Except as specified in this permission statement, this publication may not be copied, reproduced, modified, published, uploaded, posted, transmitted, or distributed in any way, without prior written permission from Cadence. Unless otherwise agreed to by Cadence in writing, this statement grants Cadence customers permission to print one (1) hard copy of this publication subject to the following conditions:

1. The publication may be used only in accordance with a written agreement between Cadence and its customer.
2. The publication may not be modified in any way.
3. Any authorized copy of the publication or portion thereof must include all original copyright, trademark, and other proprietary notices and this permission statement.
4. The information contained in this document cannot be used in the development of like products or software, whether for internal or external use, and shall not be used for the benefit of any other party, whether or not for consideration.

Disclaimer: Information in this publication is subject to change without notice and does not represent a commitment on the part of Cadence. Except as may be explicitly set forth in such agreement, Cadence does not make, and expressly disclaims, any representations or warranties as to the completeness, accuracy or usefulness of the information contained in this document. Cadence does not warrant that use of such information will not infringe any third party rights, nor does Cadence assume any liability for damages or costs of any kind that may result from use of such information. Cadence is committed to using respectful language in our code and communications. We are also active in the removal and/or replacement of inappropriate language from existing content. This product documentation may however contain material that is no longer considered appropriate but still reflects long-standing industry terminology. Such content will be addressed at a time when the related software can be updated without end-user impact.

Restricted Rights: Use, duplication, or disclosure by the Government is subject to restrictions as set forth in FAR52.227-14 and DFAR252.227-7013 et seq. or its successor.

Contents

Introduction 5

Display Parameters..... 7

Design Parameters 11

Text Parameters 15

Shapes Parameters 17

Flow Planning Parameters 19

Route Parameters 25

Manufacturing Applications Parameters..... 35

Allegro X Layout Editor Design Parameters Reference

Introduction

This document lists PCB Editor drawing parameters that controls the display of the design. This user guide describes display controls for the following layout editors:

- Allegro PCB Designer
- Allegro Venture PCB Designer
- Allegro Enterprise PCB Designer (Symphony Team Design Option included in bundle)
- Allegro Physical Viewer Plus
- Allegro Package Designer+
- SiP Layout XL

Note: The information provided in this document is based on Cadence® Allegro® release 17.4-2019.

Allegro X Layout Editor Design Parameters Reference

Introduction

Display Parameters

Display

Connect point size Specifies the size of a connect point in user units. The default is 10. Connect point sizes should be set high enough to be easily seen in a drawing. The appropriate setting (for visibility) depends on the line width in the design.

DRC marker size Determines the size, in user-defined units, of the DRC markers that appear in a design. The default is 25.

Rat T (Virtual pin) size Allows the specification of the graphical size of Rat T.

Max rband count Specifies an upper limit on the number of lines drawn during editing sessions. This value should not have to be changed with modern graphic cards. The default is 500.

Ratsnest geometry Displays a pop-up menu that allows the specification of shape of the ratsnest lines. The default is Jogged.

Ratsnest points Displays a pop-up menu that allows the specification of the closest distance between existing etch or pads (Closest endpoint) or between two pins (Pin to pin). The default is Closest endpoint.

Note: This option does not change the scheduling of the net. It only changes the way the endpoints of ratsnest are shown in the display for ratsnest that is defined by net scheduling.

Display net names (OpenGL only)

Clines Displays net names on cline segments.

Shapes Displays net names on dynamic shapes.

Pins Displays net names on pins.

Allegro X Layout Editor Design Parameters Reference

Display Parameters

Enhanced display modes

<i>Plated holes</i>	Displays plated drill holes in the design. Unchecked by default, because plating hole visibility often is not required due to the volume of entities and supporting geometries such as etch layer pads.
<i>Backdrill holes</i>	Displays backdrill holes in the design. This option should be used only after the backdrill process is done.
<i>Non-plated holes</i>	Displays non-plated drill holes in the design. Non-plated hole visibility may be preferred during placement and routing because they have no pads associated with them on etch layers and are normally invisible. As a result, they may lack proper keepout areas for guidance. By default, this option is not selected.
<i>Padless holes</i>	Displays padless holes in a design due to visible pads all being NULL or suppressed as unused. When enabled padless holes will be displayed even if plated or non-plated hole display is not enabled. This setting can also be controlled from <i>Setup – Cross-section – Unused Pads Suppression</i> user interface.
<i>Connect points</i>	Enables visibility of connect points.
<i>Filled pads</i>	Controls onscreen design display and fills pads. Unchecked by default. Leaving pads unfilled can improve display performance.
<i>Connect line endcaps</i>	Controls onscreen design display and rounds line vertices to more closely approximate artwork.
<i>Thermal pads</i>	Displays thermal and anti pads rather than regular pads when there is a negative plane. Unchecked by default.
<i>Bus rats</i>	Displays the middle part of the ratsnest lines with the same BUS_NAME property so that they appear to be merged into a thick line. Unchecked by default.
<i>Waived DRCs</i>	Displays waived DRCs. Disabled by default.

Allegro X Layout Editor Design Parameters Reference

Display Parameters

<i>Drill labels</i>	<p>Displays via label on top of each blind/buried via, indicating the from-to subclasses spanned by the via. Subclass numbers are displayed, which are shorter than subclass name. Labels fit within the visible pad shape. A colon character indicates a single via, for example, 3:4. A dash character indicates a stack of connected vias spanning the entire subclass range, for example, 2-6. Labels are not displayed for thru-hole and single-layer pad-only vias.</p> <p>Displays backdrill labels for the backdrill holes with format <Start-Layer>--<Must-Cut-Layer>--<Must-Not-Cut-Layer>, for example, B1-3-4, B27-16-15, and B2-2-3.</p>
<i>Design origin</i>	Displays a crosshair at the drawing origin.
<i>Diffpair driver pins</i>	Displays a figure on top of each visible differential pair driver pin. the pin use code of OUT is required for the figure to be displayed. Figures will not be displayed if the product does not support differential pairs.
<i>Use secondary STEP models in 3D Canvas</i>	Displays secondary STEP models in the 3D Canvas.
Grids	
<i>Grids on</i>	Displays the grid. Checked by default.
<i>Setup grids</i>	Opens Define grid dialog box.

Allegro X Layout Editor Design Parameters Reference

Display Parameters

Design Parameters

Size

User units Identifies the units of measure for the active design. Options are Mils, Inch, Microns, Millimeter, or Centimeter.

Note that changing user units during the design process can introduce errors into the database. The editor automatically sets the database accuracy based on the unit of measurement selected. Database accuracy can be reset for additional decimal places, but not less than the default.

Warning: Gerber (Artwork) export is not supported with microns and accuracy of 3 decimals or higher.

Size Specifies the size of an active design through a pop-up menu. Options are A, B, C, D, and Other. The available drawing sizes if the User units are Mils or Inches are: A, B, C, D, or Other. The available drawing sizes if the User units are Millimeter or Centimeter are: A1, A2, A3, A4 or Other. If one of the available drawing sizes is chosen, the editor automatically displays the extents for the size chosen in the drawing extent section.

Accuracy Determines the number of decimal places for calculations in the active design. The choice of the number of decimal places is determined by the User Units fields.

Note that changing the user units during the design process can introduce errors into the database.

Warning: Gerber (Artwork) export is not supported with microns and accuracy of 3 decimals or higher.

Long name size Defines the maximum number of characters for names for the following strings: net name, padstack name, slot name, and function pin name. This value can only be increased. The minimum value is 32 and the maximum is 255. The default value is 255.

Allegro X Layout Editor Design Parameters Reference

Design Parameters

<i>Pad flash mode</i>	Shapes
Extents	Determined the location and the size of your drawing. If you specified <i>Other</i> in the size field, specify the X and Y coordinate extents of the drawing size in the Drawing Extents section. The Left X and Lower Y Fields represent the X,Y coordinates of the lower left corner of the drawing. The Width and Height fields represent the available drawing work space.
<ul style="list-style-type: none"> ■ Left X ■ Lower Y ■ Width ■ Height 	
Shrink Extents to Design Contents	Reduces design extent limited to a size so that all geometries of the design fit.
Move Origin	Changes the location of the drawing according to the values you enter in the X and Y boxes. The field is then reset to 0 after the origin is moved.
<ul style="list-style-type: none"> ■ X ■ Y 	
Symbol options	This field is enabled only in Symbol Editor.
<i>Type</i>	Package, Mechanical, Format, Shape, Flash
Line lock	
<i>Lock direction</i>	Displays a pop-up menu that specifies the direction of lines added to a drawing. The options are Off, 45 and 90. The default is Off.
<i>Lock mode</i>	Specifies the type of segments to use when adding lines or connect lines. The options are Line and Arc. The default is Line.
<i>Minimum radius</i>	Determines the minimum radius allowed for an arc. The default is 0.
<i>Fixed 45 Length</i>	Specifies the length, in user units, of 45-degree segments. By default, this is unchecked. If checked, the default is 25.
<i>Fixed radius</i>	Specifies the radius, in user units, of arcs. By default, this is unchecked. If checked, the default is 25.
<i>Tangent</i>	Specifies whether tangent lines are locked. If checked, arcs construct tangent to lines. By default, this is checked.
Symbol	
<i>Mirror</i>	Mirrors symbols added to a drawing. By default, this is not checked.

Allegro X Layout Editor Design Parameters Reference

Design Parameters

<i>Angle</i>	Specifies the default angle that is used to place symbols and text. An angle with up to three decimal places can be entered, or an available angle can be chosen from the pop-up menu. The default is 0.
<i>Default symbol height</i>	Determines the height for symbols that do not have associated PACKAGE_HEIGHT_MIN/<MAX property values.

Allegro X Layout Editor Design Parameters Reference

Design Parameters

Text Parameters

Size

<i>Justification</i>	Indicates the anchor point within text added to the layout. The anchor location determines how the text appears in the text block. The default is Left.
<i>Parameter block</i>	Defines the size and spacing of the text added to the design. Using the <code>define text</code> command, up to 64 text blocks can be defined. The default is 1.
<i>Parameter name</i>	
<i>Text marker size</i>	Determines the size, in user units, of the displayed text markers. These markers indicate locations for text that will be entered later. The default is 50.
<i>Setup text sizes</i>	Opens Text Setup dialog box.

Allegro X Layout Editor Design Parameters Reference

Text Parameters

Shapes Parameters

Dynamic Shape

Dynamic shapes allow real-time shape updating during interactive etch editing. Shape parameters are structured into a global, shape instance, and object level hierarchy

Edit global dynamic shape parameter

Opens Global Dynamic Shape Parameters dialog box

Edit layer dynamic shape parameter

Opens Dynamic Shape Layers Parameter dialog box

Static Shapes

Static shapes can be used for critical handcrafted etch that should not be modified automatically

Edit static shape parameter

Opens Static Shape Parameters dialog box

Split plane

A split plane is an embedded plane with two or more copper areas associated with different nets. Split plane parameters control the fill style of shapes on the plane

Edit split plane parameters

Opens Split Plane Params dialog box

Allegro X Layout Editor Design Parameters Reference

Shapes Parameters

Flow Planning Parameters

General

Flow line relative width Specifies a display scale for flow line width. The value must be in the range of 1 to 300 inclusive and represents a percentage of the width of the physical bundle as determined by the number of rat members including the line width and spacing requirements of their nets. The display scale applied to all bundles in the design and does not affect the display of random logic.

Flow via relative size Specifies a display scale for flow via size (diameter). The value must be in the range of 1 to 300 inclusive and represents a percentage of the size determined by twice the widest unscaled flow line width. The display scale applies to all bundles in the design and does not affect the display of random logic.

Router plan

- *Auto plan visibility* Specifies the route planner's ability to make visibility changes to bundles and random logic during a planning phase. Off
- *Random logic plan visibility* indicates that you wish to control router plan visibility manually. On indicates that route plan visibility is automatically turned on when the plan is modified by the route engine.

Copy flow when split bundle Controls whether the "Split Bundle" command will automatically invoke copy flow. Otherwise, you must manually choose "copy Flow" from the pop-up menu if you want to copy the flow from the source bundle.

Default Bundle Properties

Bundle naming

Allegro X Layout Editor Design Parameters Reference

Flow Planning Parameters

<i>Bundle name prefix</i>	Specifies a prefix for naming bundles. The string entered is type checked using the same character set allowed by Allegro for net names.
<i>Prompt for name</i>	Specifies whether manual bundle creation commands (bundle create, bundle split, etc) prompt you for a bundle name. When enabled (checked) these commands prompt for a bundle name. This control does not apply to automatic bundling.
<i>Display controls</i>	
<i>Bundle</i>	Sets the initial visibility of a new bundle at the time of its creation. Existing bundles in the design are not affected. This setting also affects the visibility of flow line, flow vias, and rake lines associated with a new bundle.
<i>Expanded rakes</i>	Controls whether new bundles are created with expanded rakes enabled. Existing bundles in the design are not affected.
<i>Plan</i>	Sets the initial visibility of the route plan lines associated with a bundle at the time of its creation. Existing route plan lines are not affected by this control except for those associated with rats added to a new bundle. The visibility of those plan lines change to match this setting.
<i>Ratsnest</i>	Sets the initial visibility of the ratsnest lines associated with a bundle at the time of its creation. Existing ratsnest lines are not affected except for rats added to a new bundle. Their visibility changes to match this setting.
Auto Bundle	
<i>Minimum rat count</i>	Specifies the minimum number of rats required before a bundle can be created.
<i>Pin proximity</i>	Specifies the maximum center-to-center distance between pins before a rat can become a member of a bundle.
<i>Members must go to the same component at</i>	<ul style="list-style-type: none">■ One end: Specifies that rats must have at least one end on the same component before they can join a bundle.■ Both ends: Specifies that rats must have both ends share a component before they can join a bundle.
<i>Members must be in the same Bus</i>	Specifies that rats must be on nets that have the same Bus property on them before they can join a bundle.

Plan Invocation

Allegro X Layout Editor Design Parameters Reference

Flow Planning Parameters

Termination control

*Physical and
Spacing errors*

Unroutes

Specifies that the planner stops at the end of the current pass and terminate the route run when a rat fails to complete a connection.

Routing Controls

Etch shapes

Controls whether GRE pays attention to etch shapes when routing. When set to “Router thru”, GRE will route over etch shapes as if they are not there. When set to “Route around”, GRE will route around etch shapes.

Elongation control

*Allow in constraint
areas*

Enables (Yes), or disables (No) the ability of the planner to locate tuning patterns within constraint areas.

Allegro X Layout Editor Design Parameters Reference

Flow Planning Parameters

<i>Tuning pattern</i>	Choose to select Accordion or Trombone tuning patterns.	
	Accordion	
	Gap	Specifies the gap between adjacent wraps of regular elongation patterns. Previously used values that are entered are retained in the pull-down menu.
	Min amplitude	Specifies the minimum amplitude value allowed for any wrap of a regular elongation pattern created by the planner. Any wrap with an amplitude below this value is eliminated from the pattern.
	Max amplitude	Specifies the maximum amplitude value allowed for any wrap of a regular elongation pattern created by the planner. Any wrap with an amplitude above this value is eliminated from the pattern.
	Corner type	Specifies a corner type for bends in the elongation pattern created by the planner.
	Miter size	Specifies a minimum corner length base in the elongation pattern created by the planner.
	Trombone	
	Gap	Specifies the gap between adjacent wraps of regular elongation patterns. Previously used values that are entered are retained in the pull-down menu.
	Min amplitude	Specifies the minimum amplitude value allowed for any wrap of a regular elongation pattern created by the planner. Any wrap with an amplitude below this value is eliminated from the pattern.
	Max levels	Specifies the maximum amplitude value allowed for any wrap of a regular elongation pattern created by the planner. Any wrap with an amplitude above this value is eliminated from the pattern.
	Corner type	Specifies a corner type for bends in the elongation pattern created by the planner.

Allegro X Layout Editor Design Parameters Reference

Flow Planning Parameters

	Miter size	Specifies a minimum corner length base in the elongation pattern created by the planner.
<i>Bundle controls</i>		
<i>Space within bundle</i>	Default	Specifies that the route engine is not constrained with regard to packing or unpacking.
	Min DRC	Specifies that the route engine be given an additional spacing goal to meet. A Min value must be entered. Min is the minimum amount of additional space the router attempts to meet if it can. It must be less than the Max value (when Max is specified). The value can be any real number including 0. Max is the maximum amount of additional space the router attempts to meet if it can. If it meets this value, it stops trying to spread out the affected bundles. The value can be any real number including 0 and it must be equal to or greater than the Min value.
<i>Max transitions</i>		
	Unlimited	Specifies that the number of via transitions allowed per bundle member is unlimited. The transition count does not include pin escapes. The value does not apply to fanout vias.
	Limit to	Specifies a maximum number of via transitions that are allowed per bundle member. The value does not apply to fanout vias.

Allegro X Layout Editor Design Parameters Reference

Flow Planning Parameters

Layer matching

Off	Specifies that bundle members be allowed to route on different layers
Route on the same layer	Specifies that bundle members must route together on the same layer. If a layer transition does occur, then all members must transition together. This choice is disabled if there is no single layer on which all bundle members can be routed.

Layer Controls

Choose the direction of random logic on layers. Options are: Horizontal, Vertical, and No preference

Route Parameters

Add Connect

<i>Layer mode</i>	Specifies the use-model for adding vias with the Add Via (or double-click) button. Set to Alternate Subclass for the original-style use-model, where the user selects an alternate subclass and via padstacks in the Options. Set to Working Layers, which removes the alternate subclass and via padstack Options, but through the use of an add-via popup-gui, the user can choose a padstack or choose the via-stop layer, where the Via List determines (by priority ordering) which via or via-stack is added, with stacking/staggering rules determined by the constraints.
<i>Line lock</i>	Line lock allows default settings for routing as straight line segments, or arc segments, with either 45, 90, or 0 degrees for angle control. Arc linelock disables bubble mode, and an angle of off implies that any-angle routing is allowed.
<i>Route offset</i>	Route Offset provides an enable button and angle value for routing at angles that are offset from multiples of 45 degrees (0, 45, 90, 135...). When enabled, routes are snapped to an angle that is +/- the offset angle from the 45 degree incremental angle. This feature is only applicable when Line Lock is Line/45.
<i>Miter</i>	This field sets the corner size/radius. It accepts both integers and values relative to the current line width in the format <n>x.
<i>Line width</i>	Defines the width of the line in user units.

Allegro X Layout Editor Design Parameters Reference

Route Parameters

Style

<i>Bubble</i>	<p>Off: The wire path entered is unchanged. All clearance violations are flagged with error markers.</p> <p>Hug only: New clines hug all objects spaced at minimum design rule.</p> <p>Hug Preferred: New cline moves itself around etch objects where possible to avoid spacing DRCs; if not possible, then shoving of etch objects is attempted.</p> <p>Shove Preferred: New clines moves other etch objects where possible to avoid spacing DRCs; if not possible, then hugging of other etch objects is attempted.</p>
<i>Shove vias</i>	<p>Off: Vias are not shoved.</p> <p>Minimal: Vias are shoved in hug-preferred manner. Vias are not moved unless there is no way to draw a cline around them.</p> <p>Full: Vias are shoved in a shove-preferred manner. Any new or edited etch always shoves vias out of the way.</p>
<i>Gridless</i>	<p>Specifies that the etch/conductor can go off the routing grid. This allows connections to be added at maximum density while accommodating varying design rules and line widths. The DRC minimum space separate objects. When Bubble is disabled, this field controls the removal of a small segment at the end of the new route.</p>
<i>Clip dangling lines</i>	<p>Application for shove-preferred mode. When enabled, new etch routes through dangling clines, removing the unconnected section.</p>
<i>Smooth</i>	<p>Off disables smoothing. Minimal executes dynamic smoothing to minimize unnecessary segments. Full executes more extensive smoothing to remove any unnecessary jogs. Super extensively removes any unnecessary vertices from all shoved clines.</p> <p>Smooth option is applies when Bubble is enabled.</p>

Snap to connect point *Specifies whether the connection snaps to the connect point if it is close to a target element.*

Allegro X Layout Editor Design Parameters Reference

Route Parameters

<i>Replace etch</i>	Changes the path of an existing trace without extra delete and add steps. When a new loop is added into an existing trace, forces the older portion of the loop to be automatically deleted.
<i>Auto-blank other rats</i>	Enables automatic blanking of rats that are on nets not being routed. Those rats are blanked when you start routing a trace and are restored when you are done routing the trace.
<i>Optimize in channel</i>	Optimize by centering segments in a defined channel. Opens Channel options dialog box.
<i>Clearance view</i>	Enables polygons generations over obstacles on the active subclass. The obstacle size is determined by the spacing constraint between the trace and the obstacle for “Spacing” mode and the same spacing constraint plus half the width of the trace being routed for “Channel” mode. For “Channel” mode when adjacent polygons do not touch, routing in the channel is possible without creating a DRC.

Delay Tune

<i>Style</i>	<i>Geometry used to add delay to clines. Only one of Accordion, Trombone, and Sawtooth can be selected.</i>
<i>Centered</i>	Selecting centered option will center elongation around the chosen cline segment. The mouse position defines one half of the amplitude. If elongation is not centered, all elongation is on one side of the specified cline segment.
<i>Gap</i>	Values can be entered as integers to represent the gap in user units or <n>x space or <n>x width, where n is an integer that represents line width or line-to-line spacing respectively.
<i>Corners</i>	Values allowed are 90, 45 and FullArc. FullArc creates a single semi-circle connecting the ends of the parallel cline segments of the elongation etch.
<i>Miter size</i>	Values can be entered as integers to represent corner segment length.
<i>Allow DRCs</i>	Selecting this field will ignored design rules yet still report DRC errors when creating the elongation rectangle. In this mode, elongation is created regardless of any objects that cause a DRC. If this field is unselected, no physical DRCs are created and elongation rectangles which would result in a DRC are not allowed.

Allegro X Layout Editor Design Parameters Reference

Route Parameters

Edit Vertex

Style

<i>Bubble</i>	Enabling a hug or shove-preferred mode disallows arc linelock mode selection since bubble mode does not support arcs. Off flags all clearance violations with error markers. Hug Only will, where possible, force the routed cline to contour other etch objects to avoid spacing DRC errors and does not change other etch. Hug Preferred behaves as Hug Only does except will attempt to shove etch objects other than the routed cline to open routing paths if they cannot be successfully contoured. Shove Preferred will force the routed cline to push and shove other etch objects to avoid spacing DRC errors. If not possible, it attempts to hug other etch objects. This is true for vias if Shove via capability is enabled.
<i>Shove vias</i>	Off: Vias are not shoved. Minimal: Vias are shoved in a hug preferred manner. Any new or edited etch always shoves vias out of the way. Full: Vias are shoved in a Shove Preferred manner. Vias are not moved unless there is no way to draw a connect line around them.
<i>Clip dangling connect lines</i>	Application for shove-preferred mode. When enabled, new etch routes through dangling clines, removing the unconnected section.
<i>Smooth</i>	Off: No smoothing errors. Minimal: Executes dynamic smoothing to minimize unnecessary segments. Full: Executes more extensive smoothing to remove any unnecessary jogs. Full could, in some cases, hamper the ability to successfully edit a vertex.

Allow DRCs

Specifies that design rules can be violated in order to make a connection. If Bubble is disabled, the vertex is set at a point (between the last good point and the current point) that does not cause a DRC.

Allegro X Layout Editor Design Parameters Reference

Route Parameters

Allow gridless Specifies whether the connect line or via has to adhere to the routing grid. When this option is enabled, the tool can slide connections at maximum density while accommodating varying design rules and line widths. In addition, bubbled vertices are snapped to grid. This affects connections only if Allow DRCs is disabled.

Snap to 45 If enabled, the vertex location is snapped to create 45 degree routing when the cursor is near a point which would provide such routing. Snapping also will happen to line up segments which are almost colinear.

Slide

Min corner size Min Corner Size determines the size that Slide will use when sliding segments into corners. Applies to existing mitered segments only, and not to segments that meet at approximate 90-degree angles. Does not apply to jogs or end segments. Note that the Min Corner Size is used as a length in both X and Y directions; so the length of the mitered segment is actually square-root-of-2 times the Min Corner Size.

Min arc radius Min Arc Radius determines the smallest allowable radius when sliding arcs or sliding segments that are connected to arcs.

Vertex action Vertex Action has 3 choices (Line Corner, Arc Corner, Move), which determines the action that will be taken when the user picks at a single vertex.

Line Corner: the vertex gets converted to a straight mitered segment (with its size honoring the Min Corner Size option).

Arc Corner: the vertex gets converted to an arc (honoring Min Arc Radius option).

Move: No conversion, but just slides the vertex dynamically.

Note that some vertices may not qualify for Line Corner or Arc Corner conversions, if Min Corner sizes cannot be honored, or if picking at an arc.

New Seg Angle Specifies the angle to be used when a line changes direction or moves around an obstacle.

Allegro X Layout Editor Design Parameters Reference

Route Parameters

Style

<i>Bubble</i>	Enabling a hug or shove-preferred mode disallows arc linelock mode selection since bubble mode does not support arcs. Off flags all clearance violations with error markers. Hug Only will, where possible, force the routed cline to contour other etch objects to avoid spacing DRC errors and does not change other etch. Hug Preferred behaves as Hug Only does except will attempt to shove etch objects other than the routed cline to open routing paths if they cannot be successfully contoured. Shove Preferred will force the routed cline to push and shove other etch objects to avoid spacing DRC errors. If not possible, it attempts to hug other etch objects. This is true for vias if Shove via capability is enabled.
<i>Shove vias</i>	Off: Vias are not shoved. Minimal: Vias are shoved in a hug preferred manner. Any new or edited etch always shoves vias out of the way. Full: Vias are shoved in a Shove Preferred manner. Vias are not moved unless there is no way to draw a connect line around them.
<i>Clip dangling connect lines</i>	Application for shove-preferred mode. When enabled, new etch routes through dangling clines, removing the unconnected section.
<i>Smooth</i>	Off: Choose to disable smoothing. Minimal: Executes dynamic smoothing to minimize unnecessary segments. Full: Executes more extensive smoothing to remove any unnecessary jogs. An additional segment on each end of the changed segments can be included. Super (Apd/Cdnsip products only): Extensively remove any unnecessary vertices from all shoved clines.

Enhanced Arc Support

Enhanced Arc Support will enable bubble to generate arcs when encountering arc or circular objects. Any etch changed as a result of the slide operation will generate arc corners.

Allegro X Layout Editor Design Parameters Reference

Route Parameters

<i>Allow DRCs</i>	Specifies that design rules may be violated to make the etch edit. The violations are flagged with DRC markers which must be resolved for a successful design. If allow DRCs is disabled and DRCs already exist on the trace or in a group of traces chosen for routing, or if the tool determines that DRCs are introduced to the design, the tool does not slide the connection.
<i>Gridless</i>	Specifies whether the connect line or via to slide has to adhere to the routing grid. When gridless routing is enabled, the tool can slide connections at maximum density while accommodating varying design rules and line widths. This affects connections only if bubble is active or if Allow DRCs is disabled.
<i>Auto join</i>	Auto Join determines the behavior when sliding past a parallel segment. With Auto Join Off, construction is done to connect the parallel segments. With Auto Join On, the slide segment algorithm will look past the parallel segment to intersect with segments farther down the cline. Minimum corner controls apply wherever Auto Join intersects down the cline. Holding down the control-key will temporarily cause Slide to use the inverse value of this option.
<i>Extend selection</i>	Extend Selection option allows the selection to include the segments and/or vias adjacent to the selection while maintaining the direction of movement that you would get with the original selection. Reduces use of window-pick and improves control by limiting direction of movement for single segment selection. Can be useful, for example, when sliding tuning bump corners, to slide 3 segments together with one pick. Holding down the shift-key will temporarily cause Slide to use the inverse value of this option. Has an associated drop-down menu field for setting the mode for extending the selection.
Auto-I. Phase Tune	Displays Auto-I Phase Tune Parameters
Auto-I. Delay Tune	Displays Auto-I Delay Tune Parameters
Timing Vision	

Allegro X Layout Editor Design Parameters Reference

Route Parameters

Display control

<i>Style</i>	Solid or Striped (candycane). Controls how clines of the Nets selected for the Timing Vision are displayed. This will override any current Custom Color until the Nets are removed from the Timing Vision.
<i>Colors</i>	Select the color to use for clines that are Shorter, Longer or Within (Satisfying) Timing Constraints. Additional choices can be made for those that are a small amount shorter or longer
<i>Pattern for critical signals</i>	Controls the pattern to display pinpairs that are the target of a relative propagation delay group. This has no effect if the Striped style is in use; or if Smart Calculation is selected

Timing Mode Controls type of data that should be used by Timing Vision to determine proper color coding

Minimum for Smart Goal calc (% of total length) Influences Smart Goals for pin-pin portions of a longer Pin Pair. If the direct pin-pin length as a percentage of the overall Pin Pair length is less than the specified amount, then the calculated goal for that pin-pin portion will not be longer than its current length. Use zero (0) to disable this logic

Match Group Selection Mode Allows selection of all member nets of a match group to the Timing group

XNet Selection Mode Allows selection of XNets to the Timing group

Auto-I. Convert Corner

Convert type Accepts `ARC`, `45` and `90`. If `ARC` is chosen, the *Preferred Radius Size* and *Min Radius Size* fields are enabled. If the `45` is chosen, the *Preferred Corner Size* and *Min Corner Size* fields are enable. If the `90` is chosen, all those fields are enable.

Allow in cns areas There are two choices, `YES` or `NO`, for Allow in cns areas field. The default value is `YES` which means the corner conversion is allowed in cns areas. The value of `NO` indicates the corner conversion is disallowed in the cns areas.

Preferred radius size When Corner type `Arc` is selected, Preferred Radius Size field is applicable, which specifies the Preferred or Maximum radius size.

Min radius size When Corner type `Arc` is selected, Min Radius Size field is applicable, which specifies the Minimum radius size.

Allegro X Layout Editor Design Parameters Reference

Route Parameters

<i>Preferred corner size</i>	When Corner type 45 is selected, <i>Preferred corner size</i> field is applicable, which specifies the Preferred or Maximum corner size.
<i>Min corner size</i>	When Corner type 45 is selected, <i>Min corner size</i> field is applicable, which specifies the Minimum corner size.
<i>Allow DRCs</i>	If Allow DRCs field is checked which indicates the design rule may be violated when we do the corner conversion.
Auto-I. Breakout	Displays Auto-I Breakout Parameters
Auto-I Trunk Route	Displays Auto-I Trunk Route Parameters
Auto-I. Auto Connect	Displays Auto-I Auto Connect Parameters
Gloss	
<i>Set Gloss parameters</i>	Opens Glossing controller dialog box
Create Fanout	
<i>Create Fanout Parameters</i>	Opens Create Fanout Parameters form

Allegro X Layout Editor Design Parameters Reference

Route Parameters

Manufacturing Applications Parameters

Testprep

Edit testprep parameters Opens Testprep Parameters dialog box

Thieving

Edit thieving parameters Opens Thieving Parameters dialog box

Silkscreen

Edit silkscreen parameters Opens Auto Silkscreen dialog box

Drafting

Edit drafting parameters Opens Dimensioning Parameters dialog box