

Change Setting Preference/ Coherence Level

A user planning to change the settings and modify the levels for the coherence ratio, user needs to select the menu option of Settings then change to a desired level for the HRV.

