

# My Vehicle

## How it Works

- Ensure there is functional WIFI within operating environment.
- Switch on Vehicle. Cleaning mechanism will switch on as well. The blue LED will start blinking and remains switched on once connected to WIFI
- Place a light source on the end of pipe/tunnel as vehicle destination
- Place vehicle in tunnel. It will autonomously tracks light source and travels towards destination.
- If manual control is desired, you can control remotely using this page.
- On this page, you can remotely control vehicle and servo motor movement with arrow keys.
- If location or direction tracking is needed, monitor real time luminous flux values in "My Vehicle Data" section.
- Retrieve Vehicle and switch off if no longer in need.
- A demonstration video can be found in the home page



# Control it Here

[Click here to override default vehicle behaviour](#)

## My Vehicle Data

Here are the last 20 data points from my vehicle.

[Refresh data](#)