

Auto-Calibration

An auto-calibration may be performed on an instrument.

To perform an auto-calibration on a selected instrument, perform the following steps.

1. Click on the expansion button for the requisite instrument.
2. Click on the ellipsis button for the instrument.
3. Under the requisite *AutoCalc(x)* heading, click on **Start** or **Stop** as required to start or stop the auto-calibration.