

Auto-Calibration

An auto-calibration may be performed on a probe. Performing an auto-calibration on a probe will perform all calibrations on all instruments connected to that probe.

To perform an auto-calibration on a selected probe, perform the following steps.

1. Click on the expansion button for the requisite probe.
2. Click on the ellipsis button for the probe.
3. Under the requisite *AutoCalc(x)* heading, click on **Start** or **Stop** as required to start or stop the auto-calibration.