

6.4 How are emissions and heat input calculated for an LME unit ?

To calculate the hourly SO₂, NO_x, and CO₂ mass emissions in lb (or tons), default emission rates, expressed in units of lb/mmBtu (or ton/mmBtu)³⁶, are used together with an estimate of the unit heat input (mmBtu).