

## ACCESS CONFIGURATION

Connecting to a *SpectraView® Prism Server* via the *SpectraView® Prism Client* has several requirements. The Client, when launched, attempts to communicate with the SQL database defined in the .SVIEW XML session file. Provided access is granted, the client tool will receive information necessary to communicate with the *Windows Services* running on the *SpectraView® Prism Server*. Once this information has been received, the Client tool will attempt a connection to the *SpectraView® Prism Server*. This initial handshake between the *SpectraView® Prism Client*, *Server*, and *SQL Database* will determine which role has been assigned and which views to update.