

## Probe Service

The probes listed on the data lists may be taken in and out of service for maintenance purposes.

To place a probe in or out of service, perform the following steps.

1. Click on the expansion button for the requisite probe.
2. Click on the ellipsis button for the probe.
3. Under the *Probe Service* heading, click on **Out of Service** or **In Service** as required to place the probe in or out of service.