

SPECTRAVIEW® PRISM MAIN WINDOW

The main window of the *SpectraView® Prism Client* application is the central point for all tasks performed within the application. Tasks are performed within the different areas of the application by selecting their corresponding navigation tabs. Navigation tabs will appear based on the privileges granted to the respective end-user.

The following items are always present in the main window, regardless of end-user or task being accomplished.

- *Alarm Bar* – located at the bottom of the main window
- *Daylog* – located at the bottom of the main window, just above the alarm bar
- *Navigation Tabs* – locate on the left side of the window
- *Settings* – located in the title bar of the main window