

## Raw Points Sub-Tab

The *Raw Points* sub-tab, as seen in **FIGURE ERROR! No text of specified style in document.-1**, presents the I/O for the source selected in the right-hand pane. This source presentation is divided into three parts; the *Wired Analogs*, represented by the *Analogs XX* section of the sub-tab; the *Pseudo Analogs*, also represented by the *Analogs XX* section; and the *Digitals*, represented by the *Digital Inputs XX* and *Digital Outputs XX* sections. The *XX* in the section headings represents a number that is the count of I/O points in that particular section, (*i.e.*, *Digital Inputs 11* means there are 11 digital inputs in that section).



Figure Error! No text of specified style in document.-1 I/O Points Tab - Raw Points