

Probe Purge

Probes may be purged from this tab.

To purge a probe, perform the following steps.

1. Click on the expansion button for the requisite probe.
2. Click on the requisite instrument.
3. Under the *Blowback / Purge* heading, click on **Start** or **Stop** as required to start or stop the probe purge.