

Outputs Sub-Tab

The *Outputs Sub-Tab* allows the end-user to view, *Add*, *Edit*, or *Delete* outputs. The *Alarms Sub-Tab* is divided into two areas; the *Outputs*, and the *Associated Alarms*; as seen in **FIGURE ERROR! No text of specified style in document.-1**.

Below this area, in the bottom row of the sub-tab, there are buttons to *Add*, *Edit*, and *Delete* an alarm.

Outputs

On the left of **FIGURE ERROR! No text of specified style in document.-1** are the Outputs, themselves.

Associated Alarms

On the right of **FIGURE ERROR! No text of specified style in document.-1**, are the *Associated Alarm Outputs*. Again, by selecting an *Alarm* on the left-hand side of the sub-tab, the end-user may view any *Associated Alarms*. When selecting an output from the left-hand side of this sub-tab, the *Associated Alarms* grid will fill with any alarms that are tied to that output.

Alarms

Outputs

Name	Email	Output Tag	Is Active
Default output	specsys2012@gmail.com	CEMS Fault	<input checked="" type="checkbox"/>
Test output	andrew@spectrumsystem		<input checked="" type="checkbox"/>
Landon	landonz@gmail.com		<input type="checkbox"/>
Landon (spectrum)	landon@spectrumsysterr		<input type="checkbox"/>
Rich (spectrum)	rpmarsh@spectrumsyste		<input type="checkbox"/>

Associated Alarms

Name	Description
NOx Analyzer Fault Unit 1	
SO2 Analyzer Fault Unit 1	
CO2 Analyzer Fault Unit 1	
Flow Monitor Fault Unit 1	
Opacity Monitor Fault Unit 1	
NOx Rate Alarm Unit 1	NOx lb/mmBtu exceedance

Add

Edit

Delete

Back

Figure Error! No text of specified style in document.-1 Outputs Sub-Tab