

Sony Computer Projector

This projector has been tested with college owned PC and Macintosh laptops and should work automatically when connected.

If the laptop you are using is not projecting properly, please set the screen resolution to 800 x 600 or 1024 x 768, and the monitor refresh rate to 60 or 75 Hz. You can set these by following the instructions below.

Advanced testing is **STRONGLY Recommended**.

For Windows XP:

1. Go to the **Start Menu > Control Panel**
2. If in Category View, click on **Appearances and Themes**, then click on **Display**.
If in Classic View, double click of **Display**.
3. In the *Display Properties* window, select the **Settings** Tab.
4. In the Screen Resolution section, move the scroll bar until you see **1024 x 768** pixels, and select it.
5. Click on the **Advanced** button.
6. Click on the **Monitor** Tab.
7. In the Monitor Settings section, use the drop down menu to change the Screen Refresh Rate or *Refresh Frequency* to 60 or 75 Hz.
8. Click **OK**, then in the *Display Properties* window click **Apply**, then **OK**.
9. Close all the windows.

For Macintosh OSX:

1. Go the **Apple Menu**.
2. Scroll down to **System Preferences**.
3. Under *Hardware* click on **Displays**.
4. In the Screen Resolution section, move the scroll bar until you see **800 x 600** pixels, and select it.
5. Click **OK**.
6. Close all the windows.

If these instructions do not work for your laptop, please contact the Wellesley College Faculty and Staff Helpdesk at x3333 and tell them you are having a laptop projection problem.