


## Quickstart Recording

① Power on the unit (Press **POWER/HOME** button for 3 seconds and then release it)



② Press **RECORD** [●] to activate record standby.

The REC indicator will flash in standby mode and solid during recording mode.



③ Adjust the recording levels while in standby mode with **+** or **-** located on the command dial.

④ Press **RECORD** [●] again to start recording.

⑤ Press the **POWER/HOME** [●] to finish recording.

⑥ Press **▶** for playback.

⑦ Use the **+** and **-** located on the command dial to adjust the listening/playback volume.

⑧ Press **POWER/HOME** [●] to finish recording and start a new track.

\* By default the Tascam will record high quality audio at 44.1kHz, 16bit WAV file settings.

For more advanced, higher quality, or longer recordings see settings

④ Menu Button (See inside for details)

③ Record Button

Press once to start Stand-by recording mode

Press again to start recording

Press again to pause recording

Press again to resume rec on same track

① Display area (see inside for display details)

② Power/Home Button

Press for 3 sec and release to power on/off.

During playback press to pause

Press again to restart playback

Press during recording to stop & start a new track

Use to answer "NO"


In other screen, Press to return home



MORE INFO

**Built-in Stereo mic**  
Swivel to two positions: A-B for wider and larger audio coverage and X-Y for smaller coverage.

## Recording Audio Advanced Settings



- Portable digital recording device with highly-sensitive built in cardioid mics
- Records MP3 or WAV (16/24 bit) formats easily transferable with a USB connection.
- Mic in/Line in input capable
- Adjustable built in mics (X/Y or A/B) great for live music and interviews
- Tripod stand mount


Please check for these items **BEFORE** leaving/returning to the Clapp service desk.  
\*External mics (Sennhieser shotgun and Lavalier wireless) are also available for this unit.

- ① Tascam DR-07 Digital Recorder\*
- ② USB Cable
- ③ AA Batteries x4
- ④ RedHead Windscreen
- ⑤ microSD Card
- ⑥ XLR to 1/8" adapter
- ⑦ Documentation

# Downloading Audio Files

## Using USB bus power


Connect the unit to a PC using the attached USB cable as shown in the illustration.



## Transferring files to a computer

Click the "DR-07MK2" drive on the computer screen to show the "MUSIC" and "UTILITY" folders.

Open the "MUSIC" folder and drag and drop the files that you want to transfer to the computer to destinations of your choice.



## Manually adjusting the input level

The following procedures explain how to use the Record Screen to set the levels.

### CAUTION

Manual adjustment cannot be performed when the automatic level control mode is selected as a level control function ( **AUTO** lighted on the upper left in the recording screen). To enable manual input level adjustment, select OFF or other mode in the level control setting screen (see "Using the Level Control Function" on page 57).

### 1 Press the RECORD [●] button to begin recording standby.

The record indicator flashes red and the recording screen appears.



### 2 The L◀▶ or ▶▶ button is used to adjust

# RECORDING

## NOTE

- The setting of left-right channels is disabled if an external microphone is connected to the MIC/EXT IN jack.

## Adjusting the input level


Before starting recording, the input level should be adjusted to prevent the recorded sounds from being distorted due to excessively large input signals or from being inaudible due to excessively low input signals compared to noise.

In addition to manual adjustment, the unit has the following three level adjustment functions: peak reduction, automatic level control, and limiter. Any of these can be used as required.

### TIP

In addition to adjusting the INPUT level, try changing the distance and angle between the microphone and the sound source. The angle and distance of the microphone can also change the character of the recorded sound.

the input level. Press the L◀▶ or ▶▶ button to show a pull-up menu screen for input level setting.



If the input is too high, the **PEAK** indicator on the upper left above the display lights.

A ▼ mark is provided at -12dB on the level meters. Set the input level so that the indicator bars move to and fro with this mark at about the center without causing the **PEAK** indicator to light red when the loudest sounds occur.

## REMEMBER TO TEST! TEST! TEST!

## Are You Recording!!!

**Knapp Media Center (781) 283-2368**  
For more information or help with a video project contact Jim McLean (jmclean@wellesley.edu) x2938.

continued...