

## Sony Computer Projector

This projector has been tested with college owned PC and Macintosh laptops and may not project properly automatically.

If the laptop you are using is not projecting properly, please set the screen resolution to 800 x 600 or 1024 x 768, and the monitor refresh rate to 60 or 75 Hz. You can set these by following the instructions below.

**Advanced testing is STRONGLY Recommended.**

### For Macintosh OSX:

1. Go the **Apple Menu**.
2. Scroll down to **System Preferences**.
3. Under *Hardware* click on **Displays**.
4. In the Screen Resolution section, move the scroll bar until you see **800 x 600** pixels, and select it.
5. Click OK.
6. Close all the windows.

### For Windows XP:

1. Go to the **Start Menu > Control Panel**
2. If in Category View, click on **Appearances and Themes**, then click on **Display**. If in Classic View, double click of **Display**.
3. In the *Display Properties* window, select the **Settings** Tab.
4. In the Screen Resolution section, move the scroll bar until you see **1024 x 768** pixels, and select it.
5. Click on the **Advanced** button.
6. Click on the **Monitor** Tab.
7. In the Monitor Settings section, use the drop down menu to change the Screen Refresh Rate or *Refresh Frequency* to 60 or 75 Hz.
8. Click **OK**, then in the *Display Properties* window click **Apply**, then **OK**.
9. Close all the windows.

**If you can only see a corner of the full screen once the laptop is connected to the projector follow these steps on your Windows XP PC laptop.**

1. Go to the **Start Menu > Control Panel**
2. If in Category View, click on **Appearances and Themes**, then click on **Display**. If in Classic View, double click of **Display**.
3. In the *Display Properties* window, select the **Settings** Tab. Click the **Advanced** button.
4. In the window titled, *(Multiples Monitors) and Mobility M7 Properties*, select the **Displays** tab.
5. Click the **Monitor** button. A window titled, *Monitor Properties* will open.
6. In the *Monitor Properties* window, make sure *Maximum Resolution* is set to at least **1024 x 768**. You may also need to uncheck Use DCC Information.
7. Click **Apply**.
8. You will be asked if you want to keep these settings. If the computer is projecting correctly, click **Yes**. If the computer is still not projecting properly, choose **No** and select a higher resolution.
9. Close all windows.

If these instructions do not work for your laptop, please contact the Wellesley College Faculty and Staff Helpdesk at x3333 and tell them you are having a laptop projection problem.

