

What's new in Version 2.04 of the LabVIEW drivers for pco.cameras

type: Driver update summary

file name: WhatsNewIn204.docx

version: 2.04

release date: 03 September 2015

reference to: LabVIEW driver for pco.camera version 2.04, MA_DCLABVIEWver204.docx

author: MM

available to: All

content / history:


This document describes the features that are new to this release. For a detailed description of the full driver package, please see the LabVIEW driver for pco.cameras User Manual.

1.1. New in APIManagement.lib:


SetTransferParametersAuto.vi

Automatically sets the transfer parameters for a pco.edge 5.5. This is the recommended function when Soft-ROI is enabled. This function replaces G(S)etTransferParameter.vi and SetActiveLookupTable.vi.

Connector Pane



Front Panel



Controls and Indicators



ph Handle for the camera



error in (no error) The **error in** cluster can accept error information wired from VIs previously called.



ilen Total number of bytes in "Transfer Parameters" cluster: default is 0.



Transfer Parameters Interface-specific parameters to control the transfer of data from camera to PC. This can be left uninitialized to set the parameters automatically.

U64 **hout** Handle output


551 **error out** The **error out** cluster passes error or warning information out of a VI to be used by other VIs.

I32 **ErrorCode**


EnableSoftROIMode.vi

Enables Soft-ROI functionality for Soft-ROI capable interfaces. If it is necessary to get a smaller ROI-granularity (e.g. in x-direction it is only possible to set the ROI in steps of 160 pixels with a pco.edge 5.5) this function enables smaller granularity (e.g. a pco.edge 5.5 is reduced to 4 pixels in x-direction). If Soft-ROI is enabled it is recommended to use SetTransferParametersAuto.vi. This makes sure that the camera and interface are set to the correct transfer modes for Soft-ROI. GetTransferParameter.vi, SetTransferParameter.vi and SetActiveLookupTable.vi are replaced by SetTransferParametersAuto.vi. If SetTransferParametersAuto.vi is not used it is mandatory to ensure the correct setup of the transfer parameters (e.g. Soft-ROI is smaller than x=1920, but the camera ROI is bigger than x=1920 due to the granularity of the camera).

Connector Pane



Front Panel



Controls and Indicators

U64 **ph** Handle for the camera

551 **error in (no error)** The **error in** cluster can accept error information wired from VIs previously called

TF **SoftROI** Enables or disables Soft ROI mode in cameras that have this capability.

FALSE - Disable Soft ROI mode

TRUE - Enable Soft ROI mode.

132 **Length** Length of the Soft ROI Params structure. Set to 0.

ROI Params ROI parameters for Soft ROI mode. Not currently implemented.

064 **hout** Handle output

error out The **error out** cluster passes error or warning information out of a VI to be used by other VIs.



The pop-up option **Explain Error** (or Explain Warning) gives more information about the error displayed.

132 **ErrorCode**

1.2. New in BufferData.LLB

GetInterfaceOutputFormat.vi

Displays options for the data interface to the pco.cameras. This VI can be used to query the readout modes on the pco.edge, and various output format options on the HDSDI interface of the pco.dimax.



064 **HandleIn** Handle to selected camera



error in (no error) The **error in** cluster can accept error information wired from VIs previously called.



DestInterface Selected interface type:



Reserved2 Reserved for future options



Reserved1 Reserved for future options



ErrorCode



HandleOut Handle for selected camera




error out The **error out** cluster passes error or warning information out of a VI to be used by other VIs.



Readout mode Data interface options

SetInterfaceOutputFormat.vi

Controls options for the data interface to the pco.cameras. This VI can be used to set the readout modes on the pco.edge, and control various options on the HDSDI interface of the pco.dimax.











The front panel of the VI includes the following controls:

- HandleIn:** A numeric control set to 0.
- DestInterface:** A dropdown menu set to 'sCMOS'.
- Readout mode:** A dropdown menu set to 'Mode A: Top -> Center, Bottom -> Center' with a numeric value of 0100.
- error in (no error):** A sub-panel with 'status' (checked), 'code' (0), and 'source' (empty).
- error out:** A sub-panel with 'status' (checked), 'code' (0), and 'source' (empty).
- Reserved1:** A numeric control set to 0.
- Reserved2:** A numeric control set to 0.
- HandleOut:** A numeric control set to 0.
- ErrorCode:** A numeric control set to 0.



DestInterface Select Interface type


-  **Reserved2** Reserved for future options
-  **Reserved1** Reserved for future options
-  **HandleIn** Handle to selected camera
-  **error in (no error)** The **error in** cluster can accept error information wired from VIs previously called.
-  **Readout mode** Data interface options.
-  **ErrorCode**
-  **HandleOut** Handle for selected camera
-  **error out** The **error out** cluster passes error or warning information out of a VI to be used by other VIs.

1.3. New in Sensor.Ilb

GetHWIOSignalDescriptor.vi

Provides details of the selected hardware signal, including signal names and I/O modes

Connector Pane



Front Panel

Controls and Indicators



ph Handle to a open camera connection



ErrorIn The **error in** cluster can accept error information wired from VIs previously called.



hout Handle to a open camera connection (same as input handle)



ErrorOut The **error in** cluster can accept error information wired from VIs previously called.



SingleSignalDesc Information on the selected I/O signal



Names Name given to this I/O signal, along with any alternates



SignalDefinitions Flags for signal options. Option is available if bit is 1 (TRUE). Unlisted bits are reserved for future use.

Bit0: Signal can be enabled/disabled

Bit 1: Signal is status (output)

Other bits reserved for future use



SignalTypes Flags for the selectable I/O options. Option is supported if bit is 1 (TRUE). Unlisted bits are reserved for future use

Bit0: TTL

Bit1: Higher than TTL voltage

Bit2: Contact closure

Bit3: RS485 differential signalling



SignalPolarity Flags for level or transition triggering of I/O signal. Option is available if bit is 1 (TRUE). Unlisted bits are reserved for future use.

Bit0: Low level active

Bit 1: High level active

Bit 2: Rising edge active

Bit 3: Falling edge active



SignalFilter Flags for signal filter options. Option is available if bit is 1 (TRUE). Unlisted bits are reserved for future use.

Bit0: Filter can be disabled.


Bit1: Medium-level filter availability (t > 1 us)

Bit 2: High level filter available (t > 100 ms)


GetHWIOSignalCount.vi

Returns the number of Hardware I/O signals available.

Connector Pane




Front Panel



Controls and Indicators


 **ph** Handle to camera

 **ErrorIn** The **error in** cluster can accept error information wired from VIs previously called. Use this information to decide if any functionality should be bypassed in the event of errors from other VIs.

 **Error**

 **hout** Handle out

 **NumSignals** Number of Hardware Input/Output signals available for use.


 **ErrorOut** The **error in** cluster can accept error information wired from VIs previously called.

1.4. New in TimingControl.IIb:


GetImageTiming.vi

Returns detailed timing information, including system delays and jitter. Can be used to make more accurate determination of the exposure timing.

Connector Pane



Front Panel



Controls and Indicators



ph Handle for the camera



error in (no error) The **error in** cluster can accept error information wired from VIs previously called.



error out The **error out** cluster passes error or warning information out of a VI to be used by other VIs.



ErrorCode



handleOut Handle to the camera



ImageTiming Detailed information about the exposure and delay timing, including internal delays and jitter.



FrameTime_ns Time required, with FrameTime_s, to acquire one frame



FrameTime_s Time required, with FrameTime_ns, to acquire one frame



ExposureTime_ns This + ExposureTime_s = exposure time



ExposureTime_s This + ExposureTime_ns = exposure time



TriggerSystemDelay_ns Minimum internal trigger system delay in ns



TriggerSystemJitter_ns Maximum possible jitter, +/- in ns




TriggerDelay_ns This + TriggerDelay_s = total delay, including programmed and system delays

U32 TriggerDelay_s This + TriggerDelay_ns = total delay, including programmed and system delays

GetHWLEDSignal.vi

Gets the status of the LED at the back of the pco.edge camera



U64 HandleIn Handle to the requested camera

error in (no error) The **error in** cluster can accept error information wired from VIs previously called

U64 HandleOut Handle to the requested camera

error out The **error out** cluster passes error or warning information out of a VI to be used by other VIs.


I32 ErrorCode 0 if no error, otherwise an error code will appear here


TF LEDStatus LED enabled state:

ON = Enabled
OFF = Disabled

SetHWLEDSignal.vi

Set the state of the LED at the back of the pco.edge camera





U641 **HandleIn** Handle to the requested camera

E511 **error in (no error)** The **error in** cluster can accept error information wired from VIs previously called.

TF **LEDControl** Enable or disable LED operation:

ON = Enabled
OFF = Disabled


U641 **HandleOut** Handle to the requested camera

E511 **error out** The **error out** cluster passes error or warning information out of a VI to be used by other VIs.

I32 **ErrorCode** 0 if no error, otherwise an error code will appear here

GetCMOSLineTiming.vi

Sets the timing for an individual line in sCMOS cameras. This enables the camera scan rate to be matched to a moving source.



U64 **HandleIn** Handle to the selected camera

error in (no error) The **error in** cluster can accept error information wired from VIs previously called.

I32 **ErrorCode**

U64 **HandleOut**

error out The **error out** cluster passes error or warning information out of a VI to be used by other VIs.

U16 **Parameter** Displays the operation of the lime timing mode

CMOS_LINETIMING_PARAM_OFF = 0
CMOS_LINETIMING_PARAM_ON = 1

U16 **TimeBase** Time base (units of time) for the exposure setting.

0 - Nanoseconds
1 - Microseconds
2 - Milliseconds


U32 **LineTime** Time of one line, in time base units.

U32 **Reserved** Reserved for future use

U16 **ReservedLength** Reserved for future use

SetCMOSLineTiming.vi

Sets the timing for an individual line in sCMOS cameras. This enables the camera scan rate to be matched to a moving source.



U64 HandleIn Handle to the selected camera

U16 Parameter Controls the operation of the lime timing mode

CMOS_LINETIMING_PARAM_OFF = 0
CMOS_LINETIMING_PARAM_ON = 1

U16 TimeBase Time base (units of time) for the exposure setting.

0 - Nanoseconds
1 - Microseconds
2 - Milliseconds

U32 LineTime Time of one line, in time base units.

U32 Reserved Reserved for future use

U16 ReservedLength Length of reserved parameter list

FP1 error in (no error) The **error in** cluster can accept error information wired from VIs previously called

I32 ErrorCode


U64 HandleOut

FP1 error out The **error out** cluster passes error or warning information out of a VI to be

used by other VIs.

GetCMOSLineExposureDelay.vi

This command returns the exposure and delay time for a frame. It is only valid when the line timing parameter is set to CMOS_LINETIMING_PARAM_ON.



U64 **HandleIn** Handle for the selected camera

U32 **error in (no error)** The **error in** cluster can accept error information wired from VIs previously called

I32 **ErrorCode** 0 if no error, otherwise an error code appears here

U64 **HandleOut** Handle of the selected camera

U32 **error out** The **error out** cluster passes error or warning information out of a VI to be used by other VIs.

U32 **ExposureLines** Number of lines required for exposure



U32 **DelayLines** Number of lines between consecutive frames

U32 **Reserved** Reserved for future features

U16 **ReservedLength** Length in bytes of the reserved structure

SetCMOSLineExposureDelay.vi

This command sets the exposure and delay time for a frame. It is only available when the line timing parameter is set to CMOS_LINETIMING_PARAM_ON.



U64 **HandleIn** Handle for the selected camera

U32 **ExposureLines** Number of lines required for exposure

U32 **DelayLines** Number of lines between consecutive frames

U32 **Reserved** Reserved for future features

U16 **ReservedLength** Length in bytes of the reserved structure

E4 **error in (no error)** The **error in** cluster can accept error information wired from VIs previously called.

I32 **ErrorCode** 0 if no error, otherwise an error code appears here


U64 **HandleOut** Handle of the selected camera

E4 **error out** The **error out** cluster passes error or warning information out of a VI to be used by other VIs.

GetHWIOSignal.vi

Provides details of the selected hardware signal, including signal names and I/O modes

Connector Pane



Front Panel

The Front Panel interface includes the following controls:

- ph** and **hout**: Input handles for camera connections, both set to 0.
- SignalNumber** and **Error**: Input handles, both set to 0.
- HWIO signal** cluster:
 - SignalNumber**: Input handle set to 0.
 - Enabled**: Toggle switch, currently turned on (green).
 - Type**: Dropdown menu set to **TTL**.
 - Polarity**: Dropdown menu set to **High level active**.
 - FilterSettings**: Dropdown menu set to **Filter off**.
 - Selected**: Input handle set to 0.
- ErrorIn** and **ErrorOut** clusters:
 - Each has a **status** indicator (green checkmark) and a **code** input handle set to 40.
 - Each has a **source** dropdown menu.

Controls and Indicators



ph Handle to a open camera connection



ErrorIn The **error in** cluster can accept error information wired from VIs previously called.



Error



hout Handle to a open camera connection (same as input handle)



ErrorOut The **error out** cluster passes error or warning information out



HWIO signal Cluster of parameters describing the current configuration of the selected HWIO signal



SignalNumber Number of the HWIO signal selected



Enabled True if signal enabled, false if signal disabled



Type Signal level



Polarity Sense of signal voltage, or edge if edge sensitive




FilterSettings Level of filtering on signal

U16 Selected Indicates which variant of the signal is selected, if signal has more than one variant


SetHWIOSignal.vi

Controls the properties of the selected hardware signal, including modes and polarities

Connector Pane



Front Panel









Controls and Indicators

U641 ph Handle to a open camera connection

581 ErrorIn The **error in** cluster can accept error information wired from VIs previously called.


U166 SignalNumber


581 HWIO signal Cluster of parameters describing the current configuration of the selected HWIO signal

-  **SignalNumber** Number of the HWIO signal selected
-  **Enabled** True if signal enabled, false if signal disabled
-  **Type** Signal level
-  **Polarity** Sense of signal voltage, or edge if edge sensitive
-  **FilterSettings** Level of filtering on signal
-  **Selected** Selects which variant of the signal is used, if signal has more than one variant


Error

 **hout** Handle to a open camera connection (same as input handle)

 **ErrorOut** The **error out** cluster passes error or warning information out of a VI to be used by other VIs.

 **status** The **status** boolean is either TRUE (X) for an error, or FALSE (checkmark) for no error or a warning.

The pop-up option **Explain Error** (or Explain Warning) gives more information about the error displayed.

 **code** The **code** input identifies the error or warning.


The pop-up option **Explain Error** (or Explain Warning) gives more information about the error displayed.

 **source** The **source** string describes the origin of the error or warning.


The pop-up option **Explain Error** (or Explain Warning) gives more information about the error displayed.


GetHWIOSignalTiming.vi


Queries the functionality on any hardware I/O signal that has multiple modes of operation.





The screenshot shows a software interface with several input fields and status indicators. At the top, there are three numeric input fields labeled 'HandleIn' (value 0), 'index' (value 0003), and 'select' (value 0000). Below these are 'HandleOut' (value 0) and 'Error' (value 0). A section titled 'GetHWIOSignalTimingStructure Out' contains a table of fields: 'code' (0), 'parameter' (0), 'checksum' (0), 'length' (33), 'reserved 0' (0), 'index' (0), 'reserved 1' (0), 'select' (0), 'reserved 2' (0), 'type' (0), and 'reserved 3' (0). At the bottom, there are two 'ErrorIn' and 'ErrorOut' status boxes, each with a green checkmark icon, a status code of 0, and a source field. The 'ErrorOut' source field contains the text 'Layer: DLL, Device: SDK'.


 **ErrorIn** The **error in** cluster can accept error information wired from VIs previously called.


 **HandleIn** Handle to the selected camera

 **index** Selects the HWIO signal to be queried

 **select** On HWIO signals that have multiple functions, this selects the function of the signal. e.g. exposure out or busy out.

 **ErrorOut** The **error out** cluster passes error or warning information out of a VI to be used by other VIs.

 **GetHWIOSignalTimingStructure Out**

 **code** Low level control code

 **length** Length of message

 **index** Index of signal queried

 **select** Selected function of this signal

 **type** Type of signal

 **parameter** Timing details

U32 reserved 0

U32 reserved 1

U32 reserved 2


U32 reserved 3

U8 checksum

U64 HandleOut Handle to selected camera

SetHWIOSignalTiming.vi

Selects the functionality on any hardware I/O signal that has multiple modes of operation This can be used to configure output signals on the pco.edge.



ErrorIn The **error in** cluster can accept error information wired from VIs previously called.

U64 HandleIn Handle to selected camera

U32 Timing Selects the timing options for the HWIO signal

U16 index Selects the HWIO signal to be configured

U16 select On HWIO signals that have multiple functions, this selects the function of the signal. e.g. exposure out or busy out.

ErrorOut The **error out** cluster passes error or warning information out of a VI to be used by other VIs.

HWIOSignalTimingStructureOut


- U16 code** Low level control command
- U16 length** Length of command message
- U16 index** Selected signal
- U16 select** Selected function
- U32 type** Type of signal
- U32 parameter** Timing options
- U32 reserved 0**
- U32 reserved 1**
- U32 reserved 2**
- U32 reserved 3**
- U8 checksum**

U64 HandleOut Handle to selected camera


1.5. New In GeneralControlStatus.Ilb

GetFanControlStatus.vi


Returns information on fan set point and control mode. Indicates if fan is under automatic or manual control.




HandleIn

 **error in (no error)** The **error in** cluster can accept error information wired from VIs previously called. Use this information to decide if any functionality should be bypassed in the event of errors from other VIs.


HandleOut


 **error out** The **error out** cluster passes error or warning information out of a VI to be used by other VIs.

 **Fan Control Status** Contains information about the fan control status in the pco.edge.

 **Manual control** Indicates if the fan is available for manual control

FALSE - Fan is under automatic control
TRUE - Fan can be controlled manually.

 **FanMin** Minimum value for fan speed. This value is a percentage of the maximum fan voltage.

 **FanMax** Maximum value for fan speed. This value is a percentage of the maximum fan voltage.

U16 FanStep Step size for the fan speed set point. This is a percentage of the maximum fan voltage.



U16 FanSetPoint Sets the operating point for the fan. This is a percentage of the maximum fan voltage.

U16 FanActual Actual operating point of the fan, as a percentage of the maximum fan voltage.

U16 Reserved Reserved for future control options

SetFanControlStatus.vi

Controls the mode of fan operation, and sets the operating point of the fan in manual mode. Only pco.edge cameras with internal fan are supported.



U64 HandleIn

error in (no error) The **error in** cluster can accept error information wired from VIs previously called. Use this information to decide if any functionality should be bypassed in the event of errors from other VIs.

TF Control mode Switches the fan control mode from automatic to manual.

FALSE = Automatic (default)
TRUE = Manual

U16 Fan Set Point In manual mode, this sets the fan speed. This input is ignored if the fan is in auto mode. The number represents a percentage of the maximum fan voltage. To find

the range of acceptable values, use `GetFanControlStatus.vi`.



HandleOut



error out The **error out** cluster passes error or warning information out of a VI to be used by other VIs.



Set Point Out Current fan setpoint. The number represents a percentage of the maximum fan voltage. To find the range of acceptable values, use `GetFanControlStatus.vi`.