

MS View tutorial

November 26, 2019

Contents

1	Morningstar View Tutorial	2
1.1	Viewing Data using MSView	2
1.1.1	Step 1: Downloading the Program	2
1.1.2	Step 2: Connecting the Morningstar	3
1.1.3	Step 3: Powering the Morningstar	3
1.1.4	Step 4: Using MSView	3
1.1.5	Step 5: Viewing Live Data	3
1.1.6	Step 6: Programming the Tristar MPPT using MSView	5
1.1.7	Final Step	7

Chapter 1

Morningstar View Tutorial

1.1 Viewing Data using MSView

Here's how to view live data using MSView from your PC:

1.1.1 Step 1: Downloading the Program

First, download MSView from Morningstar's Corporate Website, located here: <https://www.morningstarcorp.com/msview/> Figure 1.2 shows what the website looks like.




Figure 1.1: Menu 1

1.1.2 Step 2: Connecting the Morningstar

If you're using a RS-232 to USB serial connector to connect your PC, connect it now.

1.1.3 Step 3: Powering the Morningstar

Connect a 12V power supply to the battery terminal of the Tristar MPPT Charge Controller. It should draw approximately 189mA of current just for management.

1.1.4 Step 4: Using MSView

Open MSView. Under Devices, select Search for Connected Devices. Your Tristar MPPT should show up under whatever virtual COM port you connected your RS-232 to USB connector to. Double-click it. You should see something like this appear.




Figure 1.2: First Menu upon initialization

1.1.5 Step 5: Viewing Live Data

Under Displays, select New. Select 'State' when a dialog box saying New Display appears and press OK. Drag and drop whatever variables you want. Our Tristar MPPT can log:

- Array Voltage (Array is shorthand for our solar panel array),
- Array Current, Input Power (how much power our solar panels are producing),
- Array Pmax,
- Array Vmp,
- Array Voc,
- Battery Voltage (The Voltage of our Battery),
- Battery Voltage (slow),
- Battery Terminal Voltage,
- Battery Sense Voltage (there's a remote voltage sensor port on our Tristar MPPT that we can connect for safety),
- Min. Battery Voltage (slow),
- Max. Battery Voltage (slow),
- Battery Current,
- Battery Current(slow),
- Output Power (how much power we're consuming),
- target regulation voltage,
- charge state (Float, equalization, etc.),
- RTS temperature,
- Battery Temperature,
- Heatsink Temperature,
- Ah Charge Resetable,
- Ah Charge Total,
- kWh Charge Resetable,
- kWh Charge Total,

- LED State, Faults (did someone change the DIP switch?),
- Faults Daily,
- Alarms (did someone overcharge?),
- Alarms Daily,
- Hourmeter (how long have we been using this thing?),
- Settings Switches(the state of our DIP switch).

1.1.6 Step 6: Programming the Tristar MPPT using MSView

There are many different types of batteries: Lithium Ion, Lead-Acid, Lithium Polymer batteries, LiFePO4 batteries, etc. Each one of them requires its own different programming. The Tristar MPPT has 7 built-in programmable settings. To custom-program our Tristar MPPT to handle a battery, follow these steps:

Under Tools, click Tristar MPPT Setup Wizard. Read and click OK for both of the warnings against switching DIP switches while the power is applied.




Figure 1.3: TSMPPPT Setup Wizard

When on the screen that looks like Figure 1.3, Click Read TSMPPPT. Make sure it's set to Solar Charge Control. If you're using a serial connection, make sure you're using the right COM port. On our Tristar MPPT, the MODBUS address is 1.




Figure 1.4: Communications settings

The Setup wizard should look something like this afterwards if reading the settings was successful.

Read the settings you extracted from the Tristar MPPT first before you reprogram it. If the settings are not to your liking (i.e. the batteries will not charge properly), you can reprogram the Tristar MPPT. If you have a file already saved, click Read from File, and all your previously made changes will be loaded. If you don't have a file made already, then click Edit. This will allow you to make your own custom settings. You can change all these




Figure 1.5: Tristar Morningstar Charge Settings Screen

settings shown below:

Once all of your changes are made, you can save it to a file, just in case you need to reprogram the Tristar MPPT. Save it by using Write to File.

Once you have your settings loaded, you need to program the Tristar MPPT. Click Program TSMPPPT, and make sure the COM port is correct.

Now, your Tristar should be ready to be used with your batteries!

1.1.7 Final Step

Oh, one more thing! If you want to use custom charging settings, DIP switches 4,5, and 6 must be switched on! That's how the custom settings work! It even says so in MSView!

Also, this is a CHARGE CONTROLLER! It won't manage all your batteries for you! You must use a BMS system for that. Luckily, we have one. I've

Charge Mode - Absorption, Temp Comp, & Reminder

Absorption voltage
14.00
V @ 25 degC

Absorption time
0
h
4
m
16
s

☒ Enable Absorption extension

Absorption extension voltage
12.50
V

Absorption extension time
0
h
0
m
0
s

Battery Temperature Compensation -
0.030
V / degC

Maximum Compensation Temp
80
degC

Minimum Compensation Temp
-30
degC

☐ Enable Battery Service Reminder

Battery Service Reminder
60
days

< Back
Next >
Cancel
Help

Figure 1.6: Absorption, Temperature Compensation, and Reminder Settings

got a separate document for that. It can help you balance out the charges on your batteries so that every battery has an even charge, and none of them use too many life cycles at the same time.

Charge Mode - Float Settings ×

☒ Enable Float

Float Voltage V @ 25 degC

Float Timeout h m s

☒ Enable Float cancel

Float cancel voltage V

Figure 1.7: Float Settings

Charge Mode - Equalize & HVD Settings ×

☐ Enable Equalize

Equalize Voltage V @ 25 degC

Equalize Time h m s

Auto Equalize interval days

Equalize Timeout h m s

☒ Enable Battery HVD

High Voltage Disconnect V

High Voltage Reconnect V

Figure 1.8: Equalize and HVD Settings

Charge Mode - Limits ✕

☐ Enable Maximum Regulation Limit

Maximum Regulation Limit V

☒ Enable Battery Current Limit

Battery Current Limit A

☒ Enable Fixed Array Voltage Target

☒ Target is V

☐ Target is % of Voc

Figure 1.9: Limits Settings




Figure 1.10: LED Settings




Figure 1.11: Logger Settings

Communication Settings

MeterBus Address (Range: 1-15. Default 1)

TriStar Modbus Address (Range: 1-247)

Controller Name

IP Address

☒ Obtain IP address from DHCP server

☐ Use static IP address

IP Address

Subnet mask

Gateway

Primary DNS

Secondary DNS

HTTP server port

Modbus/TCP port

☐ Enable Ethernet power-saving mode

☐ Bridge Modbus/TCP requests to EIA-485 network

Note: do not change communication settings unless necessary.

< Back Next > Cancel Help

Figure 1.12: Communication Settings

Notifications ×

SMTP (outgoing email)

SMTP server address

SMTP server port

SMTP server username

☐ Change control's current SMTP password

SMTP server password

"To" email address

SNMP trap receiver address

SNMP trap receiver port

SNMP sysLocation

< Back Next > Cancel Help

Figure 1.13: Mail Server Settings (TCP Exclusive)

Notification 1 X

☐ Enable Notification 1

Name (will also be the subject of any email notification sent)

Source of data

When the Modbus variable becomes V

for at least seconds, send a notification via: ☐ email ☐ SNMP trap

After sending a notification, do not resend unless the above condition has been false
for at least seconds.

Figure 1.14: Notification 1

Notification 2

☐ Enable Notification 2

Name (will also be the subject of any email notification sent)

Source of data

When the Modbus variable becomes V

for at least seconds, send a notification via: ☐ email ☐ SNMP trap

After sending a notification, do not resend unless the above condition has been false for at least seconds.

< Back Next > Cancel Help

Figure 1.15: Notification 2

Notification 3

☐ Enable Notification 3

Name (will also be the subject of any email notification sent)

Source of data

When the Modbus variable becomes V

for at least seconds, send a notification via: ☐ email ☐ SNMP trap

After sending a notification, do not resend unless the above condition has been false for at least seconds.

< Back Next > Cancel Help

Figure 1.16: Notification 3

Notification 4 X

☐ Enable Notification 4

Name (will also be the subject of any email notification sent)

Source of data

When the Modbus variable becomes V

for at least seconds, send a notification via: ☐ email ☐ SNMP trap

After sending a notification, do not resend unless the above condition has been false
for at least seconds.

Figure 1.17: Notification 4

Write Control Settings

Communications

The control is connected to

MODBUS Address

< Back Next > Cancel Help

Figure 1.18: Write Control Communication Settings




Figure 1.19: Writing Settings to the Tristar Screen