

CD Digital Servo DSP

LC78615


HOST Flowchart

ON Semiconductor

Version 0.10
(2013.10.24)


Update history
V0.10 New release(For Commander V0.10)

LC78615 HOST FLOWCHART MAIN



LC78615 HOST FLOWCHART


POWER_ON_DSP



LC78615 HOST FLOWCHART

SEQUENCER_INIT


※ The function of a blue character is control commands of DSP.
Check "LC78615 command specifications" and "Command_IF.c" in detail.



LC78615 HOST FLOWCHART

CD MAIN

※ The function of a blue character is control commands of DSP.
Check "LC78615 command specifications" and "Command_IF.c" in detail.




LC78615 HOST FLOWCHART

PAUSE_CHECK

Check PAUSE Status


When Pause Status of DSP and that of a microcomputer are not in agreement, make it in agreement.

※ The function of a blue character is control commands of DSP.
Check "LC78615 command specifications" and "Command_IF.c" in detail.



LC78615 HOST FLOWCHART

KEY_PLAY




LC78615 HOST FLOWCHART

KEY_STOP

※ The function of a blue character is control commands of DSP.
Check "LC78615 command specifications" and "Command_IF.c" in detail.

Push STOP Key




LC78615 HOST FLOWCHART


KEY_FF / KEY_FB

Push FF Skip Key

※ The function of a blue character is control commands of DSP.
Check "LC78615 command specifications" and "Command_IF.c" in detail.



Push FB Skip Key




LC78615 HOST FLOWCHART


KEY_LONG_FF / KEY_LONG_FB

Push FF key for a long time

※ The function of a blue character is control commands of DSP.
Check "LC78615 command specifications" and "Command_IF.c" in detail.





Push FB key for a long time



LC78615 HOST FLOWCHART

KEY_REPEAT


※ The function of a blue character is control commands of DSP.
Check "LC78615 command specifications" and "Command_IF.c" in detail.




LC78615 HOST FLOWCHART

RANDOM再生


※ The function of a blue character is control commands of DSP.
Check "LC78615 command specifications" and "Command_IF.c" in detail.



Set up Random OFF



Set up Random ON




LC78615 HOST FLOWCHART

ERROR_CODE_CHECK

※ The function of a blue character is control commands of DSP.
Check "LC78615 command specifications" and "Command_IF.c" in detail.

Error detect by HOST
& Error recovery




LC78615 HOST FLOWCHART


ERROR RECOVERY

※ The function of a blue character is control commands of DSP.
Check "LC78615 command specifications" and "Command_IF.c" in detail.


Error Reset Start



Error track up




Error Stop



LC78615 HOST FLOWCHART


LOADING / EJECT



LC78615 HOST FLOWCHART

LOADING / EJECT 2/2

※ The function of a blue character is control commands of DSP.
Check "LC78615 command specifications" and "Command_IF.c" in detail.



LC78615 HOST FLOWCHART

KEY_EJECT

※ The function of a blue character is control commands of DSP.
Check "LC78615 command specifications" and "Command_IF.c" in detail.

