



AOsense Integrated Laser Controller Application Programming Interface DOC-0011272

## AOsense Integrated Laser Controller (ILC) Application Programming Interface (API)

Date	Rev	Change	Author
02/05/2016	A	Initial release	Alex Radnaev

**WARNING: BY USING API YOU ACKNOWLEDGE AOSENSE PRODUCT TERMS AND CONDITIONS.  
PARTICULARLY, USING COMMANDS WHICH ARE NOT DOCUMENTED IN THIS DOCUMENT  
VOIDS WARRANTY.**

AOsense ILC can be controlled via USB virtual COM port communication using the following settings:

A screenshot of a "Configure the serial line" dialog box. It contains five settings: "Speed (baud)" set to 115200, "Data bits" set to 8, "Stop bits" set to 1, "Parity" set to None, and "Flow control" set to None. Each setting is in a text box or a dropdown menu.

Below is the Allowed command list:

Category	Command	Access	Description
1	ALERTS [A]	no admin needed	show [all/]pending alerts
1	TREG [<val.ue> ON OFF]	no admin needed	set/show TempReg enabled
1	LASER [ON OFF]	no admin needed	show/enable/disable laser current
1	PZT [ON OFF]	no admin needed	show/enable/disable PZT voltage
1	PZTFF [ON OFF]	no admin needed	show/enable/disable PZT feed-forward
1	ILMOD [ON OFF]	no admin needed	show/enable/disable laser current modulation
1	PZMOD [ON OFF]	no admin needed	show/enable/disable PZT modulation
1	TST [<val.ue>]	no admin needed	set/show set temperature



AOSense Integrated Laser Controller Application Programming Interface DOC-0011272

1	ILA [<val.ue>]	no admin needed	set/show laser set current
1	UPZ [<val.ue>]	no admin needed	set/show PZT set voltage
1	PFF [<val.ue>]	no admin needed	set/show PZT feed forward gain
1	TCU	no admin needed	show current temperature
1	MON.ILA	no admin needed	show monitored laser current
1	MON.UPZ	no admin needed	show monitored PZT voltage
1	MON.ITEC	no admin needed	show monitored TEC current
1	MON.UPZP	no admin needed	show monitored PZT power voltage
1	LOAD	no admin needed	load all knobs from NV-RAM
1	SAVE [0 1]	no admin needed	save all knobs/trims to NV-RAM (1=force)
1	TSF.MIN [<val.ue>]	need admin to set	set/show minimum safe temperature
1	TSF.MAX [<val.ue>]	need admin to set	set/show maximum safe temperature
1	TST.MIN [<val.ue>]	need admin to set	set/show minimum target temperature
1	TST.MAX [<val.ue>]	need admin to set	set/show maximum target temperature
1	ILA.MIN [<val.ue>]	need admin to set	set/show laser current minimum limit
1	ILA.MAX [<val.ue>]	need admin to set	set/show laser current maximum limit
1	ILA.ERR [<val.ue>]	need admin to set	set/show laser current error limit
1	ULC [<val.ue>]	need admin to set	set/show laser clamp voltage
1	UPZ.MAX [<val.ue>]	need admin to set	set/show PZT voltage limit
1	UPZ.ERR [<val.ue>]	need admin to set	set/show PZT voltage error limit
1	LSN [<senum>]	need admin to set	show/set laser serial number
1	VSAVE [0 1]	no admin needed	save all valves to NV-RAM (1=force)
1	HCONN [ON OFF]	no admin needed	show/connect (1) or disconnect (0) Laser Head
2	SYSTIME	no admin needed	show current system time
2	FLAG	no admin needed	show detail flags information
2	AMONS	no admin needed	show current/voltage monitors
2	TMON	no admin needed	monitor TempReg progress
2	TCHA <from> <to> <step> <min-time>	no admin needed	characterize TempReg
2	MON.UTEC	no admin needed	show monitored TEC voltage
2	MON.UILP	no admin needed	show monitored ILA power voltage



AOsense Integrated Laser Controller Application Programming Interface DOC-0011272

2	MON.IPZP	no admin needed	show monitored PZT power current
2	TLC [<val.ue>]	need admin to set	set/show cooling drive limit
2	TLH [<val.ue>]	need admin to set	set/show heating drive limit
2	TLS [<val.ue>]	need admin to set	set/show drive slew rate limit
3	VERSION	no admin needed	show version information
3	FLAGS	no admin needed	show status flags summary
3	TICK	no admin needed	show system tick count since reset
3	TCIX	no admin needed	show temp regulator cycle index
3	TRP	no admin needed	show temp regulator P component
3	TRI	no admin needed	show temp regulator I component
3	TRD	no admin needed	show temp regulator D component
3	TOUT	no admin needed	show temp regulator output
3	TDRV	no admin needed	show temp regulator drive
3	TSIX	no admin needed	show temp regulator settling index
3	PGEN	no admin needed	show profile generation
3	LLIFE	no admin needed	show laser accrued life
3	MON.5VP	no admin needed	show monitored 5V power voltage
3	MON.4VP	no admin needed	show monitored 4V power voltage
3	MON.13VP	no admin needed	show monitored 13V power voltage
3	LNAME [<name>]	no admin needed	show/set laser name
3	TRIMS	no admin needed	show all laser trims
3	KNOBS	no admin needed	show all laser knobs
3	GAGES	no admin needed	show all laser gages
3	ONCYC	no admin needed	wait for next cycle
3	VALVES.64	no admin needed	show all controller valves (base 64)
3	TRIMS.64	no admin needed	show all laser trims (base 64)
3	KNOBS.64	no admin needed	show all laser knobs (base 64)
3	GAGES.64	no admin needed	show all laser gages (base 64)
3	FLINFO	no admin needed	show Flash info
3	EEINFO	no admin needed	show EEPROM info
4	ILA.RS [<val.ue>]	need admin to set	set/show laser current shunt resistor
4	ILA.GM [<val.ue>]	need admin to set	set/show laser current monitor gain
4	ILA.RR [<val.ue>]	need admin to set	set/show laser current regulator ratio