

DENON RS-232C/IP Command Chart
Item: FY17 AV Receiver

Last Update: 1-Dec-17

(Refer to "Revision")

X

This pink color cell = New assigned code

COMMAND PARAMETER list

System		Function	COMMAND Parameter Command example	Response code example	AVR- VERSION	AVR- VERSION	AVR- VERSION	AVR- VERSION	AVR- VERSION	AVR- VERSION	AVR- VERSION	AVR- VERSION	Notes
MAIN ZONE	POWER	POWER ON/STANDBY change	PW ON	PWON<CR>	X	X	X	X	X	X	X	X	
		Return PW Status	STANDBY	STANDBY<CR>	X	X	X	X	X	X	X	X	
		MAIN ZONE ON/OFF change	PW<CR>	PW<CR>	X	X	X	X	X	X	X	X	
		Return ZM Status	ON	ZM ON<CR>	X	X	X	X	X	X	X	X	
	Volume	MASTER VOLUME UP/DOWN, direct change to "dB"	OFF	ZM OFF<CR>	X	X	X	X	X	X	X	X	
		--00 to 98 by ASCII, 00=0dB, 98=0dB(MIN)	7	ZM<CR>	X	X	X	X	X	X	X	X	
	Direct Volume	Return MV Status	UP	MV UP<CR>	X	X	X	X	X	X	X	X	
		--00 to 98 by ASCII, 00=0dB, 98=0dB(MIN)	DOWN	MV DOWN<CR>	X	X	X	X	X	X	X	X	
	Channel Volume	FRONT Lch	MV<CR>	MV<CR>	X	X	X	X	X	X	X	X	
		--38 to 62 by ASCII, 00=0dB	FL UP	CVFL UP<CR>	X	X	X	X	X	X	X	X	
SUB ZONE	POWER	POWER ON/STANDBY change	PW ON	PWON<CR>	X	X	X	X	X	X	X	X	
		Return PW Status	STANDBY	STANDBY<CR>	X	X	X	X	X	X	X	X	
		MAIN ZONE ON/OFF change	PW<CR>	PW<CR>	X	X	X	X	X	X	X	X	
		Return ZM Status	ON	ZM ON<CR>	X	X	X	X	X	X	X	X	
	Volume	MASTER VOLUME UP/DOWN, direct change to "dB"	OFF	ZM OFF<CR>	X	X	X	X	X	X	X	X	
		--00 to 98 by ASCII, 00=0dB, 98=0dB(MIN)	7	ZM<CR>	X	X	X	X	X	X	X	X	
	Channel Volume	FRONT Lch	MV<CR>	MV<CR>	X	X	X	X	X	X	X	X	
		--38 to 62 by ASCII, 00=0dB	FL UP	CVFL UP<CR>	X	X	X	X	X	X	X	X	
	Channel Volume	CENTER Rch	FR DOWN	CVFR DOWN<CR>	X	X	X	X	X	X	X	X	
		--38 to 62 by ASCII, 00=0dB	C UP	CV C UP<CR>	X	X	X	X	X	X	X	X	
SUB ZONE	POWER	POWER ON/STANDBY change	PW ON	PWON<CR>	X	X	X	X	X	X	X	X	
		Return PW Status	STANDBY	STANDBY<CR>	X	X	X	X	X	X	X	X	
		MAIN ZONE ON/OFF change	PW<CR>	PW<CR>	X	X	X	X	X	X	X	X	
		Return ZM Status	ON	ZM ON<CR>	X	X	X	X	X	X	X	X	
	Volume	MASTER VOLUME UP/DOWN, direct change to "dB"	OFF	ZM OFF<CR>	X	X	X	X	X	X	X	X	
		--00 to 98 by ASCII, 00=0dB, 98=0dB(MIN)	7	ZM<CR>	X	X	X	X	X	X	X	X	
	Channel Volume	FRONT Lch	MV<CR>	MV<CR>	X	X	X	X	X	X	X	X	
		--38 to 62 by ASCII, 00=0dB	FL UP	CVFL UP<CR>	X	X	X	X	X	X	X	X	
	Channel Volume	CENTER Rch	FR DOWN	CVFR DOWN<CR>	X	X	X	X	X	X	X	X	
		--38 to 62 by ASCII, 00=0dB	C UP	CV C UP<CR>	X	X	X	X	X	X	X	X	
SUB ZONE	POWER	POWER ON/STANDBY change	PW ON	PWON<CR>	X	X	X	X	X	X	X	X	
		Return PW Status	STANDBY	STANDBY<CR>	X	X	X	X	X	X	X	X	
		MAIN ZONE ON/OFF change	PW<CR>	PW<CR>	X	X	X	X	X	X	X	X	
		Return ZM Status	ON	ZM ON<CR>	X	X	X	X	X	X	X	X	
	Volume	MASTER VOLUME UP/DOWN, direct change to "dB"	OFF	ZM OFF<CR>	X	X	X	X	X	X	X	X	
		--00 to 98 by ASCII, 00=0dB, 98=0dB(MIN)	7	ZM<CR>	X	X	X	X	X	X	X	X	
	Channel Volume	FRONT Lch	MV<CR>	MV<CR>	X	X	X	X	X	X	X	X	
		--38 to 62 by ASCII, 00=0dB	FL UP	CVFL UP<CR>	X	X	X	X	X	X	X	X	
	Channel Volume	CENTER Rch	FR DOWN	CVFR DOWN<CR>	X	X	X	X	X	X	X	X	
		--38 to 62 by ASCII, 00=0dB	C UP	CV C UP<CR>	X	X	X	X	X	X	X	X	

[illegible]

[illegible]

Notes: Specifications subject to change without prior notice.

X = Available command for the model

— = NOT available command for the model

①

②

③: North America model only

④: Europe/Japan/China model Only

⑤: North America & Europe model Only

⑥: Europe model Only

⑦: Japan model Only

⑧

⑨: Requires to be set "Amp assign = Front B"