


# **AXPERT KS&MKS&V Communication Protocol**

<b>1</b>	<b>Message format</b> .....	<b>2</b>
<b>2</b>	<b>Inquiry Command</b> .....	<b>2</b>
2.1	QID<cr>: The inverter serial number inquiry.....	2
2.2	QSID<cr>: The inverter serial number inquiry (the length is more than 14).....	2
2.3	QVFW<cr>: Main CPU firmware version inquiry .....	2
2.4	QVFW2<cr> :Another CPU firmware version inquiry .....	2
2.5	QPIRI<cr>: Inverter rated information inquiry .....	2
2.6	QFLAG<cr>: Inverter flag status inquiry.....	5
2.7	QPIGS<cr>: Inverter general status parameters inquiry.....	5
2.8	QPGSn<cr>: Parallel Information inquiry (For 4K/5K) .....	7
2.9	QMOD<cr>: Inverter Mode inquiry.....	9
2.10	QPIWS<cr>: Inverter Warning Status inquiry .....	10
2.11	QDI<cr>: The default setting value information .....	12
2.12	QMCHGCR<cr>: Enquiry selectable value about max charging current.....	15
2.13	QMUCHGCR<cr>: Enquiry selectable value about max utility charging current.....	15
2.14	QOPM<cr>: Enquiry output mode (For 4000/5000).....	15
<b>3</b>	<b>Setting parameters Command</b> .....	<b>16</b>
3.1	PE<XXX>/PD<XXX><CRC><cr>: setting some status enable/disable.....	16
3.2	PF<cr>: Setting control parameter to default value.....	16
3.3	MCHGC<nnn><cr>: Setting max charging current.....	18
3.4	MNCHGC<mnnn><cr>: Setting max charging current (More than 100A) .....	18
3.5	MUCHGC<nnn><cr>: Setting utility max charging current.....	18
3.6	F<nn><cr>: Setting Inverter output rating frequency.....	18
3.7	POP<NN><cr>: Setting Inverter output source priority .....	19
3.8	PBCV<nn.n><cr>: Set battery re-charge voltage.....	19
3.9	PBDV<nn.n><cr>: Set battery re-discharge voltage.....	19
3.10	PCP<NN><cr>: Setting Inverter charger priority .....	20
3.11	PGR<NN><cr>: Setting Inverter grid working range .....	20
3.12	PBT<NN><cr>: Setting battery type .....	20
3.13	POPM<nn ><cr>: Set output mode (For 4000/5000) .....	20
3.14	PPCP<MNN><cr>: Setting parallel Inverter charger priority (For 4000/5000) .....	20
3.15	PSDV<nn.n><cr>: Setting battery cut-off voltage (Battery under voltage).....	21

3.16	PCVV<nn.n><cr>: Setting battery C.V. (constant voltage) charging voltage.....	21
3.17	PBFT<nn.n><cr>: Setting battery float charging voltage .....	21
3.18	PPVOKC<n ><cr>: Setting PV OK condition.....	21
3.19	PSPB<n ><cr>: Setting Solar power balance.....	21
3.20	QMN<cr>: Query model name(Just for Axpert V Series) .....	22
3.21	QGMN<cr>: Query general model name.....	22
3.22	PBEQE<n><cr>: Enable or disable battery equalization.....	23
3.23	PBEQT<nnn><cr>:Set battery equalization time .....	23
3.24	PBEQP<nnn><cr>:Set battery equalization period.....	23
3.25	PBEQV<nn.nn><cr>:Set battery equalization voltage .....	23
3.26	PBEQOT<nnn><cr>:Set battery equalization over time.....	24
3.27	PBEQA<n><cr>: Active or inactive battery equalization now .....	24
3.28	QBEQI<cr>: Battery equalization status parameters inquiry .....	24
3.29	PCVT<nnn><cr>: Setting max charging time at C.V stage (For 4000/5000, and 012, 013 model)....	25
3.30	POPLG<nn ><cr>: Setting operation logic (Only for Axpert KING) .....	25
4	<i>Appendix</i> .....	25
4.1	CRC calibration method .....	25

## Hardware connection:


### RS232 to RJ45 cable between computer and inverter



The connection between P1 and P2

P1	wire color	P2	Function
1	white and orange	2	TXD
2	blue	3	RXD
8	white and green	5	GND

### USB A to USB B cable between computer and Inverter



Standard-A plug			Standard-B plug		
1	+	+5V	1	+	+5V
2	D-	Data-	2	D-	Data-
3	D+	Data+	3	D+	Data+
4	-	GND	4	-	GND

## 1 Message format

Baud rate	Start bit	Data bit	Parity bit	Stop bit
2400	1	8	N	1

## 2 Inquiry Command

### 2.1 QID<cr>: The inverter serial number inquiry

Computer: QID <CRC><cr>

Inverter: (XXXXXXXXXXXXXXXXX <CRC><cr>

### 2.2 QSID<cr>: The inverter serial number inquiry (the length is more than 14)

Computer: QSID<CRC><cr>

Inverter: (NNXXXXXXXXXXXXXXXXXXXXX <CRC><cr>

NN: Serial number valid length, X: Serial number, invalid part is filled as '0', total X is 20.

### 2.3 QVFW<cr>: Main CPU firmware version inquiry

Computer: QVFW<CRC><cr>

Inverter: (VERFW:<NNNNN.NN><CRC><cr>

<N> is a HEX number from 0...9 or A...F.

Example:

Computer: QVFW<CRC><cr>

Inverter: (VERFW:00123.01<CRC><cr>

00123: firmware series number; 01: version

### 2.4 QVFW2<cr> :Another CPU firmware version inquiry

Computer: QVFW2<CRC><cr>

UPS: (VERFW2: <NNNNN.NN><CRC><cr>

<N> is a HEX number from 0...9 or A...F.

### 2.5 QPIRI<cr>: Inverter rated information inquiry

Computer: QPIRI<CRC><cr>

Inverter: (BBB.B CC.C DDD.D EE.E FF.F HHHH IIII JJ.J KK.K JJ.J KK.K LL.L O PP QQO  
O P Q R SS T U VV.V W X YYY Z<CRC><cr>

	Date	Description	Notes
A	(	Start byte	
B	BBB.B	Grid rating voltage	B is an integer ranging from 0 to 9. The units is V.

**AXPERT KS&MKS&V Communication Protocol**

C	CC.C	Grid rating current	C is an Integer ranging from 0 to 9. The units is A.
D	DDD.D	AC output rating voltage	D is an Integer ranging from 0 to 9. The units is V.
E	EE.E	AC output rating frequency	E is an Integer ranging from 0 to 9. The units is Hz.
F	FF.F	AC output rating current	F is an Integer ranging from 0 to 9. The unit is A.
H	HHHH	AC output rating apparent power	H is an Integer ranging from 0 to 9. The unit is VA.
I	III	AC output rating active power	I is an Integer ranging from 0 to 9. The unit is W.
J	JJ.J	Battery rating voltage	J is an Integer ranging from 0 to 9. The units is V.
K	KK.K	Battery re-charge voltage	K is an Integer ranging from 0 to 9. The units is V.
l	JJ.J	Battery under voltage	J is an Integer ranging from 0 to 9. The units is V.
M	KK.K	Battery bulk voltage	K is an Integer ranging from 0 to 9. The units is V.
N	LL.L	Battery float voltage	L is an Integer ranging from 0 to 9. The units is V.
O	O	Battery type	0: AGM 1: Flooded 2: User
P	PP	Current max AC charging current	P is an Integer ranging from 0 to 9 The units is A.
Q	QQ0	Current max charging current	Q is an Integer ranging from 0 to 9. The units is A.
O	O	Input voltage range	0: Appliance 1: UPS
P	P	Output source priority	0: Utility first 1: Solar first 2: SBU first <b>KING:</b> <b>0:Utility-&gt;Solar-&gt;Battery</b> <b>1:Solar-&gt;Utility-&gt;Battery</b> <b>2:Solar-&gt;Battery-&gt;Utility</b>
Q	Q	Charger source priority	0: Utility first 1: Solar first 2: Solar + Utility 3: Only solar charging permitted if battery voltage not too low <b>KING:</b>

## AXPERT KS&MKS&V Communication Protocol

			<p>0: Allow AC charge battery, and solar charge battery first and then power load.</p> <p>1: Disallow AC charge battery, and solar charge battery first and then power load.</p> <p>2: Allow AC charge battery, and solar power load first and then charge battery.</p> <p>3: Disallow AC charge battery, and solar power load first and then charge battery.</p>
R	R	Parallel max number	R is an Integer ranging from 0 to 9.
S	SS	Machine type	<p>00: Grid tie;</p> <p>01: Off Grid;</p> <p>10: Hybrid.</p>
T	T	Topology	<p>0: Transformerless</p> <p>1: Transformer</p>
U	U	Output mode	<p>00: single machine output</p> <p>01: parallel output</p> <p>02: Phase 1 of 3 Phase output</p> <p>03: Phase 2 of 3 Phase output</p> <p>04: Phase 3 of 3 Phase output</p>
V	VV.V	Battery re-discharge voltage	V is an Integer ranging from 0 to 9. The unit is V.
W	W	PV OK condition for parallel	<p>0: As long as one unit of inverters has connect PV, parallel system will consider PV OK;</p> <p>1: Only All of inverters have connect PV, parallel system will consider PV OK</p>
X	X	PV power balance	<p>0: PV input max current will be the max charged current;</p> <p>1: PV input max power will be the sum of the max charged power and loads power.</p>
Y	YYY	Max. charging time at C.V stage	Y is an Integer ranging from 0 to 9. The unit is minute.
Z	Z	Operation Logic(For Axpert KING)	<p>0: Automatically</p> <p>1: On-line mode</p> <p>2: ECO mode</p>

## 2.6 QFLAG<cr>: Inverter flag status inquiry

ExxxDxxx is the flag status. E means enable, D means disable

<b>x</b>	Control setting
<b>a</b>	Enable/disable silence buzzer or open buzzer
<b>b</b>	Enable/Disable bypass function
<b>c</b>	Allow/Forbidden bypass function
<b>j</b>	Enable/Disable power saving
<b>k</b>	Enable/Disable LCD display escape to default page after 1min timeout
<b>u</b>	Enable/Disable overload restart
<b>v</b>	Enable/Disable over temperature restart
<b>x</b>	Enable/Disable backlight on
<b>y</b>	Enable/Disable alarm on when primary source interrupt
<b>z</b>	Enable/Disable fault code record

Computer: QFLAG <CRC><cr>

Inverter: (ExxxDxxx <CRC><cr>

## 2.7 QPIGS<cr>: Inverter general status parameters inquiry

Computer: QPIGS <CRC><cr>

Inverter: (BBB.B CC.C DDD.D EE.E FFFF GGGG HHH III JJ.JJ KKK OOO TTTT EEEE  
UUU.U WW.WW PPPP b7b6b5b4b3b2b1b0 QQ VV MMMMM b10b9b8<CRC><cr>

	Data	Description	Notes	Axpert
a	(	Start byte		
b	BBB.B	Grid voltage	B is an Integer number 0 to 9. The units is V.	
C	CC.C	Grid frequency	C s an Integer number 0 to 9. The units is Hz.	
D	DDD.D	AC output voltage	D is an Integer number 0 to 9. The units is V.	
E	EE.E	AC output frequency	E is an Integer number from 0 to 9. The units is Hz.	
F	FFFF	AC output apparent power	F is an Integer number from 0 to 9. The units is VA	
G	GGGG	AC output active power	G is an Integer ranging from 0 to 9. The units is W.	
H	HHH	Output load percent	INVERTER: HHH is Maximum of W% or VA%. VA% is a percent of apparent power. W% is a percent of active power.	



## AXPERT KS&MKS&V Communication Protocol

			The unit is %.	
I	III	BUS voltage	I is an Integer ranging from 0 to 9. The units is V.	
j	JJ.JJ	Battery voltage	J is an Integer ranging from 0 to 9. The units is V.	
k	KKK	Battery charging current	K is an Integer ranging from 0 to 9. The units is A.	
o	OOO	Battery capacity	X is an Integer ranging from 0 to 9. The units is %.	
P	TTTT	Inverter heat sink temperature	T is an integer ranging from 0 to 9. The units is °C (NTC A/D value for AXPERT 1~3K)	
r	EEEE	PV Input current for battery.	E is an Integer ranging from 0 to 9. The units is A.	
t	UUU.U	PV Input voltage 1	U is an Integer ranging from 0 to 9. The units is V.	
u	WW.WW	Battery voltage from SCC	W is an Integer ranging from 0 to 9. The units is V.	
w	PPPPP	Battery discharge current	P is an Integer ranging from 0 to 9. The units is A.	
x	b7b6b5b4 b3b2b1b0	Inverter status	<p>b7: add SBU priority version, 1:yes,0:no</p> <p>b6: configuration status: 1: Change 0: unchanged</p> <p>b5: SCC firmware version 1: Updated 0: unchanged</p> <p>b4: Load status: 0: Load off 1:Load on</p> <p>b3: battery voltage to steady while charging</p> <p>b2: Charging status( Charging on/off)</p> <p>b1: Charging status( SCC charging on/off)</p> <p>b0: Charging status(AC charging on/off)</p> <p>b2b1b0:</p> <p>000: Do nothing</p> <p>110: Charging on with SCC charge on</p> <p>101: Charging on with AC charge on</p> <p>111: Charging on with SCC and AC charge on</p>	
y	QQ	Battery voltage offset for fans on	Q is an Integer ranging from 0 to 9. The unit is 10mV.	
z	VV	EEPROM version	V is an Integer ranging from 0 to 9.	
	MMMM M	PV Charging power	M is an Integer ranging from 0 to 9. The unit is watt.	
	b10b9b8	Inverter status	<p>b10: flag for charging to floating mode</p> <p>b9: Switch On</p>	

## AXPERT KS&MKS&V Communication Protocol

			b8: flag for dustproof installed(1-dustproof installed,0-no dustproof, only available for Axpert V series)	
--	--	--	--	--

### 2.8 QPGSn<cr>: Parallel Information inquiry (For 4K/5K)



Computer: QPGSn<CRC><cr>

Inverter: (A BBBB BBBB C DD EEE.E FF.FF GGG.G HH.HH III JJJ KKK LL.L MMM NNN OOO.O PPP QQQQ RRRR SSS b7b6b5b4b3b2b1b0 T U VVV WWW ZZ XX YYY<CRC><cr>

















	Date	Description	Notes
A	(	Start byte	
B	A	The parallel num whether exist	0: No exist. 1: Exist.
C	BBBBBBB BBBBBB	Serial number	B is an Integer ranging from 0 to 9.
D	C	Work mode	C is an character, refer to QMOD
E	DD	Fault code	D is an Integer ranging from 0 to 9.
F	EEE.E	Grid voltage	E is an Integer ranging from 0 to 9. The units is V.
G	FF.FF	Grid frequency	F is an Integer ranging from 0 to 9. The unit is Hz.
H	GGG.G	AC output voltage	G is an Integer ranging from 0 to 9. The units is V.
I	HH.HH	AC output frequency	H is an Integer ranging from 0 to 9. The unit is Hz.
J	III	AC output apparent power	I is an Integer number from 0 to 9. The units is VA
K	JJJ	AC output active power	J is an Integer ranging from 0 to 9. The units is W.
L	KKK	Load percentage	K is an Integer ranging from 0 to 9. The units is %.
M	LL.L	Battery voltage	L is an Integer ranging from 0 to 9. The unit is V.
N	MMM	Battery charging current	M is an Integer ranging from 0 to 9. The units is A.
O	NNN	Battery capacity	N is an Integer ranging from 0 to 9. The units is %.
P	OOO.O	PV Input Voltage	O is an Integer ranging from 0 to 9. The units is V.

## AXPERT KS&MKS&V Communication Protocol

Q	PPP	Total charging current	P is an Integer ranging from 0 to 9. The units is A.
R	QQQQQ	Total AC output apparent power	Q is an Integer ranging from 0 to 9. The units is VA.
S	RRRRR	Total output active power	R is an Integer ranging from 0 to 9. The units is W.
T	SSS	Total AC output percentage	S is an Integer ranging from 0 to 9. The units is %.
U	b7b6b5b4b3b2b1b0	Inverter Status	b7: 1 SCC OK, 0 SCC LOSS b6: 1 AC Charging 0 AC no charging b5: 1 SCC Charging 0 SCC no charging b4b3: 2 battery open, 1 battery under, 0 battery normal b2: 1 Line loss, 0 Line ok b1: 1 load on, 0 load off b0: configuration status: 1: Change 0: unchanged
V	T	Output mode	0: single machine 1: parallel output 2: Phase 1 of 3 phase output 3: Phase 2 of 3 phase output 4: Phase 3 of 3 phase output
W	U	Charger source priority	0: Utility first 1: Solar first 2: Solar + Utility 3: Solar only
X	VVV	Max charger current	V is an Integer ranging from 0 to 9. The units is A.
Y	WWW	Max charger range	W is an Integer ranging from 0 to 9. The units is A.
Z	ZZ	Max AC charger current	Z is an Integer ranging from 0 to 9. The units is A.
a	XX	PV input current for battery	X is an Integer ranging from 0 to 9. The units is A.
b	YYY	Battery discharge current	Y is an Integer ranging from 0 to 9. The units is A.

Fault Code	Fault Event	Icon on
01	Fan is locked	
02	Over temperature	

## AXPERT KS&MKS&V Communication Protocol

03	Battery voltage is too high	
04	Battery voltage is too low	
05	Output short circuited or Over temperature	
06	Output voltage is too high	
07	Over load time out	
08	Bus voltage is too high	
09	Bus soft start failed	
11	Main relay failed	
51	Over current inverter	
52	Bus soft start failed	
53	Inverter soft start failed	
54	Self-test failed	
55	Over DC voltage on output of inverter	
56	Battery connection is open	
57	Current sensor failed	
58	Output voltage is too low	
60	Inverter negative power	
71	Parallel version different	
72	Output circuit failed	
80	CAN communication failed	
81	Parallel host line lost	
82	Parallel synchronized signal lost	
83	Parallel battery voltage detect different	
84	Parallel Line voltage or frequency detect different	
85	Parallel Line input current unbalanced	
86	Parallel output setting different	

### 2.9 QMOD<cr>: Inverter Mode inquiry

Computer: QMOD<CRC><cr>

Inverter: (M<CRC><cr>

MODE	CODE(M)	Notes
Power On Mode	P	Power on mode
Standby Mode	S	Standby mode
Line Mode	L	Line Mode
Battery Mode	B	Battery mode
Bypass Mode	Y	Bypass mode
ECO mode	E	ECO mode
Fault Mode	F	Fault mode
Power saving Mode	H	Power saving Mode

Example:

Computer: QMOD<CRC><cr>

INVERTER: (L<CRC><cr>

Means: the current INVERTER mode is Grid mode.

## 2.10 QPIWS<cr>: Inverter Warning Status inquiry

Computer: QPIWS<CRC> <cr>














Inverter: (a0a1.....a30a31a32a33<CRC><cr>

a0,...,a31 is the warning status. a32a33 is fault code. If the warning is happened, the relevant bit will set 1, else the relevant bit will set 0. The following table is the warning code.






Bit	Warning	Description
a0	Reserved	
a1	Inverter fault	Fault
a2	Bus Over	Fault
a3	Bus Under	Fault
a4	Bus Soft Fail	Fault
a5	LINE_FAIL	Warning
a6	OPVShort	Warning
a7	Inverter voltage too low	Fault
a8	Inverter voltage too high	Fault
a9	Over temperature	Compile with a1, if a1=1,fault, otherwise warning
a10	Fan locked	Compile with a1, if a1=1,fault, otherwise warning
a11	Battery voltage high	Compile with a1, if a1=1,fault, otherwise warning
a12	Battery low alarm	Warning
a13	Overcharge	Fault
a14	Battery under shutdown	Warning

## AXPERT KS&MKS&V Communication Protocol

a15	Battery derating	Warning
a16	Over load	Compile with a1, if a1=1,fault, otherwise warning
a17	Eeprom fault	Warning
a18	Inverter Over Current	Fault
a19	Inverter Soft Fail	Fault
a20	Self Test Fail	Fault
a21	OP DC Voltage Over	Fault
a22	Bat Open	Fault
a23	Current Sensor Fail	Fault
a24	Battery Short	Fault
a25	Power limit	Warning
a26	PV voltage high	Warning/Fault
a27	MPPT overload fault	Fault
a28	MPPT overload warning	Warning
a29	Battery too low to charge	Warning
a30	DC/DC Over Current	Fault
a31	Reserved	
a32a33	Fault code	(For Axpert KING)

Fault Code	Fault Event	Icon on
01	Fan is locked	
02	Over temperature	
03	Battery voltage is too high	
04	Battery voltage is too low	
05	Output short circuited or Over temperature	
06	Output voltage is too high	
07	Over load time out	
08	Bus voltage is too high	
09	Bus soft start failed	
11	Main relay failed	
51	Over current inverter	
52	Bus soft start failed	
53	Inverter soft start failed	

## AXPERT KS&MKS&V Communication Protocol

54	Self-test failed	
55	Over DC voltage on output of inverter	
56	Battery connection is open	
57	Current sensor failed	
58	Output voltage is too low	
60	Inverter negative power	
71	Parallel version different	
72	Output circuit failed	
80	CAN communication failed	
81	Parallel host line lost	
82	Parallel synchronized signal lost	
83	Parallel battery voltage detect different	
84	Parallel Line voltage or frequency detect different	
85	Parallel Line input current unbalanced	
86	Parallel output setting different	

### 2.11 QDI<cr>: The default setting value information

Computer: QDI<CRC><cr>

Inverter: (BBB.B CC.C 00DD EE.E FF.F GG.G HH.H II J K L M N O P Q R S T U V W YY.Y X

Z aaa<CRC><cr>

	Data	Description	Notes	AXPERT							
A	(	Start byte									
B	BBB.B	AC output voltage	B is an Integer ranging from 0 to 9. The units is V.	Default 230.0							
C	CC.C	AC output frequency	C is an Integer ranging from 0 to 9. The units is Hz.	Default 50.0							
D	00DD	Max AC charging current	D is an Integer ranging from 0 to 9. The unit is A.	<table border="1"> <tr> <td>KS-1000</td> <td rowspan="3">20A</td> </tr> <tr> <td>MKS-1000-12</td> </tr> <tr> <td>MKS-1000-24</td> </tr> <tr> <td>VP-3000</td> <td rowspan="2">25A</td> </tr> <tr> <td>VM-3000</td> </tr> </table>	KS-1000	20A	MKS-1000-12	MKS-1000-24	VP-3000	25A	VM-3000
KS-1000	20A										
MKS-1000-12											
MKS-1000-24											
VP-3000	25A										
VM-3000											

**AXPERT KS&MKS&V Communication Protocol**

				<table border="1"> <tr><td>KS-2000</td><td rowspan="7">30A</td></tr> <tr><td>KS-3000</td></tr> <tr><td>KS-4000</td></tr> <tr><td>KS-5000</td></tr> <tr><td>MKS-2000-24</td></tr> <tr><td>MKS-3000-24</td></tr> <tr><td>MKS-2000-24 Plus</td></tr> <tr><td>MKS-3000-24 Plus</td></tr> <tr><td>MKS-1000-48</td><td rowspan="5">15A</td></tr> <tr><td>MKS-2000-48</td></tr> <tr><td>MKS-3000-48</td></tr> <tr><td>MKS-2000-48 Plus</td></tr> <tr><td>MKS-3000-48 Plus</td></tr> </table>	KS-2000	30A	KS-3000	KS-4000	KS-5000	MKS-2000-24	MKS-3000-24	MKS-2000-24 Plus	MKS-3000-24 Plus	MKS-1000-48	15A	MKS-2000-48	MKS-3000-48	MKS-2000-48 Plus	MKS-3000-48 Plus								
KS-2000	30A																										
KS-3000																											
KS-4000																											
KS-5000																											
MKS-2000-24																											
MKS-3000-24																											
MKS-2000-24 Plus																											
MKS-3000-24 Plus																											
MKS-1000-48	15A																										
MKS-2000-48																											
MKS-3000-48																											
MKS-2000-48 Plus																											
MKS-3000-48 Plus																											
E	EE.E	Battery Under voltage	E is an Integer ranging from 0 to 9. The unit is V.																								
F	FF.F	Charging float voltage	F is an Integer ranging from 0 to 9. The unit is V.																								
G	GG.G	Charging bulk voltage	G is an Integer ranging from 0 to 9. The unit is V.																								
H	HH.H	Battery default re-charge voltage	H is an Integer ranging from 0 to 9. The units is V.	11.5/23/46 for 12/24/48V unit.																							
I	II	Max charging current	I is an Integer ranging from 0 to 9. The units is A.	<table border="1"> <tr><td>KS Series</td><td>50A</td></tr> <tr><td>MKS-1000-12</td><td rowspan="4">25A 20A</td></tr> <tr><td>MKS-1000-24</td></tr> <tr><td>MKS-1000-48</td></tr> <tr><td>MKS-2000-48</td></tr> <tr><td>MKS-3000-48</td><td rowspan="2">50A</td></tr> <tr><td>VP-3000</td></tr> <tr><td>VP-5000</td><td>40A</td></tr> <tr><td>VM-3000</td><td rowspan="2">30A</td></tr> <tr><td>MKS-2000-24</td></tr> <tr><td>MKS-3000-24</td><td rowspan="5">60A</td></tr> <tr><td>MKS-4000</td></tr> <tr><td>MKS-5000</td></tr> <tr><td>MKS-2000-24 Plus</td></tr> <tr><td>MKS-3000-24 Plus</td></tr> <tr><td>MKS-2000-48 Plus</td></tr> <tr><td>MKS-3000-48 Plus</td></tr> </table>	KS Series	50A	MKS-1000-12	25A 20A	MKS-1000-24	MKS-1000-48	MKS-2000-48	MKS-3000-48	50A	VP-3000	VP-5000	40A	VM-3000	30A	MKS-2000-24	MKS-3000-24	60A	MKS-4000	MKS-5000	MKS-2000-24 Plus	MKS-3000-24 Plus	MKS-2000-48 Plus	MKS-3000-48 Plus
KS Series	50A																										
MKS-1000-12	25A 20A																										
MKS-1000-24																											
MKS-1000-48																											
MKS-2000-48																											
MKS-3000-48	50A																										
VP-3000																											
VP-5000	40A																										
VM-3000	30A																										
MKS-2000-24																											
MKS-3000-24	60A																										
MKS-4000																											
MKS-5000																											
MKS-2000-24 Plus																											
MKS-3000-24 Plus																											
MKS-2000-48 Plus																											
MKS-3000-48 Plus																											



**AXPERT KS&MKS&V Communication Protocol**

				VM-5000	
				VM-3000 Plus	
J	J	AC input voltage range	J is an Integer ranging from 0 to 1. No unit	Default 0 for <b>appliance</b> range <b>KING: Default 1 for UPS range.</b>	
K	K	Output source priority	K is an Integer ranging from 0 to 1. No unit	Default 0 for utility first <b>KING: Utility-&gt;Solar-&gt;Battery</b>	
L	L	Charger source priority	L is an Integer ranging from 0 to 1. No unit	Default 0 for Utility first <b>KING: Allow AC charge battery, solar charge battery first and then power load.</b>	
M	M	Battery type	M is an Integer ranging from 0 to 1. No unit	Default 0 for AGM	
N	N	Enable/disable silence buzzer or open buzzer	N is an Integer ranging from 0 to 1. No unit	Default 0 for enable buzzer	
O	O	Enable/Disable power saving	O is an Integer ranging from 0 to 1. No unit	Default 0 for disable power saving	
P	P	Enable/Disable overload restart	P is an Integer ranging from 0 to 1. No unit	Default 0 for disable overload restart	
Q	Q	Enable/Disable over temperature restart	Q is an Integer ranging from 0 to 1. No unit	Default 0 for disable over temperature restart	
R	R	Enable/Disable LCD backlight on	R is an Integer ranging from 0 to 1. No unit	Default 1 for enable LCD backlight on	
S	S	Enable/Disable alarm on when primary source interrupt	S is an Integer ranging from 0 to 1. No unit	Default 1 for enable alarm on when primary source interrupt	
T	T	Enable/Disable fault code record	T is an Integer ranging from 0 to 1. No unit	Default 0 for disable fault code record	
U	U	Overload bypass	U is an Integer ranging from 0 to 1. No unit	<del>Reserved</del> Default 0 for disable overload bypass function	
V	V	Enable/Disable LCD display escape to default page after 1min timeout	V is an Integer ranging from 0 to 1. No unit	<del>Reserved</del> Default 1 for LCD display escape to default page	

W	W	<b>Output mode</b>	W is an Integer ranging from 0 to 4. No unit	Default 0 for single output unit
Y	YY.Y	<b>Battery re-discharge voltage</b>	W is an Integer ranging from 0 to 9. The unit is V For LIYUAN MKS Plus LV: The unit is %	13.5/27/54 for 12/24/48V unit. For LIYUAN MKS Plus LV: Default is 90%
X	X	<b>PV OK condition for parallel</b>	X is an Integer ranging from 0 to 1	0: As long as one unit of inverters has connect PV, parallel system will consider PV OK;
Z	Z	<b>PV power balance</b>	X is an Integer ranging from 0 to 1	0: PV input max current will be the max charged current;
a	aaa	<b>Max. charging time at C.V stage</b>	a is an Integer ranging from 0 to 1	0: means automatically
b	b	<b>Operation logic</b>	b is an Integer ranging from 0 to 1	0: automatically

**2.12 QMCHGCR<cr>: Enquiry selectable value about max charging current**

Computer: QMCHGCR<CRC><cr>

Inverter: (AAA BBB CCC DDD.....<CRC><cr>

More value can be added, make sure there is a space character between every value.

**2.13 QMUCHGCR<cr>: Enquiry selectable value about max utility charging current**

Computer: QMUCHGCR<CRC><cr>

Inverter: (AAA BBB CCC DDD.....<CRC><cr>

More value can be added, make sure there is a space character between every value.

**2.14 QOPM<cr>: Enquiry output mode (For 4000/5000)**

Computer: QOPM<CRC><cr>

Inverter: (nn<CRC><cr>

nn:

00: single machine output

01: parallel output

02: Phase 1 of 3 Phase output

03: Phase 2 of 3 Phase output

04: Phase 3 of 3 Phase output

### 3 Setting parameters Command

#### 3.1 PE<XXX>/PD<XXX><CRC><cr>: setting some status enable/disable

Computer: PE<XXX>/PD<XXX><CRC><cr>

Inverter: (ACK<CRC><cr> if INVERTER accepts this command, otherwise, responds (NAK<cr> PExxxPDxxx set flag status. PE means enable, PD means disable

<b>x</b>	Control setting
<b>a</b>	Enable/disable silence buzzer or open buzzer
<b>b</b>	Enable/Disable bypass function
<b>c</b>	Allow/Forbidden bypass function
<b>j</b>	Enable/Disable power saving
<b>k</b>	Enable/Disable LCD display escape to default page after 1min timeout
<b>u</b>	Enable/Disable overload restart
<b>v</b>	Enable/Disable over temperature restart
<b>x</b>	Enable/Disable backlight on
<b>y</b>	Enable/Disable alarm on when primary source interrupt
<b>z</b>	Enable/Disable fault code record

#### 3.2 PF<cr>: Setting control parameter to default value

Computer: PF<CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<CRC><cr>

All Inverter parameters set to default value.

x	Parameter setting		
	Parameter	Default value	
1	AC output voltage	230.0V	
2	AC output frequency	50.0Hz	
3	Max charging current	KS Series	50A
		VP-3000	
		VP-5000	
		MKS-1000-12	20A
		MKS-1000-24	
		MKS-1000-48	
		MKS-2000-48	
		MKS-3000-48	
		MKS-2000-24	30A
MKS-3000-24			

**AXPERT KS&MKS&V Communication Protocol**

		<table border="1"> <tr><td>VM-3000</td><td>40A</td></tr> <tr><td>MKS-4000</td><td rowspan="8">60A</td></tr> <tr><td>MKS-5000</td></tr> <tr><td>MKS-2000-24 Plus</td></tr> <tr><td>MKS-3000-24 Plus</td></tr> <tr><td>MKS-2000-48 Plus</td></tr> <tr><td>MKS-3000-48 Plus</td></tr> <tr><td>VM-5000</td></tr> <tr><td>VM-3000 Plus</td></tr> </table>	VM-3000	40A	MKS-4000	60A	MKS-5000	MKS-2000-24 Plus	MKS-3000-24 Plus	MKS-2000-48 Plus	MKS-3000-48 Plus	VM-5000	VM-3000 Plus															
VM-3000	40A																											
MKS-4000	60A																											
MKS-5000																												
MKS-2000-24 Plus																												
MKS-3000-24 Plus																												
MKS-2000-48 Plus																												
MKS-3000-48 Plus																												
VM-5000																												
VM-3000 Plus																												
	Max utility charging current	<table border="1"> <tr><td>KS-1000</td><td rowspan="3">20A</td></tr> <tr><td>MKS-1000-12</td></tr> <tr><td>MKS-1000-24</td></tr> <tr><td>VP-3000</td><td>25A</td></tr> <tr><td>VM-3000</td><td>25A</td></tr> <tr><td>KS-2000</td><td rowspan="10">30A</td></tr> <tr><td>KS-3000</td></tr> <tr><td>KS-4000</td></tr> <tr><td>KS-5000</td></tr> <tr><td>MKS-2000-24</td></tr> <tr><td>MKS-3000-24</td></tr> <tr><td>MKS-2000-24 Plus</td></tr> <tr><td>MKS-3000-24 Plus</td></tr> <tr><td>VP-5000</td></tr> <tr><td>VM-5000</td></tr> <tr><td>VM-3000 Plus</td><td rowspan="5">15A</td></tr> <tr><td>MKS-1000-48</td></tr> <tr><td>MKS-2000-48</td></tr> <tr><td>MKS-3000-48</td></tr> <tr><td>MKS-2000-48 Plus</td></tr> <tr><td>MKS-3000-48 Plus</td></tr> </table>	KS-1000	20A	MKS-1000-12	MKS-1000-24	VP-3000	25A	VM-3000	25A	KS-2000	30A	KS-3000	KS-4000	KS-5000	MKS-2000-24	MKS-3000-24	MKS-2000-24 Plus	MKS-3000-24 Plus	VP-5000	VM-5000	VM-3000 Plus	15A	MKS-1000-48	MKS-2000-48	MKS-3000-48	MKS-2000-48 Plus	MKS-3000-48 Plus
KS-1000	20A																											
MKS-1000-12																												
MKS-1000-24																												
VP-3000	25A																											
VM-3000	25A																											
KS-2000	30A																											
KS-3000																												
KS-4000																												
KS-5000																												
MKS-2000-24																												
MKS-3000-24																												
MKS-2000-24 Plus																												
MKS-3000-24 Plus																												
VP-5000																												
VM-5000																												
VM-3000 Plus	15A																											
MKS-1000-48																												
MKS-2000-48																												
MKS-3000-48																												
MKS-2000-48 Plus																												
MKS-3000-48 Plus																												
4	AC input voltage range	0: Appliance range																										
5	Output source priority	0: Utility first <b>KING: Utility-&gt;Solar-&gt;Battery</b>																										
6	Battery re-charge voltage	11.5/23/46 for 12/24/48V unit.																										
7	Charger source priority	0: Utility first <b>KING: Allow AC charge battery, solar charge battery first and then power load.</b>																										
8	Battery type	0: AGM <b>KING: 2 for USE</b>																										
9	Enable/disable buzzer alarm	1: Enable buzzer alarm																										

10	Enable/Disable power saving	0: Disable power saving
11	Enable/Disable overload restart	0: Disable overload restart
12	Enable/Disable over temperature restart	0: Disable over temperature restart
13	Enable/Disable LCD backlight on	1: Enable LCD backlight on
14	Enable/Disable alarm on when primary source interrupt	1: Enable beep on when primary source interrupt
15	Enable/Disable overload bypass when overload happened in battery mode	0: Disable overload bypass
16	Enable/Disable LCD display escape to default page after 1min timeout	1: Enable LCD display escape to default page
17	Output mode	0: single output(for 4K/5K)
18	float charging voltage	13.5/27/54 for 12/24/48V unit.
19	Bulk charging voltage	14.1/28.2/56.4 for 12/24/48V unit.
20	Battery cut-off voltage	10.5/21/42 for 12/24/48V unit.
21	Battery re-discharge voltage	13.5/27/54 for 12/24/48V unit.

Note: The correct default value can be gain by QDI command.

### **3.3 MCHGC<nnn><cr>: Setting max charging current**

Computer: MCHGC<nnn><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<CRC><cr>

Setting value can be gain by QMCHGCR command.

### **3.4 MNCHGC<mnnn><cr>: Setting max charging current (More than 100A)**

Computer: MNCHGC<mnnn><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<CRC><cr>

Setting value can be gain by QMCHGCR command.

nnn is max charging current, m is parallel number.

### **3.5 MUCHGC<nnn><cr>: Setting utility max charging current**

Computer: MUCHGC<nnn><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<CRC><cr>

Setting value can be gain by QMUCHGCR command.

### **3.6 F<nn><cr>: Setting Inverter output rating frequency**

Computer: F<nn><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds

(NAK<CRC><cr>

Set UPS output rating frequency to 50Hz.or 60Hz

### **3.7 POP<NN><cr>: Setting Inverter output source priority**

Computer: POP<NN><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<CRC><cr>

Set output source priority, 00 for utility first, 01 for solar first, 02 for SBU priority

**KING:**

**00:Utility->Solar->Battery**

**01:Solar->Utility->Battery**

**02:Solar->Battery->Utility**

### **3.8 PBCV<nn.n><cr>: Set battery re-charge voltage**

Computer: PBCV<nn.n><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<CRC><cr>

12V unit: 11V/11.3V/11.5V/11.8V/12V/12.3V/12.5V/12.8V

24V unit: 22V/22.5V/23V/23.5V/24V/24.5V/25V/25.5V

48V unit: 44V/45V/46V/47V/48V/49V/50V/51V

**Model 012,013,023:**

**44V/45V/46V/47V/48V/49V/50V/51V/52V/53V/54V/55V/56V/57V**

**Model 024:**

**22V/22.5V/23V/23.5V/24V/24.5V/25V/25.5V/26V/26.5V/27V/27.5V/28V/28.5V**

### **3.9 PBDV<nn.n><cr>: Set battery re-discharge voltage**

Computer: PBDV<nn.n><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<CRC><cr>

12V unit: 00.0V/12V/12.3V/12.5V/12.8V/13V/13.3V/13.5V/13.8V/14V/14.3V/14.5

24V unit: 00.0V/24V/24.5V/25V/25.5V/26V/26.5V/27V/27.5V/28V/28.5V/29V

48V unit: 00.0V/48V/49V/50V/51V/52V/53V/54V/55V/56V/57V/58V

**Model 012,013,023:**

**00.0V/48V/49V/50V/51V/52V/53V/54V/55V/56V/57V/58V/59V/60V/61V/62V/63V/64V**

**Model 024:**

**00.0V/24V/24.5V/25V/25.5V/26V/26.5V/27V/27.5V/28V/28.5V/29V/29.5V/30V/30.5V/31V/31.5V/32V**

00.0V means battery is full(charging in float mode).

### **3.10 PCP<NN><cr>: Setting Inverter charger priority**

Computer: PCP<NN><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<CRC><cr>

Set output source priority:

00 for utility first, 01 for solar first, 02 for solar and utility, 03 for only solar charging

**KING:**

**0: Allow AC charge battery, and solar charge battery first and then power load.**

**1: Disallow AC charge battery, and solar charge battery first and then power load.**

**2: Allow AC charge battery, and solar power load first and then charge battery.**

**3: Disallow AC charge battery, and solar power load first and then charge battery.**

### **3.11 PGR<NN><cr>: Setting Inverter grid working range**

Computer: PGR<NN><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<cr>

Set Inverter grid working range, 00 for appliance, 01 for UPS

### **3.12 PBT<NN><cr>: Setting battery type**

Computer: PBT<NN><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<CRC><cr>

Set Inverter grid working range, 00 for AGM, 01 for Flooded battery, 02 for user-defined.

### **3.13 POPM<nn ><cr>: Set output mode (For 4000/5000)**

Computer: POPM <nn ><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<CRC><cr>

nn:

00: single machine output

01: parallel output

02: Phase 1 of 3 Phase output

03: Phase 2 of 3 Phase output

04: Phase 3 of 3 Phase output

### **3.14 PPCP<MNN><cr>: Setting parallel Inverter charger priority (For 4000/5000)**

Computer: PCP<MNN><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<CRC><cr>

00 for utility first, 01 for solar first, 02 for solar and utility, 03 for solar only

**KING:**

- 0: Allow AC charge battery, and solar charge battery first and then power load.
- 1: Disallow AC charge battery, and solar charge battery first and then power load.
- 2: Allow AC charge battery, and solar power load first and then charge battery.
- 3: Disallow AC charge battery, and solar power load first and then charge battery.

M is parallel machine num.

### **3.15 PSDV<nn.n><cr>: Setting battery cut-off voltage (Battery under voltage)**

Computer: **PSDV** <nn.n><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<CRC><cr>

nn.n: 40.0V ~ 48.0V for 48V unit, 40.0V ~ 54.0V for 64V unit(model 012,013,023)

20.0V~27.0V for model 024.

### **3.16 PCVV<nn.n><cr>: Setting battery C.V. (constant voltage) charging voltage**

Computer: **PCVV** <nn.n><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<CRC><cr>

nn.n: 48.0V ~ 58.4V for 48V unit

012,013,023 model: 48.0V~64.0V

024 mode: 24.0V~32.0V

### **3.17 PBFT<nn.n><cr>: Setting battery float charging voltage**

Computer: **PBFT** <nn.n><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<CRC><cr>

nn.n: 48.0V ~ 58.4V for 48V unit

012,013,023 model: 48.0V~64.0V

024 model:24.0V~32.0V

### **3.18 PPVOKC<n ><cr>: Setting PV OK condition**

Computer: **PPVOKC** <n><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<CRC><cr>

0: As long as one unit of inverters has connected PV, parallel system will consider PV OK;

1: Only all of inverters have connected PV, parallel system will consider PV OK.

### **3.19 PSPB<n ><cr>: Setting Solar power balance**

Computer: **PSPB**<n><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<CRC><cr>

0: PV input max current will be the max charged current;



1: PV input max power will be the sum of the max charged power and loads power.

**3.20 QMN<cr>: Query model name(Just for Axpert V Series)**

Computer: QMN<CRC><cr>

Inverter: (MMMM-NNNN-BB-VV-SSSS<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<cr>

MMMM: model name, NNNN: Rated output VA, BB: Battery voltage, VV: HV/LV, SSSS: Special flag

Note: The length of MMMM&NNNN&SSSS may be different for different models

MMMM-NNNN-BB-VV-SSSS list as below:

1	VP-5000	
2	VM-5000	
3	VP-3000	
4	VM-3000	
5	MKS+-2000-48-LV-LY	

**3.21 QGMN<cr>: Query general model name**

Computer: QGMN<CRC><cr>

Inverter: (NNN<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<cr>

NNN: model name number

NNN list as below:

001	VP-5000	
002	VM-5000	
003	VP-3000	
004	VM-3000	
005	MKS+-2000-48-LV-LY	
006	MLV 3KVA	Axpert MLV 3K-24
007	PLV 3KVA	Axpert PLV 3K-24
008	MKS HV 24V 3KVA	Axpert MKS 3KP
009	KS HV 24V 3KVA	Axpert KS 3KP
010	MKS HV 24V 5KVA	Axpert MKS 5KP
011	KS HV 24V 5KVA	Axpert KS 5KP
012	MKS HV 48V 4K/5KVA/64V	Axpert MKS 4K/5K 64VDC
013	KS HV 48V 4/5KVA/64V	Axpert KS 4K/5K 64VDC
014	Axpert MKS 4/5KVA	Axpert MKS 4K/5K
015	Axpert KS 4/5KVA	Axpert KS 4K/5K
016	ALFA M-5000	ALFA M-5000

017	ALFA P-5000	ALFA P-5000
018	Axpert Plus Duo/Tri 5KVA	Axpert Plus Duo/Tri 5KVA
019	EPS 5KVA	Axpert EPS 5KW
020	EPS M5K	Axpert EPS M-5KW
021	EPS 3/3 5KW	Axpert EPS 33-5KW
022	AXPERT MKS II 5KW	Axpert MKS II 5KW
023	AXPERT KING 5KW	AXPERT KING 5KW
024	AXPERT KING 3KW	AXPERT KING 3KW

**3.22 PBEQE<n><cr>: Enable or disable battery equalization**

Computer: PBEQE<n><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<cr>

Enable or Disable battery equalization, n=1 means enable; n=0 means disable;

**3.23 PBEQT<nnn><cr>:Set battery equalization time**

Computer: PBEQT<nnn><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<cr>

Set equalization time, nnn is in the range of 5 to 900minute, every click increase or decrease 5minute.

**3.24 PBEQP<nnn><cr>:Set battery equalization period**

Computer: PBEQP<nnn><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<cr>

Set equalization period, nnn is in the range of 0 to 90day, every click increase or decrease 1day.

**3.25 PBEQV<nn.nn><cr>:Set battery equalization voltage**

Computer: PBEQV<nn.nn><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<cr>

Set equalization time, nn.nn is in the range as below.

VP5000 and VM5000: 48.0~61.0V;

VP3000 and VM3000 and VM-3000 PLUS: 24.0~31.5V;

Axpert KING 5KW(Model 023): 48V~64V

**Axpert KING 3KW(Model 024): 24V~32V**

**3.26 PBEQOT<nnn><cr>:Set battery equalization over time**

Computer: PBEQOT<nnn><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<cr>

Set equalization time, nnn is in the range of 5 to 900minute, every click increase or decrease 5minute.

**3.27 PBEQA<n><cr>: Active or inactive battery equalization now**

Computer: PBEQA<n><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<cr>

Active or inactive battery equalization now, n=1 means active; n=0 means inactive;

**3.28 QBEQI<cr>: Battery equalization status parameters inquiry**

Computer: QBEQI <CRC><cr>

Inverter: (B CCC DDD EEE FFF GG.GG HHH III J KKKK <CRC><cr>

	Data	Description	Notes	Axpert
a	(	Start byte		
b	B	Enable or Disable equalization	B is an Integer number 0 to 1..	
C	CCC	equalization time	C s an Integer number 0 to 9. The unit is Minute.	
D	DDD	equalization period	D is an Integer number 0 to 9. The unit is day.	
E	EEE	equalization max current	E is an Integer number from 0 to 9. The unit is A.	
F	FFF	reserved	reserved	
G	GG.GG	equalization voltage	G is an Integer ranging from 0 to 9. The units is V.	
H	HHH	reserved	reserved	
I	III	equalization over time	I is an Integer ranging from 0 to 9. The unit is Minute.	
j	J	equalization active	J is an Integer ranging from 0 to 1.	

		status		
k	KKKK	reserved	reserved	

**3.29 PCVT<nnn><cr>: Setting max charging time at C.V stage (For 4000/5000, and 012, 013**

**model)**

Computer: PCVT<nnn><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<CRC><cr>

Setting value can be gain by QMCHGCR command.

nnn is max charging time at C.V stage, the range is from 000 to 900 but in multiples of 5. 000 means automatically.

**3.30 POPLG<nn ><cr>: Setting operation logic (Only for Axpert KING)**

Computer: POPLG <nn.n><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<CRC><cr>

nn:00: automatically, 01: On-line mode, 02: ECO mode

**4 Appendix**

**4.1 CRC calibration method**



CRC. c

---