



RT-20 Universal Disc Player RS-232 Control Guide

Harman Specialty Group 3 Oak Park, Bedford, MA, 01730-1413 USA
Customer Service: Telephone: 781-280-0300 | Service Fax: 781-280-0499 | www.lexicon.com

Part No. 070-17224 | Rev 0 | 03/05

Lexicon

RT-20 Universal Disc Player RS-232 Control Guide

Manufactured under license from Dolby Laboratories. "Dolby" and the double-D symbol are trademarks of Dolby Laboratories. Confidential unpublished works. © 1992-1997 Dolby Laboratories. All rights reserved.

"HDMI," the HDMI logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC.

"DTS" and "DTS 96/24" are trademarks of Digital Theater Systems, Inc.

"SACD" and the SACD logo are trademarks of Sony Electronics, Inc.

"TosLink" is a registered trademark of Toshiba Corporation.

"Lexicon," "LOGIC7," and the L7 logo are registered trademarks of Harman International Industries, Inc. U.S. Patent Nos. D454,553; D454,860; 5,796,844; 5,870,480 and other worldwide patents issued and pending.

This product incorporates copyright protection technology that is protected by method claims of certain U.S. patents and other intellectual property rights owned by Macrovision Corporation and other rights owners. Use of this copyright protection technology must be authorized by Macrovision Corporation, and is intended for home and other limited viewing uses only unless otherwise authorized by Macrovision Corporation. Reverse engineering or disassembly is prohibited.

© 2005 Harman Specialty Group. All rights reserved.

This document should not be construed as a commitment on the part of Harman Specialty Group. The information it contains is subject to change without notice. Harman Specialty Group assumes no responsibility for errors that may appear within this document.



3 Oak Park
Bedford, MA 01730-1413 USA
Telephone: 781-280-0300
Fax: 781-280-0490
www.lexicon.com

Customer Service

Telephone: 781-280-0300
Sales Fax: 781-280-0495
Service Fax: 781-280-0499

Product Shipments

16 Progress Road
Billerica, MA 01821-5730 USA

harman specialty group

Part No. 070-17224 | Rev 0 | 03/05

Table of Contents

| | |
|---|----------|
| 1. Introduction | 3 |
| 1-1. Purpose | 3 |
| 1-2. References | 3 |
| 2. System Description | 3 |
| 2-1. Overview | 3 |
| 2-2. Block Diagram | 3 |
| 2-3. RT-20 RS-232 Connector Pin Definition | 3 |
| 3. Detailed Description | 4 |
| 3-1. Connection format | 4 |
| 3-1-1. Physical connection | 4 |
| 3-2. Transmission data packet formats | 4 |
| 3-2-1. Transmission data packets from the HOST to the RT-20 | 4 |
| 3-2-1-1. Command Packets | 4 |
| 3-2-1-2. Status Request Packets | 4 |
| 3-2-2. Response data packets from the RT-20 to the HOST | 5 |
| 3-2-2-1. ACK/NAK Response Packets | 5 |
| 3-2-2-2. Auto Status Feedback Packets | 5 |
| 3-3. Data Transaction Sequencing and Timing Requirements | 6 |
| 3-3-1. Data Packet Transaction Sequencing Requirements | 6 |
| 3-3-2. Data Transaction Timing Requirements | 6 |
| 3-3-3. Specific Requirements for Auto Status Feedback | 6 |
| 3-3-4. Example of the transactions | 6 |
| 3-3-5. Examples of HOST/RT-20 handshaking | 7 |
| 3-3-5-1. Example of successful handshaking | 7 |
| 3-3-5-2. Examples of handshaking errors | 7 |
| 3-4. Commands | 8 |
| 3-4-1. HOST Command list | 8 |
| 3-4-2. Specific Commands | 10 |
| 3-5. Status Request and Status Response Data Packets | 11 |
| 3-5-1. HOST Status request and Status Response/feedback list AST Layer: 1 | 11 |
| 3-5-2. HOST Status request and Status Response/feedback list AST Layer: 2 | 11 |
| 3-5-3. HOST Status request and Status Response/feedback list AST Layer: 3 | 12 |
| 3-5-4. Special Status request and Status Response list AST Layer: None | 13 |
| 3-6. Status Feedback | 14 |
| 3-7. Data Packet COMMAND List | 16 |

1. Introduction

1-1. Purpose

This document was written as a reference specification for the Lexicon RT-20 Universal Disc Player RS-232 interface.

1-2. References


Refer to the RT-20 User Guide for information about the RS-232 connector and RT-20 functionality.
RT-20 User Guide p/n 070-17261.

2. System Description

2-1. Overview

The RT-20 RS-232 interface has been designed as a Master-Slave communication protocol, in which the RT-20 is the slave device. The Master-system controller is referred to as the HOST device.

2-2. Block Diagram



2-3. RT-20 RS-232 Connector Pin Definition

The RT-20 serial RS-232 connector is a male 9-pin D-sub connector. The pin definitions are listed below.


| Signal name | D-Sub Pin |
|--------------|-----------|
| N.C. | 1 |
| TxD (output) | 2 |
| RxD (input) | 3 |
| N.C. | 4 |
| GND | 5 |
| N.C. | 6 |
| N.C. | 7 |
| N.C. | 8 |
| N.C. | 9 |

3. Detailed Description

The RS-232 hardware interface specification between the HOST and the RT-20 is described below.

3-1. Connection format

3-1-1. Physical connection



(Serial Port settings)

Baud Rate : 9600bps
Data Bits : 8bit
Parity : None
Stop bit : 1bit
Handshaking : None

3-2. Transmission data packet formats

3-2-1. Transmission data packets from the HOST to the RT-20

There are two kinds of transmission data packets that are described below.

3-2-1-1. Command Packets

The Command Packets are provided for the Host Controller to request the RT-20 to perform a specific action.


Start character : '@'
COMMAND : see "Data Packet COMMAND List" on page 16
End character (CR) : 0Dh



3-2-1-2. Status Request Packets

The Status Request packets are provided for the Host Controller to request the RT-20 to report specific operating statuses.

Start character : '@'
Request status : see "Status Request and Status Response Data Packets" on page 11
Request character : '?'
End character (CR) : 0Dh



3-2-2. Response data packets from the RT-20 to the HOST

The RT-20 can respond to the HOST in a synchronous and asynchronous mode. The two different response packets are described below.

3-2-2-1. ACK/NAK Response Packets

The RT-20 provides an ACK (acknowledge) response to the HOST when the RT-20 has received a correct command packet, and the HOST command packet has requested no other status data.

Start character : '@', ACK : 06h, End character (CR) : 0Dh

| | | |
|-------|-----|-----|
| start | ACK | CR |
| '@' | 06h | 0Dh |

The RT-20 will send a NAK response packet if the RT-20 has received an incorrect HOST command packet.

Start character : '@', NAK : 15h, End character (CR) : 0Dh

| | | |
|-------|-----|-----|
| start | NAK | CR |
| '@' | 15h | 0Dh |


3-2-2-2. Auto Status Feedback Packets

The RT-20 will send to the HOST asynchronous status feedback data packets when applicable RT-20 status changes. The asynchronous status has been divided into levels or groups. The HOST can enable each of the status feedback groups independently.

Start character : '@'

Answer character : see "Status Feedback" on page 14

End character (CR) : 0Dh



3-3. Data Transaction Sequencing and Timing Requirements

3-3-1. Data Packet Transaction Sequencing Requirements

The RT-20/Host Data Packet Transactions can be described in one of the three following sequences:

- The HOST sends a command data packet and the RT-20 responds with an ACK or a NAK data packet.
- The HOST sends a status request data packet and the RT-20 responds with the corresponding status data packet or NAK if the request is invalid.
- The RT-20 sends an auto status feedback data packet if the corresponding RT-20 status has changed (The HOST is not required to respond to the RT-20).

3-3-2. Data Transaction Timing Requirements

Each of the HOST/RT-20 data transactions must meet the following timing requirements:

- Response packet transmission (ACK, NAK or Status) from the RT-20 will be initiated approximately within 50ms following the end of the HOST command packet and transmission will be completed within 500ms following the end of the HOST command packet.
- The HOST should not transmit a command or status request data packet until the RT-20 has responded to the previously sent command. A new command or status request data packet may be initiated if the RT-20 has been unresponsive for at least 1s.
- The RT-20 will complete an auto status feedback data packet within 500ms.


3-3-3. Specific Requirements for Auto Status Feedback

The following items detail specific requirements for the Auto Status Feedback data transactions.

The RT-20 Auto Status Feedback has been grouped into three layers: 1, 2 and 3:

- Layer 1 is the highest priority status. Layer 2 is the second highest priority. Layer 3 is assigned the lowest priority.
- Each layer is independently enabled or disabled by the HOST. The RT-20 will disable all three layers by default.
- The RT-20 initiates the Auto Status Feedback transaction when the corresponding RT-20 status has changed.


3-3-4. Example of the transactions



Example Data Packet Transactions


3-3-5. Examples of HOST/RT-20 handshaking

3-3-5-1. Example of successful handshaking



The RT-20 may reply with an ACK instead of requested status, if the RT-20 cannot send the requested status immediately.

3-3-5-2. Examples of handshaking errors



3-4. Commands

The following tables detail the available HOST commands.

3-4-1. HOST Command list

| Command | | | Reply from RT-20 |
|------------|--------|---------|------------------|
| POWER | OFF | "PWR:1" | ACK |
| | ON | "PWR:2" | |
| TRAY | Toggle | "TRY:0" | ACK |
| | OPEN | "TRY:1" | |
| | CLOSE | "TRY:2" | |
| STOP | | "STP:0" | ACK |
| PLAY | | "PLY:0" | ACK |
| PAUSE | | "PPS:0" | ACK |
| SLOW FWD | | "PSF:0" | ACK |
| SLOW REV | | "PSR:0" | ACK |
| FAST FWD | | "PFF:0" | ACK |
| FAST REV | | "PFR:0" | ACK |
| NEXT | | "GOT:1" | ACK |
| PREV | | "GOT:2" | ACK |
| STEP | Toggle | "PST:0" | ACK |
| SEARCH | Toggle | "SCH:0" | ACK |
| REPEAT | Step | "RPT:0" | ACK |
| A-B REPEAT | Step | "A-B:0" | ACK |
| PROGRAM | Toggle | "PRG:0" | ACK |
| RANDOM | Step | "RDM:0" | ACK |
| MARKER | Toggle | "MRK:0" | ACK |
| PAGE | + | "PAG:1" | ACK |
| | - | "PAG:2" | |

| Command | | | Reply from RT-20 |
|-----------------|--------|---------|------------------|
| SETUP | Toggle | "OSD:0" | ACK |
| TOP MENU | Toggle | "MNU:1" | ACK |
| MENU | Toggle | "MNU:0" | ACK |
| SUBTITLE | | "SBT:0" | ACK |
| AUDIO | | "AUD:0" | ACK |
| DISPLAY (OSD) | Toggle | "DIP:0" | ACK |
| DIMMER (FL/LCD) | Step | "DIM:0" | ACK |
| | OFF | "DIM:1" | |
| | DIMMER | "DIM:2" | |
| | ON | "DIM:3" | |
| CURSOR | RETURN | "CUR:0" | ACK |
| | UP | "CUR:1" | |
| | DOWN | "CUR:2" | |
| | LEFT | "CUR:3" | |
| | RIGHT | "CUR:4" | |
| NUMBER | 0 | "NUM:0" | ACK |
| | 1 | "NUM:1" | |
| | 2 | "NUM:2" | |
| | 3 | "NUM:3" | |
| | 4 | "NUM:4" | |
| | 5 | "NUM:5" | |
| | 6 | "NUM:6" | |
| | 7 | "NUM:7" | |
| | 8 | "NUM:8" | |
| | 9 | "NUM:9" | |
| | +10 | "NUM:P" | |
| ENTER | | "ENT:0" | ACK |
| CLEAR | | "CLR:0" | ACK |

| Command | | | Reply from RT-20 |
|-----------|-------------|---------|------------------|
| SACD MODE | Toggle | "SCD:0" | ACK |
| | SACD Stereo | "SCD:1" | |
| | SACD Multi | "SCD:2" | |
| | SACD CD | "SCD:3" | |
| | | | |
| HP MODE | Toggle | "HPM:0" | ACK |

| Command | | | Reply from RT-20 |
|------------------------|------------|---------|------------------|
| TV SYSTEM | Toggle | "TVS:0" | ACK |
| PROGRESSIVE /INTERLACE | Toggle | "PGR:0" | ACK |
| ASPECT | Letter Box | "ASP:1" | ACK |
| | Panscan | "ASP:2" | |
| | Wide | "ASP:3" | |
| | Squeeze | "ASP:4" | |
| VIDEO MUTE | Toggle | "VMT:0" | ACK |
| | Mute OFF | "VMT:1" | |
| | Mute ON | "VMT:2" | |
| VIDEO ADJ | Toggle | "VAJ:0" | ACK |
| ZOOM | Toggle | "ZOM:0" | ACK |

| Command | | | Reply from RT-20 |
|------------------|---------|---------|------------------|
| HDMI ON/OFF | Toggle | "HDM:0" | ACK |
| | OFF | "HDM:1" | |
| | ON | "HDM:2" | |
| HDMI RESET | | "HDR:0" | ACK |
| CONDITION MEMORY | | "CND:0" | ACK |
| AUTO POWER OFF | Disable | "ATP:1" | ACK |
| | Enable | "ATP:2" | |
| REMOTE CODE | DVD 1 | "RC6:1" | ACK |
| | DVD 2 | "RC6:2" | |
| ECO MODE | Disable | "ECO:1" | ACK |
| | Enable | "ECO:2" | |

3-4-2. Specific Commands

| Command from Host | | | | | Reply from RT-20 |
|--|--|----------|----------|----------|------------------|
| Auto status feedback (The RT-20 default will disable all auto status feedback.) | "AST:x" (x = '0' ~ '7') ex)"@AST:7r" (r = CR) | | | | ACK |
| | 'x' | Layer1 | Layer2 | Layer3 | |
| | '0' | Disable. | Disable. | Disable. | |
| | '1' | Enable. | Disable. | Disable. | |
| | '2' | Disable. | Enable. | Disable. | |
| | '3' | Disable. | Disable. | Enable. | |
| | '4' | Enable. | Enable. | Disable. | |
| | '5' | Enable. | Disable. | Enable. | |
| | '6' | Disable. | Enable. | Enable. | |
| | '7' | Enable. | Enable. | Enable. | |

3-5. Status Request and Status Response Data Packets

3-5-1. HOST Status request and Status Response/feedback list

AST Layer: 1

| Status request | | Status answer and feedback | |
|----------------|---------|----------------------------|---------|
| POWER | "PWR:?" | OFF | "PWR:1" |
| | | ON | "PWR:2" |
| TRAY MODE | "TRY:?" | OPEN | "TRY:1" |
| | | CLOSE | "TRY:2" |
| PLAY MODE | "MOD:?" | TOC (LOADING) | "MOD:0" |
| | | STOP | "MOD:1" |
| | | PLAY | "MOD:2" |
| | | PAUSE | "MOD:3" |
| | | SLOW FWD | "MOD:4" |
| | | SLOW REV | "MOD:5" |
| | | FAST FWD | "MOD:6" |
| | | FAST REV | "MOD:7" |
| DISC | "DSC:?" | UNDEFINE | "DSC:-" |
| | | No DISC | "DSC:0" |
| | | CD | "DSC:1" |
| | | VCD | "DSC:2" |
| | | DVD-VIDEO | "DSC:3" |
| | | DVD-AUDIO | "DSC:4" |
| | | SACD | "DSC:5" |
| | | MP3 / JPEG | "DSC:6" |

3-5-2. HOST Status request and Status Response/feedback list

AST Layer: 2

| Status request | | Status answer and feedback | |
|----------------|---------|----------------------------|---------|
| REPEAT | "RPT:?" | OFF | "RPT:1" |
| | | Track/Chapter REPEAT | "RPT:2" |
| | | All/Group/Title REPEAT | "RPT:3" |
| A-B REPEAT | "A-B:?" | OFF | "A-B:1" |
| | | SET A | "A-B:2" |
| | | SET A-B | "A-B:3" |
| RANDOM | "RDM:?" | OFF | "RDM:1" |
| | | ON | "RDM:2" |

| Status request | | Status answer and feedback | |
|----------------|---------|----------------------------|-----------|
| COUNTER | "TTL:?" | TITLE | "TTL:???" |
| | "GRP:?" | GROUP | "GRP:???" |
| | "CHP:?" | CHAPTER | "CHP:???" |
| | "TRK:?" | TRACK | "TRK:???" |

| Status request | | Status answer and feedback | |
|-----------------|------|----------------------------|---------|
| DIMMER (FL/LCD) | None | OFF | "DIM:1" |
| | | DIMMER | "DIM:2" |
| | | ON | "DIM:3" |

| Status request | | Status answer and feedback | |
|----------------|---------|----------------------------|---------|
| SACD MODE | "SCD:?" | SACD Stereo | "SCD:1" |
| | | SACD Multi | "SCD:2" |
| | | SACD CD | "SCD:3" |

| Status request | | Status answer and feedback | |
|------------------------|---------|----------------------------|---------|
| TV SYSTEM | "TVS:?" | NTSC | "TVS:1" |
| | | PAL | "TVS:2" |
| | | MULTI | "TVS:3" |
| PROGRESSIVE /INTERLACE | "PGR:?" | Progressive | "PGR:1" |
| | | Interlace | "PGR:2" |
| ASPECT | "ASP:?" | Letter Box | "ASP:1" |
| | | Panscan | "ASP:2" |
| | | Wide | "ASP:3" |
| | | Squeeze | "ASP:4" |
| VIDEO MUTE | "VMT:?" | Mute OFF | "VMT:1" |
| | | Mute ON | "VMT:2" |

| Status request | | Status answer and feedback | |
|----------------|---------|----------------------------|---------|
| HDMI ON/OFF | "HDM:?" | HDMI OFF | "HDM:1" |
| | | HDMI ON | "HDM:2" |
| AUTO POWER OFF | "ATP:?" | Disable | "ATP:1" |
| | | Enable | "ATP:2" |
| REMOTE CODE | "RC6:?" | DVD1 | "RC6:1" |
| | | DVD2 | "RC6:2" |
| ECO MODE | "ECO:?" | Disable | "ECO:1" |
| | | Enable | "ECO:2" |

3-5-3. HOST Status request and Status Response/feedback list

AST Layer: 3

| Send Slave status | | example | Expected reply from Host |
|-------------------|---------|---------------------------|--------------------------|
| COUNTER | "TIM:?" | TIME (DVD, DVD-Audio) | "TIH:H.MM.SS" |
| | | TIME (CD, SACD, MP3, VCD) | "TIM:MMM.SS" |

3-5-4. Special Status request and Status Response list

AST Layer: None

| Status request | | Status answer and feedback | | | |
|----------------------|---------|----------------------------|----------|----------|-----------|
| Auto status feedback | "AST:?" | Layer1 | Layer2 | Layer3 | send data |
| | | Disable. | Disable. | Disable. | "AST:0" |
| | | Enable. | Disable. | Disable. | "AST:1" |
| | | Disable. | Enable. | Disable. | "AST:2" |
| | | Disable. | Disable. | Enable. | "AST:3" |
| | | Enable. | Enable. | Disable. | "AST:4" |
| | | Enable. | Disable. | Enable. | "AST:5" |
| | | Disable. | Enable. | Enable. | "AST:6" |
| | | Enable. | Enable. | Enable. | "AST:7" |

| Status request | | Status answer and feedback | |
|---------------------|---------|----------------------------|--------------------|
| Read Version Number | "RV0:?" | RS-232C Soft Version | "VR0:????????????" |
| | "RV1:?" | B/E Soft Version | "VR1:????????????" |
| | "RV2:?" | Panel Soft Version | "VR2:????????????" |
| | "RV3:?" | AUDIO DSP Soft Version | "VR3:????????????" |

3-6. Status Feedback

| | Auto Status feedback Layer | Request | Status | Notes |
|--------------|-------------------------------|------------|-----------|---------------|
| A-B REPEAT | Layer2 | @A-B:?x0d, | @A-B:1x0d | OFF |
| | | | @A-B:2x0d | SET A |
| | | | @A-B:3x0d | SET A-B |
| ASPECT | Layer2 | @ASP:?x0d, | @ASP:1x0d | LetterBox |
| | | | @ASP:2x0d | Panscan |
| | | | @ASP:3x0d | Wide |
| | | | @ASP:4x0d | SQUEEZE |
| AutoPowerOff | Layer2 | @ATP:?x0d, | @ATP:1x0d | OFF |
| | | | @ATP:2x0d | ON |
| REMOTE CODE | Layer2 | @RC6:?x0d, | @RC6:1x0d | DVD1 |
| | | | @RC6:2x0d | DVD2 |
| EcoMode | Layer2 | @ECO:?x0d, | @ECO:1x0d | OFF |
| | | | @ECO:2x0d | ON |
| PLAY MODE | Layer1 | @MOD:?x0d | @MOD:6x0d | PLAY FAST FWD |
| | | | @MOD:7x0d | PLAY FAST REV |
| | | | @MOD:2x0d | PLAY |
| | | | @MOD:3x0d | PLAY PAUSE |
| | | | @MOD:4x0d | PLAY SLOW FWD |
| | | | @MOD:5x0d | PLAY SLOW REV |
| | | | @MOD:1x0d | STOP |
| | | | @MOD:0x0d | TOC (LOADING) |
| POWER | Layer1 | @PWR:?x0d, | @PWR:1x0d | OFF |
| | | | @PWR:2x0d | ON |
| RANDOM | Layer2 | @RDM:?x0d, | @RND:1x0d | OFF |
| | | | @RND:2x0d | ON1 |
| | | | @RND:2x0d | ON2 |
| REPEAT | Layer2 | @RPT:0x0d, | @RPT:1x0d | OFF |
| | | | @RPT:2x0d | Rep1 |
| | | | @RPT:3x0d | Rep2 |
| | | | @RPT:3x0d | Rep3 |
| S.MODE | Layer2 | @SCD:?x0d, | @SCD:1x0d | SACD |
| | | | @SCD:2x0d | SACD |
| | | | @SCD:3x0d | SACDCD |
| TRAY | Layer1 | @TRY:?x0d, | @TRY:1x0d | OPEN |
| | | | @TRY:2x0d | CLOSE |
| NTSC/PAL | Layer2 | @TVS:?x0d, | @TVS:1x0d | NTSC |
| | | | @TVS:2x0d | PAL |
| | | | @TVS:3x0d | AUTO |
| VIDEO MUTE | Layer2 | @VMT:?x0d, | @VMT:1x0d | OFF |
| | | | @VMT:2x0d | ON |

| | Auto Status feedback Layer | Request | Status | Notes |
|---------------------------|-------------------------------|------------|-----------------|------------------------|
| DISC | Layer1 | @DSC:~x0d, | @DSC:-x0d | UNDEFINE (ERROR) |
| | | | @DSC:0x0d | NoDisc |
| | | | @DSC:1x0d | CD |
| | | | @DSC:2x0d | VCD |
| | | | @DSC:3x0d | DVD |
| | | | @DSC:4x0d | DVD Audio |
| | | | @DSC:5x0d | SACD |
| | | | @DSC:6x0d | MP3/JPEG |
| COUNTER | Layer2 | @TTL:~x0d | @TTL:???x0d | Title |
| | Layer2 | @GRP:~x0d | @GRP:???x0d | Group |
| | Layer2 | @CHP:~x0d | @CHP:???x0d | Chapter |
| | Layer2 | @TRK:~x0d | @TRK:???x0d | Track |
| | Layer3 | @TIM:~x0d | @TIH:~.~.~.~x0d | Time |
| | | | @TIM:~.~.~.~x0d | |
| PROGRESSIVE/ INTERLACE | Layer2 | @PGR:~x0d | @PGR:1x0d | Progressive |
| | | | @PGR:2x0d | Interlace |
| DIMMER (FL/LCD) | Layer2 | | @DIM:1x0d, | OFF |
| | | | @DIM:2x0d, | DIMMER |
| | | | @DIM:3x0d, | ON |
| HDMI ON/OFF | Layer2 | @HDM:~x0d | @HDM:1x0d | OFF |
| | | | @HDM:2x0d | ON |
| Read Ver Number | AST layer | @RV0:~x0d | @VR0:~x0d | RS-232C Ver. No. |
| | | @RV1:~x0d | @VR1:~x0d | BE Ver. No. |
| | | @RV2:~x0d | @VR2:~x0d | Panel ucom Ver. No. |
| | | @RV3:~x0d | @VR3:~x0d | DSP Ver. No. |
| | | | | |
| Auto status feedback | AST layer | @AST:~x0d | @AST:0x0d | all layer OFF |
| | | | @AST:1x0d | layer1 ON |
| | | | @AST:2x0d | layer2 ON |
| | | | @AST:3x0d | layer3 ON |
| | | | @AST:4x0d | layer1,layer2 ON |
| | | | @AST:5x0d | layer1,layer3 ON |
| | | | @AST:6x0d | layer2,layer3 ON |
| | | | @AST:7x0d | all layer ON |

3-7. Data Packet COMMAND List

| | COMMAND | Notes |
|------------------|------------|-----------|
| A-B REPEAT | @A-B:0x0d, | Step |
| ANGLE | @AGL:0x0d | Toggle |
| ASPECT | @ASP:1x0d, | LetterBox |
| | @ASP:2x0d | Panscan |
| | @ASP:3x0d | Wide |
| | @ASP:4x0d | SQUEEZE |
| AutoPowerOff | @ATP:1x0d, | OFF |
| | @ATP:2x0d | ON |
| AUDIO | @AUD:0x0d | Toggle |
| CLEAR | @CLR:0x0d | |
| CONDITION | @CND:0x0d | Toggle |
| RETURN CURSOR | @CUR:0x0d | RETURN |
| | @CUR:1x0d | UP |
| | @CUR:2x0d | DOWN |
| | @CUR:3x0d | LEFT |
| | @CUR:4x0d | RIGHT |
| DIMMER (FL/LCD) | @DIM:0x0d | Step |
| | @DIM:1x0d | OFF |
| | @DIM:2x0d | DIMMER |
| | @DIM:3x0d | ON |
| DISPLAY (OSD) | @DIP:0x0d | Toggle |
| REMOTE CODE | @RC6:1x0d | DVD1 |
| | @RC6:2x0d | DVD2 |
| EcoMode | @ECO:1x0d | OFF |
| | @ECO:2x0d | ON |
| ENTER | @ENT:0x0d | |
| GO TO TRACK | @GOT:1x0d | NEXT |
| | @GOT:2x0d | PREV |
| I.REPLAY SKIP | @IGT:1x0d | I.SKIP |
| | @IGT:2x0d | I.REPLY |
| MARKER | @MRK:0x0d | Toggle |
| MENU | @MNU:0x0d | Toggle |
| TOP MENU | @MNU:1x0d | Toggle |
| NUMBER | @NUM:0x0d | 0 |
| | @NUM:1x0d | 1 |
| | @NUM:2x0d | 2 |
| | @NUM:3x0d | 3 |
| | @NUM:4x0d | 4 |
| | @NUM:5x0d | 5 |
| | @NUM:6x0d | 6 |
| | @NUM:7x0d | 7 |
| | @NUM:8x0d | 8 |
| | @NUM:9x0d | 9 |

| | COMMAND | Notes |
|---------------------------|------------|---------------|
| | @NUM:P\x0d | +10 |
| SETUP | @OSD:0\x0d | Step |
| PAGE | @PAG:1\x0d | + |
| | @PAG:2\x0d | - |
| PLAY MODE | @PFF:0\x0d | PLAY FAST FWD |
| | @PFR:0\x0d | PLAY FAST REV |
| | @PLY:0\x0d | PLAY |
| | @PPS:0\x0d | PLAY PAUSE |
| | @PSF:0\x0d | PLAY SLOW FWD |
| | @PSR:0\x0d | PLAY SLOW REV |
| | @STP:0\x0d | STOP |
| PROGRAM | @PRG:0\x0d | Toggle |
| PROGRESSIVE/ INTERLACE | @PGR:0\x0d | Toggle |
| POWER | @PWR:1\x0d | OFF |
| | @PWR:2\x0d | ON |
| RANDOM | @RDM:0\x0d | Step |
| REPEAT | @RPT:0\x0d | Step |
| S.MODE | @SCD:0\x0d | Toggle |
| | @SCD:1\x0d | SACD Stereo |
| | @SCD:2\x0d | SACD Multi |
| | @SCD:3\x0d | SACDCD |
| SEARCH | @SCH:0\x0d | Toggle |
| STEP | @PST:0\x0d | Toggle |
| SUBTITLE | @SBT:0\x0d | Toggle |
| TRAY | @TRY:0\x0d | Toggle |
| | @TRY:1\x0d | OPEN |
| | @TRY:2\x0d | CLOSE |
| NTSC/PAL/AUTO | @TVS:0\x0d | Toggle |
| VIDEO ADJ | @VAJ:0\x0d | Toggle |
| VIDEO MUTE | @VMT:0\x0d | Toggle |
| | @VMT:1\x0d | OFF |
| | @VMT:2\x0d | ON |
| ZOOM | @ZOM:0\x0d | Toggle |
| INFORMATION | @INF:0\x0d | Toggle |
| HDMI ON/OFF | @HDM:0\x0d | Toggle |
| | @HDM:1\x0d | OFF |
| | @HDM:2\x0d | ON |
| HDMI RESET | @HDR:0\x0d | RESET |

| | COMMAND | Notes |
|-----------------------------|-----------|------------------|
| Auto status feedback | @AST:0x0d | all layer OFF |
| @AST:7x0d | @AST:1x0d | layer1 ON |
| | @AST:2x0d | layer2 ON |
| | @AST:3x0d | layer3 ON |
| | @AST:4x0d | layer1,layer2 ON |
| | @AST:5x0d | layer1,layer3 ON |
| | @AST:6x0d | layer2,layer3 ON |
| | @AST:7x0d | all layer ON |



Harman Specialty Group 3 Oak Park, Bedford, MA, 01730-1413 USA
Customer Service: Telephone: 781-280-0300 | Service Fax: 781-280-0499 | www.lexicon.com

Part No. 070-17224 | Rev 0 | 03/05