

Description	Group-Page	Description	Group-Page	Description	Group-Page
ABS BRAKE SYSTEM, BLEEDING	5-43	AIR TEMPERATURE SENSOR—PCM		ASSIST HANDLE, QUAD CAB	23-59
ABS WARNING LAMP	5-43	INPUT, INTAKE MANIFOLD	14-35	AUDIO SYSTEM	8F-1,8F-4
ABSOLUTE PRESSURE (MAP)		AIR TESTING TRANSMISSION CLUTCH		AUDIO SYSTEM, 8W-47	8W-1
SENSOR—2.5L ENGINE, MANIFOLD	14-58	AND BAND OPERATION	21-134,21-296	AUDIO SYSTEMS	8F-21
ABSOLUTE PRESSURE (MAP)		AIR TESTING TRANSMISSION CLUTCH		AUTO SHUTDOWN (ASD) RELAY—PCM	
SENSOR—3.9/5.2/5.9L ENGINES,		OPERATION	21-444	OUTPUT	14-40
MANIFOLD	14-57	AIRBAG CONTROL MODULE	8M-12,8M-3	AUTOMATIC BELT TENSIONER	7-8
ABSOLUTE PRESSURE (MAP)		AIRBAG MODULE, DRIVER SIDE	8M-2,8M-6	AUTOMATIC BELT TENSIONER 3.9L/5.9L	
SENSOR—4.7L V-8 ENGINE,		AIRBAG MODULE, PASSENGER SIDE	8M-3,8M-9	ENGINES	7-50
MANIFOLD	14-58	AIRBAG MODULE TRIM COVER, DRIVER		AUTOMATIC BELT TENSIONER—4.7L	
ABSOLUTE PRESSURE (MAP)		SIDE	8M-8	ENGINE	7-51
SENSOR—PCM INPUT, MANIFOLD	14-36	AIRBAG ON/OFF SWITCH, PASSENGER		AUTOMATIC DAY/NIGHT MIRROR	8T-5,8T-6
ABSORBER, SHOCK	2-16,2-24,2-8	SIDE	8M-12,8M-3	AUTOMATIC DAY/NIGHT MIRROR	
ABSORBERS, SHOCK	2-14,2-23,2-6	AIRBAG SYSTEM	8M-1,8M-4,8M-5	SYSTEM	8T-5
A/C APPLICATION TABLE	24-55	AIRBAG SYSTEM, 8W-43	8W-1	AUTOMATIC SHUTDOWN (ASD) RELAY	14-51
A/C, IDLER PULLEY—4.7L ENGINE NON	7-52	AJAR SWITCH, DOOR	8Q-3,8Q-4	AUTOMATIC SHUTDOWN (ASD) RELAY	
A/C PERFORMANCE	24-10	AJAR SWITCH, DRIVER DOOR	8U-2,8U-3	SENSE—PCM INPUT	14-34
ACCELERATION, CLUNKING NOISE		ALERT, TAMPER	8Q-2	AUTOMATIC TRANSMISSION, 42RE	21-84,21-85
DURING	3-20	ALIGNMENT	2-1,2-5	AUTOMATIC TRANSMISSION, 45RFE	21-416,
ACCELERATION, SHUDDER OR		ALIGNMENT, FOG LAMP	8L-9	21-417	
VIBRATION DURING	3-20	ALIGNMENT, HEADLAMP	8L-10,8L-7	AUTOMATIC TRANSMISSION, 46RE	21-247
ACCELERATOR PEDAL	14-24	ALIGNMENT SCREEN PREPARATION,		AUTOMATIC TRANSMISSION	
ACCESSORY BELT REPLACEMENT—4.7L		LAMP	8L-7	DIAGNOSIS	21-129,21-291
ENGINE	7-48	ALIGNMENT, VEHICLE PREPARATION		AUTOMATIC TRANSMISSION GENERAL	
ACCESSORY DRIVE BELT DIAGNOSIS	7-24	FOR HEADLAMP	8L-7	DIAGNOSIS, 45RFE	21-441
ACCESSORY DRIVE BELT TENSIONER—		ALIGNMENT, WHEEL	2-1,2-4	AUTOMATIC TRANSMISSION OIL	
2.5L	7-50	ALL-WHEEL ANTI-LOCK BRAKES, 8W-35	8W-1	COOLERS	7-8
ACCESSORY DRIVE BELT TENSION—		ALUMINUM THREAD REPAIR	21-150,21-312,	AXLE, 8 1/4	3-59
2.5L ENGINE	7-56		21-448	AXLE, 8 1/4 AND 9 1/4	3-59
ACCESSORY DRIVE BELT—2.5L ENGINE	7-47	AMBIENT TEMPERATURE SENSOR	8V-13,8V-4,	AXLE, 8 1/4 AND 9 1/4 INCH	3-100
ACCESSORY DRIVE BELT—3.9L/5.9L			8V-5	AXLE, 8 1/4 INCH	3-99
ENGINES	7-49	AMPERAGE TEST, FUEL PUMP	14-9	AXLE, 9 1/4 INCH	3-99
ACCESSORY DRIVE BELTS, ENGINE	7-5	AMPLIFIER, POWER	8F-14,8F-3,8F-8	AXLE, C205F	3-31,3-55
ACCUMULATOR: HEATING AND AIR		ANALYSIS, GEAR CONTACT PATTERN	3-53,3-97	AXLE COMPONENTS	3-48
CONDITIONING	24-2,24-23	ANALYZING ROAD TEST	21-131,21-293	AXLE DRIVESHAFTS, FRONT	3-18
ACCUMULATOR: TRANSMISSION AND		ANGLE MEASUREMENT PREPARATION,		AXLE, FRONT	3-36
TRANSFER CASE	21-117,21-223,	DRIVELINE	3-7	AXLE PINION GEAR DEPTH, 8 1/4	3-92
	21-278,21-392,21-481	ANGLE MEASUREMENT, PROPELLER		AXLE PINION GEAR DEPTH, 9 1/4	3-93
ACTION TEST MODE, CIRCUIT	25-2	SHAFT	3-7	AXLE, REAR	3-69
ACTUATOR, FRONT DOOR INSIDE		ANGLE, PROPELLER SHAFT JOINT	3-4	AXLE SEAL AND BEARING, 8 1/4 AND 9	
HANDLE	23-34	ANTENNA	8F-15,8F-4,8F-8	1/4	3-71
ACTUATOR, MODE DOOR VACUUM	24-44	ANTILOCK BRAKE BLEEDING, REAR		AXLE SHAFT	3-39,3-70
ACTUATOR, REAR DOOR INSIDE		WHEEL	5-37	AXLE SHAFT SEAL AND BEARING	3-39
HANDLE	23-40	ANTILOCK BRAKE SYSTEM	5-40	AXLE SKID PLATE, FRONT	13-8
ADAPTER HOUSING SEAL	21-453	ANTILOCK BRAKES	5-43	AXLE WITH LEAF SPRINGS,	
ADDITIONAL, COOLANT—ADDING	7-28	ANTI-LOCK BRAKES, 8W-34 REAR		ADJUSTMENT AT	3-17
ADDITIVES, COOLANT SELECTION	7-30	WHEEL	8W-1	AXLES, 8 1/4 AND 9 1/4	3-100,3-91
ADHESIVE LOCATIONS, STRUCTURAL	23-89	ANTI-LOCK BRAKES, 8W-35 ALL-WHEEL	8W-1	AXLES, 9 1/4	3-61
ADJUSTER AND MOTORS, POWER SEAT	8R-1,	ANTILOCK BRAKES, CONTROLLER	5-41,5-44	BACK, BENCH SEAT	23-9
	8R-2,8R-3	ANTILOCK BRAKES, CONTROLLER REAR		BACK, BUCKET SEAT	23-11
ADJUSTER, HYDRAULIC LASH	9-123,9-164	WHEEL	5-33	BACK, CONSOLE LID/SEAT	23-13
ADJUSTER NOISE DIAGNOSIS,		ANTILOCK BRAKES, FOUR WHEEL	5-40	BACK PAD/COVER, BENCH SEAT	23-10
HYDRAULIC LASH	9-131	ANTILOCK BRAKES, REAR WHEEL	5-32	BACK PAD/COVER, BUCKET SEAT	23-11
ADJUSTMENT AT AXLE WITH LEAF		ANTILOCK CONTROL ASSEMBLY	5-44	BACK PANEL TRIM, REAR CAB	23-51
SPRINGS	3-17	ANTILOCK, REAR WHEEL	5-32,5-36	BACKLASH, DIFFERENTIAL BEARING	
ADJUSTMENT, CENTER BEARING	3-17	A-PILLAR TRIM	23-50	PRELOAD AND GEAR	3-50,3-96
ADJUSTMENT, COMPASS VARIATION	8V-6	APPLICATION, BULB	8L-19	BACKLITE	23-6
ADJUSTMENT, FRONT BAND	21-396	APPLICATION, CLUTCH DISC	6-4	BACKLITE SLIDING VENT GLASS	23-52
ADJUSTMENT, REAR BAND	21-396	APPLICATION TABLE, A/C	24-55	BACK—CLUB CAB, REAR SEAT	23-14
ADJUSTMENT, REAR DOOR	23-61	AREA LEAKS—INSPECTION, REAR SEAL	9-12,	BACK-UP LAMP BULBS, TAIL, BRAKE,	
ADJUSTMENT, SHIFTER	21-530,21-560		9-131,9-217,9-71	TURN SIGNAL	8L-12
ADJUSTMENT, TRANSMISSION		ARM AND BLADE, WIPER	8K-2	BACK-UP LAMP, TAIL, STOP, TURN	
THROTTLE VALVE CABLE	21-226,21-394	ARM, LOWER SUSPENSION	2-10,2-18	SIGNAL	8L-16
ADJUSTMENTS, BAND	21-228	ARM, ROCKER	9-124	BALANCE, TIRE AND WHEEL	22-9
AERATION, COOLANT—LOW LEVEL	7-27	ARM, UPPER SUSPENSION	2-10,2-19	BALL JOINT, LOWER	2-15,2-7
AFTERMARKET REPAIR PRODUCTS	23-2	ARM, WIPER	8K-8	BALL JOINT, UPPER	2-15,2-8
AIR CLEANER ELEMENT (FILTER)	14-62	ARMING	8Q-1	BAND ADJUSTMENT, FRONT	21-396
AIR CONDITIONER CONTROL, HEATER	24-6	ARMREST UPPER INERTIA LATCH		BAND ADJUSTMENT, REAR	21-396
AIR CONDITIONER, HEATER	24-5	COVER, CENTER	23-13	BAND ADJUSTMENTS	21-228
AIR CONDITIONING/HEATER, 8W-42	8W-1	ARMREST/CONSOLE LATCH, CENTER	23-12	BAND OPERATION, AIR TESTING	
AIR CONTROL (IAC) MOTOR—2.5L		ARMS AND PUSH RODS, ROCKER	9-235,9-34,	TRANSMISSION CLUTCH	21-134,21-296
ENGINE, IDLE	14-56		9-51	BANDS	21-123,21-285
AIR CONTROL (IAC) MOTOR—3.9/5.2/		ARMS, ROCKER	9-157	BAR, STABILIZER	2-11,2-15,2-20,2-23,2-24,2-7
5.9L ENGINES, IDLE	14-56	ARMS, SUSPENSION	2-15,2-7	BAR, TORSION	2-17
AIR CONTROL (IAC) MOTOR—4.7L V-8		ASD AND FUEL PUMP RELAYS	14-49	BARS, TORSION	2-15
ENGINE, IDLE	14-56	ASH RECEIVER, INSTRUMENT PANEL	8E-20	BASE BRAKE BLEEDING	5-11
AIR CONTROL (IAC) MOTOR—PCM		ASSEMBLY, ANTILOCK CONTROL	5-44	BASE BRAKE SYSTEM	5-1,5-5
OUTPUT, IDLE	14-41	ASSEMBLY, CYLINDER HEAD	9-251	BASE BRAKES	5-31
AIR EXHAUSTER	23-44	ASSEMBLY, ENGINE	9-148,9-231,9-88	BASE COAT/CLEAR COAT FINISH	23-1
AIR EXHAUSTER—CAB	23-44	ASSEMBLY, FINAL	3-46,3-81	BATTERY	8A-1,8A-19,8A-21,8A-22,8A-5
AIR FLOW CHECK PROCEDURE,		ASSEMBLY, INPUT CLUTCH	21-470	BATTERY CABLES	8A-14,8A-3
THROTTLE BODY MINIMUM	14-50,14-51	ASSEMBLY, INSTRUMENT PANEL	8E-27	BATTERY CHARGING	8A-16
AIR TEMPERATURE SENSOR—2.5L		ASSEMBLY, LOW/REVERSE CLUTCH	21-481	BATTERY FEED (TCM)	21-438
ENGINE, INTAKE MANIFOLD	14-64	ASSEMBLY, PARK BRAKE PEDAL	5-22	BATTERY HOLD DOWNS	8A-18,8A-4
AIR TEMPERATURE SENSOR—3.9/5.2/		ASSEMBLY, PISTON AND CONNECTING		BATTERY REPLACEMENT, REMOTE	
5.9L ENGINES, INTAKE MANIFOLD	14-64	ROD	9-102,9-245,9-252	KEYLESS ENTRY TRANSMITTER	8P-8
AIR TEMPERATURE SENSOR—4.7L V-8		ASSEMBLY, SOLENOID AND PRESSURE		BATTERY TEMPERATURE SENSOR	8C-2,8C-5
ENGINE, INTAKE MANIFOLD	14-64	SWITCH	21-438,21-450	BATTERY TRAY	8A-20,8A-4

Description	Group-Page	Description	Group-Page	Description	Group-Page
BATTERY VOLTAGE—PCM INPUT	14-34	BODY CODE PLATE	Intro-2	BREAKER, CIRCUIT; POWER WINDOW SYSTEMS	8S-2,8S-3
BEARING, 8 1/4 AND 9 1/4 AXLE SEAL	3-71	BODY COMPONENT SERVICE	23-17	BREATHER/FILTER, CRANKCASE	25-29
BEARING ADJUSTMENT, CENTER	3-17	BODY COMPONENTS	23-18	BUCKET SEAT	23-10
BEARING, AXLE SHAFT SEAL	3-39	BODY GAP AND FLUSH MEASUREMENTS	23-106	BUCKET SEAT BACK	23-11
BEARING, CENTER	3-11,3-2	BODY LUBRICATION	23-20	BUCKET SEAT BACK PAD/COVER	23-11
BEARING, CLUTCH RELEASE	6-3	BODY MINIMUM AIR FLOW CHECK PROCEDURE, THROTTLE	14-50,14-51	BUCKET SEAT CUSHION/COVER	23-11
BEARING NOISE	3-35,3-68	BODY OPENING DIMENSIONS	23-113	BUCKET SEAT TRACK	23-11
BEARING, OUTPUT SHAFT FRONT	21-159, 21-322	BODY SIDE MOLDINGS	23-45	BUCKLE, SEAT BELT	23-53
BEARING, OUTPUT SHAFT REAR	21-159,21-321	BODY, THROTTLE	14-42	BUFFING, AND POLISHING, FINESSE SANDING	23-1
BEARING, PILOT	6-14	BODY, VALVE	21-155,21-160,21-222,21-229, 21-261,21-317,21-322,21-388,21-396,21-424, 21-449,21-464,21-479,21-98	BULB APPLICATION	8L-19
BEARING PRELOAD AND GEAR BACKLASH, DIFFERENTIAL	3-50,3-96	BODY—2.5L ENGINE, THROTTLE	14-53	BULB, CARGO LAMP	8L-12
BEARING, RELEASE	6-14	BODY—3.9/5.2/5.9L ENGINES, THROTTLE	14-52	BULB, CENTER HIGH MOUNTED STOP LAMP (CHMSL)	8L-12
BEARINGS, CAMSHAFT	9-100,9-242,9-45	BODY—4.7L V-8 ENGINE, THROTTLE	14-53	BULB, DOME LAMP	8L-13
BEARINGS, CRANKSHAFT MAIN	9-100,9-144, 9-180,9-210,9-243,9-45,9-5,9-65	BOOSTER, MASTER CYLINDER/POWER	5-8	BULB, FOG LAMP	8L-11
BEARINGS, DIFFERENTIAL SIDE	3-41,3-75	BOOSTER, POWER BRAKE	5-15,5-3	BULB, FRONT SIDE MARKER LAMP	8L-12
BEARINGS—FITTING, CONNECTING ROD	9-142, 9-22,9-227,9-81	BOOT, FLOOR SHIFT	23-54	BULB, HEADLAMP	8L-11
BEARINGS—FITTING, CRANKSHAFT MAIN	9-227,9-25,9-82	BOOT SEAL	19-14	BULB, LICENSE PLATE LAMP	8L-13
BELT BUCKLE, SEAT	23-53	BOOTS, C/V JOINT	3-22,3-30	BULB, OVERHEAD CONSOLE READING LAMP	8L-13
BELT DIAGNOSIS, ACCESSORY DRIVE	7-24	BORE—HONING, CYLINDER	9-135,9-16,9-221, 9-76	BULB SERVICE, LAMP	8L-11
BELT REPLACEMENT—4.7L ENGINE, ACCESSORY	7-48	BOX, CARGO	23-48	BULB, UNDERHOOD LAMP	8L-13
BELT RETRACTOR, FRONT SEAT	23-52	BOX COMPONENTS, GLOVE	8E-25	BULBS, PARK AND TURN SIGNAL LAMP	8L-12
BELT RETRACTOR—CLUB CAB, REAR SEAT	23-54	BOX, GLOVE	8E-24	BULBS, TAIL, BRAKE, TURN SIGNAL AND BACK-UP LAMP	8L-12
BELT RETRACTOR—QUAD CAB, SEAT	23-52	BOX LAMP AND SWITCH, GLOVE	8E-23	BUMPER, FRONT	13-1
BELT SWITCH, DRIVER SEAT	8U-2,8U-5	BOX LATCH STRIKER, GLOVE	8E-23	BUMPER, REAR	13-2
BELT TENSIONER 3.9L/5.9L ENGINES, AUTOMATIC	7-50	BOX, REAR STORAGE	23-56	BUMPERS	13-1
BELT TENSIONER, AUTOMATIC	7-8	BOX SEAL, CARGO	23-49	BURNT FLUID, CAUSES OF	21-129,21-291, 21-441
BELT TENSIONER—2.5L, ACCESSORY DRIVE	7-50	B-PILLAR TRIM	23-50	BUS (+/-) CIRCUITS-PCM OUTPUTS, CCD	14-40
BELT TENSIONER—4.7L ENGINE, AUTOMATIC	7-51	BRACKET, INSTRUMENT PANEL CENTER SUPPORT	8E-19	BUSHING AND SEAL, REAR RETAINER	21-509, 21-536
BELT TENSION—2.5L ENGINE, ACCESSORY DRIVE	7-56	BRACKET, REARVIEW MIRROR SUPPORT	23-57	BUSHING, DISTRIBUTOR DRIVE SHAFT	9-242, 9-94
BELT WEATHERSTRIP, FRONT DOOR INNER	23-34	BRAKE BLEEDING, BASE	5-11	BUSHING, OUTPUT SHAFT	21-6
BELT WEATHERSTRIP, FRONT DOOR OUTER	23-34	BRAKE BLEEDING, REAR WHEEL ANTILOCK	5-37	BUSHING, OVERDRIVE HOUSING	21-159,21-321
BELT WEATHERSTRIP, REAR DOOR INNER	23-40	BRAKE BOOSTER, POWER	5-15,5-3	BUSHING, REAR HOUSING YOKE	21-43
BELT WEATHERSTRIP, REAR DOOR OUTER	23-41	BRAKE CABLE, FRONT PARK	5-21	BYPASS HOSE—3.9/5.9L ENGINES, WATER PUMP	7-37
BELT/BUCKLE—CLUB CAB, REAR SEAT	23-53	BRAKE CABLE TENSIONER, PARK	5-29	BYPASS—3.9/5.9L ENGINES, WATER PUMP	7-6
BELT—2.5L ENGINE, ACCESSORY DRIVE	7-47	BRAKE CABLES, REAR PARK	5-22	BYPASS—4.7L, WATER PUMP	7-6
BELT—3.9L/5.9L ENGINES, ACCESSORY DRIVE	7-49	BRAKE CALIPER, DISC	5-16,5-24	C205F AXLE	3-31,3-55
BELTS, ENGINE ACCESSORY DRIVE	7-5	BRAKE DRUM	5-10	CAB ASSIST HANDLE, QUAD	23-59
BENCH SEAT	23-8	BRAKE DRUM MACHINING	5-12	CAB BACK PANEL TRIM, REAR	23-51
BENCH SEAT BACK	23-9	BRAKE FLUID	5-30	CAB, REAR SEAT BACK—CLUB	23-14
BENCH SEAT BACK PAD/COVER	23-10	BRAKE FLUID CONTAMINATION	5-10	CAB, REAR SEAT BELT RETRACTOR—CLUB	23-54
BENCH SEAT CUSHION/COVER	23-10	BRAKE FLUID LEVEL	5-11	CAB, REAR SEAT BELT/BUCKLE—CLUB	23-53
BENCH SEAT TRACK	23-9	BRAKE HOSES AND LINES	5-5	CAB REAR SEAT CUSHION COVER, QUAD	23-16
BETTS CONNECTORS, TERMINAL/CONNECTOR REPAIR—THOMAS	8W-10	BRAKE LAMP SWITCH; SPEED CONTROL SYSTEM	8H-3	CAB, REAR SEAT CUSHION—CLUB	23-15
BEZEL, CLUSTER	8E-12	BRAKE LINE AND HOSES	5-10	CAB, REAR SEAT QUAD	23-16
BEZEL, INSTRUMENT PANEL LOWER	8E-21	BRAKE PEDAL	5-14,5-2	CAB, SEAT BELT RETRACTOR—QUAD	23-52
BEZEL, SHIFT	23-55	BRAKE PEDAL ASSEMBLY, PARK	5-22	CABLE ADJUSTMENT, TRANSMISSION THROTTLE VALVE	21-226,21-394
BIN DOOR, GARAGE DOOR OPENER STORAGE	8V-12	BRAKE, REAR DRUM	5-27,5-28	CABLE (EXCEPT 4.7L ENGINE), SERVO	8H-6
BIN, GARAGE DOOR OPENER STORAGE	8V-3	BRAKE RELEASE HANDLE, PARK	8E-18	CABLE, FRONT PARK BRAKE	5-21
BIN, SUNGLASSES STORAGE	8V-12,8V-4	BRAKE ROTOR, DISC	5-19,5-9	CABLE, GEARSHIFT	21-130,21-153,21-227, 21-292,21-316,21-395,21-442,21-454,21-482
BLADE, FAN	7-55	BRAKE SHOES, DISC	5-17	CABLE, HOOD RELEASE	23-23
BLADE, WIPER	8K-8	BRAKE SHOES, REAR	5-19	CABLE RESISTANCE, SPARK PLUG	8D-28
BLADE, WIPER ARM	8K-2	BRAKE SUPPORT PLATE	5-21	CABLE, SERVO	8H-3
BLEEDING ABS BRAKE SYSTEM	5-43	BRAKE SWITCH—PCM INPUT	14-34	CABLE, TAILGATE CHECK	23-46
BLEEDING, BASE BRAKE	5-11	BRAKE SYSTEM	5-2	CABLE, TEMPERATURE CONTROL	24-47,24-55
BLEEDING, MASTER CYLINDER	5-11	BRAKE SYSTEM, ANTILOCK	5-40	CABLE TENSIONER, PARK BRAKE	5-29
BLEEDING, REAR WHEEL ANTILOCK BRAKE	5-37	BRAKE SYSTEM, BASE	5-1,5-5	CABLE, THROTTLE	14-25
BLOCK, 8W-11 FUSE/RELAY	8W-1	BRAKE SYSTEM, BLEEDING ABS	5-43	CABLE—4.7L V-8 ENGINE, SERVO	8H-6
BLOCK, 8W-12 JUNCTION	8W-1	BRAKE TUBE FLARING	5-12	CABLE—4.7L V-8 ENGINE, THROTTLE	14-27
BLOCK, CYLINDER	9-110,9-122,9-195,9-254, 9-52	BRAKE, TURN SIGNAL AND BACK-UP LAMP BULBS, TAIL	8L-12	CABLES, BATTERY	8A-14,8A-3
BLOCK HEATER	7-9	BRAKE WARNING LAMP, RED	5-3,5-8	CABLES, REAR PARK BRAKE	5-22
BLOCK HEATER, ENGINE	7-46	BRAKE WARNING LAMPS	5-35	CABLES, SPARK PLUG	8D-12,8D-2,8D-8
BLOCK, JUNCTION	80-2,80-6	BRAKES, 8W-34 REAR WHEEL ANTI-LOCK	8W-1	CALIBRATION, COMPASS	8V-6
BLOCK, RELAY AND FUSE	80-4,80-8	BRAKES, ANTILOCK	5-43	CALIPER	5-27
BLOWER MOTOR	24-13,24-2,24-24	BRAKES, BASE	5-31	CALIPER, DISC BRAKE	5-16,5-24
BLOWER MOTOR RELAY	24-13,24-2,24-25	BRAKES, CONTROLLER ANTILOCK	5-41,5-44	CAM, TURN SIGNAL CANCELLING	8J-2
BLOWER MOTOR RESISTOR	24-14,24-25,24-3	BRAKES, CONTROLLER REAR WHEEL ANTILOCK	5-33	CAM/OVERDRIVE PISTON RETAINER, OVERRUNNING CLUTCH	21-189,21-355
BLOWER MOTOR SWITCH	24-15,24-3	BRAKES, DRUM	5-4	CAMSHAFT	9-124,9-240,9-42,9-98
BODY	23-116	BRAKES, FOUR WHEEL ANTILOCK	5-40	CAMSHAFT BEARINGS	9-100,9-242,9-45
		BRAKES, FRONT DISC	5-4	CAMSHAFT PIN REPLACEMENT	9-43
		BRAKES, PARKING	5-5	CAMSHAFT PLUGS, ENGINE CORE OIL	9-106, 9-250
		BRAKES, REAR WHEEL ANTILOCK	5-32	CAMSHAFT POSITION SENSOR	8D-17,8D-5
		BREAKER, CIRCUIT; POWER SEAT SYSTEMS	8R-2		

Description	Group-Page	Description	Group-Page	Description	Group-Page
CAMSHAFT POSITION SENSOR—4.7L ENGINE	8D-18,8D-6	CHART, TORQUE; SPEED CONTROL SYSTEM	8H-9	CLUTCH OPERATION, AIR TESTING TRANSMISSION	21-444
CAMSHAFTS—IN VEHICLE	9-173	CHART, TORQUE; STEERING	19-10,19-14,19-19	CLUTCH, OVERDRIVE	21-122,21-284
CANCELLING CAM, TURN SIGNAL	8J-2	CHART, TORQUE; SUSPENSION	2-12,2-22,2-26	CLUTCH, OVERRUNNING	21-122,21-284
CANISTER, EVAPORATION (EVAP)	25-24,25-33	CHART, TORQUE; TIRES AND WHEELS	22-11	CLUTCH PEDAL	6-16
CANISTER PURGE SOLENOID, DUTY CYCLE EVAP	25-25,25-33	CHARTS, CLUTCH DIAGNOSIS	6-8	CLUTCH PEDAL POSITION SWITCH	6-5
CAP, DISTRIBUTOR	8D-7	CHARTS—RE TRANSMISSION, DIAGNOSIS TABLES	21-136,21-298	CLUTCH PRESSURE PLATE	6-2
CAP, FUEL TANK FILLER TUBE	14-24,14-7	CHECK CABLE, TAILGATE	23-46	CLUTCH, REAR	21-120,21-197,21-225,21-282, 21-364,21-393
CAP, RADIATOR	7-55	CHECK, COOLANT LEVEL	7-28	CLUTCH RELAY, COMPRESSOR	24-16,24-30, 24-4
CAP, RADIATOR PRESSURE	7-10	CHECK, COOLANT—ROUTINE LEVEL	7-27	CLUTCH RELEASE BEARING	6-3
CAPACITIES, COOLING SYSTEM	7-56	CHECK, FLUID LEVEL	21-147,21-309,21-445	CLUTCH RELEASE OR ENGAGEMENT, IMPROPER	6-7
CAPACITIES, FLUID	0-2	CHECK, OIL PUMP VOLUME	21-149,21-311, 21-447	CLUTCH SWITCH, LOW PRESSURE CYCLING	24-18,24-43,24-7
CAPACITIES, LUBRICANTS	0-1	CHECK PROCEDURE, THROTTLE BODY MINIMUM AIR FLOW	14-50,14-51	CLUTCHES, HOLDING	21-431
CAPACITY, FUEL TANK	14-27	CHECK, RADIATOR CAP-TO-FILLER NECK SEAL—PRESSURE RELIEF	7-26	CLUTCHES, INPUT	21-428
CAPACITY TEST, FUEL PUMP	14-8	CHECK, RADIATOR COOLANT FLOW	7-21	CLUTCH/LOW-REVERSE DRUM/ OVERDRIVE PISTON RETAINER, OVERRUNNING	21-223,21-391
CAP—PRESSURE TESTING, RADIATOR	7-26	CHECK VALVE SERVICE, CONVERTER DRAINBACK	21-148,21-310	COAT FINISH, BASE COAT/CLEAR	23-1
CAP-TO-FILLER NECK SEAL—PRESSURE RELIEF CHECK, RADIATOR	7-26	CHECK VALVE, VACUUM	24-48,24-9	COAT HOOK	23-58
CARDAN JOINT, DOUBLE	3-13	CHECKING ENGINE OIL PRESSURE	9-132	COAT/CLEAR COAT FINISH, BASE	23-1
CARDAN UNIVERSAL JOINT, SINGLE	3-11	CHECKS, PRELIMINARY	7-14	CODE DESCRIPTIONS, DIAGNOSTIC TROUBLE	25-3
CARGO BOX	23-48	CHIME WARNING SYSTEM	8U-1	CODE, PAINT	23-1
CARGO BOX SEAL	23-49	CHIME WARNING SYSTEM SWITCHES	8U-5	CODE PLATE, BODY	Intro-2
CARGO LAMP	8L-16	CIGAR LIGHTER	8E-11,8E-4	CODES, DIAGNOSTIC TROUBLE	25-2
CARGO LAMP BULB	8L-12	CIGAR LIGHTER AND POWER OUTLET	8E-22	COIL, COMPRESSOR CLUTCH	24-16
CARPET OR MAT, FLOOR	23-57	CIRCUIT ACTUATION TEST MODE	25-2	COIL, EVAPORATOR	24-34,24-5
CARTRIDGE FUSE, GENERATOR	80-2,80-6	CIRCUIT BREAKER: POWER SEAT SYSTEMS	8R-2	COIL (EXCEPT 4.7L ENGINE), IGNITION	8D-2
CASE COVER OIL SEAL, TIMING	9-39	CIRCUIT BREAKER; POWER WINDOW SYSTEMS	8S-2,8S-3	COIL RESISTANCE—4.7L V-8 ENGINE, IGNITION	8D-28
CASE COVER, TIMING	9-40	CIRCUIT FUNCTIONS	8W-4	COIL RESISTANCE—EXCEPT 4.7L ENGINE, IGNITION	8D-28
CASE, NV231 TRANSFER	21-506,21-511,21-527	CIRCUIT INFORMATION	8W-4	COIL SPRING	2-8
CASE, NV242 TRANSFER	21-533,21-538,21-558	CIRCUIT SENSE—PCM INPUT, IGNITION	14-35	COIL SPRINGS	2-7
CASE SHIFTER, TRANSFER	21-509,21-535	CIRCUITS, NON-MONITORED	25-22	COIL—2.5L ENGINE, IGNITION	8D-14
CASE SKID PLATE, TRANSFER	13-9	CIRCUITS, SPEED CONTROL SOLENOID	8H-2	COIL—3.9/5.2/5.9L ENGINES, IGNITION	8D-14
CASE, TRANSFER	21-508,21-535	CIRCUITS-PCM OUTPUTS, CCD BUS (+/-)	14-40	COIL—4.7L ENGINE, IGNITION	8D-15,8D-3
CATALYTIC CONVERTER	11-1,11-10,11-5	CLAMPS, FUEL TUBES/LINES/HOSES	14-7	COLUMN OPENING COVER, STEERING	8E-16
CAUTIONS, AND WARNINGS, NOTES	8W-7	CLAMPS, HOSE	7-10	COLUMN SHIFT INTERLOCK	8D-26
CAUTIONS, SERVICE WARNINGS &	5-2	CLASSIFICATION OF LUBRICANTS	0-1	COLUMN, STEERING	19-15,19-16
CCD BUS (+/-) CIRCUITS-PCM OUTPUTS	14-40	CLEANER ELEMENT (FILTER), AIR	14-62	COMBINATION FLASHER	8J-3,8J-5
CENTER ARMREST UPPER INERTIA LATCH COVER	23-13	CLEANING TIRES	22-6	COMBINATION VALVE	5-14,5-3,5-9
CENTER ARMREST/CONSOLE LATCH	23-12	CLEARANCE, SIDE GEAR	3-99	COMBUSTION PRESSURE LEAKAGE TEST, CYLINDER	9-10,9-129,9-216,9-70
CENTER BEARING	3-11,3-2	CLOCKSPRING	8M-13,8M-4	COMPASS CALIBRATION	8V-6
CENTER BEARING ADJUSTMENT	3-17	CLOCKSPRING CENTERING	8M-15	COMPASS DEMAGNETIZING	8V-7
CENTER HIGH MOUNTED STOP LAMP (CHMSL)	8L-15	CLUNKING NOISE DURING ACCELERATION	3-20	COMPASS MINI-TRIP COMPUTER	8V-11,8V-2, 8V-5
CENTER HIGH MOUNTED STOP LAMP (CHMSL) BULB	8L-12	CLUSTER, 8W-40 INSTRUMENT	8W-1	COMPASS VARIATION ADJUSTMENT	8V-6
CENTER, POWER DISTRIBUTION	80-1,80-4	CLUSTER BEZEL	8E-12	COMPONENTS—IN VEHICLE SERVICE, CYLINDER HEAD	9-89
CENTER SEAT CUSHION/COVER	23-13	CLUSTER COMPONENTS, INSTRUMENT	8E-14	COMPRESSION PRESSURE TEST, CYLINDER	9-128,9-215,9-70,9-9
CENTER SEAT/CONSOLE	23-12	CLUSTER, INSTRUMENT; CHIME/BUZZER WARNING SYSTEMS	8U-2,8U-5	COMPRESSOR	24-15,24-26,24-4
CENTER SUPPORT BRACKET, INSTRUMENT PANEL	8E-19	CLUSTER, INSTRUMENT; INSTRUMENT PANEL SYSTEMS	8E-13,8E-2,8E-6	COMPRESSOR CLUTCH	24-27,24-4
CENTERING, CLOCKSPRING	8M-15	CLUTCH	6-1	COMPRESSOR CLUTCH COIL	24-16
CENTRAL TIMER MODULE; CHIME/BUZZER WARNING SYSTEMS	8U-1,8U-3	CLUTCH AND BAND OPERATION, AIR TESTING TRANSMISSION	21-134,21-296	COMPRESSOR CLUTCH RELAY	24-16,24-30,24-4
CENTRAL TIMER MODULE; INSTRUMENT PANEL SYSTEMS	8E-25,8E-4	CLUTCH ASSEMBLY, INPUT	21-470	COMPUTER, COMPASS MINI-TRIP	8V-11,8V-2, 8V-5
CENTRAL TIMER MODULE; POWER LOCK SYSTEMS	8P-2,8P-6	CLUTCH ASSEMBLY, LOW/REVERSE	21-481	CONDENSER	24-31,24-5
CENTRAL TIMER MODULE; VEHICLE THEFT/SECURITY SYSTEMS	8Q-2	CLUTCH CAM/OVERDRIVE PISTON RETAINER, OVERRUNNING	21-189,21-355	CONDITIONER CONTROL, HEATER AND AIR	24-6
CENTRAL TIMER MODULE; WIPER AND WASHER SYSTEMS	8K-3	CLUTCH COIL, COMPRESSOR	24-16	CONDITIONER, HEATER AND AIR	24-5
CENTRAL TIMER MODULE, 8W-45	8W-1	CLUTCH COMPONENT LUBRICATION	6-10	CONDITIONING/HEATER, 8W-42 AIR	8W-1
CHAIN AND SPROCKETS, TIMING	9-166,9-40	CLUTCH, COMPRESSOR	24-27,24-4	CONDITIONS, SPARK PLUG	8D-9
CHAIN AND TENSIONER, TIMING	9-97	CLUTCH CONTAMINATION	6-5	CONNECTING ROD ASSEMBLY, PISTON	9-102, 9-245,9-252
CHAIN COVER, TIMING	9-165,9-238,9-96	CLUTCH COVER AND DISC	6-12	CONNECTING ROD BEARINGS—FITTING	9-142, 9-22,9-227,9-81
CHAIN STRETCH, MEASURING TIMING	9-225	CLUTCH COVER AND DISC RUNOUT	6-7	CONNECTING ROD INSPECTION, PISTON	9-108
CHAIN STRETCH—MEASURING, TIMING	9-79	CLUTCH DIAGNOSIS CHARTS	6-8	CONNECTING ROD, PISTON	9-123,9-182,9-193, 9-210,9-49,9-64
CHAIN TENSIONER, TIMING	9-64	CLUTCH DIAGNOSTIC INFORMATION	6-5	CONNECTIONS, INTERMITTENT AND POOR	8W-8
CHAIN, TIMING	9-240	CLUTCH DISC	6-2	CONNECTOR AND TERMINAL REPLACEMENT	8W-12
CHAIN—MEASURING WEAR, TIMING	9-139	CLUTCH DISC APPLICATION	6-4	CONNECTOR INFORMATION	8W-7
CHANGE, LUBRICANT	3-36,3-69	CLUTCH ENGAGEMENT, ELECTRONICALLY MODULATED CONVERTER	21-423	CONNECTOR LOCATIONS, 8W-90	8W-1
CHANNELS, FRONT DOOR LOWER GLASS RUN	23-36	CLUTCH FLUID LEVEL	6-11	CONNECTOR PIN-OUTS, 8W-80	8W-1
CHANNELS, REAR DOOR GLASS RUN	23-40	CLUTCH FLYWHEEL RUNOUT	6-7	CONNECTOR REPLACEMENT	8W-11
CHARGE, REFRIGERANT SYSTEM	24-20	CLUTCH, FRONT	21-119,21-195,21-225,21-281, 21-362,21-393	CONNECTOR/GROUND LOCATIONS	8W-1
CHARGING, BATTERY	8A-16	CLUTCH HOUSING MISALIGNMENT	6-7	CONNECTOR—PCM INPUT AND OUTPUT, DATA LINK	14-40
CHARGING SYSTEM	8C-18C-2	CLUTCH HOUSING REPLACEMENT	6-13		
CHARGING SYSTEM, 8W-20	8W-1	CLUTCH HYDRAULIC FLUID	6-11		
CHARGING SYSTEM, ON-BOARD DIAGNOSTIC TEST	8C-3	CLUTCH HYDRAULIC LINKAGE	6-15		
CHART, TORQUE; BRAKES	5-31,5-39,5-47	CLUTCH LINKAGE, HYDRAULIC	6-4		
CHART, TORQUE; CHARGING SYSTEM	8C-6	CLUTCH, LOW/REVERSE	21-478		
CHART, TORQUE; EMISSION CONTROL SYSTEMS	25-35	CLUTCH MISALIGNMENT	6-7		
CHART, TORQUE; FUEL SYSTEM	14-29,14-66				
CHART, TORQUE; IGNITION SYSTEM	8D-28				

Description	Group-Page	Description	Group-Page	Description	Group-Page
CONNECTORS, TERMINAL/CONNECTOR REPAIR—MOLEX	8W-10	COOLANT—ADDING ADDITIONAL	7-28	CRANKSHAFT POSITION SENSOR—5.2/ 5.9L V-8 ENGINE	8D-4
CONNECTORS, TERMINAL/CONNECTOR REPAIR—THOMAS AND BETTS	8W-10	COOLANT—LOW LEVEL AERATION	7-27	CRANKSHAFT REAR OIL SEALS	9-104
CONSOLE, 8W-49 OVERHEAD	8W-1	COOLANT—ROUTINE LEVEL CHECK	7-27	CURVES, GOVERNOR PRESSURE	21-128,21-290
CONSOLE, FLOOR	23-56	COOLER LINES, TRANSMISSION OIL	7-44	CUSHION COVER, QUAD CAB REAR SEAT	23-16
CONSOLE LID/SEAT BACK	23-13	COOLERS AND TUBES, FLUSHING	21-149, 21-311,21-447	CUSHION/COVER, BENCH SEAT	23-10
CONSOLE, OVERHEAD	8V-1,8V-9	COOLERS, AUTOMATIC TRANSMISSION OIL	7-8	CUSHION/COVER, BUCKET SEAT	23-11
CONSOLE READING AND COURTESY LAMP HOUSING, OVERHEAD	8V-11	COOLING	7-57	CUSHION/COVER, CENTER SEAT	23-13
CONSOLE READING AND COURTESY LAMP LENS, OVERHEAD	8V-8	COOLING FAN, ELECTRIC	7-20	CUSHION—CLUB CAB, REAR SEAT	23-15
CONSOLE READING AND COURTESY LAMP, OVERHEAD	8V-3	COOLING FAN RELAY—PCM OUTPUT, RADIATOR	14-42	CUT-OFF SWITCH, DUAL FUNCTION HIGH PRESSURE SWITCH/HIGH PRESSURE	24-18
CONSOLE READING LAMP BULB, OVERHEAD	8L-13	COOLING SYSTEM	7-15,7-2	CUT-OFF SWITCH, HIGH PRESSURE	24-42,24-7
CONSOLE READING LAMP, OVERHEAD	8L-17	COOLING SYSTEM CAPACITIES	7-56	C/V JOINT	3-28
CONSOLE SYSTEM, OVERHEAD	8V-1	COOLING SYSTEM FAN	7-11	C/V JOINT BOOTS	3-22,3-30
CONSOLE SYSTEMS, OVERHEAD	8V-13	COOLING SYSTEM—CLEANING/REVERSE FLUSHING	7-29	C/V JOINT DRIVESHAFT	3-30
CONTACT PATTERN ANALYSIS, GEAR	3-53,3-97	COOLING SYSTEM—DEAERATION	7-27	C/V JOINT, INNER	3-23
CONTAMINATION, BRAKE FLUID	5-10	COOLING SYSTEM—DRAINING AND FILLING	7-28	C/V JOINT, OUTER	3-24
CONTAMINATION, CLUTCH	6-5	COOLING SYSTEM—TESTING FOR LEAKS	7-21	CYCLE EVAP CANISTER PURGE SOLENOID, DUTY	25-25,25-33
CONTAMINATION, FLUID	21-129,21-291,21-441	CORE, HEATER	24-41,24-7	CYCLING CLUTCH SWITCH, LOW PRESSURE	24-18,24-43,24-7
CONTROL, 8W-33 VEHICLE SPEED	8W-1	CORE OIL AND CAMSHAFT PLUGS, ENGINE	9-106,9-250	CYLINDER BLEEDING, MASTER	5-11
CONTROL ASSEMBLY, ANTILOCK	5-44	CORE PLUGS, ENGINE	9-191	CYLINDER BLOCK	9-110,9-122,9-195,9-254,9-52
CONTROL CABLE, TEMPERATURE	24-47,24-55	COUPLER, REFRIGERANT LINE	24-45	CYLINDER BORE—HONING	9-135,9-16,9-221, 9-76
CONTROL, HEATER AND AIR CONDITIONER	24-6	COUPLERS, REFRIGERANT LINE	24-8	CYLINDER COMBUSTION PRESSURE LEAKAGE TEST	9-10,9-129,9-216,9-70
CONTROL, HEATER-A/C	24-17,24-35	COURTESY LAMP HOUSING, OVERHEAD CONSOLE READING	8V-11	CYLINDER COMPRESSION PRESSURE TEST	9-128,9-215,9-70,9-9
CONTROL (IAC) MOTOR—2.5L ENGINE, IDLE AIR	14-56	COURTESY LAMP LENS, OVERHEAD CONSOLE READING	8V-8	CYLINDER, FRONT DOOR LOCK	23-33
CONTROL (IAC) MOTOR—3.9/5.2/5.9L ENGINES, IDLE AIR	14-56	COURTESY LAMP, OVERHEAD CONSOLE READING	8V-3	CYLINDER HEAD	9-108,9-123,9-209,9-236,9-3, 9-36,9-51,9-64
CONTROL (IAC) MOTOR—4.7L V-8 ENGINE, IDLE AIR	14-56	COVER AND DISC, CLUTCH	6-12	CYLINDER HEAD ASSEMBLY	9-251
CONTROL (IAC) MOTOR—PCM OUTPUT, IDLE AIR	14-41	COVER AND DISC RUNOUT, CLUTCH COVER, CENTER ARMREST UPPER INERTIA LATCH	23-13	CYLINDER HEAD COMPONENTS—IN VEHICLE SERVICE	9-89
CONTROL INFORMATION (VECI) LABEL, VEHICLE EMISSION	25-29	COVER, COWL TRIM	23-49	CYLINDER HEAD COVER	9-108,9-124,9-155, 9-235,9-251,9-33,9-89
CONTROL, LINE PRESSURE	21-439	COVER, CYLINDER HEAD	9-108,9-124,9-155, 9-235,9-251,9-33,9-89	CYLINDER HEAD COVER GASKET	9-209,9-63
CONTROL MODULE, AIRBAG	8M-12,8M-3	COVER, DOOR SILL TRIM	23-50	CYLINDER HEAD, ENGINE	9-52
CONTROL MODULE (PCM), POWERTRAIN; FUEL SYSTEM	14-31,14-59	COVER, DRIVER SIDE AIRBAG MODULE TRIM	8M-8	CYLINDER HEAD GASKET FAILURE DIAGNOSIS	9-10,9-129,9-215,9-70
CONTROL MODULE (PCM), POWERTRAIN; TRANSMISSION AND TRANSFER CASE	21-125,21-287	COVER GASKET, CYLINDER HEAD	9-209,9-63	CYLINDER HEADS	9-158,9-193,9-90
CONTROL MODULE, TRANSMISSION	21-435	COVER, INSTRUMENT PANEL TOP	8E-30	CYLINDER, IGNITION SWITCH AND KEY	8D-23
CONTROL RELAY, TRANSMISSION	21-438	COVER OIL SEAL, TIMING CASE	9-39	CYLINDER, IGNITION SWITCH AND KEY LOCK	8D-11,8D-6
CONTROL SERVO, SPEED	8H-2,8H-4	COVER, QUAD CAB REAR SEAT CUSHION	23-16	CYLINDER, MASTER	5-15,5-3
CONTROL SOLENOID CIRCUITS, SPEED	8H-2	COVER, STEERING COLUMN OPENING	8E-16	CYLINDER RESERVOIR, MASTER	5-23
CONTROL SWITCHES, SPEED	8H-2,8H-5	COVER, STRUCTURAL	9-147	CYLINDER SWITCH, DOOR LOCK	8Q-3,8Q-4
CONTROL SYSTEM, 8W-31 TRANSMISSION	8W-1	COVER, STRUCTURAL DUST	9-124	CYLINDER, WHEEL	5-21,5-25,5-28
CONTROL SYSTEM, EVAPORATION	25-23	COVER, TIMING CASE	9-40	CYLINDER/POWER BOOSTER, MASTER	5-8
CONTROL SYSTEM, SPEED	8H-1	COVER, TIMING CHAIN	9-165,9-238,9-96	CYLINDERS, LOCK	23-33
CONTROL UNIT, HYDRAULIC	5-41	COWL GRILLE	23-23	DAMAGED OR WORN THREADS, REPAIR	9-135, 9-16,9-221,9-76
CONTROLLER	5-37	COWL SEAL	23-24	DAMPER, CRANKSHAFT	9-164
CONTROLLER ANTILOCK BRAKES	5-41,5-44	COWL TRIM COVER	23-49	DAMPER, VIBRATION	9-238,9-39,9-95
CONTROLLER REAR WHEEL ANTILOCK BRAKES	5-33	CRANKCASE BREATHER/FILTER	25-29	DAMPER—2.5L ENGINE, FUEL INJECTOR RAIL/FUEL	14-19,14-6
CONTROLS, EVAPORATIVE EMISSION	25-23	CRANKCASE VENTILATION (CCV) SYSTEM—2.5L ENGINE	25-29	DATA LINK CONNECTOR—PCM INPUT AND OUTPUT	14-40
CONTROLS, OVERDRIVE ELECTRICAL	21-130, 21-292	CRANKCASE VENTILATION (PCV) SYSTEM—3.9/5.2/5.9L ENGINE, POSITIVE	25-26	DAY/NIGHT MIRROR, AUTOMATIC	8T-5,8T-6
CONVERTER, CATALYTIC	11-1,11-10,11-5	CRANKCASE VENTILATION (PCV) SYSTEM—4.7L ENGINE, POSITIVE	25-27	DAY/NIGHT MIRROR SYSTEM, AUTOMATIC	8T-5
CONVERTER CLUTCH ENGAGEMENT, ELECTRONICALLY MODULATED	21-423	CRANKSHAFT	9-103,9-122,9-185,9-210,9-246, 9-3,9-64	DAYTIME RUNNING LAMP MODULE (DRLM)	8L-18
CONVERTER DRAINBACK CHECK VALVE SERVICE	21-148,21-310	CRANKSHAFT DAMPER	9-164	DEFINITION, TRIP	25-21
CONVERTER DRAINBACK VALVE	21-125,21-287	CRANKSHAFT FRONT OIL SEAL	9-103	DEFOGGER SWITCH	8N-2,8N-3,8N-5
CONVERTER HOUSING FLUID LEAK DIAGNOSIS	21-135,21-297,21-444	CRANKSHAFT MAIN BEARINGS	9-100,9-144, 9-180,9-210,9-243,9-45,9-5,9-65	DEFOGGER SYSTEM	8N-2
CONVERTER, TORQUE	21-152,21-256,21-314, 21-418,21-453,21-93	CRANKSHAFT MAIN BEARINGS— FITTING	9-227,9-25,9-82	DEFOGGER SYSTEM, REAR WINDOW	8N-1
COOLANT	7-30	CRANKSHAFT OIL SEAL—FRONT	9-189,9-247	DELIVERY SYSTEM, FUEL	14-1
COOLANT FLOW CHECK, RADIATOR	7-21	CRANKSHAFT OIL SEAL—REAR	9-191	DEMAGNETIZING, COMPASS	8V-7
COOLANT LEVEL CHECK	7-28	CRANKSHAFT OIL SEALS	9-209,9-5,9-65	DEPTH, 8 1/4 AXLE PINION GEAR	3-92
COOLANT RESERVE/OVERFLOW SYSTEM	7-5	CRANKSHAFT OIL SEALS—REAR	9-248	DEPTH, 9 1/4 AXLE PINION GEAR	3-93
COOLANT RESERVE/OVERFLOW TANK	7-30	CRANKSHAFT POSITION SENSOR—2.5L ENGINE	8D-16,8D-3	DEPTH, PINION GEAR	3-48
COOLANT SELECTION AND ADDITIVES	7-30	CRANKSHAFT POSITION SENSOR—3.9/ 5.2/5.9L ENGINES	8D-16	DESCRIPTION	0-1
COOLANT SERVICE	7-27	CRANKSHAFT POSITION SENSOR—3.9L V-6 ENGINE	8D-4	DESCRIPTIONS, DIAGNOSTIC TROUBLE CODE	25-3
COOLANT TEMPERATURE SENSOR— 2.5L ENGINE, ENGINE	14-63	CRANKSHAFT POSITION SENSOR—4.7L ENGINE	8D-5	DETECTION PUMP (LDP), LEAK	25-25,25-32, 25-34
COOLANT TEMPERATURE SENSOR—3.9/ 5.2/5.9L ENGINES, ENGINE	14-62	CRANKSHAFT POSITION SENSOR—4.7L V-8 ENGINE	8D-17	DEVICES, ELECTROSTATIC DISCHARGE (ESD) SENSITIVE	8W-8
COOLANT TEMPERATURE SENSOR— 4.7L V-8 ENGINE, ENGINE	14-63			DIAGNOSIS, 45RFE AUTOMATIC TRANSMISSION GENERAL	21-441
COOLANT TEMPERATURE SENSOR— PCM INPUT, ENGINE	14-35			DIAGNOSIS, ACCESSORY DRIVE BELT	7-24
				DIAGNOSIS, AUTOMATIC TRANSMISSION	21-129,21-291
				DIAGNOSIS CHARTS, CLUTCH	6-8

Description	Group-Page	Description	Group-Page	Description	Group-Page
DIAGNOSIS, CONVERTER HOUSING		DOOR, HEATER-A/C HOUSING	24-40	DRUM/OVERDRIVE PISTON RETAINER,	
FLUID LEAK	21-135,21-297,21-444	DOOR HINGE, FRONT	23-31	OVERRUNNING CLUTCH/LOW-	
DIAGNOSIS, CYLINDER HEAD GASKET		DOOR HINGE, REAR	23-37	REVERSE	21-223,21-391
FAILURE	9-10,9-129,9-215,9-70	DOOR INNER BELT WEATHERSTRIP,		DUAL FUNCTION HIGH PRESSURE	
DIAGNOSIS, EXHAUST SYSTEM	11-3	FRONT	23-34	SWITCH/HIGH PRESSURE CUT-OFF	
DIAGNOSIS, HYDRAULIC LASH		DOOR INNER BELT WEATHERSTRIP,		SWITCH	24-18
ADJUSTER NOISE	9-131	REAR	23-40	DUCTS AND OUTLETS	24-32
DIAGNOSIS, INTAKE MANIFOLD		DOOR IN/OUT, FRONT	23-60	DUST COVER, STRUCTURAL	9-124
LEAKAGE	9-128,9-215,9-70,9-9	DOOR INSIDE HANDLE ACTUATOR,		DUTY CYCLE EVAP CANISTER PURGE	
DIAGNOSIS, LAMP	8L-3	FRONT	23-34	SOLENOID	25-25,25-33
DIAGNOSIS, NV231	21-507	DOOR INSIDE HANDLE ACTUATOR,		EFFECTS OF INCORRECT FLUID LEVEL	21-129,
DIAGNOSIS, NV242	21-534	REAR	23-40		21-291,21-440
DIAGNOSIS, PRELIMINARY	21-130,21-292,	DOOR LATCH, FRONT	23-33,23-60	ELECTRIC COOLING FAN	7-20
	21-441	DOOR LATCH, REAR	23-39	ELECTRIC FAN	7-54
DIAGNOSIS, SHOCK	2-16,2-8	DOOR LATCH STRIKER, FRONT	23-34	ELECTRICAL CONTROLS, OVERDRIVE	21-130,
DIAGNOSIS, SYSTEM	8L-3	DOOR LATCH STRIKER, REAR	23-39		21-292
DIAGNOSIS TABLES AND CHARTS—RE		DOOR LOCK CYLINDER, FRONT	23-33	ELECTRONIC GOVERNOR	21-126,21-288
TRANSMISSION	21-136,21-298	DOOR LOCK CYLINDER SWITCH	8Q-3,8Q-4	ELECTRONIC VOLTAGE REGULATOR	8C-2
DIAGNOSIS—GASOLINE ENGINES,		DOOR LOCKS, 8W-61 POWER	8W-1	ELECTRONICALLY MODULATED	
SERVICE	9-211,9-66	DOOR LOWER GLASS RUN CHANNELS,		CONVERTER CLUTCH ENGAGEMENT	21-423
DIAGNOSIS—INTRODUCTION, ENGINE	9-125,	FRONT	23-36	ELECTROSTATIC DISCHARGE (ESD)	
	9-210,9-6,9-65	DOOR OPENER STORAGE BIN DOOR,		SENSITIVE DEVICES	8W-8
DIAGNOSIS—LUBRICATION, SERVICE	9-128,9-9	GARAGE	8V-12	ELEMENT (FILTER), AIR CLEANER	14-62
DIAGNOSIS—MECHANICAL, SERVICE	9-127,9-8	DOOR OPENER STORAGE BIN, GARAGE	8V-3	EMISSION CONTROL INFORMATION	
DIAGNOSIS—PERFORMANCE, SERVICE	9-125,	DOOR OPENING WEATHERSTRIP, REAR	23-41	(VECI) LABEL, VEHICLE	25-29
	9-6	DOOR OUTER BELT WEATHERSTRIP,		EMISSION CONTROLS, EVAPORATIVE	25-23
DIAGNOSTIC INFORMATION, CLUTCH	6-5	FRONT	23-34	EMISSION SYSTEM	25-1
DIAGNOSTIC TEST FOR CHARGING		DOOR OUTER BELT WEATHERSTRIP,		ENABLING	8Q-1
SYSTEM, ON-BOARD	8C-3	REAR	23-41	END, TIE ROD	19-11
DIAGNOSTIC TROUBLE CODE		DOOR OUTSIDE HANDLE, FRONT	23-32	ENGAGEMENT, ELECTRONICALLY	
DESCRIPTIONS	25-3	DOOR OUTSIDE HANDLE, REAR	23-39	MODULATED CONVERTER CLUTCH	21-423
DIAGNOSTIC TROUBLE CODES	25-2	DOOR QUARTER GLASS, REAR	23-42	ENGAGEMENT, IMPROPER CLUTCH	
DIAGNOSTICS (OBD), ON-BOARD	7-12	DOOR, REAR	23-37	RELEASE OR	6-7
DIAGNOSTICS, ON-BOARD	25-1	DOOR SEAL, FRONT	23-36	ENGINE	9-119,9-2,9-205,9-29,9-60
DIFFERENTIAL	3-40,3-74	DOOR SECONDARY SEAL, FRONT	23-37	ENGINE, 2.5L	9-1,9-57
DIFFERENTIAL, 8 1/4 TRAC-LOK™	3-82	DOOR SECONDARY SEAL, REAR	23-41	ENGINE, 3.9L	9-116,9-59
DIFFERENTIAL, 9 1/4 TRAC-LOK™	3-87	DOOR SILL TRIM COVER	23-50	ENGINE, 4.7L	9-118,9-196,9-200
DIFFERENTIAL BEARING PRELOAD AND		DOOR TRIM PANEL, FRONT	23-29	ENGINE, 5.9L	9-204,9-259
GEAR BACKLASH	3-50,3-96	DOOR TRIM PANEL, REAR	23-37	ENGINE, ACCESSORY BELT	
DIFFERENTIAL NOISE, TRAC-LOK™	3-68	DOOR UP/DOWN, FRONT	23-61	REPLACEMENT—4.7L	7-48
DIFFERENTIAL SIDE BEARINGS	3-41,3-75	DOOR VACUUM ACTUATOR, MODE	24-44	ENGINE, ACCESSORY DRIVE BELT	
DIFFERENTIAL, STANDARD	3-32,3-47,3-64,3-82	DOOR WATERDAM, FRONT	23-30	TENSION—2.5L	7-56
DIMENSIONS, BODY OPENING	23-113	DOOR WATERDAM, REAR	23-38	ENGINE, ACCESSORY DRIVE BELT—2.5L	7-47
DIMENSIONS, FRAME	13-11	DOOR WINDOW REGULATOR, FRONT	23-35	ENGINE ACCESSORY DRIVE BELTS	7-5
DIODE REPLACEMENT	8W-14	DOOR WINDOW REGULATOR, REAR	23-42	ENGINE ASSEMBLY	9-148,9-231,9-88
DISARMING	8Q-2	DOUBLE CARDAN JOINT	3-13	ENGINE, AUTOMATIC BELT	
DISC APPLICATION, CLUTCH	6-4	DOWN, BATTERY HOLD	8A-18,8A-4	TENSIONER—4.7L	7-51
DISC BRAKE CALIPER	5-16,5-24	DRAINBACK CHECK VALVE SERVICE,		ENGINE BLOCK HEATER	7-46
DISC BRAKE ROTOR	5-19,5-9	CONVERTER	21-148,21-310	ENGINE, CAMSHAFT POSITION	
DISC BRAKE SHOES	5-17	DRAINBACK VALVE, CONVERTER	21-125,21-287	SENSOR—4.7L	8D-18,8D-6
DISC BRAKES, FRONT	5-4	DRAINCOCK, RADIATOR	7-52	ENGINE COOLANT TEMPERATURE	
DISC, CLUTCH	6-2	DRAW FUSE, IGNITION-OFF	8Q-3,8Q-7	SENSOR—2.5L ENGINE	14-63
DISC, CLUTCH COVER	6-12	DRB SCAN TOOL	7-13	ENGINE COOLANT TEMPERATURE	
DISC ROTOR MACHINING	5-12	DRIVE BELT DIAGNOSIS, ACCESSORY	7-24	SENSOR—3.9/5.2/5.9L ENGINES	14-62
DISC RUNOUT, CLUTCH COVER	6-7	DRIVE BELT TENSIONER—2.5L,		ENGINE COOLANT TEMPERATURE	
DISCHARGE (ESD) SENSITIVE DEVICES,		ACCESSORY	7-50	SENSOR—4.7L V-8 ENGINE	14-63
ELECTROSTATIC	8W-8	DRIVE BELT TENSION—2.5L ENGINE,		ENGINE COOLANT TEMPERATURE	
DISCHARGE LINE, SUCTION	24-46	ACCESSORY	7-56	SENSOR—PCM INPUT	14-35
DISPLAY TEST MODE, STATE	25-2	DRIVE BELT—2.5L ENGINE, ACCESSORY	7-47	ENGINE CORE OIL AND CAMSHAFT	
DISTANCE—PCM INPUT, VEHICLE		DRIVE BELT—3.9L/5.9L ENGINES,		PLUGS	9-106,9-250
SPEED	14-40	ACCESSORY	7-49	ENGINE CORE PLUGS	9-191
DISTRIBUTION, 8W-10 POWER	8W-1	DRIVE BELTS, ENGINE ACCESSORY	7-5	ENGINE, CRANKCASE VENTILATION	
DISTRIBUTION, 8W-15 GROUND	8W-1	DRIVE, IDLER SHAFT—TIMING	9-172	(CCV) SYSTEM—2.5L	25-29
DISTRIBUTION CENTER, POWER	8Q-1,8Q-4	DRIVE SHAFT BUSHING, DISTRIBUTOR	9-242,	ENGINE, CRANKSHAFT POSITION	
DISTRIBUTION SYSTEM, POWER	8Q-1		9-94	SENSOR—2.5L	8D-16,8D-3
DISTRIBUTOR	8D-2	DRIVE SYSTEM, TIMING	9-123	ENGINE, CRANKSHAFT POSITION	
DISTRIBUTOR CAP	8D-7	DRIVE VEHICLE TOWING, TWO WHEEL	0-12	SENSOR—3.9L V-6	8D-4
DISTRIBUTOR DRIVE SHAFT BUSHING	9-242,	DRIVE, VISCOUS FAN	7-11,7-53	ENGINE, CRANKSHAFT POSITION	
	9-94	DRIVELINE ANGLE MEASUREMENT		SENSOR—4.7L	8D-5
DISTRIBUTOR ROTOR	8D-7	PREPARATION	3-7	ENGINE, CRANKSHAFT POSITION	
DISTRIBUTOR—2.5L ENGINE	8D-18	DRIVELINE SNAP	3-36,3-68	SENSOR—4.7L V-8	8D-17
DISTRIBUTORS—3.9/5.2/5.9L ENGINES	8D-21	DRIVE—3.9L/4.7L AND 5.9L ENGINES,		ENGINE, CRANKSHAFT POSITION	
DOME LAMP	8L-17	VISCOUS FAN	7-23	SENSOR—5.2/5.9L V-8	8D-4
DOME LAMP BULB	8L-13	DRIVER DOOR AJAR SWITCH	8U-2,8U-3	ENGINE CYLINDER HEAD	9-52
DOOR ADJUSTMENT, REAR	23-61	DRIVER SEAT BELT SWITCH	8U-2,8U-5	ENGINE DIAGNOSIS—INTRODUCTION	9-125,
DOOR AJAR SWITCH	8Q-3,8Q-4	DRIVER SIDE AIRBAG MODULE	8M-2,8M-6		9-210,9-6,9-65
DOOR AJAR SWITCH, DRIVER	8U-2,8U-3	DRIVER SIDE AIRBAG MODULE TRIM		ENGINE, DISTRIBUTOR—2.5L	8D-18
DOOR, FRONT	23-31	COVER	8M-8	ENGINE, ENGINE COOLANT	
DOOR, FUEL FILLER	23-45	DRIVER UNLOCK RELAY	8P-10,8P-4	TEMPERATURE SENSOR—2.5L	14-63
DOOR, GARAGE DOOR OPENER		DRIVESHIFT, C/V JOINT	3-30	ENGINE, ENGINE COOLANT	
STORAGE BIN	8V-12	DRIVESHIFT, FRONT	3-21	TEMPERATURE SENSOR—4.7L V-8	14-63
DOOR GLASS, FRONT	23-34	DRIVESHIFTS, FRONT AXLE	3-18	ENGINE, ENGINE FIRING ORDER—2.5L	
DOOR GLASS, REAR	23-41	DRUM, BRAKE	5-10	4-CYLINDER	8D-27
DOOR GLASS RUN CHANNELS, REAR	23-40	DRUM BRAKE, REAR	5-27,5-28	ENGINE, ENGINE FIRING ORDER—3.9L	
DOOR GLASS RUN WEATHERSTRIP,		DRUM BRAKES	5-4	V-6	8D-27
FRONT	23-36	DRUM MACHINING, BRAKE	5-12	ENGINE, ENGINE FIRING ORDER—4.7L	
DOOR GLASS RUN WEATHERSTRIP,				V-8	8D-27
REAR	23-40				

Description	Group-Page	Description	Group-Page	Description	Group-Page
ENGINE FIRING ORDER—2.5L 4-CYLINDER ENGINE	8D-27	ENGINES, FUEL INJECTOR RAIL—3.9/ 5.2/5.9L	14-18	FILL LEVEL, LUBRICANT	21-507,21-534
ENGINE FIRING ORDER—3.9L V-6 ENGINE	8D-27	ENGINES, FUEL RAIL—3.9/5.2/5.9L	14-5	FILL PROCEDURE, TRANSMISSION	21-148, 21-310,21-446
ENGINE FIRING ORDER—4.7L V-8 ENGINE	8D-27	ENGINES, IDLE AIR CONTROL (IAC) MOTOR—3.9/5.2/5.9L	14-56	FILLER DOOR, FUEL	23-45
ENGINE FIRING ORDER—5.2L/5.9L V-8 ENGINES	8D-27	ENGINES, IDLER PULLEY—2.5L/3.9L/ 5.9L	7-51	FILLER TUBE CAP, FUEL TANK	14-24,14-7
ENGINE FRONT MOUNTS	9-228,9-82	ENGINES, IGNITION COIL—3.9/5.2/5.9L	8D-14	FILLING, COOLING SYSTEM—DRAINING	7-28
ENGINE, FUEL INJECTOR RAIL/FUEL DAMPER—2.5L	14-19,14-6	ENGINES, INTAKE MANIFOLD AIR TEMPERATURE SENSOR—3.9/5.2/5.9L	14-64	FILTER, FUEL PUMP INLET	14-16
ENGINE, FUEL INJECTOR RAIL—4.7L	14-5	ENGINES, MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR—3.9/5.2/ 5.9L	14-57	FILTER REPLACEMENT, FLUID	21-147,21-309, 21-445
ENGINE, FUEL INJECTOR RAIL—4.7L V-8	14-20	ENGINES ONLY, TASK MANAGER— GASOLINE POWERED	25-16	FILTER/FUEL PRESSURE REGULATOR, FUEL	14-4
ENGINE, IDLE AIR CONTROL (IAC) MOTOR—2.5L	14-56	ENGINES, POWER STEERING PUMP - 3.9L & 5.9L	19-8	FINAL ASSEMBLY	3-46,3-81
ENGINE, IDLE AIR CONTROL (IAC) MOTOR—4.7L V-8	14-56	ENGINES, SERVICE DIAGNOSIS— GASOLINE	9-211,9-66	FINESSE SANDING, BUFFING, AND POLISHING	23-1
ENGINE, IGNITION COIL RESISTANCE— 4.7L V-8	8D-28	ENGINES, THERMOSTAT—3.9L/5.9L	7-39,7-7	FINISH, BASE COAT/CLEAR COAT	23-1
ENGINE, IGNITION COIL RESISTANCE— EXCEPT 4.7L	8D-28	ENGINES, THROTTLE BODY—3.9/5.2/ 5.9L	14-52	FIRING ORDER—2.5L 4-CYLINDER ENGINE, ENGINE	8D-27
ENGINE, IGNITION COIL—2.5L	8D-14	ENGINES, THROTTLE POSITION SENSOR (TPS)—3.9/5.2/5.9L	14-54	FIRING ORDER—3.9L V-6 ENGINE, ENGINE	8D-27
ENGINE, IGNITION COIL—4.7L	8D-15,8D-3	ENGINES, VISCOUS FAN DRIVE—3.9L/ 4.7L AND 5.9L	7-23	FIRING ORDER—4.7L V-8 ENGINE, ENGINE	8D-27
ENGINE, INTAKE MANIFOLD AIR TEMPERATURE SENSOR—2.5L	14-64	ENGINES, VISUAL INSPECTION—3.9/5.2/ 5.9L	14-42	FIRING ORDER—5.2L/5.9L V-8 ENGINES, ENGINE	8D-27
ENGINE, INTAKE MANIFOLD AIR TEMPERATURE SENSOR—4.7L V-8	14-64	ENGINES, WATER PUMP 4.7L	7-35	FITTINGS, QUICK-CONNECT	14-11,14-7
ENGINE LUBRICATION SYSTEM	9-120,9-205, 9-60	ENGINES, WATER PUMP BYPASS HOSE—3.9/5.9L	7-37	FIVE VOLT SENSOR SUPPLIES— PRIMARY AND SECONDARY	14-35
ENGINE, MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR—2.5L	14-58	ENGINES, WATER PUMP BYPASS—3.9/ 5.9L	7-6	FIXED ORIFICE TUBE	24-35,24-5
ENGINE, MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR—4.7L V-8	14-58	ENGINES, WATER PUMP—3.9L/5.9L	7-32	FLARING, BRAKE TUBE	5-12
ENGINE MOUNT—REAR	9-146	ENTRY RECEIVER, REMOTE KEYLESS	8P-4	FLASHER, COMBINATION	8J-3,8J-5
ENGINE MOUNTS—FRONT	9-28	ENTRY SYSTEM, POWER LOCK SYSTEM AND REMOTE KEYLESS	8P-4	FLEXPLATE	9-187
ENGINE MOUNTS—LEFT AND RIGHT	9-145	ENTRY SYSTEM, REMOTE KEYLESS	8P-1	FLOOR CARPET OR MAT	23-57
ENGINE NON A/C, IDLER PULLEY—4.7L	7-52	ENTRY TRANSMITTER BATTERY REPLACEMENT, REMOTE KEYLESS	8P-8	FLOOR CONSOLE	23-56
ENGINE OIL	9-133,9-14,9-219,9-74	ENTRY TRANSMITTER PROGRAMMING, REMOTE KEYLESS	8P-9	FLOOR SHIFT BOOT	23-54
ENGINE OIL LEAK INSPECTION	9-11,9-130	ENTRY TRANSMITTER, REMOTE KEYLESS	8P-3,8P-8	FLOW AND PRESSURE, POWER STEERING	19-4
ENGINE OIL PAN	9-209	EQUIPMENT IDENTIFICATION PLATE	Intro-3	FLOW CHECK PROCEDURE, THROTTLE BODY MINIMUM AIR	14-50,14-51
ENGINE OIL PRESSURE	9-13,9-218,9-73	EQUIPMENT, REFRIGERANT SYSTEM SERVICE	24-20	FLOW CHECK, RADIATOR COOLANT	7-21
ENGINE OIL PRESSURE, CHECKING	9-132	EVACUATE, REFRIGERANT SYSTEM	24-20	FLUID	21-255,21-418,21-92
ENGINE OIL PRESSURE SENDING UNIT	9-188	EVAP CANISTER PURGE SOLENOID, DUTY CYCLE	25-25,25-33	FLUID AND FILTER REPLACEMENT	21-147, 21-309,21-445
ENGINE, OXYGEN SENSOR—2.5L	14-61	EVAPORATION CONTROL SYSTEM	25-23	FLUID, BRAKE	5-30
ENGINE, OXYGEN SENSOR—EXCEPT 2.5L	14-59	EVAPORATIVE (EVAP) CANISTER	25-24,25-33	FLUID CAPACITIES	0-2
ENGINE, PCV VALVE TEST—3.9/5.2/5.9L	25-30	EVAPORATIVE EMISSION CONTROLS	25-23	FLUID, CAUSES OF BURNT	21-129,21-291, 21-441
ENGINE, PCV VALVE—4.7L V-8	25-32	EVAPORATOR COIL	24-34,24-5	FLUID, CLUTCH HYDRAULIC	6-11
ENGINE, PCV VALVE/PCV SYSTEM TEST—4.7L V-8	25-31	EXCITER RING	5-39,5-47	FLUID CONTAMINATION	21-129,21-291,21-441
ENGINE PERFORMANCE	9-219	EXCITER RING, REAR WHEEL SPEED SENSOR	5-34	FLUID CONTAMINATION, BRAKE	5-10
ENGINE, POSITIVE CRANKCASE VENTILATION (PCV) SYSTEM—3.9/5.2/ 5.9L	25-26	EXHAUST HEAT SHIELDS	11-1	FLUID LEAK DIAGNOSIS, CONVERTER HOUSING	21-135,21-297,21-444
ENGINE, POSITIVE CRANKCASE VENTILATION (PCV) SYSTEM—4.7L	25-27	EXHAUST MANIFOLD	9-111,9-124,9-193,9-208, 9-234,9-254,9-3,9-33,9-53,9-63,9-87	FLUID LEVEL, BRAKE	5-11
ENGINE, PUMP RESERVOIR - 2.5L	19-8	EXHAUST MANIFOLDS	9-153	FLUID LEVEL CHECK	21-147,21-309,21-445
ENGINE REAR SUPPORT	9-230,9-29,9-84	EXHAUST PIPE	11-10,11-3	FLUID LEVEL, CLUTCH	6-11
ENGINE, SERVO CABLE—4.7L V-8	8H-6	EXHAUST SYSTEM	11-1	FLUID LEVEL, EFFECTS OF INCORRECT	21-129, 21-291,21-440
ENGINE SPECIFICATIONS	9-53	EXHAUST SYSTEM DIAGNOSIS	11-3	FLUID LEVEL SENSOR, WASHER	8K-4
ENGINE SPECIFICATIONS, 3.9L	9-111	EXHAUSTER, AIR	23-44	FLUSH MEASUREMENTS, BODY GAP	23-106
ENGINE SPECIFICATIONS, 5.9L	9-255	EXHAUSTER—CAB, AIR	23-44	FLUSHING COOLERS AND TUBES	21-149, 21-311,21-447
ENGINE, THERMOSTAT—4.7L	7-43	EXTENSION PIPE	11-6	FLUSHING, COOLING SYSTEM— CLEANING/REVERSE	7-29
ENGINE, THERMOSTAT—2.5L	7-42	EXTERIOR LAMPS	8L-19	FLYWHEEL	6-11,6-2
ENGINE, THERMOSTAT—4.7L	7-7	EXTERIOR MIRRORS	8T-1	FLYWHEEL RUNOUT, CLUTCH	6-7
ENGINE, THROTTLE BODY—2.5L	14-53	EXTERIOR NAMEPLATES	23-27	FOG LAMP	8L-14
ENGINE, THROTTLE BODY—4.7L V-8	14-53	FAILURE DIAGNOSIS, CYLINDER HEAD GASKET	9-10,9-129,9-215,9-70	FOG LAMP ALIGNMENT	8L-9
ENGINE, THROTTLE CABLE—4.7L V-8	14-27	FAN BLADE	7-55	FOG LAMP BULB	8L-11
ENGINE, THROTTLE POSITION SENSOR (TPS)—4.7L V-8	14-54	FAN, COOLING SYSTEM	7-11	FORM-IN-PLACE GASKETS	9-132,9-14,9-218, 9-73
ENGINE, THROTTLE POSITION SENSOR—2.5L	14-55	FAN DRIVE, VISCOUS	7-11,7-53	FOUR WHEEL ANTILOCK BRAKES	5-40
ENGINE TIMING—VERIFICATION	9-137	FAN DRIVE—3.9L/4.7L AND 5.9L ENGINES, VISCOUS	7-23	FOUR-WHEEL-DRIVE VEHICLE TOWING	0-12
ENGINE, VISUAL INSPECTION—2.5L	14-46	FAN, ELECTRIC	7-54	FRAME	13-4
ENGINE, WATER PUMP—2.5L	7-30	FAN, ELECTRIC COOLING	7-20	FRAME DIMENSIONS	13-11
ENGINES, ACCESSORY DRIVE BELT—3.9L/5.9L	7-49	FAN RELAY—PCM OUTPUT, RADIATOR COOLING	14-42	FRAME SERVICE	13-7
ENGINES, AUTOMATIC BELT TENSIONER 3.9L/5.9L	7-50	FASCIA, FRONT BUMPER	13-1	FREQUENCY INTERFERENCE, RADIO	8F-9
ENGINES, CRANKSHAFT POSITION SENSOR—3.9/5.2/5.9L	8D-16	FASTENER IDENTIFICATION	Intro-4	FRONT AXLE	3-36
ENGINES, DISTRIBUTORS—3.9/5.2/5.9L	8D-21	FASTENER USAGE	Intro-7	FRONT AXLE DRIVESHAFTS	3-18
ENGINES, ENGINE COOLANT TEMPERATURE SENSOR—3.9/5.2/5.9L	14-62	FEED (TCM), BATTERY	21-438	FRONT AXLE SKID PLATE	13-8
ENGINES, ENGINE FIRING ORDER—5.2L/ 5.9L V-8	8D-27	FENDER, LEFT FRONT	23-24	FRONT BAND ADJUSTMENT	21-396
		FENDER, RIGHT FRONT	23-26	FRONT BEARING, OUTPUT SHAFT	21-159, 21-322

Description	Group-Page	Description	Group-Page	Description	Group-Page
FRONT DOOR GLASS RUN		FUSE, IGNITION-OFF DRAW	80-3,80-7	HAZARD WARNING SWITCH, TURN	
WEATHERSTRIP	23-36	FUSE/RELAY BLOCK, 8W-11	8W-1	SIGNAL SWITCH	8J-2,8J-5,8J-6
FRONT DOOR HINGE	23-31	GAP AND FLUSH MEASUREMENTS, BODY	23-106	HAZARD WARNING SYSTEM	8J-1
FRONT DOOR INNER BELT		GARAGE DOOR OPENER STORAGE BIN	8V-3	HAZARD WARNING SYSTEMS, TURN SIGNAL	8J-4
WEATHERSTRIP	23-34	GARAGE DOOR OPENER STORAGE BIN DOOR	8V-12	HEAD ASSEMBLY, CYLINDER	9-251
FRONT DOOR IN/OUT	23-60	GASKET, CYLINDER HEAD COVER	9-209,9-63	HEAD COMPONENTS—IN VEHICLE SERVICE, CYLINDER	9-89
FRONT DOOR INSIDE HANDLE		GASKET FAILURE DIAGNOSIS, CYLINDER HEAD	9-10,9-129,9-215,9-70	HEAD COVER, CYLINDER	9-108,9-124,9-155,9-235,9-251,9-33,9-89
ACTUATOR	23-34	GASKETS, FORM-IN-PLACE	9-132,9-14,9-218,9-73	HEAD COVER GASKET, CYLINDER	9-209,9-63
FRONT DOOR LATCH	23-33,23-60	GAUGE SENDING UNIT, FUEL	14-10,14-16,14-3	HEAD, CYLINDER	9-108,9-123,9-209,9-236,9-3,9-36,9-51,9-64
FRONT DOOR LATCH STRIKER	23-34	GAUGES, PRESSURE	22-3	HEAD, ENGINE CYLINDER	9-52
FRONT DOOR LOCK CYLINDER	23-33	GEAR - 4X2, RACK & PINION STEERING	19-12	HEAD GASKET FAILURE DIAGNOSIS, CYLINDER	9-10,9-129,9-215,9-70
FRONT DOOR LOWER GLASS RUN CHANNELS	23-36	GEAR - 4X4, RACK & PINION STEERING	19-13	HEAD REMOVED, VALVES AND VALVE SPRINGS—CYLINDER	9-91
FRONT DOOR OUTER BELT		GEAR AND EXCITER RING, RING	3-75	HEADLAMP	8L-14
WEATHERSTRIP	23-34	GEAR BACKLASH, DIFFERENTIAL BEARING PRELOAD	3-50,3-96	HEADLAMP ALIGNMENT	8L-10,8L-7
FRONT DOOR OUTSIDE HANDLE	23-32	GEAR CLEARANCE, SIDE	3-99	HEADLAMP ALIGNMENT, VEHICLE PREPARATION	8L-7
FRONT DOOR SEAL	23-36	GEAR CONTACT PATTERN ANALYSIS	3-53,3-97	HEADLAMP BULB	8L-11
FRONT DOOR SECONDARY SEAL	23-37	GEAR DEPTH, 8 1/4 AXLE PINION	3-92	HEADLAMP RELAY; POWER LOCK SYSTEMS	8P-10,8P-4
FRONT DOOR TRIM PANEL	23-29	GEAR DEPTH, 9 1/4 AXLE PINION	3-93	HEADLAMP RELAY; VEHICLE THEFT/SECURITY SYSTEMS	8Q-3,8Q-5
FRONT DOOR UP/DOWN	23-61	GEAR DEPTH, PINION	3-48	HEADLAMP SWITCH; CHIME/BUZZER WARNING SYSTEMS	8U-2,8U-4
FRONT DOOR WATERDAM	23-30	GEAR NOISE	3-35,3-67	HEADLAMP SWITCH; INSTRUMENT PANEL SYSTEMS	8E-13
FRONT DOOR WINDOW REGULATOR	23-35	GEAR, PINION	3-42,3-77	HEADLINER	23-59
FRONT DRIVESHAFT	3-21	GEAR, RACK & PINION STEERING	19-11,19-14	HEADS, CYLINDER	9-158,9-193,9-90
FRONT FENDER, LEFT	23-24	GEAR, RING	3-41	HEAT SHIELDS	11-7
FRONT FENDER, RIGHT	23-26	GEAR SELECTOR INDICATOR	8E-17,8E-5	HEAT SHIELDS, EXHAUST	11-1
FRONT LIGHTING, 8W-50	8W-1	GEAR SET, PLANETARY	21-476	HEAT STAKING	23-20
FRONT MOUNTS, ENGINE	9-228,9-82	GEAR SHIFT LEVER	19-18	HEATED MIRROR SYSTEM	8N-1
FRONT OIL SEAL, CRANKSHAFT	9-103	GEARSET, PLANETARY	21-123,21-285	HEATER AND AIR CONDITIONER	24-5
FRONT OUTPUT SHAFT SEAL	21-509,21-536	GEARSHIFT CABLE	21-130,21-153,21-227,21-292,21-316,21-395,21-442,21-454,21-482	HEATER AND AIR CONDITIONER CONTROL	24-6
FRONT PARK BRAKE CABLE	5-21	GEARSHIFT MECHANISM	21-125,21-287,21-435	HEATER, BLOCK	7-9
FRONT PROPELLER SHAFT	3-10	GEARTRAIN, PLANETARY	21-225,21-433,21-481	HEATER CORE	24-41,24-7
FRONT SEAL, OIL PUMP	21-453	GEARTRAIN/OUTPUT SHAFT, PLANETARY	21-200,21-368,21-393	HEATER, ENGINE BLOCK	7-46
FRONT SEAT BELT RETRACTOR	23-52	GENERAL DIAGNOSIS, 45RFE AUTOMATIC TRANSMISSION	21-441	HEATER PERFORMANCE	24-17
FRONT SERVO	21-224,21-392	GENERAL INFORMATION	3-32,3-65	HEATER RELAYS, OXYGEN SENSOR	14-52
FRONT SERVO PISTON	21-191,21-357	GENERAL INFORMATION, 8W-01	8W-1	HEATER RELAYS—PCM OUTPUT, OXYGEN SENSOR	14-41
FRONT SIDE MARKER LAMP BULB	8L-12	GENERATOR	8C-1,8C-3	HEATER-A/C CONTROL	24-17,24-35
FRONT SUSPENSION	2-13,2-22	GENERATOR CARTRIDGE FUSE	80-2,80-6	HEATER-A/C HOUSING	24-36
FRONT SUSPENSION - 4X2	2-6	GENERATOR RATINGS	8C-6	HEATER-A/C HOUSING DOOR	24-40
FRONT SUSPENSION - 4X4	2-14	GLASS, BACKLITE SLIDING VENT	23-52	HEATING GRID, OUTSIDE MIRROR	8N-2
FRONT WHEEL SPEED SENSOR - 4X2	5-45	GLASS, FRONT DOOR	23-34	HEATING GRID, REAR GLASS	8N-2,8N-3
FRONT WHEEL SPEED SENSOR - 4X4	5-46	GLASS HEATING GRID, REAR	8N-2,8N-3	HEATING GRID REPAIR, REAR GLASS	8N-4
FRONT WHEELHOUSE LINER	23-24	GLASS HEATING GRID REPAIR, REAR	8N-4	HEIGHT- 4X4, SUSPENSION	2-3
FUEL DELIVERY SYSTEM	14-1	GLASS, REAR DOOR	23-41	HIGH AND LOW LIMITS	25-22
FUEL FILLER DOOR	23-45	GLASS, REAR DOOR QUARTER	23-42	HIGH MOUNTED STOP LAMP (CHMSL) BULB, CENTER	8L-12
FUEL FILTER/FUEL PRESSURE REGULATOR	14-4	GLASS RUN CHANNELS, FRONT DOOR LOWER	23-36	HIGH MOUNTED STOP LAMP (CHMSL), CENTER	8L-15
FUEL GAUGE SENDING UNIT	14-10,14-16,14-3	GLASS RUN CHANNELS, REAR DOOR	23-40	HIGH PRESSURE CUT-OFF SWITCH	24-42,24-7
FUEL INJECTION SYSTEM	14-30	GLASS RUN WEATHERSTRIP, FRONT DOOR	23-36	HIGH PRESSURE RELIEF VALVE	24-7
FUEL INJECTOR RAIL/FUEL DAMPER—2.5L ENGINE	14-19,14-6	GLASS RUN WEATHERSTRIP, REAR DOOR	23-40	HIGH PRESSURE SWITCH/HIGH PRESSURE CUT-OFF SWITCH, DUAL FUNCTION	24-18
FUEL INJECTOR RAIL—3.9/5.2/5.9L ENGINES	14-18	GLASS, STATIONARY	23-4	HIGH SPEED, TIRE PRESSURE	22-3
FUEL INJECTOR RAIL—4.7L ENGINE	14-5	GLOVE BOX	8E-24	HIGHWAY SPEEDS, VIBRATION AT	3-20
FUEL INJECTOR RAIL—4.7L V-8 ENGINE	14-20	GLOVE BOX COMPONENTS	8E-25	HINGE, FRONT DOOR	23-31
FUEL INJECTOR TEST	14-11	GLOVE BOX LAMP AND SWITCH	8E-23	HINGE, HOOD	23-21
FUEL INJECTOR(S)	14-22	GLOVE BOX LATCH STRIKER	8E-23	HINGE, REAR DOOR	23-37
FUEL INJECTORS	14-4	GOVERNOR, ELECTRONIC	21-126,21-288	HITCH, TRAILER	13-10
FUEL INJECTORS—PCM OUTPUT	14-40	GOVERNOR PRESSURE CURVES	21-128,21-290	HOISTING, JUMP STARTING, TOWING	0-10
FUEL LEVEL SENSOR—PCM INPUT	14-35	GOVERNOR SOLENOID AND PRESSURE SENSOR	21-154,21-317	HOISTING RECOMMENDATIONS	0-13
FUEL PRESSURE LEAK DOWN TEST	14-8	GRID, OUTSIDE MIRROR HEATING	8N-2	HOLD DOWNS, BATTERY	8A-18,8A-4
FUEL PUMP	14-2	GRID, REAR GLASS HEATING	8N-2,8N-3	HOLDING CLUTCHES	21-431
FUEL PUMP AMPERAGE TEST	14-9	GRID REPAIR, REAR GLASS HEATING	8N-4	HOLE REPAIR, THREADED	Intro-7
FUEL PUMP CAPACITY TEST	14-8	GRILLE	23-20	HOOD	23-21,23-59
FUEL PUMP INLET FILTER	14-16	GRILLE, COWL	23-23	HOOD HINGE	23-21
FUEL PUMP MODULE	14-14,14-2	GROUND DISTRIBUTION, 8W-15	8W-1	HOOD LATCH	23-22,23-60
FUEL PUMP PRESSURE TEST	14-7	GROUND—PCM INPUT, SIGNAL	14-39	HOOD LATCH STRIKER	23-22,23-59
FUEL PUMP RELAY	14-52	GROUPS, POWER	14-38	HOOD RELEASE CABLE	23-23
FUEL PUMP RELAY-PCM OUTPUT	14-40	GUIDE AND SEAL, VALVE	9-17	HOOD SAFETY LATCH	23-22
FUEL PUMP RELAYS, ASD	14-49	GUIDES AND SPRINGS, VALVES	9-77	HOOD SEAL	23-24
FUEL RAIL—3.9/5.2/5.9L ENGINES	14-5	GUIDES, VALVE	9-123	HOOD SILENCER PAD	23-21
FUEL REQUIREMENTS	14-27	HANDLE ACTUATOR, FRONT DOOR INSIDE	23-34	HOOK, COAT	23-58
FUEL SYSTEM	14-66	HANDLE ACTUATOR, REAR DOOR INSIDE	23-40	HORN	8G-1,8G-4,8G-5
FUEL SYSTEM PRESSURE	14-27	HANDLE, FRONT DOOR OUTSIDE	23-32	HORN RELAY; HORN SYSTEMS	8G-2,8G-3,8G-4
FUEL SYSTEM PRESSURE RELEASE PROCEDURE	14-11	HANDLE, PARK BRAKE RELEASE	8E-18	HORN RELAY; POWER LOCK SYSTEMS	8P-10,8P-4
FUEL TANK	14-22,14-4	HANDLE, QUAD CAB ASSIST	23-59		
FUEL TANK CAPACITY	14-27	HANDLE, REAR DOOR OUTSIDE	23-39		
FUEL TANK FILLER TUBE CAP	14-24,14-7	HANDLE, TAILGATE LATCH RELEASE	23-47		
FUEL TANK SKID PLATE—4WD VEHICLES	13-9	HARD SHIFTING	21-39,21-4		
FUEL TUBES/LINES/HOSES AND CLAMPS	14-7				
FUEL/IGNITION SYSTEMS, 8W-30	8W-1				
FUNCTION HIGH PRESSURE SWITCH/HIGH PRESSURE CUT-OFF SWITCH, DUAL	24-18				
FUNCTIONS, CIRCUIT	8W-4				
FUSE BLOCK, RELAY	80-4,80-8				
FUSE, GENERATOR CARTRIDGE	80-2,80-6				

Description	Group-Page	Description	Group-Page	Description	Group-Page
HORN RELAY; VEHICLE THEFT/SECURITY SYSTEMS	8Q-3,8Q-6	INJECTOR RAIL—4.7L V-8 ENGINE, FUEL	14-20	INTERFERENCE, RADIO FREQUENCY	8F-9
HORN SWITCH	8G-2,8G-4	INJECTOR TEST, FUEL	14-11	INTERIOR LAMPS	8L-19
HORN SYSTEM	8G-1	INJECTOR(S), FUEL	14-22	INTERIOR LIGHTING, 8W-44	8W-1
HORN/CIGAR LIGHTER/POWER OUTLET, 8W-41	8W-1	INJECTORS, FUEL	14-4	INTERIOR MIRRORS	8T-5
HOSE CLAMPS	7-10	INJECTORS—PCM OUTPUT, FUEL	14-40	INTERIOR TRIM PANELS	23-18
HOSE—3.9/5.9L ENGINES, WATER PUMP BYPASS	7-37	INLET FILTER, FUEL PUMP	14-16	INTERLOCK, COLUMN SHIFT	8D-26
HOSES AND LINES, BRAKE	5-5	INNER BELT WEATHERSTRIP, FRONT DOOR	23-34	INTERMITTENT AND POOR CONNECTIONS	8W-8
HOSSES, BRAKE LINE	5-10	INNER BELT WEATHERSTRIP, REAR DOOR	23-40	INTERMITTENT WIPE RELAY	8K-11,8K-3,8K-7
HOUSING BUSHING, OVERDRIVE	21-159,21-321	INNER C/V JOINT	3-23	INTERNATIONAL SYMBOLS; INTRODUCTION	Intro-3
HOUSING DOOR, HEATER-A/C	24-40	IN/OUT, FRONT DOOR	23-60	INTERNATIONAL SYMBOLS; LUBRICATION AND MAINTENANCE	0-1
HOUSING FLUID LEAK DIAGNOSIS, CONVERTER	21-135,21-297,21-444	INPUT AND OUTPUT, DATA LINK CONNECTOR—PCM	14-40	INTRODUCTION; CHIME/BUZZER WARNING SYSTEMS	8U-1
HOUSING, HEATER-A/C	24-36	INPUT AND OUTPUT SPEED SENSORS	21-439	INTRODUCTION; ELECTRICALLY HEATED SYSTEMS	8N-1
HOUSING MISALIGNMENT, CLUTCH	6-7	INPUT, AUTOMATIC SHUTDOWN (ASD) RELAY SENSE—PCM	14-34	INTRODUCTION; POWER LOCK SYSTEMS	8P-1
HOUSING, OVERHEAD CONSOLE READING AND COURTESY LAMP	8V-11	INPUT, BATTERY VOLTAGE—PCM	14-34	INTRODUCTION; POWER MIRROR SYSTEMS	8T-1,8T-5
HOUSING REPLACEMENT, CLUTCH	6-13	INPUT, BRAKE SWITCH—PCM	14-34	INTRODUCTION; POWER SEAT SYSTEMS	8R-1
HOUSING SEAL, ADAPTER	21-453	INPUT CLUTCH ASSEMBLY	21-470	INTRODUCTION; POWER WINDOW SYSTEMS	8S-1
HOUSING YOKE BUSHING, REAR	21-43	INPUT CLUTCHES	21-428	INTRODUCTION; VEHICLE THEFT/SECURITY SYSTEMS	8Q-1
HUB/BEARING	2-11,2-21	INPUT, ENGINE COOLANT TEMPERATURE SENSOR—PCM	14-35	INTRODUCTION; WIPER AND WASHER SYSTEMS	8K-1
HYDRAULIC CLUTCH LINKAGE	6-4	INPUT, FUEL LEVEL SENSOR—PCM	14-35	INTRODUCTION; WIRING DIAGRAMS	8W-1
HYDRAULIC CONTROL UNIT	5-41	INPUT, IGNITION CIRCUIT SENSE—PCM	14-35	JOINT ANGLE, PROPELLER SHAFT	3-4
HYDRAULIC FLUID, CLUTCH	6-11	INPUT, INTAKE MANIFOLD AIR TEMPERATURE SENSOR—PCM	14-35	JOINT BOOTS, C/V	3-22,3-30
HYDRAULIC LASH ADJUSTER	9-123,9-164	INPUT, MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR—PCM	14-36	JOINT, C/V	3-28
HYDRAULIC LASH ADJUSTER NOISE DIAGNOSIS	9-131	INPUT, OIL PRESSURE SENSOR—PCM	14-37	JOINT, DOUBLE CARDAN	3-13
HYDRAULIC LINKAGE, CLUTCH	6-15	INPUT, OXYGEN SENSOR (O2S)—PCM	14-37	JOINT DRIVESHAFT, C/V	3-30
HYDRAULIC PRESSURE TEST	21-132,21-294,21-443	INPUT, POWER STEERING PRESSURE SWITCH—PCM	14-38	JOINT, INNER C/V	3-23
HYDRAULIC SCHEMATICS	21-229,21-397,21-482	INPUT, SENSOR RETURN—PCM	14-39	JOINT, LOWER BALL	2-15,2-7
HYDRAULIC TAPPETS	9-12,9-217,9-237,9-38,9-51,9-72,9-92	INPUT, SIGNAL GROUND—PCM	14-39	JOINT MOLDING, ROOF	23-43
HYDROSTATIC LOCK	9-136,9-17,9-222,9-76	INPUT SPEED SENSOR	21-448	JOINT, OUTER C/V	3-24
IDENTIFICATION, FASTENER	Intro-4	INPUT, THROTTLE POSITION SENSOR (TPS)—PCM	14-39	JOINT, SINGLE CARDAN UNIVERSAL	3-11
IDENTIFICATION NUMBER (VIN) PLATE, VEHICLE	Intro-1	INPUT, VEHICLE SPEED	8H-3	JOINT, UPPER BALL	2-15,2-8
IDENTIFICATION PLATE, EQUIPMENT	Intro-3	INPUT, VEHICLE SPEED AND DISTANCE—PCM	14-40	JOINTS, PROPELLER SHAFT	3-4
IDENTIFICATION, SECTION	8W-5	INSIDE HANDLE ACTUATOR, FRONT DOOR	23-34	JUMP STARTING PROCEDURE	0-10
IDLE AIR CONTROL (IAC) MOTOR—2.5L ENGINE	14-56	INSIDE HANDLE ACTUATOR, REAR DOOR	23-40	JUMP STARTING, TOWING AND HOISTING	0-10
IDLE AIR CONTROL (IAC) MOTOR—3.9/5.2/5.9L ENGINES	14-56	INSPECTION, ENGINE OIL LEAK	9-11,9-130	JUNCTION BLOCK	8O-2,8O-6
IDLE AIR CONTROL (IAC) MOTOR—4.7L V-8 ENGINE	14-56	INSPECTION (ENGINE OIL LEAKS IN GENERAL)	9-216,9-71	JUNCTION BLOCK, 8W-12	8W-1
IDLE AIR CONTROL (IAC) MOTOR—PCM OUTPUT	14-41	INSPECTION, PISTON AND CONNECTING ROD	9-108	KEY CYLINDER, IGNITION SWITCH	8D-23
IDLER PULLEY—2.5L/3.9L/5.9L ENGINES	7-51	INSPECTION, PRE-ALIGNMENT	2-2	KEY LOCK CYLINDER, IGNITION SWITCH	8D-11,8D-6
IDLER PULLEY—4.7L ENGINE NON A/C	7-52	INSPECTION, VEHICLE	3-20	KEY-IN IGNITION SWITCH	8U-2,8U-4
IDLER SHAFT—TIMING DRIVE	9-172	INSPECTION, WHEEL	22-7	KEYLESS ENTRY RECEIVER, REMOTE	8P-4
IGNITION CIRCUIT SENSE—PCM INPUT	14-35	INSPECTION—2.5L ENGINE, VISUAL	14-46	KEYLESS ENTRY SYSTEM, POWER LOCK SYSTEM AND REMOTE	8P-4
IGNITION COIL (EXCEPT 4.7L ENGINE)	8D-2	INSPECTION—3.9/5.2/5.9L ENGINES, VISUAL	14-42	KEYLESS ENTRY SYSTEM, REMOTE	8P-1
IGNITION COIL RESISTANCE—4.7L V-8 ENGINE	8D-28	INSTALLATION METHODS AND PARTS USAGE	6-5	KEYLESS ENTRY TRANSMITTER BATTERY REPLACEMENT, REMOTE	8P-8
IGNITION COIL RESISTANCE—EXCEPT 4.7L ENGINE	8D-28	INSTALLATION, WHEEL	22-8	KEYLESS ENTRY TRANSMITTER PROGRAMMING, REMOTE	8P-9
IGNITION COIL—2.5L ENGINE	8D-14	INSTRUMENT CLUSTER; CHIME/BUZZER WARNING SYSTEMS	8U-2,8U-5	KEYLESS ENTRY TRANSMITTER, REMOTE	8P-3,8P-8
IGNITION COIL—3.9/5.2/5.9L ENGINES	8D-14	INSTRUMENT CLUSTER; INSTRUMENT PANEL SYSTEMS	8E-13,8E-2,8E-6	KNOCK, LOW SPEED	3-35,3-68
IGNITION COIL—4.7L ENGINE	8D-15,8D-3	INSTRUMENT CLUSTER, 8W-40	8W-1	KNUCKLE, STEERING	2-15,2-17,2-7,2-9
IGNITION SWITCH	19-16	INSTRUMENT CLUSTER COMPONENTS	8E-14	LABEL, VEHICLE EMISSION CONTROL INFORMATION (VECI)	25-29
IGNITION SWITCH AND KEY CYLINDER	8D-23	INSTRUMENT PANEL	8E-1	LAMP, ABS WARNING	5-43
IGNITION SWITCH AND KEY LOCK CYLINDER	8D-11,8D-6	INSTRUMENT PANEL ASH RECEIVER	8E-20	LAMP ALIGNMENT, FOG	8L-9
IGNITION SWITCH, KEY-IN	8U-2,8U-4	INSTRUMENT PANEL ASSEMBLY	8E-27	LAMP ALIGNMENT SCREEN PREPARATION	8L-7
IGNITION SYSTEM	8D-1	INSTRUMENT PANEL CENTER SUPPORT BRACKET	8E-19	LAMP AND SWITCH, GLOVE BOX	8E-23
IGNITION TIMING	8D-27	INSTRUMENT PANEL LOWER BEZEL	8E-21	LAMP BULB, CARGO	8L-12
IGNITION-OFF DRAW FUSE	8O-3,8O-7	INSTRUMENT PANEL LOWER REINFORCEMENT	8E-19	LAMP BULB, DOME	8L-13
IMPROPER CLUTCH RELEASE OR ENGAGEMENT	6-7	INSTRUMENT PANEL SYSTEM	8E-1	LAMP BULB, FOG	8L-11
INCORRECT FLUID LEVEL, EFFECTS OF	21-129,21-291,21-440	INSTRUMENT PANEL TOP COVER	8E-30	LAMP BULB, FRONT SIDE MARKER	8L-12
INDEX, 8W-02 COMPONENT	8W-1	INTAKE MANIFOLD	9-110,9-124,9-152,9-192,9-208,9-232,9-254,9-3,9-31,9-52,9-63,9-92	LAMP BULB, LICENSE PLATE	8L-13
INDICATOR, GEAR SELECTOR	8E-17,8E-5	INTAKE MANIFOLD AIR TEMPERATURE SENSOR—2.5L ENGINE	14-64	LAMP BULB, OVERHEAD CONSOLE READING	8L-13
INDICATOR LAMP (MIL), MALFUNCTION	25-2	INTAKE MANIFOLD AIR TEMPERATURE SENSOR—3.9/5.2/5.9L ENGINES	14-64	LAMP BULB SERVICE	8L-11
INDICATORS, TREAD WEAR	22-3	INTAKE MANIFOLD AIR TEMPERATURE SENSOR—4.7L V-8 ENGINE	14-64	LAMP BULB, UNDERHOOD	8L-13
INERTIA LATCH COVER, CENTER ARMREST UPPER	23-13	INTAKE MANIFOLD AIR TEMPERATURE SENSOR—PCM INPUT	14-35	LAMP BULBS, PARK AND TURN SIGNAL	8L-12
INFLATION PRESSURES, TIRE	22-2	INTAKE MANIFOLD LEAKAGE DIAGNOSIS	9-128,9-215,9-70,9-9	LAMP BULBS, TAIL, BRAKE, TURN SIGNAL AND BACK-UP	8L-12
INITIAL OPERATION, POWER STEERING PUMP	19-7			LAMP, CARGO	8L-16
INJECTION SYSTEM, FUEL	14-30			LAMP (CHMSL) BULB, CENTER HIGH MOUNTED STOP	8L-12
INJECTOR RAIL/FUEL DAMPER—2.5L ENGINE, FUEL	14-19,14-6				
INJECTOR RAIL—3.9/5.2/5.9L ENGINES, FUEL	14-18				
INJECTOR RAIL—4.7L ENGINE, FUEL	14-5				

Description	Group-Page	Description	Group-Page	Description	Group-Page
LAMP (CHMSL), CENTER HIGH MOUNTED STOP	8L-15	LICENSE PLATE LAMP	8L-16	MALFUNCTION INDICATOR LAMP (MIL)	25-2
LAMP DIAGNOSIS	8L-3	LICENSE PLATE LAMP BULB	8L-13	MANAGER—GASOLINE POWERED ENGINES ONLY, TASK	25-16
LAMP, DOME	8L-17	LID/SEAT BACK, CONSOLE	23-13	MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR—2.5L ENGINE	14-58
LAMP, FOG	8L-14	LIGHTER AND POWER OUTLET, CIGAR	8E-22	MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR—3.9/5.2/5.9L ENGINES	14-57
LAMP HOUSING, OVERHEAD CONSOLE READING AND COURTESY	8V-11	LIGHTER, CIGAR	8E-11,8E-4	MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR—4.7L V-8 ENGINE	14-58
LAMP LENS, OVERHEAD CONSOLE READING AND COURTESY	8V-8	LIGHTER/POWER OUTLET, 8W-41 HORN/CIGAR	8W-1	MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR—PCM INPUT	14-36
LAMP, LICENSE PLATE	8L-16	LIGHTING, 8W-44 INTERIOR	8W-1	MANIFOLD AIR TEMPERATURE SENSOR—2.5L ENGINE, INTAKE	14-64
LAMP (MIL), MALFUNCTION INDICATOR	25-2	LIGHTING, 8W-50 FRONT	8W-1	MANIFOLD AIR TEMPERATURE SENSOR—4.7L V-8 ENGINE, INTAKE	14-64
LAMP MODULE (DRLM), DAYTIME RUNNING	8L-18	LIGHTING, 8W-51 REAR	8W-1	MANIFOLD AIR TEMPERATURE SENSOR—PCM INPUT, INTAKE	14-35
LAMP, OVERHEAD CONSOLE READING	8L-17	LIMITS, HIGH AND LOW	25-22	MANIFOLD, EXHAUST	9-111,9-124,9-193,9-208,9-234,9-254,9-3-33,9-53,9-63,9-87
LAMP, OVERHEAD CONSOLE READING AND COURTESY	8V-3	LINE AND HOSES, BRAKE	5-10	MANIFOLD, INTAKE	9-110,9-124,9-152,9-192,9-208,9-232,9-254,9-3-31,9-52,9-63,9-92
LAMP, PARK, TURN SIGNAL AND SIDE MARKER	8L-14	LINE COUPLER, REFRIGERANT	24-45	MANIFOLD LEAKAGE DIAGNOSIS, INTAKE	9-128,9-215,9-70,9-9
LAMP, RED BRAKE WARNING	5-3,5-8	LINE COUPLERS, REFRIGERANT	24-8	MANIFOLDS, EXHAUST	9-153
LAMP, SECURITY	8Q-3	LINE, LIQUID	24-43	MANUAL TRANSMISSION, NV1500	21-1,21-34
LAMP SERVICE	8L-14	LINE PRESSURE CONTROL	21-439	MANUAL TRANSMISSION, NV3500	21-36,21-81
LAMP SWITCH, BRAKE; BRAKES	5-13,5-36,5-8	LINE PRESSURE SENSOR	21-449	MARKER LAMP BULB, FRONT SIDE	8L-12
LAMP SWITCH, BRAKE; SPEED CONTROL SYSTEM	8H-3	LINE, SUCTION AND DISCHARGE	24-46	MARKER LAMP, PARK, TURN SIGNAL AND SIDE	8L-14
LAMP SWITCH, STOP	5-2	LINER, FRONT WHEELHOUSE	23-24	MASTER CYLINDER	5-15,5-3
LAMP SYSTEMS	8L-1,8L-18	LINES, BRAKE HOSES	5-5	MASTER CYLINDER BLEEDING	5-11
LAMP, TAIL, STOP, TURN SIGNAL AND BACK-UP	8L-16	LINES, REFRIGERANT	24-8	MASTER CYLINDER RESERVOIR	5-23
LAMP, UNDERHOOD	8L-16	LINES, TRANSMISSION OIL COOLER	7-44	MASTER CYLINDER/POWER BOOSTER	5-8
LAMPS, BRAKE WARNING	5-35	LINK CONNECTOR—PCM INPUT AND OUTPUT, DATA	14-40	MAT, FLOOR CARPET OR	23-57
LAMPS, EXTERIOR	8L-19	LINKAGE AND PIVOT, WIPER	8K-2,8K-9	MATCH MOUNTING	22-4
LAMPS, INTERIOR	8L-19	LINKAGE, CLUTCH HYDRAULIC	6-15	MEASUREMENT PREPARATION, DRIVELINE ANGLE	3-7
LASH ADJUSTER, HYDRAULIC	9-123,9-164	LINKAGE, HYDRAULIC CLUTCH	6-4	MEASUREMENT, PROPELLER SHAFT ANGLE	3-7
LASH ADJUSTER NOISE DIAGNOSIS, HYDRAULIC	9-131	LIQUID LINE	24-43	MEASUREMENTS, BODY GAP AND FLUSH	23-106
LATCH, CENTER ARMREST/CONSOLE	23-12	LOAD VALUE	25-22	MEASURING TIMING CHAIN STRETCH	9-225
LATCH COVER, CENTER ARMREST UPPER INERTIA	23-13	LOCATION, RWAL COMPONENT	5-33	MECHANISM, GEARSHIFT	21-125,21-287,21-435
LATCH, FRONT DOOR	23-33,23-60	LOCATIONS, 8W-90 CONNECTOR	8W-1	METRIC SYSTEM	Intro-7
LATCH, HOOD	23-22,23-60	LOCATIONS, 8W-95 SPLICE	8W-1	MILE, TIRE REVOLUTION PER	22-6
LATCH, HOOD SAFETY	23-22	LOCATIONS, CONNECTOR/GROUND	8W-1	MINIMUM AIR FLOW CHECK PROCEDURE, THROTTLE BODY	14-50,14-51
LATCH, REAR DOOR	23-39	LOCATIONS, SEALER	23-94	MINI-TRIP COMPUTER, COMPASS	8V-11,8V-2,8V-5
LATCH RELEASE HANDLE, TAILGATE	23-47	LOCATIONS, SPLICE	8W-1,8W-7	MIRROR, AUTOMATIC DAY/NIGHT	8T-5,8T-6
LATCH STRIKER, FRONT DOOR	23-34	LOCATIONS, STRUCTURAL ADHESIVE	23-89	MIRROR HEATING GRID, OUTSIDE	8N-2
LATCH STRIKER, GLOVE BOX	8E-23	LOCATIONS, WELD	23-62	MIRROR, POWER	8T-1,8T-4
LATCH STRIKER, HOOD	23-22,23-59	LOCK CYLINDER, FRONT DOOR	23-33	MIRROR, REARVIEW	23-57
LATCH STRIKER, REAR DOOR	23-39	LOCK CYLINDER, IGNITION SWITCH AND KEY	8D-11,8D-6	MIRROR, SIDE VIEW	23-28
LATCH STRIKER, TAILGATE	23-48	LOCK CYLINDER SWITCH, DOOR	8Q-3,8Q-4	MIRROR SUPPORT BRACKET, REARVIEW	23-57
LATCH, TAILGATE	23-48	LOCK CYLINDERS	23-33	MIRROR SWITCH, POWER	8T-2,8T-3
LEAF SPRINGS	2-23,2-25	LOCK, HYDROSTATIC	9-136,9-17,9-222,9-76	MIRROR SYSTEM, AUTOMATIC DAY/NIGHT	8T-5
LEAF SPRINGS, ADJUSTMENT AT AXLE WITH	3-17	LOCK MOTOR, POWER	8P-3,8P-7,8P-9	MIRROR SYSTEM, HEATED	8N-1
LEAK DETECTION PUMP (LDP)	25-25,25-32,25-34	LOCK SWITCH, POWER	8P-3,8P-5,8P-9	MIRROR SYSTEM, POWER	8T-1,8T-2
LEAK DIAGNOSIS, CONVERTER HOUSING FLUID	21-135,21-297,21-444	LOCK SYSTEM AND REMOTE KEYLESS ENTRY SYSTEM, POWER	8P-4	MIRRORS, 8W-62 POWER	8W-1
LEAK DOWN TEST, FUEL PRESSURE	14-8	LOCK SYSTEM, POWER	8P-1	MIRRORS, EXTERIOR	8T-1
LEAK INSPECTION, ENGINE OIL	9-11,9-130	LOCKS, 8W-61 POWER DOOR	8W-1	MIRRORS, INTERIOR	8T-5
LEAKAGE DIAGNOSIS, INTAKE MANIFOLD	9-128,9-215,9-70,9-9	LOW LIMITS, HIGH	25-22	MISALIGNMENT, CLUTCH	6-7
LEAKAGE, PUMP	19-7	LOW LUBRICANT LEVEL	21-3,21-39	MISALIGNMENT, CLUTCH HOUSING	6-7
LEAKAGE TEST, CYLINDER COMBUSTION PRESSURE	9-10,9-129,9-216,9-70	LOW PRESSURE CYCLING CLUTCH SWITCH	24-18,24-43,24-7	MODE, CIRCUIT ACTUATION TEST	25-2
LEAKS, COOLING SYSTEM—TESTING	7-21	LOW SPEED KNOCK	3-35,3-68	MODE DOOR VACUUM ACTUATOR	24-44
LEAKS, REFRIGERANT SYSTEM	24-19	LOWER BALL JOINT	2-15,2-7	MODE, POWER-UP	8Q-2
LEAKS, REPAIRING	22-5	LOWER BEZEL, INSTRUMENT PANEL	8E-21	MODE, STATE DISPLAY TEST	25-2
LEAKS, WATER	23-18	LOWER GLASS RUN CHANNELS, FRONT DOOR	23-36	MODES OF OPERATION	14-32
LEAKS—INSPECTION, REAR SEAL AREA	9-12,9-131,9-217,9-71	LOWER REINFORCEMENT, INSTRUMENT PANEL	8E-19	MODULATED CONVERTER CLUTCH ENGAGEMENT, ELECTRONICALLY	21-423
LEARN PROCEDURE, TRANSMISSION QUICK	21-447	LOWER SUSPENSION ARM	2-10,2-18	MODULE, 8W-45 CENTRAL TIMER	8W-1
LEFT FRONT FENDER	23-24	LOW/REVERSE CLUTCH	21-47	MODULE, AIRBAG CONTROL	8M-12,8M-3
LENS, OVERHEAD CONSOLE READING AND COURTESY LAMP	8V-8	LOW/REVERSE CLUTCH ASSEMBLY	21-481	MODULE, CENTRAL TIMER: CHIME/BUZZER WARNING SYSTEMS	8U-1,8U-3
LEVEL AERATION, COOLANT—LOW	7-27	LUBRICANT: DIFFERENTIAL AND DRIVELINE	3-31,3-63	MODULE, CENTRAL TIMER: INSTRUMENT PANEL SYSTEMS	8E-25,8E-4
LEVEL, BRAKE FLUID	5-11	LUBRICANT: TRANSMISSION AND TRANSFER CASE	21-3,21-39	MODULE, CENTRAL TIMER: POWER LOCK SYSTEMS	8P-2,8P-6
LEVEL CHECK, COOLANT	7-28	LUBRICANT AND FILL LEVEL	21-507,21-534	MODULE, CENTRAL TIMER: VEHICLE THEFT/SECURITY SYSTEMS	8Q-2
LEVEL CHECK, COOLANT—ROUTINE	7-27	LUBRICANT CHANGE	3-36,3-69		
LEVEL CHECK, FLUID	21-147,21-309,21-445	LUBRICANT LEVEL, LOW	21-3,21-39		
LEVEL, CLUTCH FLUID	6-11	LUBRICANT RECOMMENDATIONS, PARTS	0-1		
LEVEL, EFFECTS OF INCORRECT FLUID	21-129,21-291,21-440	LUBRICANTS AND CAPACITIES	0-1		
LEVEL, LOW LUBRICANT	21-3,21-39	LUBRICANTS, CLASSIFICATION OF	0-1		
LEVEL, LUBRICANT AND FILL	21-507,21-534	LUBRICATION	2-16		
LEVEL, REFRIGERANT OIL	24-19	LUBRICATION, BODY	23-20		
LEVEL SENSOR, WASHER FLUID	8K-4	LUBRICATION, CLUTCH COMPONENT	6-10		
LEVEL SENSOR—PCM INPUT, FUEL	14-35	LUBRICATION SYSTEM	9-2		
LEVER, GEAR SHIFT	19-18	LUBRICATION SYSTEM, ENGINE	9-120,9-205,9-60		
		MACHINING, BRAKE DRUM	5-12		
		MACHINING, DISC ROTOR	5-12		
		MAIN BEARINGS, CRANKSHAFT	9-100,9-144,9-180,9-210,9-243,9-45,9-5,9-65		
		MAIN BEARINGS—FITTING, CRANKSHAFT	9-227,9-25,9-82		
		MAIN OIL SEAL, REAR	9-50		
		MAINTENANCE SCHEDULES	0-4		

Description	Group-Page	Description	Group-Page	Description	Group-Page
MODULE, CENTRAL TIMER; WIPER AND WASHER SYSTEMS	8K-3	OIL LEAK INSPECTION, ENGINE	9-11,9-130	OUTPUT SPEED SENSORS, INPUT	21-439
MODULE, DRIVER SIDE AIRBAG	8M-2,8M-6	OIL LEVEL, REFRIGERANT	24-19	OUTPUTS, CCD BUS (+/-) CIRCUITS-PCM	14-40
MODULE (DRLM), DAYTIME RUNNING LAMP	8L-18	OIL PAN	9-100,9-109,9-124,9-193,9-244,9-252,9-47	OUTSIDE HANDLE, FRONT DOOR	23-32
MODULE, FUEL PUMP	14-14,14-2	OIL PAN 4X2 VEHICLE	9-180	OUTSIDE HANDLE, REAR DOOR	23-39
MODULE, PASSENGER SIDE AIRBAG	8M-3,8M-9	OIL PAN 4X4 VEHICLE	9-182	OUTSIDE MIRROR HEATING GRID	8N-2
MODULE (PCM), POWERTRAIN CONTROL; FUEL SYSTEM	14-31,14-59	OIL PAN, ENGINE	9-209	OVERDRIVE CLUTCH	21-122,21-284
MODULE (PCM), POWERTRAIN CONTROL; TRANSMISSION AND TRANSFER CASE	21-125,21-287	OIL PRESSURE, CHECKING ENGINE	9-132	OVERDRIVE ELECTRICAL CONTROLS	21-130,21-292
MODULE, TRANSMISSION CONTROL	21-435	OIL PRESSURE, ENGINE	9-13,9-218,9-73	OVERDRIVE HOUSING BUSHING	21-159,21-321
MODULE TRIM COVER, DRIVER SIDE AIRBAG	8M-8	OIL PRESSURE SENDING UNIT, ENGINE	9-188	OVERDRIVE OFF SWITCH	21-129,21-291,21-435
MOLDING, ROOF JOINT	23-43	OIL PRESSURE SENSOR—PCM INPUT	14-37	OVERDRIVE UNIT	21-157,21-206,21-319,21-372,21-394
MOLDING, WHEEL OPENING	23-45	OIL PUMP; ENGINE	9-102,9-107,9-108,9-187,9-192,9-194,9-247,9-250,9-252,9-48	OVERHEAD CONSOLE	8V-1,8V-9
MOLDINGS, BODY SIDE	23-45	OIL PUMP; TRANSMISSION AND TRANSFER CASE	21-261,21-423,21-467,21-97	OVERHEAD CONSOLE, 8W-49	8W-1
MONITORED SYSTEMS	25-19	OIL PUMP AND REACTION SHAFT SUPPORT	21-192,21-224,21-358,21-392,21-481	OVERHEAD CONSOLE READING AND COURTESY LAMP	8V-3
MONITORS, COMPONENT	25-21	OIL PUMP FRONT SEAL	21-453	OVERHEAD CONSOLE READING AND COURTESY LAMP HOUSING	8V-11
MOTOR, BLOWER	24-13,24-2,24-24	OIL PUMP VOLUME CHECK	21-149,21-311,21-447	OVERHEAD CONSOLE READING AND COURTESY LAMP LENS	8V-8
MOTOR, POWER LOCK	8P-3,8P-7,8P-9	OIL, REFRIGERANT	24-8	OVERHEAD CONSOLE READING LAMP	8L-17
MOTOR, POWER WINDOW	8S-2,8S-4,8S-6	OIL SEAL, CRANKSHAFT FRONT	9-103	OVERHEAD CONSOLE READING LAMP BULB	8L-13
MOTOR RELAY, BLOWER	24-13,24-2,24-25	OIL SEAL, REAR MAIN	9-50	OVERHEAD CONSOLE SYSTEM	8V-1
MOTOR RESISTOR, BLOWER	24-14,24-25,24-3	OIL SEAL, TIMING CASE COVER	9-39	OVERHEAD CONSOLE SYSTEMS	8V-13
MOTOR, STARTER	8B-10,8B-2,8B-8	OIL SEAL—FRONT, CRANKSHAFT	9-189,9-247	OVERRUNNING CLUTCH	21-122,21-284
MOTOR SWITCH, BLOWER	24-15,24-3	OIL SEAL—REAR, CRANKSHAFT	9-191	OVERRUNNING CLUTCH CAM/ OVERDRIVE PISTON RETAINER	21-189,21-355
MOTOR, WIPER	8K-2,8K-9	OIL SEALS, CRANKSHAFT	9-209,9-5,9-65	OVERRUNNING CLUTCH/LOW-REVERSE DRUM/OVERDRIVE PISTON RETAINER	21-223,21-391
MOTOR—2.5L ENGINE, IDLE AIR CONTROL (IAC)	14-56	OIL SEALS, CRANKSHAFT REAR	9-104	OXYGEN SENSOR HEATER RELAYS	14-52
MOTOR—3.9/5.2/5.9L ENGINES, IDLE AIR CONTROL (IAC)	14-56	OIL SEALS—REAR, CRANKSHAFT	9-248	OXYGEN SENSOR HEATER RELAYS—PCM OUTPUT	14-41
MOTOR—4.7L V-8 ENGINE, IDLE AIR CONTROL (IAC)	14-56	ON-BOARD DIAGNOSTIC TEST FOR CHARGING SYSTEM	8C-3	OXYGEN SENSOR (O2S)—PCM INPUT	14-37
MOTOR—PCM OUTPUT, IDLE AIR CONTROL (IAC)	14-41	ON-BOARD DIAGNOSTICS	25-1	OXYGEN SENSOR—2.5L ENGINE	14-61
MOTORS, POWER SEAT ADJUSTER	8R-1,8R-2,8R-3	ON/OFF SWITCH, PASSENGER SIDE AIRBAG	8M-12,8M-3	OXYGEN SENSOR—EXCEPT 2.5L ENGINE	14-59
MOUNTED STOP LAMP (CHMSL) BULB, CENTER HIGH	8L-12	OPENER STORAGE BIN DOOR, GARAGE DOOR	8V-12	PAD, HOOD SILENCER	23-21
MOUNTED STOP LAMP (CHMSL), CENTER HIGH	8L-15	OPENER STORAGE BIN, GARAGE DOOR	8V-3	PAD/COVER, BENCH SEAT BACK	23-10
MOUNTING, MATCH	22-4	OPENING COVER, STEERING COLUMN	8E-16	PAD/COVER, BUCKET SEAT BACK	23-11
MOUNTING STUDS, WHEEL	2-12,2-21	OPENING DIMENSIONS, BODY	23-113	PAINT	23-1
MOUNT—REAR, ENGINE	9-146	OPENING MOLDING, WHEEL	23-45	PAINT CODE	23-1
MOUNTS, ENGINE FRONT	9-228,9-82	OPENING WEATHERSTRIP, REAR DOOR	23-41	PAINTED SURFACE TOUCH-UP	23-2
MOUNTS—FRONT, ENGINE	9-28	OPERATION, AIR TESTING TRANSMISSION CLUTCH	21-444	PAN 4X2 VEHICLE, OIL	9-180
MOUNTS—LEFT AND RIGHT, ENGINE	9-145	OPERATION, AIR TESTING TRANSMISSION CLUTCH AND BAND	21-134,21-296	PAN 4X4 VEHICLE, OIL	9-182
MUFFLER	11-1,11-6	OPERATION, MODES OF	14-32	PAN, ENGINE OIL	9-209
NAMEPLATES, EXTERIOR	23-27	OPERATION, POWER STEERING PUMP - INITIAL	19-7	PAN, OIL	9-100,9-109,9-124,9-193,9-244,9-252,9-47
NECK SEAL—PRESSURE RELIEF CHECK, RADIATOR CAP-TO-FILLER	7-26	OPERATION, TRAC-LOK [™]	3-64	PANEL ASH RECEIVER, INSTRUMENT	8E-20
NOISE AND/OR VIBRATION IN TURNS	3-20	ORDER—2.5L 4-CYLINDER ENGINE, ENGINE FIRING	8D-27	PANEL ASSEMBLY, INSTRUMENT	8E-27
NOISE, BEARING	3-35,3-68	ORDER—3.9L V-6 ENGINE, ENGINE FIRING	8D-27	PANEL CENTER SUPPORT BRACKET, INSTRUMENT	8E-19
NOISE DIAGNOSIS, HYDRAULIC LASH ADJUSTER	9-131	ORDER—4.7L V-8 ENGINE, ENGINE FIRING	8D-27	PANEL, FRONT DOOR TRIM	23-29
NOISE DURING ACCELERATION, CLUNKING	3-20	ORDER—5.2L/5.9L V-8 ENGINES, ENGINE FIRING	8D-27	PANEL, INSTRUMENT	8E-1
NOISE, GEAR	3-35,3-67	ORIFICE TUBE, FIXED	24-35,24-5	PANEL LOWER BEZEL, INSTRUMENT	8E-21
NOISE OR VIBRATION, TIRE	22-4	OUTER BELT WEATHERSTRIP, FRONT DOOR	23-34	PANEL LOWER REINFORCEMENT, INSTRUMENT	8E-19
NOISE SUPPRESSION COMPONENTS, RADIO	8F-18	OUTER BELT WEATHERSTRIP, REAR DOOR	23-41	PANEL, QUARTER TRIM	23-51
NOISE SUPPRESSION, RADIO	8F-4	OUTER C/V JOINT	3-24	PANEL, REAR DOOR TRIM	23-37
NOISE, TRAC-LOK [™] DIFFERENTIAL	3-68	OUTLET, 8W-41 HORN/CIGAR LIGHTER/POWER	8W-1	PANEL SYSTEM, INSTRUMENT	8E-1
NOISE, TRANSMISSION	21-4,21-40	OUTLET, CIGAR LIGHTER AND POWER	8E-22	PANEL TOP COVER, INSTRUMENT	8E-30
NOISE, WIND	23-19	OUTLET, POWER	8E-12,8E-5	PANEL TRIM, REAR CAB BACK	23-51
NON A/C, IDLER PULLEY—4.7L ENGINE	7-52	OUTLETS, DUCTS	24-32	PANEL, VALANCE	13-3
NON-MONITORED CIRCUITS	25-22	OUTPUT, AUTO SHUTDOWN (ASD) RELAY—PCM	14-40	PANELS, INTERIOR TRIM	23-18
NOTES, CAUTIONS, AND WARNINGS	8W-7	OUTPUT, DATA LINK CONNECTOR—PCM INPUT	14-40	PAPERCLIP	8V-10,8V-4
NOZZLE AND PLUMBING, WASHER	8K-4	OUTPUT, FUEL INJECTORS—PCM	14-40	PARK AND TURN SIGNAL LAMP BULBS	8L-12
NUMBER (VIN) PLATE, VEHICLE IDENTIFICATION	Intro-1	OUTPUT, FUEL PUMP RELAY-PCM	14-40	PARK BRAKE CABLE, FRONT	5-21
NV1500 MANUAL TRANSMISSION	21-1,21-34	OUTPUT, IDLE AIR CONTROL (IAC) MOTOR—PCM	14-41	PARK BRAKE CABLE TENSIONER	5-29
NV231	21-531	OUTPUT, OXYGEN SENSOR HEATER RELAYS—PCM	14-41	PARK BRAKE CABLES, REAR	5-22
NV231 DIAGNOSIS	21-507	OUTPUT, RADIATOR COOLING FAN RELAY—PCM	14-42	PARK BRAKE PEDAL ASSEMBLY	5-22
NV231 TRANSFER CASE	21-506,21-511,21-527	OUTPUT SHAFT BUSHING	21-6	PARK BRAKE RELEASE HANDLE	8E-18
NV242	21-561	OUTPUT SHAFT FRONT BEARING	21-159,21-322	PARK, TURN SIGNAL AND SIDE MARKER LAMP	8L-14
NV242 DIAGNOSIS	21-534	OUTPUT SHAFT REAR BEARING	21-159,21-321	PARKING BRAKES	5-5
NV242 TRANSFER CASE	21-533,21-538,21-558	OUTPUT SHAFT SEAL	21-6	PARK/NEUTRAL POSITION SWITCH	21-130,21-153,21-292,21-315
NV3500 MANUAL TRANSMISSION	21-36,21-81	OUTPUT SHAFT SEAL, FRONT	21-509,21-536	PARTS AND LUBRICANT RECOMMENDATIONS	0-1
(O2S)—PCM INPUT, OXYGEN SENSOR	14-37	OUTPUT SPEED SENSOR	21-448	PARTS USAGE, INSTALLATION METHODS	6-5
OFF SWITCH, OVERDRIVE	21-129,21-291,21-435			PASSENGER SIDE AIRBAG MODULE	8M-3,8M-9
OIL AND CAMSHAFT PLUGS, ENGINE CORE	9-106,9-250			PASSENGER SIDE AIRBAG ON/OFF SWITCH	8M-12,8M-3
OIL COOLER LINES, TRANSMISSION	7-44			PASSIVE RESTRAINT SYSTEMS	8M-16
OIL COOLERS, AUTOMATIC TRANSMISSION	7-8			PATTERN ANALYSIS, GEAR CONTACT	3-53,3-97
OIL, ENGINE	9-133,9-14,9-219,9-74			PATTERNS, TIRE WEAR	22-3

Description	Group-Page	Description	Group-Page	Description	Group-Page
PCM VIN REPROGRAMMING	14-1	POSITION SENSOR—3.9/5.2/5.9L		PRESSURE CURVES, GOVERNOR	21-128,21-290
PCV VALVE TEST—3.9/5.2/5.9L ENGINE	25-30	ENGINES, CRANKSHAFT	8D-16	PRESSURE CUT-OFF SWITCH, DUAL	
PCV VALVE—4.7L V-8 ENGINE	25-32	POSITION SENSOR—3.9L V-6 ENGINE,		FUNCTION HIGH PRESSURE	
PCV VALVE/PCV SYSTEM TEST—4.7L		CRANKSHAFT	8D-4	SWITCH/HIGH	24-18
V-8 ENGINE	25-31	POSITION SENSOR—4.7L ENGINE,		PRESSURE CUT-OFF SWITCH, HIGH	24-42,24-7
PEDAL, ACCELERATOR	14-24	CAMSHAFT	8D-18,8D-6	LOW	24-18,24-43,24-7
PEDAL ASSEMBLY, PARK BRAKE	5-22	POSITION SENSOR—4.7L ENGINE,		PRESSURE, ENGINE OIL	9-13,9-218,9-73
PEDAL, BRAKE	5-14,5-2	CRANKSHAFT	8D-5	PRESSURE FOR HIGH SPEED, TIRE	22-3
PEDAL, CLUTCH	6-16	POSITION SENSOR—4.7L V-8 ENGINE,		PRESSURE, FUEL SYSTEM	14-27
PEDAL POSITION SWITCH, CLUTCH	6-5	CRANKSHAFT	8D-17	PRESSURE GAUGES	22-3
PER MILE, TIRE REVOLUTION	22-6	POSITION SENSOR—5.2/5.9L V-8		PRESSURE LEAK DOWN TEST, FUEL	14-8
PERFORMANCE, A/C	24-10	ENGINE, CRANKSHAFT	8D-4	PRESSURE LEAKAGE TEST, CYLINDER	
PERFORMANCE, ENGINE	9-219	POSITION SWITCH, CLUTCH PEDAL	6-5	COMBUSTION	9-10,9-129,9-216,9-70
PERFORMANCE, HEATER	24-17	POSITION SWITCH, PARK/NEUTRAL	21-130,	PRESSURE (MAP) SENSOR—2.5L	
PILOT BEARING	6-14	21-153,21-292,21-315		ENGINE, MANIFOLD ABSOLUTE	14-58
PIN REPLACEMENT, CAMSHAFT	9-43	POSITIVE CRANKCASE VENTILATION		PRESSURE (MAP) SENSOR—3.9/5.2/	
PINION GEAR	3-42,3-77	(PCV) SYSTEM—3.9/5.2/5.9L ENGINE	25-26	5.9L ENGINES, MANIFOLD ABSOLUTE	14-57
PINION GEAR DEPTH	3-48	POSITIVE CRANKCASE VENTILATION		PRESSURE (MAP) SENSOR—4.7L V-8	
PINION GEAR DEPTH, 8 1/4 AXLE	3-92	(PCV) SYSTEM—4.7L ENGINE	25-27	ENGINE, MANIFOLD ABSOLUTE	14-58
PINION GEAR DEPTH, 9 1/4 AXLE	3-93	POWER AMPLIFIER	8F-14,8F-3,8F-8	PRESSURE (MAP) SENSOR—PCM	
PINION SEAL	3-72	POWER BRAKE BOOSTER	5-15,5-3	INPUT, MANIFOLD ABSOLUTE	14-36
PINION SHAFT SEAL	3-37	POWER DISTRIBUTION, 8W-10	8W-1	PRESSURE PLATE, CLUTCH	6-2
PINION STEERING GEAR - 4X2, RACK &	19-12	POWER DISTRIBUTION CENTER	80-1,80-4	PRESSURE, POWER STEERING FLOW	19-4
PINION STEERING GEAR - 4X4, RACK &	19-13	POWER DISTRIBUTION SYSTEM	80-1	PRESSURE REGULATOR, FUEL	
PINION STEERING GEAR, RACK &	19-11,19-14	POWER DOOR LOCKS, 8W-61	8W-1	FILTER/FUEL	14-4
PIN-OUTS, 8W-80 CONNECTOR	8W-1	POWER GROUNDS	14-38	PRESSURE RELEASE PROCEDURE, FUEL	
PIPE, EXHAUST	11-10,11-3	POWER LOCK MOTOR	8P-3,8P-7,8P-9	SYSTEM	14-11
PIPE, EXTENSION	11-6	POWER LOCK SWITCH	8P-3,8P-5,8P-9	PRESSURE RELIEF VALVE, HIGH	24-7
PISTON AND CONNECTING ROD	9-123,9-182,	POWER LOCK SYSTEM	8P-1	PRESSURE SENDING UNIT, ENGINE OIL	9-188
9-193,9-210,9-49,9-64		POWER LOCK SYSTEM AND REMOTE		PRESSURE SENSOR, GOVERNOR	
PISTON AND CONNECTING ROD		KEYLESS ENTRY SYSTEM	8P-4	SOLENOID	21-154,21-317
ASSEMBLY	9-102,9-245,9-252	POWER MIRROR	8T-1,8T-4	PRESSURE SENSOR, LINE	21-449
PISTON AND CONNECTING ROD		POWER MIRROR SWITCH	8T-2,8T-3	PRESSURE SENSOR—PCM INPUT, OIL	14-37
INSPECTION	9-108	POWER MIRROR SYSTEM	8T-1,8T-2	PRESSURE SWITCH ASSEMBLY,	
PISTON, FRONT SERVO	21-191,21-357	POWER MIRRORS, 8W-62	8W-1	SOLENOID	21-438,21-450
PISTON, REAR SERVO	21-192,21-358	POWER OUTLET	8E-12,8E-5	PRESSURE SWITCH, POWER STEERING	14-65
PISTON RETAINER, OVERRUNNING		POWER OUTLET, CIGAR LIGHTER	8E-22	PRESSURE SWITCHES	21-438
CLUTCH CAM/OVERDRIVE	21-189,21-355	POWER SEAT, 8W-63	8W-1	PRESSURE SWITCH/HIGH PRESSURE	
PISTON RETAINER, OVERRUNNING		POWER SEAT ADJUSTER AND MOTORS	8R-1,	CUT-OFF SWITCH, DUAL FUNCTION	
CLUTCH/LOW-REVERSE DRUM/			8R-2,8R-3	HIGH	24-18
OVERDRIVE	21-223,21-391	POWER SEAT SWITCH	8R-1,8R-2	PRESSURE SWITCH—PCM INPUT,	
PISTON RING—FITTING	9-20	POWER SEAT SYSTEM	8R-1,8R-2	POWER STEERING	14-38
PISTON RINGS—FITTING	9-140,9-226,9-80	POWER STEERING	19-1	PRESSURE TEST, CYLINDER	
PISTON—FITTING	9-19,9-79	POWER STEERING FLOW AND		COMPRESSION	9-128,9-215,9-70,9-9
PISTONS	21-117,21-280,21-427	PRESSURE	19-4	PRESSURE TEST, FUEL PUMP	14-7
PISTONS—FITTING	9-139,9-225	POWER STEERING PRESSURE SWITCH	14-65	PRESSURE TEST, HYDRAULIC	21-132,21-294,
PIVOT, WIPER LINKAGE	8K-2,8K-9	POWER STEERING PRESSURE		21-443	
PLANETARY GEAR SET	21-476	SWITCH—PCM INPUT	14-38	PRESSURES, TIRE INFLATION	22-2
PLANETARY GEARSET	21-123,21-285	POWER STEERING PUMP	19-10,19-6	PROBLEMS, TROUBLESHOOTING	
PLANETARY GEARTRAIN	21-225,21-433,21-481	POWER STEERING PUMP - 2.5L	19-7	WIRING	8W-9
PLANETARY GEARTRAIN/OUTPUT		POWER STEERING PUMP - 3.9L & 5.9L		PRODUCTS, AFTERMARKET REPAIR	23-2
SHAFT	21-200,21-368,21-393	ENGINES	19-8	PROGRAMMING, REMOTE KEYLESS	
PLATE, BODY CODE	Intro-2	POWER STEERING PUMP - 4.7L	19-9	ENTRY TRANSMITTER	8P-9
PLATE, BRAKE SUPPORT	5-21	POWER STEERING PUMP - INITIAL		PROPELLER SHAFT	3-1,3-17
PLATE, CLUTCH PRESSURE	6-2	OPERATION	19-7	PROPELLER SHAFT ANGLE	
PLATE, EQUIPMENT IDENTIFICATION	Intro-3	POWER STEERING SYSTEM	19-2	MEASUREMENT	3-7
PLATE, FRONT AXLE SKID	13-8	POWER WINDOW MOTOR	8S-2,8S-4,8S-6	PROPELLER SHAFT, FRONT	3-10
PLATE LAMP BULB, LICENSE	8L-13	POWER WINDOW SWITCH	8S-1,8S-3,8S-5	PROPELLER SHAFT JOINT ANGLE	3-4
PLATE LAMP, LICENSE	8L-16	POWER WINDOW SYSTEM	8S-1,8S-2	PROPELLER SHAFT JOINTS	3-4
PLATE, TRANSFER CASE SKID	13-9	POWER WINDOWS, 8W-60	8W-1	PROPELLER SHAFT, REAR	3-10
PLATE, VEHICLE IDENTIFICATION		POWERED ENGINES ONLY, TASK		PROPELLER SHAFTS	3-1
NUMBER (VIN)	Intro-1	MANAGER—GASOLINE	25-16	PULLEY, PUMP	19-9
PLATE—4WD VEHICLES, FUEL TANK		POWERTRAIN CONTROL MODULE		PULLEY—2.5L/3.9L/5.9L ENGINES,	
SKID	13-9	(PCM); FUEL SYSTEM	14-31,14-59	IDLER	7-51
PLUG CABLE RESISTANCE, SPARK	8D-28	POWERTRAIN CONTROL MODULE		PULLEY—4.7L ENGINE NON A/C, IDLER	7-52
PLUG CABLES, SPARK	8D-12,8D-2,8D-8	(PCM); TRANSMISSION AND		PUMP - 2.5L, POWER STEERING	19-7
PLUG CONDITIONS, SPARK	8D-9	TRANSFER CASE	21-125,21-287	PUMP - 3.9L & 5.9L ENGINES, POWER	
PLUGS, ENGINE CORE	9-191	POWER-UP MODE	8Q-2	STEERING	19-8
PLUGS, ENGINE CORE OIL AND		PRE-ALIGNMENT INSPECTION	2-2	PUMP - 4.7L, POWER STEERING	19-9
CAMSHAFT	9-106,9-250	PRECAUTIONS, RWAL SERVICE	5-36	PUMP - INITIAL OPERATION, POWER	
PLUGS, SPARK	8D-13,8D-2,8D-28	PRECAUTIONS, SAFETY: CLUTCH	6-5	STEERING	19-7
PLUMBING, WASHER NOZZLE	8K-4	PRECAUTIONS, SAFETY: LAMPS	8L-2	PUMP 4.7L ENGINES, WATER	7-35
POLISHING, FINESSE SANDING,		PRECAUTIONS, SERVICE WARNINGS	24-22	PUMP AMPERAGE TEST, FUEL	14-9
BUFFING	23-1	PRECAUTIONS, WINDSHIELD SAFETY	23-4	PUMP AND REACTION SHAFT SUPPORT,	
POOR CONNECTIONS, INTERMITTENT	8W-8	PRELIMINARY CHECKS	7-14	OIL	21-192,21-224,21-358,21-392,21-481
PORTS, REFRIGERANT SYSTEM SERVICE	24-9	PRELIMINARY DIAGNOSIS	21-130,21-292,	PUMP BYPASS HOSE—3.9/5.9L	
POSITION SENSOR, CAMSHAFT	8D-17,8D-5	21-441		ENGINES, WATER	7-37
POSITION SENSOR, THROTTLE	21-439	PRELOAD AND GEAR BACKLASH,		PUMP BYPASS—3.9/5.9L ENGINES,	
POSITION SENSOR (TPS)—3.9/5.2/5.9L		DIFFERENTIAL BEARING	3-50,3-96	WATER	7-6
ENGINES, THROTTLE	14-54	PREPARATION, DRIVELINE ANGLE		PUMP BYPASS—4.7L, WATER	7-6
POSITION SENSOR (TPS)—4.7L V-8		MEASUREMENT	3-7	PUMP CAPACITY TEST, FUEL	14-8
ENGINE, THROTTLE	14-54	PREPARATION FOR HEADLAMP		PUMP FRONT SEAL, OIL	21-453
POSITION SENSOR (TPS)—PCM INPUT,		ALIGNMENT, VEHICLE	8L-7	PUMP, FUEL	14-2
THROTTLE	14-39	PREPARATION, LAMP ALIGNMENT		PUMP INLET FILTER, FUEL	14-16
POSITION SENSOR—2.5L ENGINE,		SCREEN	8L-7	PUMP (LDP), LEAK DETECTION	25-25,25-32,
CRANKSHAFT	8D-16,8D-3	PRESSURE CAP, RADIATOR	7-10	25-34	
POSITION SENSOR—2.5L ENGINE,		PRESSURE, CHECKING ENGINE OIL	9-132	PUMP LEAKAGE	19-7
THROTTLE	14-55	PRESSURE CONTROL, LINE	21-439		

Description	Group-Page	Description	Group-Page	Description	Group-Page
PUMP MODULE, FUEL	14-14,14-2	REAR DOOR GLASS	23-41	REINFORCEMENT, INSTRUMENT PANEL	
PUMP, OIL; ENGINE	9-102,9-107,9-108,9-187, 9-192,9-194,9-247,9-250,9-252,9-48	REAR DOOR GLASS RUN CHANNELS	23-40	LOWER	8E-19
PUMP, OIL; TRANSMISSION AND		REAR DOOR GLASS RUN		RELAY AND FUSE BLOCK	80-4,80-8
TRANSFER CASE	21-261,21-423,21-467,21-97	WEATHERSTRIP	23-40	RELAY, AUTOMATIC SHUTDOWN (ASD)	14-51
PUMP, POWER STEERING	19-10,19-6	REAR DOOR HINGE	23-37	RELAY, BLOWER MOTOR	24-13,24-2,24-25
PUMP PRESSURE TEST, FUEL	14-7	REAR DOOR INNER BELT		RELAY, COMPRESSOR CLUTCH	24-16,24-30, 24-4
PUMP PULLEY	19-9	WEATHERSTRIP	23-40	RELAY, DRIVER UNLOCK	8P-10,8P-4
PUMP RELAY, FUEL	14-52	REAR DOOR INSIDE HANDLE ACTUATOR	23-40	RELAY, FUEL PUMP	14-52
PUMP RELAY-PCM OUTPUT, FUEL	14-40	REAR DOOR LATCH	23-39	RELAY, HEADLAMP; POWER LOCK	
PUMP RELAYS, ASD AND FUEL	14-49	REAR DOOR LATCH STRIKER	23-39	SYSTEMS	8P-10,8P-4
PUMP RESERVOIR - 2.5L ENGINE	19-8	REAR DOOR OPENING WEATHERSTRIP	23-41	RELAY, HEADLAMP; VEHICLE THEFT/ SECURITY SYSTEMS	8Q-3,8Q-5
PUMP TESTS, WATER	7-13	REAR DOOR OUTER BELT		RELAY, HORN; HORN SYSTEMS	8G-2,8G-3,8G-4
PUMP VOLUME CHECK, OIL	21-149,21-311, 21-447	WEATHERSTRIP	23-41	RELAY, HORN; POWER LOCK SYSTEMS	8P-10, 8P-4
PUMP, WASHER	8K-4	REAR DOOR OUTSIDE HANDLE	23-39	RELAY, HORN; VEHICLE THEFT/ SECURITY SYSTEMS	8Q-3,8Q-6
PUMP, WATER	7-55,7-6	REAR DOOR QUARTER GLASS	23-42	RELAY, INTERMITTENT WIPE	8K-11,8K-3,8K-7
PUMP—2.5L ENGINE, WATER	7-30	REAR DOOR SECONDARY SEAL	23-41	RELAY SENSE—PCM INPUT, AUTOMATIC SHUTDOWN (ASD)	14-34
PUMP—3.9L/5.9L ENGINES, WATER	7-32	REAR DOOR TRIM PANEL	23-37	RELAY, STARTER	8B-12,8B-3,8B-8
PURGE SOLENOID, DUTY CYCLE EVAP CANISTER	25-25,25-33	REAR DOOR WATERDAM	23-38	RELAY, TRANSMISSION CONTROL	21-438
PUSH RODS, ROCKER ARMS	9-235,9-34,9-51	REAR DOOR WINDOW REGULATOR	23-42	RELAY—PCM OUTPUT, AUTO SHUTDOWN (ASD)	14-40
QUAD CAB ASSIST HANDLE	23-59	REAR DRUM BRAKE	5-27,5-28	RELAY—PCM OUTPUT, RADIATOR COOLING FAN	14-42
QUAD CAB, REAR SEAT	23-16	REAR GLASS HEATING GRID	8N-2,8N-3	RELAY-PCM OUTPUT, FUEL PUMP	14-40
QUAD CAB REAR SEAT CUSHION COVER	23-16	REAR GLASS HEATING GRID REPAIR	8N-4	RELAYS; POWER LOCK SYSTEMS	8P-8
QUARTER GLASS, REAR DOOR	23-42	REAR HOUSING YOKE BUSHING	21-43	RELAYS; VEHICLE THEFT/SECURITY SYSTEMS	8Q-4
QUARTER TRIM PANEL	23-51	REAR LIGHTING, 8W-51	8W-1	RELAYS, ASD AND FUEL PUMP	14-49
QUARTER VENT WINDOW	23-43	REAR MAIN OIL SEAL	9-50	RELAYS, OXYGEN SENSOR HEATER	14-52
QUARTER VENT WINDOW WEATHERSTRIP	23-44	REAR OIL SEALS, CRANKSHAFT	9-104	RELAYS—PCM OUTPUT, OXYGEN SENSOR HEATER	14-41
QUICK LEARN PROCEDURE, TRANSMISSION	21-447	REAR PARK BRAKE CABLES	5-22	RELEASE BEARING	6-14
QUICK-CONNECT FITTINGS	14-11,14-7	REAR PROPELLER SHAFT	3-10	RELEASE BEARING, CLUTCH	6-3
RACK & PINION STEERING GEAR	19-11,19-14	REAR RETAINER BUSHING AND SEAL	21-509, 21-536	RELEASE CABLE, HOOD	23-23
RACK & PINION STEERING GEAR - 4X2	19-12	REAR SEAL AREA LEAKS—INSPECTION	9-12, 9-131,9-217,9-71	RELEASE HANDLE, PARK BRAKE	8E-18
RACK & PINION STEERING GEAR - 4X4	19-13	REAR SEAT BACK—CLUB CAB	23-14	RELEASE HANDLE, TAILGATE LATCH	23-47
RADIAL-PLY TIRES	22-2	REAR SEAT BELT RETRACTOR—CLUB CAB	23-54	RELEASE OR ENGAGEMENT, IMPROPER CLUTCH	6-7
RADIATOR	7-44,7-5,7-55	REAR SEAT BELT/BUCKLE—CLUB CAB	23-53	RELEASE PROCEDURE, FUEL SYSTEM PRESSURE	14-11
RADIATOR CAP	7-55	REAR SEAT CUSHION COVER, QUAD CAB	23-16	RELIEF CHECK, RADIATOR CAP-TO- FILLER NECK SEAL—PRESSURE	7-26
RADIATOR CAP—PRESSURE TESTING	7-26	REAR SEAT CUSHION—CLUB CAB	23-15	RELIEF VALVE, HIGH PRESSURE	24-7
RADIATOR CAP-TO-FILLER NECK SEAL—PRESSURE RELIEF CHECK	7-26	REAR SEAT QUAD CAB	23-16	REMOTE KEYLESS ENTRY RECEIVER	8P-4
RADIATOR COOLANT FLOW CHECK	7-21	REAR SERVO	21-224,21-392	REMOTE KEYLESS ENTRY SYSTEM	8P-1
RADIATOR COOLING FAN RELAY—PCM OUTPUT	14-42	REAR SERVO PISTON	21-192,21-358	REMOTE KEYLESS ENTRY SYSTEM, POWER LOCK SYSTEM	8P-4
RADIATOR DRAINCOCK	7-52	REAR SPLASH SHIELD	23-46	REMOTE KEYLESS ENTRY TRANSMITTER	8P-3,8P-8
RADIATOR PRESSURE CAP	7-10	REAR STORAGE BOX	23-56	REMOTE KEYLESS ENTRY TRANSMITTER BATTERY REPLACEMENT	8P-8
RADIO FREQUENCY INTERFERENCE	8F-9	REAR SUPPORT, ENGINE	9-230,9-29,9-84	REMOTE KEYLESS ENTRY TRANSMITTER PROGRAMMING	8P-9
RADIO NOISE SUPPRESSION	8F-4	REAR SUSPENSION	2-23	REMOTE RADIO SWITCH	8F-11,8F-2,8F-6
RADIO NOISE SUPPRESSION COMPONENTS	8F-18	REAR WHEEL ANTILOCK	5-32,5-36	REPAIR, ALUMINUM THREAD	21-150,21-312, 21-448
RADIO RECEIVER	8F-10,8F-2,8F-5	REAR WHEEL ANTILOCK BRAKE BLEEDING	5-37	REPAIR DAMAGED OR WORN THREADS	9-135, 9-16,9-221,9-76
RADIO SWITCH, REMOTE	8F-11,8F-2,8F-6	REAR WHEEL ANTILOCK BRAKES	5-32	REPAIR PRODUCTS, AFTERMARKET	23-2
RAIL WEATHERSTRIP AND RETAINER, ROOF	23-43	REAR WHEEL ANTI-LOCK BRAKES, 8W-34	8W-1	REPAIR, REAR GLASS HEATING GRID	8N-4
RAIL/FUEL DAMPER—2.5L ENGINE, FUEL INJECTOR	14-19,14-6	REAR WHEEL ANTILOCK BRAKES, CONTROLLER	5-33	REPAIR, THREADED HOLE	Intro-7
RAIL—3.9/5.2/5.9L ENGINES, FUEL	14-5	REAR WHEEL SPEED SENSOR	5-38,5-47	REPAIR, WIRING	8W-10
RAIL—3.9/5.2/5.9L ENGINES, FUEL INJECTOR	14-18	REAR WHEEL SPEED SENSOR AND EXCITER RING	5-34	REPAIRING LEAKS	22-5
RAIL—4.7L ENGINE, FUEL INJECTOR	14-5	REAR WINDOW DEFOGGER SYSTEM	8N-1	REPAIR-MOLEX CONNECTORS, TERMINAL/CONNECTOR	8W-10
RAIL—4.7L V-8 ENGINE, FUEL INJECTOR	14-20	REARVIEW MIRROR	23-57	REPAIR—THOMAS AND BETTS CONNECTORS, TERMINAL/CONNECTOR	8W-10
RANGE SENSOR, TRANSMISSION	21-439	REARVIEW MIRROR SUPPORT BRACKET	23-57	REPLACEMENT-IN VEHICLE, VALVE SPRING AND STEM SEAL	9-236
RATINGS, GENERATOR	8C-6	RECEIVER, INSTRUMENT PANEL ASH	8E-20	REPLACEMENT—4.7L ENGINE, ACCESSORY BELT	7-48
RE TRANSMISSION	21-410,21-412	RECEIVER, RADIO	8F-10,8F-2,8F-5	REPROGRAMMING, PCM VIN	14-1
RE TRANSMISSIONS	21-243	RECEIVER, REMOTE KEYLESS ENTRY	8P-4	REQUIREMENTS, FUEL	14-27
REACTION SHAFT SUPPORT, OIL PUMP	21-192, 21-224,21-358,21-392,21-481	RECOMMENDATIONS, HOISTING	0-13	RESERVE/OVERFLOW SYSTEM, COOLANT	7-5
READING AND COURTESY LAMP		RECOMMENDATIONS, PARTS AND LUBRICANT	0-1	RESERVE/OVERFLOW TANK, COOLANT	7-30
HOUSING, OVERHEAD CONSOLE	8V-11	RECOVERY, REFRIGERANT	24-20	RESERVOIR - 2.5L ENGINE, PUMP	19-8
READING AND COURTESY LAMP LENS, OVERHEAD CONSOLE	8V-8	RED BRAKE WARNING LAMP	5-3,5-8	RESERVOIR, MASTER CYLINDER	5-23
READING AND COURTESY LAMP, OVERHEAD CONSOLE	8V-3	REFERENCES, TORQUE	Intro-7	RESERVOIR, VACUUM; HEATING AND AIR CONDITIONING	24-48,24-9
READING LAMP BULB, OVERHEAD CONSOLE	8L-13	REFRIGERANT	24-8	RESERVOIR, VACUUM; SPEED CONTROL SYSTEM	8H-3,8H-8
READING LAMP, OVERHEAD CONSOLE	8L-17	REFRIGERANT LINE COUPLER	24-45	RESERVOIR, WASHER	8K-4
REAR AXLE	3-69	REFRIGERANT LINE COUPLERS	24-8		
REAR BAND ADJUSTMENT	21-396	REFRIGERANT LINES	24-8		
REAR BEARING, OUTPUT SHAFT	21-159,21-321	REFRIGERANT OIL	24-8		
REAR BRAKE SHOES	5-19	REFRIGERANT OIL LEVEL	24-19		
REAR BUMPER	13-2	REFRIGERANT RECOVERY	24-20		
REAR CAB BACK PANEL TRIM	23-51	REFRIGERANT SYSTEM CHARGE	24-20		
REAR CLUTCH	21-120,21-197,21-225,21-282, 21-364,21-393	REFRIGERANT SYSTEM EVACUATE	24-20		
REAR DOOR	23-37	REFRIGERANT SYSTEM LEAKS	24-19		
REAR DOOR ADJUSTMENT	23-61	REFRIGERANT SYSTEM SERVICE EQUIPMENT	24-20		
		REFRIGERANT SYSTEM SERVICE PORTS	24-9		
		REGULATOR, ELECTRONIC VOLTAGE	8C-2		
		REGULATOR, FRONT DOOR WINDOW	23-35		
		REGULATOR, FUEL FILTER/FUEL PRESSURE	14-4		
		REGULATOR, REAR DOOR WINDOW	23-42		

Description	Group-Page	Description	Group-Page	Description	Group-Page
RESISTANCE, SPARK PLUG CABLE	8D-28	SEAL AND BEARING, 8 1/4 AND 9 1/4 AXLE	3-71	SENSOR, AMBIENT TEMPERATURE	8V-13,8V-4, 8V-5
RESISTANCE—4.7L V-8 ENGINE, IGNITION COIL	8D-28	SEAL AND BEARING, AXLE SHAFT	3-39	SENSOR AND EXCITER RING, REAR WHEEL SPEED	5-34
RESISTANCE—EXCEPT 4.7L ENGINE, IGNITION COIL	8D-28	SEAL AREA LEAKS—INSPECTION, REAR	9-12, 9-131,9-217,9-71	SENSOR, BATTERY TEMPERATURE	8C-2,8C-5
RESISTOR, BLOWER MOTOR	24-14,24-25,24-3	SEAL, BOOT	19-14	SENSOR, CAMSHAFT POSITION	8D-17,8D-5
RESTRAINT SYSTEMS, PASSIVE	8M-16	SEAL, CARGO BOX	23-49	SENSOR, GOVERNOR SOLENOID AND PRESSURE	21-154,21-317
RETRACTOR BUSHING AND SEAL, REAR	21-509, 21-536	SEAL, COWL	23-24	SENSOR HEATER RELAYS, OXYGEN	14-52
RETAINER, OVERRUNNING CLUTCH CAM/OVERDRIVE PISTON	21-189,21-355	SEAL, CRANKSHAFT FRONT OIL	9-103	SENSOR HEATER RELAYS—PCM OUTPUT, OXYGEN	14-41
RETAINER, OVERRUNNING CLUTCH/ LOW-REVERSE DRUM/OVERDRIVE PISTON	21-223,21-391	SEAL, FRONT DOOR	23-36	SENSOR, INPUT SPEED	21-448
RETAINER, ROOF RAIL WEATHERSTRIP	23-43	SEAL, FRONT DOOR SECONDARY	23-37	SENSOR, LINE PRESSURE	21-449
RETAINER/BULKHEAD, 4C	21-474	SEAL, FRONT OUTPUT SHAFT	21-509,21-536	SENSOR (O2S)—PCM INPUT, OXYGEN	14-37
RETRACTOR, FRONT SEAT BELT	23-52	SEAL, HOOD	23-24	SENSOR, OUTPUT SPEED	21-448
RETRACTOR—CLUB CAB, REAR SEAT BELT	23-54	SEAL, OIL PUMP FRONT	21-453	SENSOR, REAR WHEEL SPEED	5-38,5-47
RETRACTOR—QUAD CAB, SEAT BELT	23-52	SEAL, OUTPUT SHAFT	21-6	SENSOR RETURN—PCM INPUT	14-39
RETURN—PCM INPUT, SENSOR	14-39	SEAL, PINION	3-72	SENSOR SUPPLIES—PRIMARY AND SECONDARY, FIVE VOLT	14-35
REVOLUTION PER MINUTE, TIRE	22-6	SEAL, PINION SHAFT	3-37	SENSOR, THROTTLE POSITION	21-439
RIGHT, ENGINE MOUNTS—LEFT	9-145	SEAL, REAR DOOR SECONDARY	23-41	SENSOR (TPS)—3.9/5.2/5.9L ENGINES, THROTTLE POSITION	14-54
RIGHT FRONT FENDER	23-26	SEAL, REAR MAIN OIL	9-50	SENSOR (TPS)—4.7L V-8 ENGINE, THROTTLE POSITION	14-54
RING, EXCITER	5-39,5-47	SEAL, REAR RETAINER BUSHING	21-509,21-536	SENSOR (TPS)—PCM INPUT, THROTTLE POSITION	14-39
RING GEAR	3-41	SEAL REPLACEMENT, YOKE	21-152,21-315	SENSOR, TRANSMISSION RANGE	21-439
RING GEAR AND EXCITER RING	3-75	SEAL REPLACEMENT-IN VEHICLE, VALVE SPRING AND STEM	9-236	SENSOR, TRANSMISSION TEMPERATURE	21-440
RING, REAR WHEEL SPEED SENSOR AND EXCITER	5-34	SEAL, TIMING CASE COVER OIL	9-39	SENSOR, WASHER FLUID LEVEL	8K-4
RING, RING GEAR AND EXCITER	3-75	SEAL, VALVE, GUIDE	9-17	SENSOR, WHEEL SPEED	5-42
RING—FITTING, PISTON	9-20	SEAL, VALVE SPRING	9-35	SENSOR—2.5L ENGINE, CRANKSHAFT POSITION	8D-16,8D-3
RINGS—FITTING, PISTON	9-140,9-226,9-80	SEAL, VALVE STEM	9-123	SENSOR—2.5L ENGINE, ENGINE COOLANT TEMPERATURE	14-63
ROAD TEST	8H-4	SEALER LOCATIONS	23-94	SENSOR—2.5L ENGINE, INTAKE MANIFOLD AIR TEMPERATURE	14-64
ROAD TEST, ANALYZING	21-131,21-293	SEAL—2WD, YOKE	21-43	SENSOR—2.5L ENGINE, MANIFOLD ABSOLUTE PRESSURE (MAP)	14-58
ROAD TESTING	21-131,21-293,21-442	SEAL—FRONT, CRANKSHAFT OIL	9-189,9-247	SENSOR—2.5L ENGINE, OXYGEN	14-61
ROCKER ARM	9-124	SEAL—PRESSURE RELIEF CHECK, RADIATOR CAP-TO-FILLER NECK	7-26	SENSOR—2.5L ENGINE, THROTTLE POSITION	14-55
ROCKER ARMS	9-157	SEAL—REAR, CRANKSHAFT OIL	9-191	SENSOR—3.9/5.2/5.9L ENGINES, CRANKSHAFT POSITION	8D-16
ROCKER ARMS AND PUSH RODS	9-235,9-34, 9-51	SEALS, CRANKSHAFT OIL	9-209,9-5,9-65	SENSOR—3.9/5.2/5.9L ENGINES, ENGINE COOLANT TEMPERATURE	14-62
ROD ASSEMBLY, PISTON AND CONNECTING	9-102,9-245,9-252	SEALS, CRANKSHAFT REAR OIL	9-104	SENSOR—3.9/5.2/5.9L ENGINES, INTAKE MANIFOLD AIR TEMPERATURE	14-64
ROD BEARINGS—FITTING, CONNECTING	9-142, 9-22,9-227,9-81	SEALS, VALVE SPRINGS	9-163	SENSOR—3.9/5.2/5.9L ENGINES, MANIFOLD ABSOLUTE PRESSURE (MAP)	14-57
ROD END, TIE	19-11	SEALS—REAR, CRANKSHAFT OIL	9-248	SENSOR—3.9L V-6 ENGINE, CRANKSHAFT POSITION	8D-4
ROD INSPECTION, PISTON AND CONNECTING	9-108	SEAT, 8W-63 POWER	8W-1	SENSOR—4.7L ENGINE, CAMSHAFT POSITION	8D-18,8D-6
ROD, PISTON AND CONNECTING	9-123,9-182, 9-193,9-210,9-49,9-64	SEAT ADJUSTER AND MOTORS, POWER	8R-1, 8R-2,8R-3	SENSOR—4.7L ENGINE, CRANKSHAFT POSITION	8D-5
RODS, ROCKER ARMS AND PUSH	9-235,9-34, 9-51	SEAT BACK, BENCH	23-9	SENSOR—4.7L V-8 ENGINE, ENGINE COOLANT TEMPERATURE	14-63
ROLLOVER VALVE(S)	25-24,25-34	SEAT BACK, BUCKET	23-11	SENSOR—4.7L V-8 ENGINE, INTAKE MANIFOLD AIR TEMPERATURE	14-64
ROOF JOINT MOLDING	23-43	SEAT BACK PAD/COVER, BENCH	23-10	SENSOR—5.2/5.9L V-8 ENGINE, CRANKSHAFT POSITION	8D-4
ROOF RAIL WEATHERSTRIP AND RETAINER	23-43	SEAT BACK PAD/COVER, BUCKET	23-11	SENSOR—EXCEPT 2.5L ENGINE, OXYGEN	14-59
ROTATION	22-4	SEAT BACK—CLUB CAB, REAR	23-14	SENSOR—PCM INPUT, ENGINE COOLANT TEMPERATURE	14-35
ROTOR, DISC BRAKE	5-19,5-9	SEAT BELT BUCKLE	23-53	SENSOR—PCM INPUT, FUEL LEVEL	14-35
ROTOR, DISTRIBUTOR	8D-7	SEAT BELT RETRACTOR, FRONT	23-52	SENSOR—PCM INPUT, INTAKE MANIFOLD AIR TEMPERATURE	14-35
ROTOR MACHINING, DISC	5-12	SEAT BELT RETRACTOR—CLUB CAB, REAR	23-54	SENSOR—PCM INPUT, MANIFOLD ABSOLUTE PRESSURE (MAP)	14-36
RUN CHANNELS, FRONT DOOR LOWER GLASS	23-36	SEAT BELT RETRACTOR—QUAD CAB	23-52	SENSOR—PCM INPUT, OIL PRESSURE	14-37
RUN CHANNELS, REAR DOOR GLASS	23-40	SEAT BELT SWITCH, DRIVER	8U-2,8U-5	SENSORS, INPUT AND OUTPUT SPEED	21-439
RUN WEATHERSTRIP, FRONT DOOR GLASS	23-36	SEAT BELT/BUCKLE—CLUB CAB, REAR	23-53	SERVO CABLE	8H-3
RUN WEATHERSTRIP, REAR DOOR GLASS	23-40	SEAT, BENCH	23-8	SERVO CABLE (EXCEPT 4.7L ENGINE)	8H-6
RUNNING LAMP MODULE (DRLM), DAYTIME	8L-18	SEAT, BUCKET	23-10	SERVO CABLE—4.7L V-8 ENGINE	8H-6
RUNOUT	3-6	SEAT CUSHION COVER, QUAD CAB	23-16	SERVO, FRONT	21-224,21-392
RUNOUT, CLUTCH COVER AND DISC	6-7	SEAT CUSHION/COVER, BENCH	23-10	SERVO PISTON, FRONT	21-191,21-357
RUNOUT, CLUTCH FLYWHEEL	6-7	SEAT CUSHION/COVER, BUCKET	23-11	SERVO PISTON, REAR	21-192,21-358
RUNOUT, TIRE AND WHEEL	22-7	SEAT CUSHION/COVER, CENTER	23-13	SERVO, REAR	21-224,21-392
RWAL COMPONENT LOCATION	5-33	SEAT CUSHION—CLUB CAB, REAR	23-15	SERVO, SPEED CONTROL	8H-2,8H-4
RWAL SERVICE PRECAUTIONS	5-36	SEAT QUAD CAB, REAR	23-16	SERVOS	21-124,21-286
RWAL VALVE	5-34,5-38	SEAT SWITCH, POWER	8R-1,8R-2	SET, PLANETARY GEAR	21-476
SAFETY LATCH, HOOD	23-22	SEAT SYSTEM, POWER	8R-1,8R-2		
SAFETY PRECAUTIONS; CLUTCH	6-5	SEAT SYSTEMS	23-8		
SAFETY PRECAUTIONS; LAMPS	8L-2	SEAT TRACK, BENCH	23-9		
SAFETY PRECAUTIONS, WINDSHIELD	23-4	SEAT TRACK, BUCKET	23-11		
SANDING, BUFFING, AND POLISHING, FINESSE	23-1	SEAT/CONSOLE, CENTER	23-12		
SCAN TOOL, DRB	7-13	SEATS	23-8		
SCHEDULES, MAINTENANCE	0-4	SECONDARY, FIVE VOLT SENSOR SUPPLIES—PRIMARY	14-35		
SCHEMATICS, HYDRAULIC	21-229,21-397, 21-482	SECONDARY SEAL, FRONT DOOR	23-37		
SCHEMATICS, VACUUM	25-32	SECONDARY SEAL, REAR DOOR	23-41		
SCREEN PREPARATION, LAMP ALIGNMENT	8L-7	SECTION IDENTIFICATION	8W-5		
SEAL, ADAPTER HOUSING	21-453	SECURITY LAMP	8Q-3		
		SECURITY SYSTEM, 8W-39 VEHICLE THEFT	8W-1		
		SECURITY SYSTEM, VEHICLE THEFT	8Q-1,8Q-4		
		SELECTION AND ADDITIVES, COOLANT	7-30		
		SELECTOR INDICATOR, GEAR	8E-17,8E-5		
		SENDING UNIT, ENGINE OIL PRESSURE	9-188		
		SENDING UNIT, FUEL GAUGE	14-10,14-16,14-3		
		SENSE—PCM INPUT, AUTOMATIC SHUTDOWN (ASD) RELAY	14-34		
		SENSE—PCM INPUT, IGNITION CIRCUIT	14-35		
		SENSITIVE DEVICES, ELECTROSTATIC DISCHARGE (ESD)	8W-8		
		SENSOR - 4X2, FRONT WHEEL SPEED	5-45		
		SENSOR - 4X4, FRONT WHEEL SPEED	5-46		

Description	Group-Page	Description	Group-Page	Description	Group-Page
SHAFT ANGLE MEASUREMENT, PROPELLER	3-7	SOLENOID AND PRESSURE SWITCH ASSEMBLY	21-438,21-450	STEERING PRESSURE SWITCH, POWER	14-65
SHAFT, AXLE	3-39,3-70	SOLENOID CIRCUITS, SPEED CONTROL	8H-2	STEERING PRESSURE SWITCH—PCM INPUT, POWER	14-38
SHAFT BUSHING, DISTRIBUTOR DRIVE	9-242, 9-94	SOLENOID, DUTY CYCLE EVAP CANISTER PURGE	25-25,25-33	STEERING PUMP - 2.5L, POWER	19-7
SHAFT BUSHING, OUTPUT	21-6	SOLENOID SWITCH VALVE	21-440	STEERING PUMP - 3.9L & 5.9L ENGINES, POWER	19-8
SHAFT FRONT BEARING, OUTPUT	21-159, 21-322	SOLENOIDS	21-440	STEERING PUMP - 4.7L, POWER	19-9
SHAFT, FRONT PROPELLER	3-10	SPARE TIRE WINCH	13-10	STEERING PUMP - INITIAL OPERATION, POWER	19-7
SHAFT JOINT ANGLE, PROPELLER	3-4	SPARE TIRE—TEMPORARY	22-2	STEERING PUMP, POWER	19-10,19-6
SHAFT JOINTS, PROPELLER	3-4	SPARK PLUG CABLE RESISTANCE	8D-28	STEERING SYSTEM	19-1
SHAFT, PLANETARY GEARTRAIN/OUTPUT	21-200,21-368,21-393	SPARK PLUG CABLES	8D-12,8D-2,8D-8	STEERING SYSTEM, POWER	19-2
SHAFT, PROPELLER	3-1,3-17	SPARK PLUG CONDITIONS	8D-9	STEM SEAL REPLACEMENT-IN VEHICLE, VALVE SPRING	9-236
SHAFT REAR BEARING, OUTPUT	21-159,21-321	SPARK PLUGS	8D-13,8D-2,8D-28	STEM SEAL, VALVE	9-123
SHAFT, REAR PROPELLER	3-10	SPEAKER	8F-11,8F-7	STOP LAMP (CHMSL) BULB, CENTER HIGH MOUNTED	8L-12
SHAFT SEAL AND BEARING, AXLE	3-39	SPEAKER SYSTEM	8F-3	STOP LAMP (CHMSL), CENTER HIGH MOUNTED	8L-15
SHAFT SEAL, FRONT OUTPUT	21-509,21-536	SPECIFICATIONS, 3.9L ENGINE	9-111	STOP LAMP SWITCH	5-2
SHAFT SEAL, OUTPUT	21-6	SPECIFICATIONS, 5.9L ENGINE	9-255	STOP, TURN SIGNAL AND BACK-UP LAMP, TAIL	8L-16
SHAFT SEAL, PINION	3-37	SPECIFICATIONS, ENGINE	9-53	STORAGE BIN DOOR, GARAGE DOOR OPENER	8V-12
SHAFT SUPPORT, OIL PUMP AND REACTION	21-192,21-224,21-358,21-392,21-481	SPECIFICATIONS, TORQUE; BODY	23-116	STORAGE BIN, GARAGE DOOR OPENER	8V-3
SHAFT—TIMING DRIVE, IDLER	9-172	SPECIFICATIONS, TORQUE; COOLING SYSTEM	7-56	STORAGE BIN, SUNGLASSES	8V-12,8V-4
SHAFTS, PROPELLER	3-1	SPECIFICATIONS, TORQUE; ENGINE	9-115	STORAGE BOX, REAR	23-56
SHIELD, REAR SPLASH	23-46	SPECIFICATIONS, TORQUE; EXHAUST SYSTEM	11-10	STRETCH, MEASURING TIMING CHAIN	9-225
SHIELDS, EXHAUST HEAT	11-1	SPECIFICATIONS, TORQUE; FRAME AND BUMPERS	13-16	STRETCH—MEASURING, TIMING CHAIN	9-79
SHIELDS, HEAT	11-7	SPECIFICATIONS—TORQUE	9-56	STRIKER, FRONT DOOR LATCH	23-34
SHIFT BEZEL	23-55	SPEED AND DISTANCE—PCM INPUT, VEHICLE	14-40	STRIKER, GLOVE BOX LATCH	8E-23
SHIFT BOOT, FLOOR	23-54	SPEED CONTROL, 8W-33 VEHICLE	8W-1	STRIKER, HOOD LATCH	23-22,23-59
SHIFT INTERLOCK, COLUMN	8D-26	SPEED CONTROL SERVO	8H-2,8H-4	STRIKER, REAR DOOR LATCH	23-39
SHIFT LEVER, GEAR	19-18	SPEED CONTROL SOLENOID CIRCUITS	8H-2	STRIKER, TAILGATE LATCH	23-48
SHIFT TOWER	21-42,21-5	SPEED CONTROL SWITCHES	8H-2,8H-5	STRUCTURAL ADHESIVE LOCATIONS	23-89
SHIFTER ADJUSTMENT	21-530,21-560	SPEED CONTROL SYSTEM	8H-1	STRUCTURAL COVER	9-147
SHIFTER, TRANSFER CASE	21-509,21-535	SPEED INPUT, VEHICLE	8H-3	STRUCTURAL DUST COVER	9-124
SHIFTING, HARD	21-39,21-4	SPEED KNOCK, LOW	3-35,3-68	STUDS, WHEEL MOUNTING	2-12,2-21
SHOCK ABSORBER	2-16,2-24,2-8	SPEED SENSOR - 4X2, FRONT WHEEL	5-45	SUCTION AND DISCHARGE LINE	24-46
SHOCK ABSORBERS	2-14,2-23,2-6	SPEED SENSOR - 4X4, FRONT WHEEL	5-46	SUNGLASSES STORAGE BIN	8V-12,8V-4
SHOCK DIAGNOSIS	2-16,2-8	SPEED SENSOR AND EXCITER RING, REAR WHEEL	5-34	SUNVISORS	23-58
SHOCK, SPRING	2-24	SPEED SENSOR, INPUT	21-448	SUPPLIES—PRIMARY AND SECONDARY, FIVE VOLT SENSOR	14-35
SHOES, DISC BRAKE	5-17	SPEED SENSOR, OUTPUT	21-448	SUPPLY TEST, VACUUM	8H-4
SHOES, REAR BRAKE	5-19	SPEED SENSOR, REAR WHEEL	5-38,5-47	SUPPORT BRACKET, INSTRUMENT PANEL CENTER	8E-19
SHUDDER OR VIBRATION DURING ACCELERATION	3-20	SPEED SENSOR, WHEEL	5-42	SUPPORT BRACKET, REARVIEW MIRROR	23-57
SHUTDOWN (ASD) RELAY, AUTOMATIC	14-51	SPEED SENSORS, INPUT AND OUTPUT	21-439	SUPPORT, ENGINE REAR	9-230,9-29,9-84
SHUTDOWN (ASD) RELAY SENSE—PCM INPUT, AUTOMATIC	14-34	SPEED, TIRE PRESSURE FOR HIGH SPEEDS, VIBRATION AT HIGHWAY	22-3, 3-20	SUPPORT, OIL PUMP AND REACTION SHAFT	21-192,21-224,21-358,21-392,21-481
SHUTDOWN (ASD) RELAY—PCM OUTPUT, AUTO	14-40	SPLASH SHIELD, REAR	23-46	SUPPORT PLATE, BRAKE	5-21
SIDE AIRBAG MODULE, DRIVER	8M-2,8M-6	SPLICE INFORMATION, 8W-70	8W-1	SUPPRESSION COMPONENTS, RADIO NOISE	8F-18
SIDE AIRBAG MODULE, PASSENGER	8M-3,8M-9	SPLICE LOCATIONS	8W-1,8W-7	SUPPRESSION, RADIO NOISE	8F-4
SIDE AIRBAG MODULE TRIM COVER, DRIVER	8M-8	SPLICE LOCATIONS, 8W-95	8W-1	SURFACE TOUCH-UP, PAINTED	23-2
SIDE AIRBAG ON/OFF SWITCH, PASSENGER	8M-12,8M-3	SPRING AND SEAL, VALVE	9-35	SUSPENSION - 4X2, FRONT	2-6
SIDE BEARINGS, DIFFERENTIAL	3-41,3-75	SPRING AND SHOCK	2-24	SUSPENSION - 4X4, FRONT	2-14
SIDE GEAR CLEARANCE	3-99	SPRING AND STEM SEAL REPLACEMENT-IN VEHICLE, VALVE	9-236	SUSPENSION ARM, LOWER	2-10,2-18
SIDE MARKER LAMP BULB, FRONT	8L-12	SPRING, COIL	2-8	SUSPENSION ARM, UPPER	2-10,2-19
SIDE MARKER LAMP, PARK, TURN SIGNAL	8L-14	SPRING, VALVE	9-123	SUSPENSION ARMS	2-15,2-7
SIDE MOLDINGS, BODY	23-45	SPRINGS, ADJUSTMENT AT AXLE WITH LEAF	3-17	SUSPENSION, FRONT	2-13,2-22
SIDE VIEW MIRROR	23-28	SPRINGS AND SEALS, VALVE	9-163	SUSPENSION HEIGHT- 4X4	2-23
SIGNAL AND BACK-UP LAMP BULBS, TAIL, BRAKE, TURN	8L-12	SPRINGS, COIL	2-7	SUSPENSION, REAR	2-23
SIGNAL AND BACK-UP LAMP, TAIL, STOP, TURN	8L-16	SPRINGS, LEAF	2-23,2-25	SWITCH AND HAZARD WARNING SWITCH, TURN SIGNAL	8J-2,8J-5,8J-6
SIGNAL AND HAZARD WARNING SYSTEMS, TURN	8J-4	SPRINGS, VALVES AND VALVE	9-209,9-237,9-64	SWITCH AND KEY CYLINDER, IGNITION	8D-23
SIGNAL AND SIDE MARKER LAMP, PARK, TURN	8L-14	SPRINGS, VALVES, GUIDES	9-77	SWITCH AND KEY LOCK CYLINDER, IGNITION	8D-11,8D-6
SIGNAL CANCELLING CAM, TURN	8J-2	SPRINGS—CYLINDER HEAD REMOVED, VALVES AND VALVE	9-91	SWITCH AND WASHER SWITCH, WIPER	8K-11, 8K-2,8K-6
SIGNAL GROUND—PCM INPUT	14-39	SPROCKETS, TIMING CHAIN	9-166,9-40	SWITCH ASSEMBLY, SOLENOID AND PRESSURE	21-438,21-450
SIGNAL LAMP BULBS, PARK AND TURN	8L-12	STABILIZER BAR	2-11,2-15,2-20,2-23,2-24,2-7	SWITCH, BLOWER MOTOR	24-15,24-3
SIGNAL SWITCH AND HAZARD WARNING SWITCH, TURN	8J-2,8J-5,8J-6	STAKING, HEAT	23-20	SWITCH, BRAKE LAMP; BRAKES	5-13,5-36,5-8
SIGNAL SYSTEM, TURN	8J-1	STANDARD DIFFERENTIAL	3-32,3-47,3-64,3-82	SWITCH, BRAKE LAMP; SPEED CONTROL SYSTEM	8H-3
SIGNALS, 8W-52 TURN	8W-1	STARTER MOTOR	8B-10,8B-2,8B-8	SWITCH, CLUTCH PEDAL POSITION	6-5
SILENCER PAD, HOOD	23-21	STARTER RELAY	8B-12,8B-3,8B-8	SWITCH, DEFOGGER	8N-2,8N-3,8N-5
SILL TRIM COVER, DOOR	23-50	STARTING PROCEDURE, JUMP	0-10	SWITCH, DOOR AJAR	8Q-3,8Q-4
SINGLE CARDAN UNIVERSAL JOINT	3-11	STARTING SYSTEM	8B-1,8B-13,8B-3	SWITCH, DOOR LOCK CYLINDER	8Q-3,8Q-4
SKID PLATE, FRONT AXLE	13-8	STARTING SYSTEM, 8W-21	8W-1	SWITCH, DRIVER DOOR AJAR	8U-2,8U-3
SKID PLATE, TRANSFER CASE	13-9	STARTING, TOWING AND HOISTING, JUMP	0-10	SWITCH, DRIVER SEAT BELT	8U-2,8U-5
SKID PLATE—4WD VEHICLES, FUEL TANK	13-9	STATE DISPLAY TEST MODE	25-2	SWITCH, DUAL FUNCTION HIGH PRESSURE SWITCH/HIGH PRESSURE CUT-OFF	24-18
SLIDING VENT GLASS, BACKLITE	23-52	STATIONARY GLASS	23-4	SWITCH, GLOVE BOX LAMP	8E-23
SNAP, DRIVELINE	3-36,3-68	STEERING COLUMN	19-15,19-16	SWITCH, HEADLAMP; CHIME/BUZZER WARNING SYSTEMS	8U-2,8U-4
SOLENOID AND PRESSURE SENSOR, GOVERNOR	21-154,21-317	STEERING COLUMN OPENING COVER	8E-16		
		STEERING FLOW AND PRESSURE, POWER	19-4		
		STEERING GEAR - 4X2, RACK & PINION	19-12		
		STEERING GEAR - 4X4, RACK & PINION	19-13		
		STEERING GEAR, RACK & PINION	19-11,19-14		
		STEERING KNUCKLE	2-15,2-17,2-7,2-9		
		STEERING, POWER	19-1		

Description	Group-Page	Description	Group-Page	Description	Group-Page
SWITCH, HEADLAMP; INSTRUMENT PANEL SYSTEMS	8E-13	SYSTEM, POWER DISTRIBUTION	80-1	TEMPERATURE SENSOR—2.5L ENGINE, INTAKE MANIFOLD AIR	14-64
SWITCH, HIGH PRESSURE CUT-OFF	24-42,24-7	SYSTEM, POWER LOCK	8P-1	TEMPERATURE SENSOR—3.9/5.2/5.9L ENGINES, ENGINE COOLANT	14-62
SWITCH, HORN	8G-2,8G-4	SYSTEM, POWER LOCK SYSTEM AND REMOTE KEYLESS ENTRY	8P-4	TEMPERATURE SENSOR—3.9/5.2/5.9L ENGINES, INTAKE MANIFOLD AIR	14-64
SWITCH, IGNITION	19-16	SYSTEM, POWER MIRROR	8T-1,8T-2	TEMPERATURE SENSOR—4.7L V-8 ENGINE, ENGINE COOLANT	14-63
SWITCH, KEY-IN IGNITION	8U-2,8U-4	SYSTEM, POWER SEAT	8R-1,8R-2	TEMPERATURE SENSOR—4.7L V-8 ENGINE, INTAKE MANIFOLD AIR	14-64
SWITCH, LOW PRESSURE CYCLING CLUTCH	24-18,24-43,24-7	SYSTEM, POWER STEERING	19-2	TEMPERATURE SENSOR—PCM INPUT, ENGINE COOLANT	14-35
SWITCH, OVERDRIVE OFF	21-129,21-291,21-435	SYSTEM, POWER WINDOW	8S-1,8S-2	TEMPERATURE SENSOR—PCM INPUT, INTAKE MANIFOLD AIR	14-35
SWITCH, PARK/NEUTRAL POSITION	21-130, 21-153,21-292,21-315	SYSTEM PRESSURE, FUEL	14-27	TENSIONER 3.9L/5.9L ENGINES, AUTOMATIC BELT	7-50
SWITCH, PASSENGER SIDE AIRBAG ON/OFF	8M-12,8M-3	SYSTEM PRESSURE RELEASE PROCEDURE, FUEL	14-11	TENSIONER, AUTOMATIC BELT	7-8
SWITCH, POWER LOCK	8P-3,8P-5,8P-9	SYSTEM, REAR WINDOW DEFOGGER	8N-1	TENSIONER, PARK BRAKE CABLE	5-29
SWITCH, POWER MIRROR	8T-2,8T-3	SYSTEM, REMOTE KEYLESS ENTRY	8P-1	TENSIONER, TIMING CHAIN	9-64,9-97
SWITCH, POWER SEAT	8R-1,8R-2	SYSTEM SERVICE EQUIPMENT, REFRIGERANT	24-20	TENSIONER—2.5L, ACCESSORY DRIVE BELT	7-50
SWITCH, POWER STEERING PRESSURE	14-65	SYSTEM SERVICE PORTS, REFRIGERANT	24-9	TENSIONER—4.7L ENGINE, AUTOMATIC BELT	7-51
SWITCH, POWER WINDOW	8S-1,8S-3,8S-5	SYSTEM, SPEAKER	8F-3	TENSION—2.5L ENGINE, ACCESSORY DRIVE BELT	7-56
SWITCH, REMOTE RADIO	8F-11,8F-2,8F-6	SYSTEM, SPEED CONTROL	8H-1	TERMINAL REPLACEMENT	8W-13
SWITCH, STOP LAMP	5-2	SYSTEM, STARTING	8B-1,8B-13,8B-3	TERMINAL REPLACEMENT, CONNECTOR	8W-12
SWITCH, TURN SIGNAL SWITCH AND HAZARD WARNING	8J-2,8J-5,8J-6	SYSTEM, STEERING	19-1	TERMINAL/CONNECTOR REPAIR—MOLEX CONNECTORS	8W-10
SWITCH VALVE, SOLENOID	21-440	SYSTEM SWITCHES, CHIME WARNING	8U-5	TERMINAL/CONNECTOR REPAIR—THOMAS AND BETTS CONNECTORS	8W-10
SWITCH, WIPER SWITCH AND WASHER	8K-11, 8K-2,8K-6	SYSTEM TEST—4.7L V-8 ENGINE, PCV VALVE/PCV	25-31	TEST, ANALYZING ROAD	21-131,21-293
SWITCHES, CHIME WARNING SYSTEM	8U-5	SYSTEM, TIMING DRIVE	9-123	TEST, CYLINDER COMBUSTION PRESSURE LEAKAGE	9-10,9-129,9-216,9-70
SWITCHES, PRESSURE	21-438	SYSTEM, TURN SIGNAL	8J-1	TEST, CYLINDER COMPRESSION PRESSURE	9-128,9-215,9-70,9-9
SWITCHES, SPEED CONTROL	8H-2,8H-5	SYSTEM, VACUUM	24-50	TEST FOR CHARGING SYSTEM, ON-BOARD DIAGNOSTIC	8C-3
SWITCH/HIGH PRESSURE CUT-OFF SWITCH, DUAL FUNCTION HIGH PRESSURE	24-18	SYSTEM, VEHICLE THEFT SECURITY	8Q-1,8Q-4	TEST, FUEL INJECTOR	14-11
SWITCH—PCM INPUT, BRAKE	14-34	SYSTEM, WASHER	8K-12,8K-5	TEST, FUEL PRESSURE LEAK DOWN	14-8
SWITCH—PCM INPUT, POWER STEERING PRESSURE	14-38	SYSTEM, WINDSHIELD WASHER	8K-1	TEST, FUEL PUMP AMPERAGE	14-9
SYMBOLS	8W-5	SYSTEM, WINDSHIELD WIPER	8K-1	TEST, FUEL PUMP CAPACITY	14-8
SYMBOLS, INTERNATIONAL; INTRODUCTION	Intro.-3	SYSTEM, WIPER	8K-4	TEST, FUEL PUMP PRESSURE	14-7
SYMBOLS, INTERNATIONAL; LUBRICATION AND MAINTENANCE	0-1	SYSTEM—2.5L ENGINE, CRANKCASE VENTILATION (CCV)	25-29	TEST, HYDRAULIC PRESSURE	21-132,21-294, 21-443
SYSTEM, 8W-20 CHARGING	8W-1	SYSTEM—3.9/5.2/5.9L ENGINE, POSITIVE CRANKCASE VENTILATION (PCV)	25-26	TEST MODE, CIRCUIT ACTUATION	25-2
SYSTEM, 8W-21 STARTING	8W-1	SYSTEM—4.7L ENGINE, POSITIVE CRANKCASE VENTILATION (PCV)	25-27	TEST MODE, STATE DISPLAY	25-2
SYSTEM, 8W-31 TRANSMISSION CONTROL	8W-1	SYSTEM—CLEANING/REVERSE FLUSHING, COOLING	7-29	TEST, ROAD	8H-4
SYSTEM, 8W-39 VEHICLE THEFT SECURITY	8W-1	SYSTEM—DEAERATION, COOLING	7-27	TEST, TRAC-LOK™	3-68
SYSTEM, 8W-43 AIRBAG	8W-1	SYSTEM—DRAINING AND FILLING, COOLING	7-28	TEST, VACUUM SUPPLY	8H-4
SYSTEM, 8W-47 AUDIO	8W-1	SYSTEM—TESTING FOR LEAKS, COOLING	7-21	TESTING, RADIATOR CAP—PRESSURE	7-26
SYSTEM, AIRBAG	8M-1,8M-4,8M-5	SYSTEMS, 8W-30 FUEL/IGNITION	8W-1	TESTING, ROAD	21-131,21-293,21-442
SYSTEM AND REMOTE KEYLESS ENTRY		SYSTEMS, AUDIO	8F-21	TESTING TRANSMISSION CLUTCH AND BAND OPERATION, AIR	21-134,21-296
SYSTEM, POWER LOCK	8P-4	SYSTEMS, LAMP	8L-1,8L-18	TESTING TRANSMISSION CLUTCH OPERATION, AIR	21-444
SYSTEM, ANTILOCK BRAKE	5-40	SYSTEMS, MONITORED	25-19	TEST—3.9/5.2/5.9L ENGINE, PCV VALVE	25-30
SYSTEM, AUDIO	8F-1,8F-4	SYSTEMS, OVERHEAD CONSOLE	8V-13	TEST—4.7L V-8 ENGINE, PCV VALVE/PCV SYSTEM	25-31
SYSTEM, AUTOMATIC DAY/NIGHT MIRROR	8T-5	SYSTEMS, PASSIVE RESTRAINT	8M-16	TESTS, TROUBLESHOOTING	8W-9
SYSTEM, BASE BRAKE	5-1,5-5	SYSTEMS, SEAT	23-8	TESTS, WATER PUMP	7-13
SYSTEM, BLEEDING ABS BRAKE	5-43	SYSTEMS, TURN SIGNAL AND HAZARD WARNING	8J-4	THEFT SECURITY SYSTEM, 8W-39 VEHICLE	8W-1
SYSTEM, BRAKE	5-2	TABLE, A/C APPLICATION	24-55	THEFT SECURITY SYSTEM, VEHICLE	8Q-1,8Q-4
SYSTEM CAPACITIES, COOLING	7-56	TABLES AND CHARTS—RE TRANSMISSION, DIAGNOSIS	21-136,21-298	THERMOSTAT	7-26
SYSTEM CHARGE, REFRIGERANT	24-20	TAIL, BRAKE, TURN SIGNAL AND BACK-UP LAMP BULBS	8L-12	THERMOSTAT—4.7L ENGINE	7-43
SYSTEM, CHARGING	8C-1,8C-2	TAIL, STOP, TURN SIGNAL AND BACK-UP LAMP	8L-16	THERMOSTAT—2.5L ENGINE	7-42
SYSTEM, CHIME WARNING	8U-1	TAILGATE	23-47	THERMOSTAT—3.9L/5.9L ENGINES	7-39,7-7
SYSTEM, COOLANT RESERVE/OVERFLOW	7-5	TAILGATE CHECK CABLE	23-46	THERMOSTAT—4.7L ENGINE	7-7
SYSTEM, COOLING	7-15,7-2	TAILGATE LATCH	23-48	THREAD REPAIR, ALUMINUM	21-150,21-312, 21-448
SYSTEM, DEFOGGER	8N-2	TAILGATE LATCH RELEASE HANDLE	23-47	THREADED HOLE REPAIR	Intro.-7
SYSTEM DIAGNOSIS	8L-3	TAILGATE LATCH STRIKER	23-48	THREADS, REPAIR DAMAGED OR WORN	9-135, 9-16,9-221,9-76
SYSTEM DIAGNOSIS, EXHAUST	11-3	TAILPIPE	11-1,11-7	THROTTLE BODY	14-42
SYSTEM, EMISSION	25-1	TAKE OUTS	8W-7	THROTTLE BODY MINIMUM AIR FLOW CHECK PROCEDURE	14-50,14-51
SYSTEM, ENGINE LUBRICATION	9-120,9-205, 9-60	TAMPER ALERT	8Q-2	THROTTLE BODY—2.5L ENGINE	14-53
SYSTEM EVACUATE, REFRIGERANT	24-20	TANK CAPACITY, FUEL	14-27	THROTTLE BODY—3.9/5.2/5.9L ENGINES	14-52
SYSTEM, EVAPORATION CONTROL	25-23	TANK, COOLANT RESERVE/OVERFLOW	7-30	THROTTLE BODY—4.7L V-8 ENGINE	14-53
SYSTEM, EXHAUST	11-1	TANK FILLER TUBE CAP, FUEL	14-24,14-7	THROTTLE CABLE	14-25
SYSTEM FAN, COOLING	7-11	TANK, FUEL	14-22,14-4	THROTTLE CABLE—4.7L V-8 ENGINE	14-27
SYSTEM, FUEL	14-66	TANK SKID PLATE—4WD VEHICLES, FUEL	13-9	THROTTLE POSITION SENSOR	21-439
SYSTEM, FUEL DELIVERY	14-1	TAPPETS, HYDRAULIC	9-12,9-217,9-237,9-38, 9-51,9-72,9-92	THROTTLE POSITION SENSOR (TPS)—3.9/5.2/5.9L ENGINES	14-54
SYSTEM, FUEL INJECTION	14-30	TASK MANAGER—GASOLINE POWERED ENGINES ONLY	25-16	THROTTLE POSITION SENSOR (TPS)—4.7L V-8 ENGINE	14-54
SYSTEM, HAZARD WARNING	8J-1	TEMPERATURE CONTROL CABLE	24-47,24-55		
SYSTEM, HEATED MIRROR	8N-1	TEMPERATURE SENSOR, AMBIENT	8V-13,8V-4, 8V-5		
SYSTEM, HORN	8G-1	TEMPERATURE SENSOR, BATTERY	8C-2,8C-5		
SYSTEM, IGNITION	8D-1	TEMPERATURE SENSOR, TRANSMISSION	21-440		
SYSTEM, INSTRUMENT PANEL	8E-1	TEMPERATURE SENSOR—2.5L ENGINE, ENGINE COOLANT	14-63		
SYSTEM LEAKS, REFRIGERANT	24-19				
SYSTEM, LUBRICATION	9-2				
SYSTEM, METRIC	Intro.-7				
SYSTEM, ON-BOARD DIAGNOSTIC TEST FOR CHARGING	8C-3				
SYSTEM, OVERHEAD CONSOLE	8V-1				

Description	Group-Page	Description	Group-Page	Description	Group-Page
THROTTLE POSITION SENSOR (TPS)—PCM INPUT	14-39	(TPS)—3.9/5.2/5.9L ENGINES, THROTTLE POSITION SENSOR	14-54	TROUBLESHOOTING WIRING PROBLEMS	8W-9
THROTTLE POSITION SENSOR—2.5L ENGINE	14-55	(TPS)—4.7L V-8 ENGINE, THROTTLE POSITION SENSOR	14-54	TUBE CAP, FUEL TANK FILLER	14-24,14-7
THROTTLE VALVE CABLE ADJUSTMENT, TRANSMISSION	21-226,21-394	(TPS)—PCM INPUT, THROTTLE POSITION SENSOR	14-39	TUBE, FIXED ORIFICE	24-35,24-5
TIE ROD END	19-11	TRACK, BENCH SEAT	23-9	TUBE FLARING, BRAKE	5-12
TIMER MODULE, 8W-45 CENTRAL	8W-1	TRACK, BUCKET SEAT	23-11	TUBES, FLUSHING COOLERS	21-149,21-311, 21-447
TIMER MODULE, CENTRAL; CHIME/BUZZER WARNING SYSTEMS	8U-1,8U-3	TRAC-LOK [®]	3-92	TUBES/LINES/HOSES AND CLAMPS, FUEL	14-7
TIMER MODULE, CENTRAL; INSTRUMENT PANEL SYSTEMS	8E-25,8E-4	TRAC-LOK [®] DIFFERENTIAL, 8 1/4	3-82	TURN SIGNAL AND BACK-UP LAMP BULBS, TAIL, BRAKE	8L-12
TIMER MODULE, CENTRAL; POWER LOCK SYSTEMS	8P-2,8P-6	TRAC-LOK [®] DIFFERENTIAL, 9 1/4	3-87	TURN SIGNAL AND BACK-UP LAMP, TAIL, STOP	8L-16
TIMER MODULE, CENTRAL; VEHICLE THEFT/SECURITY SYSTEMS	8Q-2	TRAC-LOK [®] OPERATION	3-64	TURN SIGNAL AND HAZARD WARNING SYSTEMS	8J-4
TIMER MODULE, CENTRAL; WIPER AND WASHER SYSTEMS	8K-3	TRAC-LOK [®] DIFFERENTIAL NOISE	3-68	TURN SIGNAL AND SIDE MARKER LAMP, PARK	8L-14
TIMING CASE COVER	9-40	TRAC-LOK [®] TEST	3-68	TURN SIGNAL CANCELLING CAM	8J-2
TIMING CASE COVER OIL SEAL	9-39	TRAILER HITCH	13-10	TURN SIGNAL LAMP BULBS, PARK	8L-12
TIMING CHAIN	9-240	TRAILER TOW, 8W-54	8W-1	TURN SIGNAL SWITCH AND HAZARD WARNING SWITCH	8J-2,8J-5,8J-6
TIMING CHAIN AND SPROCKETS	9-166,9-40	TRANSFER CASE	21-508,21-535	TURN SIGNAL SYSTEM	8J-1
TIMING CHAIN AND TENSIONER	9-97	TRANSFER CASE, NV231	21-506,21-511,21-527	TURN SIGNALS, 8W-52	8W-1
TIMING CHAIN COVER	9-165,9-238,9-96	TRANSFER CASE, NV242	21-533,21-538,21-558	URNS, NOISE AND/OR VIBRATION IN	3-20
TIMING CHAIN STRETCH, MEASURING	9-225	TRANSFER CASE SHIFTER	21-509,21-535	TWO WHEEL DRIVE VEHICLE TOWING	0-12
TIMING CHAIN STRETCH—MEASURING	9-79	TRANSFER CASE SKID PLATE	13-9	UNBALANCE	3-6
TIMING CHAIN TENSIONER	9-64	TRANSMISSION	21-150,21-178,21-223,21-242, 21-312,21-341,21-391,21-4,21-44,21-450,21-455, 21-480,21-502,21-7	UNDERHOOD LAMP	8L-16
TIMING CHAIN—MEASURING WEAR	9-139	TRANSMISSION, 42RE AUTOMATIC	21-84,21-85	UNDERHOOD LAMP BULB	8L-13
TIMING DRIVE SYSTEM	9-123	TRANSMISSION, 45RFE	21-502	UNIT, ENGINE OIL PRESSURE SENDING	9-188
TIMING, IGNITION	8D-27	TRANSMISSION, 45RFE AUTOMATIC	21-416, 21-417	UNIT, FUEL GAUGE SENDING	14-10,14-16,14-3
TIMING, VALVE	9-17,9-222,9-77	TRANSMISSION CLUTCH AND BAND OPERATION, AIR TESTING	21-134,21-296	UNIT, HYDRAULIC CONTROL	5-41
TIMING—VERIFICATION, ENGINE	9-137	TRANSMISSION CLUTCH OPERATION, AIR TESTING	21-444	UNIT, OVERDRIVE	21-157,21-206,21-226, 21-319,21-372,21-394
TIRE AND WHEEL BALANCE	22-9	TRANSMISSION COMPONENTS	21-32,21-78	UNIVERSAL JOINT, SINGLE CARDAN	3-11
TIRE AND WHEEL RUNOUT	22-7	TRANSMISSION CONTROL MODULE	21-435	UNLOCK RELAY, DRIVER	8P-10,8P-4
TIRE INFLATION PRESSURES	22-2	TRANSMISSION CONTROL RELAY	21-438	UP/DOWN, FRONT DOOR	23-61
TIRE NOISE OR VIBRATION	22-4	TRANSMISSION CONTROL SYSTEM, 8W-31	8W-1	UPPER BALL JOINT	2-15,2-8
TIRE PRESSURE FOR HIGH SPEED	22-3	TRANSMISSION DIAGNOSIS, AUTOMATIC	21-129,21-291	UPPER INERTIA LATCH COVER, CENTER ARMREST	23-13
TIRE REVOLUTION PER MILE	22-6	TRANSMISSION, DIAGNOSIS TABLES AND CHARTS—RE	21-136,21-298	UPPER SUSPENSION ARM	2-10,2-19
TIRE WEAR PATTERNS	22-3	TRANSMISSION FILL PROCEDURE	21-148, 21-310,21-446	USAGE, FASTENER	Intro-7
TIRE WINCH, SPARE	13-10	TRANSMISSION GENERAL DIAGNOSIS, 45RFE AUTOMATIC	21-441	USAGE, INSTALLATION METHODS AND PARTS	6-5
TIRE—TEMPORARY, SPARE	22-2	TRANSMISSION NOISE	21-4,21-40	V-6 ENGINE, CRANKSHAFT POSITION SENSOR—3.9L	8D-4
TIRES	22-1	TRANSMISSION, NV1500 MANUAL	21-1,21-34	V-6 ENGINE, ENGINE FIRING ORDER—3.9L	8D-27
TIRES, CLEANING	22-6	TRANSMISSION, NV3500 MANUAL	21-36,21-81	V-8 ENGINE, CRANKSHAFT POSITION SENSOR—4.7L	8D-17
TIRES, RADIAL-PLY	22-2	TRANSMISSION OIL COOLER LINES	7-44	V-8 ENGINE, CRANKSHAFT POSITION SENSOR—5.2/5.9L	8D-4
TIRES, REPLACEMENT	22-3	TRANSMISSION OIL COOLERS, AUTOMATIC	7-8	V-8 ENGINE, ENGINE COOLANT TEMPERATURE SENSOR—4.7L	14-63
TONE WHEEL	5-46	TRANSMISSION QUICK LEARN PROCEDURE	21-447	V-8 ENGINE, ENGINE FIRING ORDER—4.7L	8D-27
TOOL, DRB SCAN	7-13	TRANSMISSION RANGE SENSOR	21-439	V-8 ENGINE, IGNITION COIL RESISTANCE—4.7L	8D-28
TOOLS, TROUBLESHOOTING	8W-8	TRANSMISSION, RE	21-410,21-412	V-8 ENGINE, INTAKE MANIFOLD AIR TEMPERATURE SENSOR—4.7L	14-64
TOP COVER, INSTRUMENT PANEL	8E-30	TRANSMISSION TEMPERATURE SENSOR	21-440	V-8 ENGINE, PCV VALVE—4.7L	25-32
TORQUE; CLUTCH	6-16	TRANSMISSION THROTTLE VALVE CABLE ADJUSTMENT	21-226,21-394	V-8 ENGINE, PCV VALVE/PCV SYSTEM TEST—4.7L	25-31
TORQUE; DIFFERENTIAL AND DRIVELINE	3-17,3-30	TRANSMISSION—2WD	21-40	V-8 ENGINE, SERVO CABLE—4.7L	8H-6
TORQUE; ENGINE	9-199	TRANSMISSION—4WD	21-41	V-8 ENGINE, THROTTLE BODY—4.7L	14-53
TORQUE; TRANSMISSION AND TRANSFER CASE	21-34,21-531,21-561,21-81	TRANSMISSIONS, RE	21-243	V-8 ENGINE, THROTTLE CABLE—4.7L	14-27
TORQUE CHART; BRAKES	5-31,5-39,5-47	TRANSMITTER BATTERY REPLACEMENT, REMOTE KEYLESS ENTRY	8P-8	V-8 ENGINE, THROTTLE POSITION SENSOR (TPS)—4.7L	14-54
TORQUE CHART; CHARGING SYSTEM	8C-6	TRANSMITTER PROGRAMMING, REMOTE KEYLESS ENTRY	8P-9	V-8 ENGINES, ENGINE FIRING ORDER—5.2L/5.9L	8D-27
TORQUE CHART; EMISSION CONTROL SYSTEMS	25-35	TRANSMITTER, REMOTE KEYLESS ENTRY	8P-3,8P-8	VACUUM ACTUATOR, MODE DOOR	24-44
TORQUE CHART; FUEL SYSTEM	14-29,14-66	TRAY, BATTERY	8A-20,8A-4	VACUUM CHECK VALVE	24-48,24-9
TORQUE CHART; IGNITION SYSTEM	8D-28	TREAD WEAR INDICATORS	22-3	VACUUM RESERVOIR; HEATING AND AIR CONDITIONING	24-48,24-9
TORQUE CHART; SPEED CONTROL SYSTEM	8H-9	TRIM, A-PILLAR	23-50	VACUUM RESERVOIR; SPEED CONTROL SYSTEM	8H-3,8H-8
TORQUE CHART; STEERING	19-10,19-14,19-19	TRIM, B-PILLAR	23-50	VACUUM SCHEMATICS	25-32
TORQUE CHART; SUSPENSION	2-12,2-22,2-26	TRIM COVER, COWL	23-49	VACUUM SUPPLY TEST	8H-4
TORQUE CHART; TIRES AND WHEELS	22-11	TRIM COVER, DOOR SILL	23-50	VACUUM SYSTEM	24-50
TORQUE CONVERTER	21-152,21-256,21-314, 21-418,21-453,21-93	TRIM COVER, DRIVER SIDE AIRBAG MODULE	8M-8	VALANCE PANEL	13-3
TORQUE REFERENCES	Intro-7	TRIM PANEL, FRONT DOOR	23-29	VALUE, LOAD	25-22
TORQUE SPECIFICATIONS; BODY	23-116	TRIM PANEL, QUARTER	23-51	VALVE BODY	21-155,21-160,21-222,21-229, 21-261,21-317,21-322,21-388,21-396,21-424, 21-449,21-464,21-479,21-98
TORQUE SPECIFICATIONS; COOLING SYSTEM	7-56	TRIM PANEL, REAR DOOR	23-37	VALVE CABLE ADJUSTMENT, TRANSMISSION THROTTLE	21-226,21-394
TORQUE SPECIFICATIONS; ENGINE	9-115	TRIM PANELS, INTERIOR	23-18	VALVE, COMBINATION	5-14,5-3,5-9
TORQUE SPECIFICATIONS; EXHAUST SYSTEM	11-10	TRIM, REAR CAB BACK PANEL	23-51	VALVE, CONVERTER DRAINBACK	21-125,21-287
TORQUE SPECIFICATIONS; FRAME AND BUMPERS	13-16	TRIP DEFINITION	25-21	VALVE, GUIDE AND SEAL	9-17
TORSION BAR	2-17	TROUBLE CODE DESCRIPTIONS, DIAGNOSTIC	25-3	VALVE GUIDES	9-123
TORSION BARS	2-15	TROUBLE CODES, DIAGNOSTIC	25-2		
TOUCH-UP, PAINTED SURFACE	23-2	TROUBLESHOOTING TESTS	8W-9		
TOW, 8W-54 TRAILER	8W-1	TROUBLESHOOTING TOOLS	8W-8		
TOWER, SHIFT	21-42,21-5				
TOWING AND HOISTING, JUMP STARTING	0-10				
TOWING, FOUR-WHEEL-DRIVE VEHICLE	0-12				
TOWING RECOMMENDATIONS	0-11				
TOWING, TWO WHEEL DRIVE VEHICLE	0-12				

Description	Group-Page	Description	Group-Page	Description	Group-Page
VALVE, HIGH PRESSURE RELIEF	24-7	VISCOUS FAN DRIVE	7-11,7-53	WEATHERSTRIP, REAR DOOR OPENING	23-41
VALVE, RWAL	5-34,5-38	VISCOUS FAN DRIVE—3.9L/4.7L AND 5.9L ENGINES	7-23	WEATHERSTRIP, REAR DOOR OUTER BELT	23-41
VALVE SERVICE	9-136,9-223	VISUAL INSPECTION—2.5L ENGINE	14-46	WELD LOCATIONS	23-62
VALVE SERVICE, CONVERTER DRAINBACK CHECK	21-148,21-310	VISUAL INSPECTION—3.9/5.2/5.9L ENGINES	14-42	WHEEL	22-7
VALVE, SOLENOID SWITCH	21-440	V-8 ENGINE, FUEL INJECTOR RAIL—4.7L	14-20	WHEEL ALIGNMENT	2-1,2-4
VALVE SPRING	9-123	V-8 ENGINE, IDLE AIR CONTROL (IAC) MOTOR—4.7L	14-56	WHEEL ANTILOCK BRAKE BLEEDING, REAR	5-37
VALVE SPRING AND SEAL	9-35	V-8 ENGINE, MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR—4.7L	14-58	WHEEL ANTI-LOCK BRAKES, 8W-34 REAR	8W-1
VALVE SPRING AND STEM SEAL REPLACEMENT-IN VEHICLE	9-236	VOLT SENSOR SUPPLIES—PRIMARY AND SECONDARY, FIVE	14-35	WHEEL ANTILOCK BRAKES, CONTROLLER REAR	5-33
VALVE SPRINGS AND SEALS	9-163	VOLTAGE REGULATOR, ELECTRONIC	8C-2	WHEEL ANTILOCK BRAKES, FOUR	5-40
VALVE SPRINGS, VALVES	9-209,9-237,9-64	VOLTAGE—PCM INPUT, BATTERY	14-34	WHEEL ANTILOCK BRAKES, REAR	5-32
VALVE SPRINGS—CYLINDER HEAD REMOVED, VALVES	9-91	VOLUME CHECK, OIL PUMP	21-149,21-311, 21-447	WHEEL ANTILOCK, REAR	5-32,5-36
VALVE STEM SEAL	9-123	WARNING LAMP, ABS	5-43	WHEEL BALANCE, TIRE	22-9
VALVE TEST—3.9/5.2/5.9L ENGINE, PCV	25-30	WARNING LAMP, RED BRAKE	5-3,5-8	WHEEL CYLINDER	5-21,5-25,5-28
VALVE TIMING	9-17,9-222,9-77	WARNING LAMPS, BRAKE	5-35	WHEEL DRIVE VEHICLE TOWING, TWO	0-12
VALVE, VACUUM CHECK	24-48,24-9	WARNING SWITCH, TURN SIGNAL SWITCH AND HAZARD	8J-2,8J-5,8J-6	WHEEL INSPECTION	22-7
VALVE—4.7L V-8 ENGINE, PCV	25-32	WARNING SYSTEM, CHIME	8U-1	WHEEL INSTALLATION	22-8
VALVE/PCV SYSTEM TEST—4.7L V-8 ENGINE, PCV	25-31	WARNING SYSTEM, HAZARD	8J-1	WHEEL MOUNTING STUDS	2-12,2-21
VALVES	9-123	WARNING SYSTEM SWITCHES, CHIME	8U-5	WHEEL OPENING MOLDING	23-45
VALVES AND VALVE SPRINGS	9-209,9-237,9-64	WARNING SYSTEMS, TURN SIGNAL AND HAZARD	8J-4	WHEEL RUNOUT, TIRE	22-7
VALVES AND VALVE SPRINGS—CYLINDER HEAD REMOVED	9-91	WARNINGS & CAUTIONS, SERVICE	5-2	WHEEL SPEED SENSOR	5-42
VALVES, GUIDES AND SPRINGS	9-77	WARNINGS AND PRECAUTIONS, SERVICE	24-22	WHEEL SPEED SENSOR - 4X2, FRONT	5-45
VALVE(S), ROLLOVER	25-24,25-34	WARNINGS, NOTES, CAUTIONS	8W-7	WHEEL SPEED SENSOR - 4X4, FRONT	5-46
VARIATION ADJUSTMENT, COMPASS	8V-6	WASHER FLUID LEVEL SENSOR	8K-4	WHEEL SPEED SENSOR AND EXCITER RING, REAR	5-34
VEHICLE, CAMSHAFTS—IN	9-173	WASHER NOZZLE AND PLUMBING	8K-4	WHEEL SPEED SENSOR, REAR	5-38,5-47
VEHICLE EMISSION CONTROL INFORMATION (VECI) LABEL	25-29	WASHER PUMP	8K-4	WHEEL, TONE	5-46
VEHICLE IDENTIFICATION NUMBER (VIN) PLATE	Intro-1	WASHER RESERVOIR	8K-4	WHEELHOUSE LINER, FRONT	23-24
VEHICLE INSPECTION	3-20	WASHER SWITCH, WIPER SWITCH	8K-11,8K-2, 8K-6	WHEELS	22-7
VEHICLE, OIL PAN 4X2	9-180	WASHER SYSTEM	8K-12,8K-5	WINCH, SPARE TIRE	13-10
VEHICLE, OIL PAN 4X4	9-182	WASHER SYSTEM, WINDSHIELD	8K-1	WIND NOISE	23-19
VEHICLE PREPARATION FOR HEADLAMP ALIGNMENT	8L-7	WATER LEAKS	23-18	WINDOW DEFOGGER SYSTEM, REAR	8N-1
VEHICLE SERVICE, CYLINDER HEAD COMPONENTS—IN	9-89	WATER PUMP	7-55,7-6	WINDOW MOTOR, POWER	8S-2,8S-4,8S-6
VEHICLE SPEED AND DISTANCE—PCM INPUT	14-40	WATER PUMP 4.7L ENGINES	7-35	WINDOW, QUARTER VENT	23-43
VEHICLE SPEED CONTROL, 8W-33	8W-1	WATER PUMP BYPASS HOSE—3.9/5.9L ENGINES	7-37	WINDOW REGULATOR, FRONT DOOR	23-35
VEHICLE SPEED INPUT	8H-3	WATER PUMP BYPASS—3.9/5.9L ENGINES	7-6	WINDOW REGULATOR, REAR DOOR	23-42
VEHICLE THEFT SECURITY SYSTEM	8Q-1,8Q-4	WATER PUMP BYPASS—4.7L	7-6	WINDOW SWITCH, POWER	8S-1,8S-3,8S-5
VEHICLE THEFT SECURITY SYSTEM, 8W-39	8W-1	WATER PUMP TESTS	7-13	WINDOW SYSTEM, POWER	8S-1,8S-2
VEHICLE TOWING, FOUR-WHEEL-DRIVE	0-12	WATER PUMP—2.5L ENGINE	7-30	WINDOW WEATHERSTRIP, QUARTER VENT	23-44
VEHICLE TOWING, TWO WHEEL DRIVE	0-12	WATER PUMP—3.9L/5.9L ENGINES	7-32	WINDOWS, 8W-60 POWER	8W-1
VEHICLE, VALVE SPRING AND STEM SEAL REPLACEMENT-IN	9-236	WATERDAM, FRONT DOOR	23-30	WINDSHIELD	23-4
VENT GLASS, BACKLITE SLIDING	23-52	WATERDAM, REAR DOOR	23-38	WINDSHIELD SAFETY PRECAUTIONS	23-4
VENT WINDOW, QUARTER	23-43	WEAR INDICATORS, TREAD	22-3	WINDSHIELD WASHER SYSTEM	8K-1
VENT WINDOW WEATHERSTRIP, QUARTER	23-44	WEAR PATTERNS, TIRE	22-3	WINDSHIELD WIPER SYSTEM	8K-1
VENTILATION (CCV) SYSTEM—2.5L ENGINE, CRANKCASE	25-29	WEAR, TIMING CHAIN—MEASURING	9-139	WIPE RELAY, INTERMITTENT	8K-11,8K-3,8K-7
VENTILATION (PCV) SYSTEM—3.9/5.2/5.9L ENGINE, POSITIVE CRANKCASE	25-26	WEATHERSTRIP AND RETAINER, ROOF RAIL	23-43	WIPER ARM	8K-8
VENTILATION (PCV) SYSTEM—4.7L ENGINE, POSITIVE CRANKCASE	25-27	WEATHERSTRIP, FRONT DOOR GLASS RUN	23-36	WIPER ARM AND BLADE	8K-2
VIBRATION	3-35,3-5,3-68	WEATHERSTRIP, FRONT DOOR INNER BELT	23-34	WIPER BLADE	8K-8
VIBRATION AT HIGHWAY SPEEDS	3-20	WEATHERSTRIP, FRONT DOOR OUTER BELT	23-34	WIPER LINKAGE AND PIVOT	8K-2,8K-9
VIBRATION DAMPER	9-238,9-39,9-95	WEATHERSTRIP, QUARTER VENT WINDOW	23-44	WIPER MOTOR	8K-2,8K-9
VIBRATION DURING ACCELERATION, SHUDDER OR	3-20	WEATHERSTRIP, REAR DOOR GLASS RUN	23-40	WIPER SWITCH AND WASHER SWITCH	8K-11, 8K-2,8K-6
VIBRATION IN TURNS, NOISE AND/OR	3-20	WEATHERSTRIP, REAR DOOR INNER BELT	23-40	WIPER SYSTEM	8K-4
VIBRATION, TIRE NOISE OR	22-4			WIPER SYSTEM, WINDSHIELD	8K-1
VIEW MIRROR, SIDE	23-28			WIPERS, 8W-53	8W-1
VIN REPROGRAMMING, PCM	14-1			WIRING PROBLEMS, TROUBLESHOOTING	8W-9
				WIRING REPAIR	8W-10
				WIRING/TERMINAL	8W-15
				WORN THREADS, REPAIR DAMAGED OR	9-135, 9-16,9-221,9-76
				YOKE BUSHING, REAR HOUSING	21-43
				YOKE SEAL REPLACEMENT	21-152,21-315
				YOKE SEAL—2WD	21-43

