

Figure item, etc.	Work instructions		
	Engine Starting distance 15.000 km when using oils as per MBBV	Engine 112 Sheet 229.1, 229.3	*BE18.00-P-1001-06S
	Starting distance 20.000 km when using oils as per MBBV	Sheet 229.5	*BE18.00-P-1002-06S

Number	Designation	Engine 112 in model 163
BE18.00-P-1001-06S	Starting distance 15 000 km at service when using oils as per MBBV	229.1
		229.3
		-
		-
		-
		Sheet BB00.40-P-0223-02 A
BE18.00-P-1002-06S	Starting distance 20 000 km at service when using oils as per MBBV	-
		-
		-
		229.5
		-
		Sheet BB00.40-P-0223-02 A