

Figure item, etc.	Work instructions		
	Increase in starting distance, model 163	<p>i Gasoline engines, see: ↓</p> <p>Engine 111</p> <p>Engine 112</p> <p>Engine 113</p> <p>Engine 113 AMG</p> <p>i Diesel engines without diesel particulate filter, see: ↓</p> <p>Engine 612 without diesel particulate filter</p> <p>Engine 628 without diesel particulate filter</p>	<p>AP18.00-P-1841RA</p> <p>AP18.00-P-1841RB</p> <p>AP18.00-P-1841RC</p> <p>AP18.00-P-1841RD</p> <p>AP18.00-P-1841RE</p> <p>AP18.00-P-1841RF</p>