



# Gowin Software Tcl Commands User Guide

SUG1220-1.0E, 08/29/2025

**Copyright © 2025 Guangdong Gowin Semiconductor Corporation. All Rights Reserved.**

**GOWIN**, GOWIN, and LittleBee are trademarks of Guangdong Gowin Semiconductor Corporation and are registered in China, the U.S. Patent and Trademark Office, and other countries. All other words and logos identified as trademarks or service marks are the property of their respective holders. No part of this document may be reproduced or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written consent of GOWINSEMI.

#### **Disclaimer**

GOWINSEMI assumes no liability and provides no warranty (either expressed or implied) and is not responsible for any damage incurred to your hardware, software, data, or property resulting from usage of the materials or intellectual property except as outlined in the GOWINSEMI Terms and Conditions of Sale. GOWINSEMI may make changes to this document at any time without prior notice. Anyone relying on this documentation should contact GOWINSEMI for the current documentation and errata.

**Revision History**

Date	Version	Description
08/29/2025	1.0E	Initial version published.

# Contents

<b>Contents .....</b>	<b>i</b>
<b>List of Tables .....</b>	<b>iii</b>
<b>1 About This Guide .....</b>	<b>1</b>
1.1 Purpose .....	1
1.2 Related Documents .....	1
1.3 Terminology and Abbreviations.....	1
1.4 Support and Feedback .....	1
<b>2 Tcl Overview .....</b>	<b>2</b>
2.1 Introduction .....	2
2.2 Launching Command Line Mode.....	2
<b>3 Tcl Commands.....</b>	<b>3</b>
3.1 Command .....	3
3.1.1 Command Type.....	3
3.1.2 Command List.....	3
3.2 Command Description .....	4
3.2.1 add_file .....	4
3.2.2 create_ipc .....	5
3.2.3 create_project .....	6
3.2.4 generate_target.....	7
3.2.5 get_ips .....	7
3.2.6 import_files.....	8
3.2.7 list_property .....	9
3.2.8 open_project .....	10
3.2.9 read_ipc .....	11
3.2.10report_property .....	11
3.2.11 rm_file .....	12
3.2.12run .....	12
3.2.13run close .....	13
3.2.14saveto .....	13
3.2.15set_device.....	14

3.2.16 set_file_enable .....	15
3.2.17 set_file_prop .....	15
3.2.18 set_csr .....	16
3.2.19 set_option .....	17
3.2.20 set_property .....	57
3.2.21 source .....	58
3.2.22 write_ip_tcl .....	59

# List of Tables

Table 1-1 Terminology and Abbreviations .....	1
---	---

# 1 About This Guide

## 1.1 Purpose

This manual provides a detailed description of the command-line mode and related Tcl command usage for Gowin Software.

## 1.2 Related Documents

The latest user guides are available on GOWINSEMI Website. You can find the related documents at [www.gowinsemi.com](http://www.gowinsemi.com): [SUG100, Gowin Software User Guide](#).

## 1.3 Terminology and Abbreviations

Table 1-1 shows the abbreviations and terminology used in this manual.

**Table 1-1 Terminology and Abbreviations**

Terminology and Abbreviations	Meaning
CRC	Cyclic Redundancy Check
FPGA	Field Programmable Gate Array
GowinSynthesis	GowinSynthesis
GPA	Gowin Power Analyzer
IP Core	Intellectual Property Core
PnR	Place & Route
SEU Handler	Single-Event Upsets Handler
Tcl	Tool Command Language

## 1.4 Support and Feedback

Gowin Semiconductor provides customers with comprehensive technical support. If you have any questions, comments, or suggestions, please feel free to contact us directly by the following ways.

Website: [www.gowinsemi.com](http://www.gowinsemi.com)

E-mail: [support@gowinsemi.com](mailto:support@gowinsemi.com)

# 2 Tcl Overview

## 2.1 Introduction

Tool Command Language (Tcl) is a scripting language integrated into Gowin Software. Gowin Software supports command-line mode operation, allowing users to interact with the tool and manage projects through Tcl commands.

## 2.2 Launching Command Line Mode

Gowin Software supports operation in command-line mode, which can be accessed via gw\_sh.exe.

### Syntax

Command: (Windows example)

Launch gw\_sh.exe from the installation directory:

\x.x\IDE\bin\gw\_sh.exe.

Parameter: [script file]

- If no parameter is provided: Enters the command line console mode directly.
- script file: Executes a specified script file, optional.

### Application Example

# Launch Command-line mode

gw\_sh.exe

#Execute a script file; for the examples, you can see the section Tcl Quick Start in [SUG918, Gowin Software Quick Start Guide](#).

gw\_sh.exe script\_file

# 3Tcl Commands

Gowin Software supports command line mode. In the following description, the content in <> must be specified, and the content in [] is optional. When creating file names, special characters such as /, \*, - and space are not supported. Additionally, when specifying an IP module\_name, names starting with a digit are prohibited.

## 3.1 Command

### 3.1.1 Command Type

[IPFlow](#)

[Project](#)

### 3.1.2 Command List

#### IPFlow

[create\\_ipc](#)

[generate\\_target](#)

[get\\_ips](#)

[list\\_property](#)

[read\\_ipc](#)

[report\\_property](#)

[set\\_property](#)

[source](#)

[write\\_ip\\_tcl](#)

#### Project

[add\\_file](#)

[create\\_project](#)

[import\\_files](#)

[open\\_project](#)

[rm file](#)[run](#)[run close](#)[saveto](#)[set device](#)[set file enable](#)[set file prop](#)[set option](#)[source](#)

## 3.2 Command Description

### 3.2.1 add\_file

Adds design files to the project.

#### Syntax

`add_file [-type] [-disable] [-h/--help] <file>`

#### Usage

Name	Description
<code>[-type]</code>	Specifies the type of design file to add
<code>[-disable]</code>	Disables the file
<code>[-h/--help]</code>	Displays help information
<code>&lt;file&gt;</code>	File(s) to add

#### Type

[Project](#)

#### Description

When adding design files, two types of file path separators / or \\ are supported on Windows and Linux systems. Both relative and absolute paths are supported. In Gowin Software, the relative path is relative to the current project directory, and in command line mode, it is relative to the path from which gw\_sh is launched.

#### Parameter

- `<file>`: The design file(s) to be added. Multiple files can be specified, separated by spaces.
- `[-type <type>]`: The `add_file` command will automatically determine the file type based on the file extension. Alternatively, this option can be used to explicitly specify the file type. Supported file types include verilog, vhdl, sv, vg, cst, sdc, gao, gpa, gsc, etc.
- `[-disable]`: Disables the added files. The disabled files are only added to the file list and are excluded from implementation processes. Related command: `set_file_enable`.

- [-h/--help]: Displays help information.

### Example

```
add_file abc.v
add_file -type vhd 1.vhd 2.vhd 3.vhd
add_file D:/gowin_project/top.v
add_file D:\\gowin_project\\top.v
```

## 3.2.2 create\_ipc

Creates IPC file with default configuration.

### Syntax

```
create_ipc -name <ipName> -module_name <moduleName>
[-language <arg>] [-file_name <fileName>] [-dir <path>] [-force]
```

### Usage

Name	Description
-name	IP name
-module_name	The module name of the IP to be created
[-language]	Language for the IP file, template file, and simulation file
[-file_name]	IP file name
[-dir]	The path to generate the IP
[-force]	Overwrites existing files

### Type

[IPFlow](#)

### Description

This command is used to create an IPC file for the IP core in the IP Core Generator.

### Parameter

- -name <ipName>: Specifies the name of the IP, and the name can be obtained from the IP Core Generator.
- -module\_name <moduleName>: Specifies the module name of the IP to be created.
- [-language <arg>]: Specifies the language of the generated IP files, template files, and simulation files (Verilog/VHDL). If not specified, the default is Verilog.
- [-file\_name <fileName>]: Specifies the name of the generated IP file. If not specified, it will be the same as the name specified by the module\_name.
- [-dir <path>]: Specifies the directory path to generate the IP. If not specified, it will be generated into the current project's src folder.
- [-force]: Overwrite existing files.

### Example

In the following example, the IP core specified by `-name` is created in the current project's `src` folder, and the module name, language, and file name is specified.

```
create_ip -name fifo -module_name FIFO_Top -language Verilog
-file_name fifo
```

### See also

[generate\\_target](#)

## 3.2.3 create\_project

Creates a project.

### Syntax

```
create_project [-name <prjName>] [-dir <path>] [-pn <pnName>]
[-device_version <arg>] [-force] [-h/--help]
```

### Usage

Name	Description
<code>[-name]</code>	The name of the project to be created
<code>[-dir]</code>	The path to generate the project
<code>[-pn]</code>	The part number for the project to be created
<code>[-device_version]</code>	The device version for the project to be created
<code>[-force]</code>	Overwrites existing files
<code>[-h/--help]</code>	Displays help information

### Type

[Project](#)

### Description

Creates a project. For the file path format, see [3.2.1 add\\_file](#).

### Parameter

- `[-name <prjName>]`: Specifies the name of the project to be created.
- `[-dir <path>]`: Specifies the path where the project will be created. If the specified path does not exist, a new path will be created. If this option is not specified, the default will be the current working path or the path where the TCL script is located.
- `[-pn <pnName>]`: Specifies the part number for the project to be created.
- `[-device_version <arg>]`: Specifies the device version for the part number. For devices with only an initial version, the value of the device version will be NA.
- `[-force]`: Overwrites existing projects.
- `[-h/--help]`: Displays help information.

**Example**

```
create_project -name prj0 -dir D:/tclprj -pn GW1N-UV4LQ144C6/15
-device_version B
create_project -name prjlest -pn GW1N-UV4LQ144C6/15 -
device_version B -force
```

**3.2.4 generate\_target**

Generates target files for specified objects.

**Syntax**

```
generate_target <objects> [-force]
```

**Usage**

Name	Description
<objects>	Specifies the object to generate the target file
[-force]	Overwrite existing files

**Type**

[IPFlow](#)

**Description**

This command is used to generate target files for the specified IP objects (get\_ips) and adds the IP core design files to the current project.

**Parameter**

- <objects>: Specifies one or more IP objects to generate design files. An object is specified using [get\_ips module\_name]. Multiple objects are specified using [get\_ips module\_name0 module\_name1 ...].
- [-force]: Overwrites existing files.

**Example**

In the following example, design files and template files for the specified IP are generated, and load them into the current project.

```
generate_target [get_ips FIFO_Top]
```

**See also**

- [generate\\_target](#)
- [create\\_ipc](#)
- [read\\_ipc](#)

**3.2.5 get\_ips**

Specifies IP objects.

**Syntax**

```
get_ips <module_name>
```

**Usage**

Name	Description
<module_name>	Specifies the module name of the IP

**Type**

[IPFlow](#)

**Description**

Specifies the IP objects in the current project.

**Parameter**

<module\_name>: Specifies the module name of the IP object, which can be one or multiple.

**Example**

In the following example, a single IP object in the current project is specified.

```
get_ips FIFO_Top
```

In the following example, multiple IP objects in the current project are specified.

```
get_ips FIFO_Top FIFO_Top_1
```

**See also**

- [generate\\_target](#)
- [list\\_property](#)
- [report\\_property](#)
- [set\\_property](#)

**3.2.6 import\_files**

Copies files or directories to the current project.

**Syntax**

```
import_files [-file <file>] [-dir <path>] [-fileList <fileList>] [-force]
[-h/--help]
```

**Usage**

Name	Description
[-file]	Specifies the file(s) to copy
[-dir]	Specifies the path to copy from
[-fileList]	Specifies a file list.
[-force]	Overwrites existing files with the same name
[-h/--help]	Displays help information

**Type**

[Project](#)

## Description

Copy files or directories to the current project path /src. The values for -file, -dir, and -fileList can be absolute or relative paths. If a tcl script is executed via gwsh.exe, the relative path is based on the tcl script's path. If the import\_files command is executed via the console window in Gowin Software, the relative path is based on the current working directory (pwd). If no options are specified after import\_files, it defaults to copying all files specified by the add\_file command to the project path /src.

## Parameter

- [-file <file>]: Adds one or more files to the project path /src.
- [-dir <path>]: Adds all files and subfolders in the path to the project path /src.
- [-fileList <fileList>]: Specifies a file list where each line represents a file to be added to the project. Examples are as follows:
  - D:/test1.v
  - D:/test2.v
  - This option allows adding all the files specified in each line of the file to the project path /src.
- [-force]: Overwrites files with the same name in the project path /src.
- [-h/--help]: Displays help information.

## Example

```
import_files -file D/test1 .v -force
```

```
import_files -file D:/test1 .v D:/test2.v -force
```

```
import_files -dir D:/sourceFile
```

```
import_files -fileList log, and the file contents are as follows:
```

```
D:/Test1.v
```

```
D:/Test2.v
```

## 3.2.7 list\_property

Lists the properties of an object.

## Syntax

```
list_property <object>
```

## Usage

Name	Description
<object>	The object that queries properties.

## Type

[IPFlow](#)

**Description**

Obtains a list of all options for the specified IP object.

**Parameter**

<object>: Specifies the IP object that queries option. Use [get\_ips module\_name] to specify.

**Example**

In the following example, all properties of the specified IP object are listed.

```
list_property [get_ips FIFO_Top]
```

**See also**

- [report\\_property](#)
- [set\\_property](#)

**3.2.8 open\_project**

Opens a project.

**Syntax**

```
open_project <file>] [-pn] [-device_version] [-h/--help]
```

**Usage**

Name	Description
<file>	Specifies the project file
[-pn]	Specifies part number
[-device_version]	Specifies device version
[-h/--help]	Displays help information

**Type**

[Project](#)

**Description**

This command is used to open a project, and allows specifying a new part number for the opened project. For the file path format, see [3.2.1 add\\_file](#).

- <file>: Specifies the name of the project file to be opened.
- [-pn]: Specifies the part number for the project.
- [-device\_version]: Specifies the device version for the project.
- [-h/--help]: Displays help information.

**Example**

```
open_project D:\test.gprj
```

### 3.2.9 read\_ipc

Reads ipc files.

#### Syntax

```
read_ipc <file>
```

#### Usage

Name	Description
<file>	IPC files

#### Type

[IPFlow](#)

#### Description

Read the specified IPC file and configure options through the IPC file. For the file path format, see [3.2.1 add\\_file](#).

#### Parameter

<file>: Specifies the name of the IPC file to be opened.

#### Example

In the following example, an IPC file is read from the specified path.

```
read_ipc D:/gowin_project/src/fifo/fifio.ipc
```

#### See also

[generate\\_target](#)

### 3.2.10 report\_property

Reports properties of an object.

#### Syntax

```
report_property <object>
```

#### Usage

Name	Description
<object>	The object that queries properties.

#### Type

[IPFlow](#)

#### Description

This command is used to obtain the option names, types, and values for the specified IP object.

#### Parameter

<object>: Specifies the IP object that queries option. Use [get\_ips module\_name] to specify.

**Example**

In the following example, all the properties of a specified IP object are listed.

```
report_property [get_ips FIFO_Top]
```

**See also**

- [set\\_property](#)
- [list\\_property](#)

**3.2.11 rm\_file**

Removes design files.

**Syntax**

```
rm_file [-h/--help ] <files>
```

**Usage**

Name	Description
<-files>	Design files to be removed
[-h/--help]	Displays help information

**Type**

[Project](#)

**Description**

Removes design files; and for the file path format, see [3.2.1 add\\_file](#).

**Parameter**

- <-files> Specifies the design files to be removed. Multiple files can be specified, separated by spaces.
- [-h/--help]: Displays help information.

**Example**

```
rm_file a.v
rm_file a.v b.v c.v
rm_file D:/gowin_project/top.v
rm_file D:\\gowin_project\\top.v
```

**3.2.12 run**

Runs flows.

**Syntax**

```
run [-h/--help] <syn/pnr/all>
```

**Usage**

Name	Description
<syn/pnr/all>	Specifies the name of the flow to be run

Name	Description
<code>[-h/--help]</code>	Displays help information

**Type**[Project](#)**Description**

Runs a specified flow or all flows.

**Parameter**

- `<syn/pnr/all>`: Specifies the name of the flow to be run. The available flow names are "syn" (synthesis), "pnr" (place and route), or you can specify all to run all flows.
- `[-h/--help]`: Displays help information

**Example**

```
run pnr
run all
```

### 3.2.13 run close

Closes a project.

**Syntax**

```
run close
```

**Type**[Project](#)**Description**

Closes the current project.

**Example**

```
run close
```

### 3.2.14 saveto

Saves project data to a tcl script.

**Syntax**

```
saveto [-all_options] [-h/--help] <file>
```

**Usage**

Name	Description
<code>[-all_options]</code>	Saves all option information
<code>[-h/--help]</code>	Displays help information
<code>&lt;file&gt;</code>	The file to be saved

**Type**[Project](#)

### Description

Saves the current project design data to a tcl script. For the file path format, see [3.2.1 add file](#).

### Parameter

- [-all\_options]: By default, the saveto command only saves the modified options, i.e., those different from the default values. By using -all\_options, all option information will be saved.
- [-h/--help]: Displays help information.
- <file>: The file to be saved.

### Example

```
saveto project.tcl
saveto -all_options project.tcl
saveto -all_options D:/gowin_project/project.tcl
saveto -all_options D:\\gowin_project\\project.tcl
```

## 3.2.15 set\_device

Sets device part number.

### Syntax

```
set_device [-device_version <value>] [-h/--help ] <part number>
```

### Usage

Name	Description
[-device_version <value>]	Sets device version
[-h/--help]	Displays help information
<part number>	Sets device part number

### Type

[Project](#)

### Description

Sets device part number.

### Parameter

- <part number>: Specifies the part number of the target device, such as GW1N-UV4LQ144C6/I5.
- [-device\_version <value>]: Specifies the device version. Supported values are NA|B|C|D.
- [-h/--help]: Displays help information.

### Example

```
set_device GW1N-LV1CS30C6/I5
set_device -device_version C GW1N-UV4LQ144C6/I5
```

### 3.2.16 set\_file\_enable

Sets file enable properties.

#### Syntax

```
set_file_enable <file> <true|false> [-h/--help]
```

#### Usage

Name	Description
<file>	Specifies the design file to be set
<true false>	Whether the file can be used or not
[-h/--help]	Displays help information

#### Type

[Project](#)

#### Description

Sets whether the file can be used. For the file path format, see [3.2.1 add\\_file](#).

#### Parameter

- <file>: Specifies the file to be set.
- <true|false>: true means the file can be used, and false means it cannot.
- [-h/--help]: Displays help information.

#### Example

```
set_file_enable top.v false
set_file_enable D:/gowin_project/top.v
set_file_enable D:\\gowin_project\\top.v
```

### 3.2.17 set\_file\_prop

Sets file properties.

#### Syntax

```
set_file_prop <file> [-lib <name>] [-h/--help]
```

#### Usage

Name	Description
<file>	Specifies the design files to be set
[-lib <name>]	Sets the library name for the file
[-h/--help]	Displays help information

#### Type

[Project](#)

### Description

Sets properties for the specified files. For the file path format, see [3.2.1 add file](#).

### Parameter

- `<file>`: Specifies the file(s) to be set. Multiple files can be listed, separated by spaces.
- `[-lib <name>]`: Sets the library name for the file. This option is only valid for VHDL files.
- `[-h/--help]`: Displays help information.

### Example

```
set_file_prop -lib work top .vhd
set_file_prop -lib work D:/gowin_project/top.vhd
set_file_prop -lib work D:\\gowin_project\\top.vhd
```

## 3.2.18 set\_csr

Specifies the CSR file.

### Syntax

```
set_csr [-h/--help ] <file>
```

### Usage

Name	Description
<code>&lt;file&gt;</code>	The CSR file to be specified.
<code>[-h/--help]</code>	Displays help information

### Type

[Project](#)

### Description

Specifies the CSR file. For the file path format, see [3.2.1 add file](#).

### Parameter

- `<files>`: Specifies the CSR file.
- `[-h/--help]`: Displays help information.

### Example

```
set_csr a.csr
set_csr D:/gowin_project/a.csr
set_csr D:\\gowin_project\\a.csr
```

### 3.2.19 set\_option

Sets project-related property configurations and flow options.

#### Syntax

```
set_option [options] [-h/--help]
```

#### Usage

Name	Description
[options]	Specifies configurations or flow options
[-h/--help]	Displays help information

#### Type

[Project](#)

#### Description

Sets project-related property configurations and flow options.

#### Parameter

- [options]: Specifies configurations or flow options.
- [-h/--help]: Displays help information.

#### Global Property Configuration

##### -output\_base\_name

Specify the output file name.

#### Syntax

```
-output_base_name <name>
```

#### Usage

Name	Description
<name>	Specifies the output file name

#### Type

[Project](#)

#### Description

Specifies the name of the output file. This option is only used to set the base name, and different flows will append appropriate extensions based on the output file type. For example, if -output\_base\_name abc is set, the netlist file generated by Gowin Synthesis will be named abc.vg.

#### Parameter

<name>: Specifies the output file name.

#### Example

```
set_option -output_base_name abc
```

##### -global\_freq

Specify frequency value

**Syntax**

-global\_freq <default|value>

**Usage**

Name	Description
<default value>	Specifies frequency value

**Type**

[Project](#)

**Description**

Specifies the frequency value. The default setting is: 50 MHz for the LittleBee family, 100 MHz for Arora family.

**Parameter**

<default|value>frequency value

**Example**

set\_option -global\_freq 80

**Synthesis Property Configuration****-synthesis\_tool**

Specifies Synthesis tool.

**Syntax**

-synthesis\_tool <tool>

**Usage**

Name	Description
<tool>	Specifies Synthesis tool

**Type**

[Project](#)

**Description**

Specifies Synthesis tool GowinSynthesis.

**Parameter**

<tool>: Specifies Synthesis tool GowinSynthesis.

**Example**

set\_option -synthesis\_tool GowinSynthesis

**-top\_module**

Specifies Top Module/Entity.

**Syntax**

-top\_module <name>

**Usage**

Name	Description
<name>	Specifies top module

**Type**[Project](#)**Description**

Specifies top module.

**Parameter**

<name>: Specifies top module.

**Example**

```
set_option -top_module test
```

**-include\_path**

Specifies Include Path.

**Syntax**

```
-include_path <path or path list>
```

**Usage**

Name	Description
<path or path list>	Specifies Include Path

**Type**[Project](#)**Description**

Specifies the include path. When specifying multiple include paths, separate them with semicolons (;) and enclose all paths within curly braces {}. For example: -include\_path {/path1;/path2;/path3}. Both relative and absolute paths are supported. A relative path is interpreted relative to the program's current working directory.

**Parameter**

<path or path list>: Specifies Include Path.

**Example**

```
set_option -include_path D:/project
```

**-verilog\_std**

Specifies Verilog language standard.

**Syntax**

```
-verilog_std<v1995|v2001|sysv2017>
```

**Usage**

Name	Description
<v1995 v2001 sysv2017>	Specifies Verilog language standard

**Type**[Project](#)**Description**

Specifies Verilog language standard: Verilog 95/Verilog 2001/System Verilog 2017, and the default is Verilog 2001.

**Parameter**

<v1995|v2001|sysv2017>: Specifies Verilog language standard.

**Example**

```
set_option -verilog_std v1995
```

**-vhdl\_std**

Specifies VHDL language standard.

**Syntax**

-vhdl\_std <vhdl1993|vhdl2008|vhdl2019>

**Usage**

Name	Description
<vhdl1993 vhdl2008 vhdl2019>	Specifies VHDL language standard

**Type**[Project](#)**Description**

Specifies VHDL language standard: VHDL 1993/VHDL 2008/VHDL 2019, and the default is VHDL 1993.

**Parameter**

<vhdl1993|vhdl2008|vhdl2019>: Specifies VHDL language standard.

**Example**

```
set_option -vhdl_std vhdl2008
```

**-print\_all\_synthesis\_warning <0|1>**

Specifies whether to print all synthesis warning messages. The default is 0.

**Syntax**

-print\_all\_synthesis\_warning <0|1>

**Usage**

Name	Description
<0 1>	0: Do not print all warning messages. 1: Print all warning messages.

**Type**[Project](#)

**Description**

Specifies whether to print all synthesis warning messages. The default is 0.

**Parameter**

<0|1>: Specifies whether to print all synthesis warning messages.

**Example**

```
set_option -print_all_synthesis_warning 1
```

**-disable\_io\_insertion**

Enables or disables I/O insertion.

**Syntax**

```
-disable_io_insertion <0|1>
```

**Usage**

Name	Description
<0 1>	0: Enables I/O insertion 1: Disables I/O insertion

**Type**

[Project](#)

**Description**

Enables or disables I/O insertion. The default is 0.

**Parameter**

<0|1>: Enables or disables I/O insertion.

**Example**

```
set_option -disable_io_insertion 1
```

**-looplevelimit <value>**

The loop limit value of default compiler in RTL.

**Syntax**

```
-looplevelimit <value>
```

**Usage**

Name	Description
<value>	Looplevelimit value

**Type**

[Project](#)

**Description**

The loop limit value of default compiler in RTL, with the default value being 2000.

**Parameter**

<value>: The loop limit value of default compiler in RTL.

### Example

```
set_option -looplimit 1000
```

### -maxfan <value>

Set fanout value.

### Syntax

```
-maxfan <value>
```

### Usage

Name	Description
<value>	Maxfan value

### Type

[Project](#)

### Description

Set the fanout value for input ports, nets, or register output ports, with the default value being 10000.

### Parameter

<value>: The fanout value for input ports, nets, or register output ports.

### Example

```
set_option -maxfan 5000
```

### -rw\_check\_on\_ram

Insert bypass logic around RAM.

### Syntax

```
-rw_check_on_ram <0|1>
```

### Usage

Name	Description
<0 1>	0: Disable 1: Enable

### Type

[Project](#)

### Description

If there are read or write conflicts in RAM, enabling this option will insert bypass logic around the RAM to prevent simulation mismatches, with the default being 0.

### Parameter

<0|1>: Enables or disables the insertion of bypass logic around RAM.

### Example

```
set_option -rw_check_on_ram 1
```

## Place & Route Property Configuration

### -vccx

Specifies vccx value.

#### Syntax

```
-vccx <value>
```

#### Usage

Name	Description
<value>	Specifies vccx value

#### Type

[Project](#)

#### Description

Specifies vccx value.

#### Parameter

<value>: Specifies vccx value.

#### Example

```
set_option -vccx 3.3
```

### -vcc

#### Syntax

```
-vcc <value>
```

#### Usage

Name	Description
<value>	Specifies vcc value

#### Type

[Project](#)

#### Description

Specifies vccx value.

#### Parameter

<value>: Specifies vccx value.

#### Example

```
set_option -vcc 3.3
```

### -gen\_sdf

Whether to generate the SDF file.

#### Syntax

```
-gen_sdf <0|1>
```

**Usage**

Name	Description
<0 1>	0: Do not generate the SDF file. 1: Generates the SDF file.

**Type**[Project](#)**Description**

Specifies whether the Place & Route generates an SDF, and the default is 0.

**Parameter**

<0|1>: Enable control for generating the SDF file.

**Example**

```
set_option -gen_sdf 1
```

**-gen\_io\_cst**

Whether to generate the physical constraint file for the port, named \*.io.cst.

**Syntax**

```
-gen_io_cst <0|1>
```

**Usage**

Name	Description
<0 1>	0: Does not generate the *.io.cst file. 1: Generates the *.io.cst file.

**Type**[Project](#)**Description**

Specifies whether the Place & Route generates the physical constraint file for the port, named \*.io.cst. The default is 0.

**Parameter**

<0|1>: Generates physical constraints file enable control for port.

**Example**

```
set_option -gen_io_cst 1
```

**-gen\_ibis**

Specifies whether to generate the input/output buffer information file named \*.ibs.

**Syntax**

```
-gen_ibis <0|1>
```

**Usage**

Name	Description
<0 1>	0: Do not generate *.ibs file. 1: Generates *.ibs file.

**Type**[Project](#)**Description**

Specifies whether Place & Route generates the input/output buffer information file named \*.ibs.

**Parameter**

<0|1>: Generates the input/output buffer information file enable control.

**Example**

```
set_option -gen_ibis 1
```

**-gen\_posp**

Whether to generate a device placement file.

**Syntax**

```
-gen_posp <0|1>
```

**Usage**

Name	Description
<0 1>	0: Do not generate *.posp file. 1: Generates *.posp file.

**Type**[Project](#)**Description**

Specifies whether Place & Route generates a device placement file named \*.posp, which contains only BSRAM placement information. The default value is 0.

**Parameter**

<0|1>: Generates device placement file enable control.

**Example**

```
set_option -gen_posp 1
```

**-gen\_text\_timing\_rpt**

Generate a timing report in text format.

**Syntax**

```
-gen_text_timing_rpt <0|1>
```

**Usage**

Name	Description
<0 1>	0: Do not generate *.tr file.

Name	Description
	1: Generates *.tr file.

**Type**[Project](#)**Description**

Specifies whether Place & Route generates a timing report in text format with the filename \*.tr. The default value is 0.

**Parameter**

<0|1>: Generates a text-format timing report enable control.

**Example**

```
set_option -gen_text_timing_rpt 1
```

**-gen\_verilog\_sim\_netlist**

Specifies whether to generate a Verilog timing simulation model file.

**Syntax**

```
-gen_verilog_sim_netlist <0|1>
```

**Usage**

Name	Description
<0 1>	0: Do not generate *.vo file. 1: Generates *.vo file.

**Type**[Project](#)**Description**

Specifies whether Place & Route generates a Verilog timing simulation model file named \*.vo, and the default is 0.

**Parameter**

<0|1>: Generates enable control for the Verilog timing simulation model file.

**Example**

```
set_option -gen_verilog_sim_netlist 1
```

**-gen\_vhdl\_sim\_netlist**

Generates VHDL timing simulation model file or not.

**Syntax**

```
-gen_vhdl_sim_netlist <0|1>
```

**Usage**

Name	Description
<0 1>	0: Do not generate *.vho file. 1: Generates *.vho file.

**Type**[Project](#)**Description**

Specifies whether Place & Route generates a VHDL timing simulation model file named \*.vho, and the default is 0.

**Parameter**

<0|1>: Generates enable control for the VHDL timing simulation model file.

**Example**

```
set_option -gen_vhdl_sim_netlist 1
```

**-show\_init\_in\_vo**

Adds default initial values to the instances in the timing simulation model file.

**Syntax**

```
-show_init_in_vo <0|1>
```

**Usage**

Name	Description
<0 1>	0: Do not add default initial values to the instances in the timing simulation model file. 1: Adds default initial values to the instances in the timing simulation model file.

**Type**[Project](#)**Description**

Adds default initial values to the instances in the generated Place & Route timing simulation model file, and the default is 0.

**Parameter**

<0|1>: Enable control for adding default initial values to the instances in the generated Place & Route timing simulation model file.

**Example**

```
set_option -show_init_in_vo 1
```

**-show\_all\_warn**

Whether to show all warnings.

**Syntax**

```
-show_all_warn<0|1>
```

**Usage**

Name	Description
<0 1>	0: Do not output all warning messages during

Name	Description
	Placement & Routing. 1: Outputs all warning messages during Placement & Routing.

**Type**[Project](#)**Description**

Outputs all warning messages when running Place & Route, and the default is 0.

**Parameter**

<0|1>: Enable control for outputting all warning messages when running Place & Route.

**Example**

```
set_option -show_all_warn 1
```

**-timing\_driven**

Whether optimizes timing driven for Place & Route.

**Syntax**

```
-timing_driven <0|1>
```

**Usage**

Name	Description
<0 1>	0: Disables Place & Route timing driven. 1: Enables Place & Route timing driven.

**Type**[Project](#)**Description**

Timing-driven optimization is performed when running Place & Route. The default value is 1.

**Parameter**

<0|1>: Enable control for timing-driven optimization when running Place & Route.

**Example**

```
set_option -timing_driven 1
```

**-cst\_warn\_to\_error**

Elevates physical constraint warnings to errors.

**Syntax**

```
-cst_warn_to_error <0|1>
```

**Usage**

Name	Description
<0 1>	0: Physical constraint warnings will not be elevated to errors. 1: Physical constraint warnings will be elevated to errors.

**Type**[Project](#)**Description**

Elevates physical constraint warnings to errors when running Place & Route. The default value is 1.

**Parameter**

<0|1>: Enable control for elevating physical constraint warnings to errors when running Place & Route.

**Example**

```
set_option -cst_warn_to_error 1
```

**-rpt\_auto\_place\_io\_info**

Reports auto-placed IO location information.

**Syntax**

```
-rpt_auto_place_io_info <0|1>
```

**Usage**

Name	Description
<0 1>	0: Auto-placed IO location information will not be reported. 1: Auto-placed IO location information will be reported.

**Type**[Project](#)**Description**

Reports auto-placed IO location information when running Place & Route. The default value is 0.

**Parameter**

<0|1>: Enable control for reporting auto-placed IO location information.

**Example**

```
set_option -cst_warn_to_error 1
```

**-place\_option**

Placement algorithm option.

**Syntax**

```
-place_option <0|1|2|3|4>
```

**Usage**

Name	Description
<0 1 2 3 4>	0: Uses the default placement algorithm. 1: Uses placement algorithm 1. 2: Uses placement algorithm 2. 3: Uses placement algorithm 3. 4: Uses placement algorithm 4.

**Type**[Project](#)**Description**

Placement algorithm option. The default value is 0.

**Parameter**

<0|1|2|3|4>: Placement algorithm option.

**Example**

```
set_option -place_option 1
```

**-route\_option**

Routing algorithm option.

**Syntax**

```
-route_option <0|1|2>
```

**Usage**

Name	Description
<0 1 2>	0: Uses the default routing algorithm. 1: Uses the default routing algorithm 1. 2: Uses the default routing algorithm 2.

**Type**[Project](#)**Description**

Routing algorithm option. The default value is 0.

**Parameter**

<0|1|2>: Routing algorithm option.

**Example**

```
set_option -route_option 1
```

**-ireg\_in\_iob**

Place registers connected to input buffers to IOB.

**Syntax**

```
-ireg_in_iob <0|1>
```

**Usage**

Name	Description
<0 1>	0: Do not place registers connected to input buffers to IOB. 1: Place registers connected to input buffers to IOB.

**Type**[Project](#)**Description**

Enabling this option will cause Place & Route to place registers connected to input buffers to IOB. The default value is 1.

**Parameter**

<0|1>: Enable control for placing registers connected to input buffers to IOB.

**Example**

```
set_option -ireg_in_iob 1
```

**-oreg\_in\_iob**

Place registers connected to output/tristate buffers to IOB.

**Syntax**

```
-oreg_in_iob <0|1>
```

**Usage**

Name	Description
<0 1>	0: Do not place registers connected to output/tristate buffers to IOB. 1: Place registers connected to output/tristate buffers to IOB.

**Type**[Project](#)**Description**

Enabling this option will cause Place & Route to place registers connected to output/tristate buffers to IOB. The default value is 1.

**Parameter**

<0|1>: Enable control for place registers connected to output/tristate buffers to IOB.

**Example**

```
set_option -oreg_in_iob 1
```

**-ioreg\_in\_iob**

Place registers connected to bidirectional buffers to IOB.

**Syntax**

```
-ioreg_in_iob <0|1>
```

## Usage

Name	Description
<0 1>	0: Do not place registers connected to bidirectional buffers to IOB. 1: Place registers connected to bidirectional buffers to IOB.

## Type

[Project](#)

## Description

Enabling this option will cause Place & Route to place registers connected to bidirectional buffers in IOB. The default value is 1.

## Parameter

<0|1>: Enable control for placing registers connected to bidirectional buffers to IOB.

## Example

```
set_option -ioreg_in_job 1
```

## -replicate\_resources

Replicate resources for high fanout to reduce fanout and improve timing.

## Syntax

```
-replicate_resources <0|1>
```

## Usage

Name	Description
<0 1>	0: Do not replicate resources for high fanout to reduce fanout. 1: Replicate resources for high fanout to reduce fanout.

## Type

[Project](#)

## Description

Enabling this option will cause Place & Route to replicate resources for high fanout to reduce fanout and improve timing results. The default value is 0.

## Parameter

<0|1>: Enable control for replicate resources for high fanout to reduce fanout.

## Example

```
set_option -replicate_resources 1
```

## -clock\_route\_order

Specifies the routing order for clock wires other than those generated by Clock primitives. The optional values are 0 and 1, with the default value

being 0.

### Syntax

-clock\_route\_order <0|1>

### Usage

Name	Description
<0 1>	0: Route clock wires in the order of net fanout, from highest to lowest. 1: Route clock wires in the order of frequency, from highest to lowest.

### Type

[Project](#)

### Description

Specifies the routing order for clock wires other than those generated by clock primitives.

### Parameter

<0|1>: Specifies the routing order for clock wires other than those generated by clock primitives.

### Example

```
set_option -clock_route_order 1
```

### -route\_maxfan

Sets maximum fanout for routing.

### Syntax

-route\_maxfan <value>

### Usage

Name	Description
< value>	Sets maximum fanout for routing.

### Type

[Project](#)

### Description

Based on routing optimization, this option is used to set the maximum fanout for routing. The value should be an integer greater than 0 and less than or equal to 100. For GW1NZ-1/GW1N-2/GW1NR-2/GW1N-1P5 devices, the default value of this option is 10, while for other devices, the default value is 23.

### Parameter

<value>: Sets maximum fanout for routing.

### Example

```
set_option -route_maxfan 60
```

**-correct\_hold\_violation**

Automatic hold violation fixing for routing.

**Syntax**

-correct\_hold\_violation <0|1>

**Usage**

Name	Description
<0 1>	0: Do not automatically fix hold violations during routing. 1: Automatically fix hold violations during routing.

**Type**

[Project](#)

**Description**

Enabling this option allows automatically fixing hold timing violations during routing. The default value is 1.

**Parameter**

<0|1>: Enable control for automatically fixing hold timing violations during routing

**Example**

```
set_option -correct_hold_violation 1
```

**-convert\_sdp32\_36\_to\_sdp16\_18**

Converts 32/36-bit wide SDPB/SDPX9B into two 16/18-bit wide SDPB/SDPX9B. This command is only supported by Arora V devices.

**Syntax**

-convert\_sdp32\_36\_to\_sdp16\_18 <0|1>

**Usage**

Name	Description
<0 1>	0: Disables conversion 1: Converts 32/36-bit wide SDPB/SDPX9B into two 16/18-bit wide SDPB/SDPX9B

**Type**

[Project](#)

**Description**

Enabling this option will convert 32/36-bit wide SDPB/SDPX9B into two 16/18-bit wide SDPB/SDPX9B. The default value is 0.

**Parameter**

<0|1> Enable control for converting 32/36-bit wide SDPB/SDPX9B into two 16/18-bit wide SDPB/SDPX9B.

**Example**

```
set_option -convert_sdp32_36_to_sdp16_18 1
```

**-inc\_place <0|auto|file>**

Incremental placement.

**Syntax**

-inc\_place <0|auto|file>

**Usage**

Name	Description
<0 auto file >	0: Disables incremental placement. auto: Automatic incremental placement. file: Specifies a *.p file for incremental placement.

**Type**

[Project](#)

**Description**

Enabling this option allows incremental placement. The default value is 0.

**Parameter**

<0|auto|file >: Enable control for incremental placement.

**Example**

```
set_option -inc_place auto
```

- -inc\_pnr <0|auto|file>  
Incremental place & route.

**Syntax**

-inc\_pnr <0|auto|file>

**Usage**

Name	Description
<0 auto file >	0: Disables incremental place & route. auto: Automatic incremental place & route. file: Specifies a *.p file for incremental place & route.

**Type**

[Project](#)

**Description**

Enabling this option allows incremental place & route. The default value is 0.

**Parameter**

<0|auto|file >: Enable control for incremental place & route.

**Example**

```
set_option -inc_pnr auto
```

**Note!**

For detailed usage of Place & Route-related running, see Place & Route section in [SUG100, Gowin Software User Guide](#).

## Pin Multiplexing Property Configuration

### **-use\_jtag\_as\_gpio**

Multiplexes JTAG-related pins as general IO pins.

#### **Syntax**

`-use_jtag_as_gpio <0|1>`

#### **Usage**

Name	Description
<0 1>	0: Uses as JTAG-dedicated pins. 1: Multiplexes as general IO pins.

#### **Type**

[Project](#)

#### **Description**

Multiplexes JTAG-related pins as general IO pins, and the default is 0.

#### **Parameter**

<0|1>: Enable control for multiplexing JTAG-related pins as general IO pins.

#### **Example**

```
set_option -use_jtag_as_gpio 1
```

### **-use\_sspi\_as\_gpio**

Multiplexes SSPI-related pins as general IO pins.

#### **Syntax**

`-use_sspi_as_gpio <0|1>`

#### **Usage**

Name	Description
<0 1>	0: Uses as SSPI-dedicated pins. 1: Multiplexes as general IO pins.

#### **Type**

[Project](#)

#### **Description**

Multiplexes SSPI-related pins as general IO pins, and the default is 0.

#### **Parameter**

<0|1>: Enable control for multiplexing SSPI-related pins as general IO pins.

#### **Example**

```
set_option -use_sspi _as_gpio 1
```

**-use\_mspi\_as\_gpio**

Multiplexes MSPI-related pins as general IO pins.

**Syntax**

-use\_mspi\_as\_gpio <0|1>

**Usage**

Name	Description
<0 1>	0: Uses as MSPI-dedicated pins. 1: Multiplexes as general IO pins.

**Type**

[Project](#)

**Description**

Multiplexes MSPI-related pins as general IO pins, and the default is 0.

**Parameter**

<0|1>: Enable control for multiplexing MSPI-related pins as general IO pins.

**Example**

```
set_option -use_mspi_as_gpio 1
```

**-use\_ready\_as\_gpio**

Multiplexes READY-related pins as general IO pins.

**Syntax**

-use\_ready\_as\_gpio <0|1>

**Usage**

Name	Description
<0 1>	0: Uses as READY-dedicated pins. 1: Multiplexes as general IO pins.

**Type**

[Project](#)

**Description**

Multiplexes READY-related pins as general IO pins, and the default is 0.

**Parameter**

<0|1>: Enable control for multiplexing READY-related pins as general IO pins.

**Example**

```
set_option -use_ready_as_gpio 1
```

**-use\_done\_as\_gpio**

Multiplexes DONE-related pins as general IO pins.

**Syntax**

-use\_done\_as\_gpio <0|1>

**Usage**

Name	Description
<0 1>	0: Uses as DONE-dedicated pins. 1: Multiplexes as general IO pins.

**Type**

[Project](#)

**Description**

Multiplexes DONE-related pins as general IO pins, and the default is 0.

**Parameter**

<0|1>: Enable control for multiplexing DONE-related pins as general IO pins.

**Example**

```
set_option -use_done_as_gpio 1
```

**-use\_reconfig\_as\_gpio**

Multiplexes RECONFIG\_N-related pins as general IO pins.

**Syntax**

-use\_reconfig\_as\_gpio <0|1>

**Usage**

Name	Description
<0 1>	0: Uses as RECONFIG_N-related pins. 1: Multiplexes as general IO pins.

**Type**

[Project](#)

**Description**

Multiplexes RECONFIG\_N-related pins as general IO pins, and the default is 0.

**Parameter**

<0|1>: Enable control for multiplexing RECONFIG\_N-related pins as general IO pins.

**Example**

```
set_option -use_reconfig_as_gpio 1
```

**-use\_i2c\_as\_gpio**

Multiplexes I2C-related pins as general IO pins.

**Syntax**

-use\_i2c\_as\_gpio <0|1>

**Usage**

Name	Description
<0 1>	0: Uses as I2C-related pins. 1: Multiplexes as general IO pins.

**Type**[Project](#)**Description**

Multiplexes I2C-related pins as general IO pins, and the default is 0.

**Parameter**

<0|1>: Enable control for multiplexing I2C-related pins as general IO pins.

**Example**

```
set_option -use_i2c_as_gpio 1
```

**BitStream Property Configuration****-bit\_format**

Specifies the format of the generated bitstream file content.

**Syntax**

```
-bit_format <txt|bin>
```

**Usage**

Name	Description
<txt bin>	The format of the bitstream file content.

**Type**[Project](#)**Description**

Used to specify the format of the generated bitstream file content.

**Parameter**

<txt|bin>: the format of the generated bitstream file content.

**Example**

```
set_option -bit_format txt
```

**-bit\_crc\_check**

Cyclic redundancy check.

**Syntax**

```
-bit_crc_check <0|1>
```

**Usage**

Name	Description
<0 1>	0: Disables cyclic redundancy check. 1: Enables cyclic redundancy check.

**Type**[Project](#)**Description**

Enables CRC for the bitstream file. The default is 1.

**Parameter**

<0|1>: Enables CRC for the bitstream file.

**Example**

```
set_option -bit_crc_check 1
```

**-bit\_compress**

Compresses the bitstream file.

**Syntax**

```
-bit_compress <0|1>
```

**Usage**

Name	Description
<0 1>	0: Do not compress the bitstream file. 1: Compresses the bitstream file.

**Type**[Project](#)**Description**

Compresses the generated bitstream file. The default value is 1.

**Parameter**

<0|1>: Compresses the bitstream file.

**Example**

```
set_option -bit_compress 1
```

**-bit\_encrypt**

Encrypts the bitstream file.

**Syntax**

```
-bit_encrypt <0|1>
```

**Usage**

Name	Description
<0 1>	0: Do not encrypt the bitstream file. 1: Encrypts the bitstream file.

**Type**



**Parameter**

<0|1>: Security bit enable control.

**Example**

```
set_option -bit_security 1
```

**-bit\_incl\_bsram\_init**

Prints initial values of BSRAM to the Bitstream file.

**Syntax**

```
-bit_incl_bsram_init <0|1>
```

**Usage**

Name	Description
<0 1>	0: Do not print initial values of BSRAM to the Bitstream file; 1: Prints initial values of BSRAM to the Bitstream file.

**Type**

[Project](#)

**Description**

This option is used to control whether the initial values of BSRAM are printed into the bitstream file. The default value is 1. For GW1N and GW2A devices, when this option is set to 1, all positions of the BSRAM will have their initial values printed in the bitstream file, and the initial values of unoccupied BSRAM positions are printed as 0. For GW5A(N)(S)(R)(T) devices, when this option is set to 1, all initial values of BSRAM in the same column as the occupied BSRAM will be printed to the bitstream file, and the initial values of unoccupied BSRAM positions in that column are printed as 0.

**Parameter**

<0|1>: Enable control for printing initial values of BSRAM to the Bitstream file.

**Example**

```
set_option -bit_incl_bsram_init 1
```

**-bg\_programming**

Background programming function.

**Syntax**

```
-bg_programming <off | jtag | i2c | goconfig | userlogic |  
i2c_jtag_ssipi_qsspi | jtag_ssipi_qsspi>
```

**Usage**

Name	Description
<off jtag i2c goconfig userlogic  i2c_jtag_ssipi_qsspi jtag_ssipi_qsspi>	Off: Do not use background programming function.

Name	Description
	jtag: Background programming via JTAG mode. i2c: Background programming via I2C mode. goconfig: Background programming using goConfig IP. userlogic: Background programming using FPGA internal logic. i2c_jtag_ssipi_qsspi: Background programming using I2C/JTAG/SSPI/QSSPI mode. jtag_ssipi_qsspi: Background programming using JTAG/SSPI/QSSPI mode.

**Type**[Project](#)**Description**

It allows programming of Flash without disrupting the FPGA chip's current operations. The default setting is off.

**Parameter**

< off | jtag | i2c | goconfig | userlogic | i2c\_jtag\_ssipi\_qsspi | jtag\_ssipi\_qsspi>: Background programming method.

**Example**

```
set_option -bg_programming userlogic
```

**-hotboot**

Hotboot mode.

**Syntax**

```
-hotboot <0|1>
```

**Usage**

Name	Description
<0 1>	0: Disables hotboot mode. 1: Enables hotboot mode.

**Type**[Project](#)**Description**

Hotboot mode enable control. The default is 0.

**Parameter**

<0|1>: Hotboot mode enable control.

**Example**

```
set_option -hotboot 1
```

**-i2c\_slave\_addr**

Sets I2C device address.

**Syntax**

-i2c\_slave\_addr <value>

**Usage**

Name	Description
<value>	Sets I2C device address.

**Type**

[Project](#)

**Description**

Sets the I2C device address, and the configurable range is from 00 to 7F. The default is 00.

**Parameter**

<value>: I2C device address.

**Example**

```
set_option -i2c_slave_addr 2F
```

**-secure\_mode**

Enables secure mode.

**Syntax**

-secure\_mode <0|1>

**Usage**

Name	Description
<0 1>	0: Disables secure mode. 1: Enables secure mode.

**Type**

[Project](#)

**Description**

Enables secure mode, and at this time the JTAG pins are used as GPIOs; the bitstream file can only be programmed into the device once. The default is 0.

**Parameter**

<0|1>: Enables control for secure mode.

**Example**

```
set_option -secure_mode 1
```

**-loading\_rate**

The loading speed of bitstream data from Flash to SRAM in AutoBoot and MSPI configuration modes.

**Syntax**

-loading\_rate <value>

**Usage**

Name	Description
<value>	The loading speed of bitstream data from Flash to SRAM in AutoBoot and MSPI configuration modes.

**Type**

[Project](#)

**Description**

The loading speed of bitstream data from Flash to SRAM in AutoBoot and MSPI configuration modes, and the default value is 2.500MHz.

**Parameter**

<value>: The loading speed of bitstream data from Flash to SRAM.

**Example**

```
set_option -loading_rate 21.000MHz
```

**-seu\_handler**

Enable Single Event Upset (SEU) handler.

**Syntax**

-seu\_handler <0|1>

**Usage**

Name	Description
<0 1>	0: Disables SEU handler. 1: Enables SEU handler.

**Type**

[Project](#)

**Description**

Enables SEU handler, and the default is 0.

**Parameter**

<0|1>: Enable control for SEU handler.

**Example**

```
set_option -seu_handler 1
```

**-seu\_handler\_mode**

Selects the mode for booting or stopping the SEU Handler.

**Syntax**

-seu\_handler\_mode <auto|userlogic>

**Usage**

Name	Description
<0 1>	auto: Automatically enables the SEU handler after the chip wakes up. userlogic: Uses logic to enable or stop the SEU handler.

**Type**[Project](#)**Description**

Selects the mode for booting or stopping the SEU Handler, and the default is auto.

**Parameter**

< auto|userlogic>: The mode for booting or stopping the SEU Handler.

**Example**

```
set_option -seu_handler_mode userlogic
```

**-seu\_handler\_checksum**

Enables SEU processing, checking, calculation, and comparison.

**Syntax**

```
-seu_handler_checksum <0|1>
```

**Usage**

Name	Description
<0 1>	0: Disables SEU processing, checking, calculation, and comparison. 1: Enables SEU processing, checking, calculation, and comparison.

**Type**[Project](#)**Description**

Enables SEU processing, checking, calculation, and comparison, and the default is 0.

**Parameter**

<0|1>: Enables control for SEU processing, checking, calculation, and comparison.

**Example**

```
set_option -seu_handler_checksum 1
```

**-error\_detection**

Enables error detection only.

**Syntax**

```
-error_detection <0|1>
```

**Usage**

Name	Description
<0 1>	0: Disables error detection. 1: Enables error detection only.

**Type**[Project](#)**Description**

Enables error detection only, and the default is 0.

**Parameter**

<0|1>: Enables control for error detection only.

**Example**

```
set_option -error_detection 1
```

**-error\_detection\_correction**

Enables error detection and correction.

**Syntax**

```
-error_detection_correction <0|1>
```

**Usage**

Name	Description
<0 1>	0: Disables error detection and correction. 1: Enables error detection and correction.

**Type**[Project](#)**Description**

Enables error detection and correction, and the default is 0.

**Parameter**

<0|1>: Enables control for error detection and correction.

**Example**

```
set_option -error_detection_correction 1
```

**-stop\_seu\_handler**

Stops SEU Handler.

**Syntax**

```
-stop_seu_handler <0|1>
```

**Usage**

Name	Description
<0 1>	0: Do not stop the SEU Handler when an uncorrectable ECC error or CRC checksum mismatch is detected. 1: Stops the SEU Handler when an uncorrectable ECC error or CRC checksum mismatch is detected.

**Type**[Project](#)**Description**

Stops the SEU Handler when an uncorrectable ECC error or CRC checksum mismatch is detected. The default is 0.

**Parameter**

<0|1>: Enable control for stopping SEU Handler.

**Example**

```
set_option -stop_seu_handler 1
```

**-osc\_div**

Sets the frequency division ratio for the extended control register.

**Syntax**

-osc\_div <4|8|16|32>

**Usage**

Name	Description
<4 8 16 32>	<p>4: Sets the frequency division ratio of the extended control register to 4.</p> <p>8: Sets the frequency division ratio of the extended control register to 8.</p> <p>16: Sets the frequency division ratio of the extended control register to 16.</p> <p>32: Sets the frequency division ratio of the extended control register to 32.</p>

**Type**[Project](#)**Description**

Sets the frequency division ratio for the extended control register, and the default is 8.

**Parameter**

<4|8|16|32>: The frequency division ratio for the extended control register.

**Example**

```
set_option -osc_div 8
```

**-error\_injection**

Enables error injection.

**Syntax**

-error\_injection <0|1>

**Usage**

Name	Description
<0 1>	0: Disables error injection. 1: Enables error injection.

**Type**[Project](#)**Description**

Enables error injection, and the default is 0

**Parameter**

<0|1>: Enables control for error injection.

**Example**

```
set_option -error_injection 1
```

**-ext\_cclk**

Enables external primary configuration clock.

**Syntax**

```
-ext_cclk <0|1>
```

**Usage**

Name	Description
<0 1>	0: Disables external primary configuration clock. 1: Enables external primary configuration clock.

**Type**[Project](#)**Description**

Enables external primary configuration clock. The default is 0.

**Parameter**

<0|1>: Enable control for external primary configuration clock.

**Example**

```
set_option -ext_cclk 1
```

**-ext\_cclk\_div**

Sets the frequency divider parameter.

**Syntax**

```
-ext_cclk_div <value>
```

**Usage**

Name	Description
<value>	Frequency divider Parameter

**Type**[Project](#)

**Description**

Sets the frequency divider parameter.

**Parameter**

<value>: Sets the frequency divider parameter.

**Example**

```
set_option -ext_cclk_div 4
```

**-multi\_boot**

Multi Boot enable control.

**Syntax**

-multi\_boot <0|1>

**Usage**

Name	Description
<0 1>	0: Disables Multi Boot. 1: Enables Multi Boot.

**Type**

[Project](#)

**Description**

Multi Boot enable control, and the default is 0.

**Parameter**

<0|1>: Multi Boot enable control.

**Example**

```
set_option -multi_boot 1
```

**-multiboot\_address\_width**

Configures SPI Flash address width.

**Syntax**

-multiboot\_address\_width<24|32>

**Usage**

Name	Description
<24 32>	24: Sets the SPI Flash address width to 24. 32: Sets the SPI Flash address width to 32.

**Type**

[Project](#)

**Description**

Configures SPI Flash address width, and the default is 24.

**Parameter**

<24|32>: SPI Flash address width.

**Example**

```
set_option -multiboot_address_width 32
```

**-multiboot\_spi\_flash\_address**

Specifies SPI Flash address.

**Syntax**

```
-multiboot_spi_flash_address <value>
```

**Usage**

Name	Description
<value>	SPI Flash address.

**Type**

[Project](#)

**Description**

Specifies the SPI Flash address. The SPI Flash address refers to the start address of the bitstream file to be loaded during the next multiboot, with the default value of 000000.

**Parameter**

< value>: SPI Flash address.

**Example**

```
set_option -multiboot_spi_flash_address 000110
```

**-multiboot\_mode**

Configures SPI Flash address access mode.

**Syntax**

```
-multiboot_mode <single | fast | dual | quad>
```

**Usage**

Name	Description
< single fast dual quad >	single: Uses single mode fast: Uses fast mode dual: Uses gedual mode quad: Uses gequad mode

**Type**

[Project](#)

**Description**

Configures SPI Flash address access mode, and the default is single.

**Parameter**

<single | fast | dual | quad>: SPI Flash address access mode.

**Example**

```
set_option -multiboot_mode single
```

**-mspi\_jump**

MSPI JUMP enable control.

**Syntax**

-mspi\_jump<0|1>

**Usage**

Name	Description
<0 1>	0: Disables MSPI JUMP. 1: Enables MSPI JUMP.

**Type**

[Project](#)

**Description**

MSPI JUMP enable control, and the default is 0.

**Parameter**

<0|1>: MSPI JUMP enable control.

**Example**

```
set_option -mspi_jump 1
```

**-merge\_jumpbit**

Merges the MSPI JUMP bitstream file into the general bitstream file.

**Syntax**

-merge\_jumpbit <0|1>

**Usage**

Name	Description
<0 1>	0: Do not merge the bitstream file. 1: Merges the bitstream file.

**Type**

[Project](#)

**Description**

Merges the MSPI JUMP bitstream file into the general bitstream file, and the default is 0.

**Parameter**

<0|1>: Enables control for merging the MSPI JUMP bitstream file into the general bitstream file.

**Example**

```
set_option -merge_jumpbit 1
```

**-mspijump\_address\_width**

Configures SPI Flash address width.

**Syntax**

-mspijump\_address\_width <24|32>

**Usage**

Name	Description
<24 32>	24: Sets the SPI Flash address width to 24. 32: Sets the SPI Flash address width to 32.

**Type**

[Project](#)

**Description**

Configures SPI Flash address width, and the default is 24.

**Parameter**

<24|32>: SPI Flash address width.

**Example**

```
set_option - mspijump_address_width 32
```

**-mspijump\_spi\_flash\_address**

Specifies SPI Flash address.

**Syntax**

-mspijump\_spi\_flash\_address <value>

**Usage**

Name	Description
<value>	SPI Flash address

**Type**

[Project](#)

**Description**

Specifies SPI Flash address, and the default is 000000.

**Parameter**

<value>: SPI Flash address

**Example**

```
set_option - mspijump_spi_flash_address 000110
```

**-mspijump\_mode<single | fast | dual | quad>**

Configures SPI Flash address access mode.

**Syntax**

-mspijump\_mode <single | fast | dual | quad>

**Usage**

Name	Description
< single fast dual quad >	single: Usagesingle mode fast: Usagefast mode dual: Usagedual mode quad: Usagequad mode

**Type**[Project](#)**Description**

Configures SPI Flash address access mode, and the default is single.

**Parameter**

< single | fast | dual | quad >: SPI Flash address access mode.

**Example**

```
set_option -mspijump_mode single
```

**-program\_done\_bypass**

Forward new bitstream.

**Syntax**

```
-program_done_bypass <0|1>
```

**Usage**

Name	Description
<0 1>	0: Disables this function. 1: Enables this function.

**Type**[Project](#)**Description**

After configuring this option, when the internal signal of Done Final is activated, the external Done Pin will remain low, allowing the new bitstream to be forwarded after the current bitstream is loaded. The default value is 0.

**Parameter**

<0|1>: Enable control for forwarding new bitstream.

**Example**

```
set_option -program_done_bypass 1
```

**-power\_on\_reset\_monitor <0|1>**

Power on reset.

**Syntax**

```
-power_on_reset_monitor <0|1>
```

**Usage**

Name	Description
<0 1>	0: Disables power on reset. 1: Enables power on reset.

**Type**[Project](#)**Description**

Enable control for power on reset. The default is 0.

**Parameter**

<0|1>: Enable control for power on reset.

**Example**

```
set_option -power_on_reset_monitor 1
```

**-turn\_off\_bg**

Bandgap function.

**Syntax**

-turn\_off\_bg <0|1>

**Usage**

Name	Description
<0 1>	0: Enables Bandgap. 1: Disables Bandgap.

**Type**[Project](#)**Description**

Enable control for Bandgap. The default is 0.

**Parameter**

<0|1>: Enable control for Bandgap.

**Example**

```
set_option -turn_off_bg 1
```

**-wakeup\_mode**

Wake Up Mode enable control.

**Syntax**

-wakeup\_mode <0|1>

**Usage**

Name	Description
<0 1>	0: Disables Wake Up Mode. 1: Enables Wake Up Mode.

**Type**

[Project](#)**Description**

Enable control for Wake Up Mode. The default is 0.

**Parameter**

<0|1>: Enable control for Wake Up Mode.

**Example**

```
set_option -wakeup_mode 1
```

**-user\_code**

Custom User Code.

**Syntax**

-user\_code <default|value>

**Usage**

Name	Description
<default value>	Custom User Cod value.

**Type**[Project](#)**Description**

Users can customize the User Code. The default value is default (00000000).

**Parameter**

<default|value>: Custom User Code.

**Example**

```
set_option -user_code 00000010
```

**Note!**

For a detailed explanation of the BitStream-related options, see BitStream section in [SUG100, Gowin Software User Guide](#).

**Unused Pin Property Configuration****-unused\_pin**

Sets different IO properties for unused GPIOs.

**Syntax**

-unused\_pin <default|open\_drain>

**Usage**

Name	Description
<default open_drain>	Default: All unused GPIO pins will be configured as input tri-state with weak pull-up. open_drain: All unused GPIO pins will be configured as output with setting OPEN DRAIN as ON.

**Type**[Project](#)**Description**

Sets different IO properties for unused GPIOs.

**Parameter**

<default|open\_drain>: Sets different IO properties for unused GPIOs.

**Example**

```
set_option -unused_pin open_drain
```

**Note!**

For a detailed explanation of Unused Pin-related options, see Unused Pin in [SUG100, Gowin Software User Guide](#).

### 3.2.20 set\_property

Sets the properties of an object.

**Syntax**

```
set_property [-dict <args>] <name> <value> <objects>
```

**Usage**

Name	Description
[-dict]	A property list of (name/value) pairs to be set.
<name>	The name of the property to be set. Not applicable when using -dict.
<value>	The value of the property to be set. Not applicable when using -dict.
<objects>	The object of the property to be set.

**Type**[IPFlow](#)**Description**

Configure options and their corresponding values for specified IP object.

**Parameter**

- [-dict]: Specifies a dictionary containing multiple pairs of options and their corresponding values. Each pair is defined as (<name> <value>), and multiple pairs are separated by spaces. The dictionary should be enclosed in curly braces {}.
- <name>: Specifies the name of the option to be configured. The description is in the form of CONFIG.property, and the property refers to the option name.
- <value>: Specifies the value for the corresponding option. The value needs to be valid according to the property type. If the option value is a string, it should follow the original form.

- **<objects>**: Specifies one or more IP objects for which the option is to be configured. A single object is specified using [get\_ips module\_name]. To specify multiple objects, use [get\_ips module\_name0 module\_name1 ...].

### Example

The -dict option is used to specify multiple properties in the current design at once:

```
set_property -dict {CONFIG.Data_Width 16 CONFIG.Write_Depth 1024 CONFIG.Read_Depth 1024} [get_ips FIFO_Top]
```

Use name, value, objects to specify a single property in the current design:

```
set_property CONFIG.Data_Width {16} [get_ips FIFO_Top]
```

This example shows how to set a property value that contains a hyphen ("-") or spaces:

```
set_property {CONFIG.Almost_Full_Type} {Full-Single Threshold Constant Parameter} [get_ips FIFO_Top]
```

### Note!

In some cases, the option value may contain special characters, such as a hyphen ("-") or spaces, which could cause the value to be incorrectly parsed. In such cases, it is necessary to enclose the option value in curly braces {}.

### See also

- [list\\_property](#)
- [report\\_property](#)

## 3.2.21 source

In tcl command editor window of Gowin Software, or after launching command-line mode, this command can be used to execute a tcl script. For file path formats, see [3.2.1 add\\_file](#).

### Syntax

```
source <file>
```

### Usage

Name	Description
<file>	The tcl script to be executed.

### Type

[IPFlow](#), [Project](#)

### Description

Sets different IO properties for unused GPIOs.

### Parameter

<file>: The tcl script to be executed.

**Example**

```
source project.tcl
source D:/gowin_project/project.tcl
source D:\\gowin_project\\project.tcl
```

**3.2.22 write\_ip\_tcl**

Exports a tcl script that can regenerate the given IP.

**Syntax**

```
write_ip_tcl [-ip_name <newModuleName>] [-multiple_files] [-force]
[<tcl_filename>] <objects>
```

**Usage**

Name	Description
[-ip_name]	Sets the IP module name
[-multiple_files]	Creates a separate .tcl file for each IP object
[-force]	Overwrites existing files
[<tcl_filename>]	Exported tcl file
<objects>	IP objects that export tcl files

**Type**

[IPFlow](#)

**Description**

This command is used to export tcl script files for specified IP objects, enabling regeneration of the IPs via tcl scripts. For file path formats, see [3.2.1 add\\_file](#).

**Parameter**

- [<tcl\_filename>]: Name of the generated tcl script file. If not specified, the current project name is used.
- <objects>: Specifies one or more IP objects to generate the tcl script. A single object is specified using [get\_ips module\_name], and multiple objects are specified using [get\_ips module\_name0 module\_name1 ...].
- [-ip\_name <newModuleName>]: Renames the IP module name in the generated tcl script. Only one object can be specified.
- [-multiple\_files]: Generates tcl script files for all specified IPs, with file names based on the respective module\_name. This option is mutually exclusive with -ip\_name and <tcl\_filename>.
- [-force] Overwrites existing tcl files with the same name.

**Example**

In this example, a tcl file is created, and this file is used to specify the IP object FIFO\_Top, but when using the source command, it is created with the new name FIFO\_Top\_new:

```
write_ip_tcl -ip_name FIFO_Top_new [get_ips FIFO_Top]
```

In this example, a separate tcl file is generated for each specified IP module in the project.

```
write_ip_tcl -multiple_files [get_ips FIFO_Top FIFO_Top_1]
```

In this example, multiple specified IP modules from the project are written into a single Tcl file:

```
write_ip_tcl [get_ips FIFO_Top  
p FIFO_Top_1] my_fifo.tcl
```

