

NOVAR LCD PANEL JOB AID

Lighting Overrides & Store Temperature Adjustments

The **Novar LCD Panel** provides important system information and easy access to:

- Override interior/exterior lighting and heating, ventilation, air conditioning (HVAC) for 2 hours
- Adjust temperature down by 2 degrees
- Roof Top Unit (RTU) operation
- Overnight operations for 10 hours

For any questions concerning the use of the LCD Panel or any Temperature/Lighting general service requests, contact **TJXEnergyMgmt_Dept@tjx.com** or call **877-541-5905, Option 1**.

Operation

To navigate the panel, press the appropriate **icon** on the **Home Screen** and then scroll to the desired line item using the **green arrows**.



The 3 **green** icons - **OVERNIGHT**, **2 HR TIMER** and **STORE TEMP** will be used by the store management team. The other 5 icons are for troubleshooting and system setup.




Press the **Home icon** located at the bottom left of the panel to return to the **Home Screen** at any time.

Password Setup

The Setpoint Adjustment and the Overnight function are password protected.

1. Enter the 4 digit store number as the password. Stores with less than 4 digits such as Store 5, enter 0005.
2. Press **OK** icon. Passwords time out after 60 seconds of inactivity and must be re-entered.




NOVAR LCD PANEL JOB AID


2 HR TIMER

Override interior/exterior lights and store temperature for 2 hours.


1. Press the **2 HR TIMER** icon.



2. Use the **green up/down arrows** to scroll through the list.



3. Press the desired lighting or store temperature to make it **Active**.



Inactive indicates override is **OFF**.
Active indicates override is **ON**.

Lighting overrides are scheduled to run for 120 minutes.


4. When finished, press the **Home** icon to return to the **Home Screen**.

NOVAR LCD PANEL JOB AID


STORE TEMP

Check the temperature in each area of the store.


1. Press the **STORE TEMP** icon to access the RTU menu.



2. Select the **RTU** to obtain the current area's temperature.



3. When finished, press the **Home** icon to return to the **Home Screen**.




NOVAR LCD PANEL JOB AID


Setpoint Adjustment

Adjust the temperature down 1 or 2 degrees (per RTU).


1. Press the **STORE TEMP** icon to access the RTU menu.



2. Select the **RTU** to obtain the current area's temperature.




3. Press the **Setpoint Adjust** tab. This function is password protected. Enter the 4 digit store number.




NOVAR LCD PANEL JOB AID


4. Adjust the setpoint down 1 or 2 degrees using the **green up/down arrows**.



5. When the temperature is set, press the **OK** icon.



6. When complete, press the **Home** icon to return to the Home Screen.



NOVAR LCD PANEL JOB AID


OVERNIGHT

Choose a 10 hour override for lighting and store temperature (HVAC) operations for projects performed in the store after hours such as a floor care service.


1. Press the **Overnight** icon. This function is password protected. Enter the 4 digit store number.



2. Press **Confirm Override**.




3. Choose **Yes** using the **green up/down arrows**.




NOVAR LCD PANEL JOB AID

4. Press the **OK** icon.



5. Overnight Status will change to **Active**.



6. When finished, press the **Home** icon to return to the **Home Screen**.

