

## Keyer I/F & AK4951 v2.0.1 Installation guide

17th Aug, 2017

ji1udd

Please read Errata document and do counter measure.

### HLv2 modification

1. Remove FB28 and install FB27 ( Vlvds is set to 3.3V ).
2. Remove J14 and install J13 ( CN4-3 and CN4-4 are set to Vlvds).
3. install three 0 ohm resistors at R85, R86 and R87 ( I2S signals are connect to AK4951).

### Note

When connectors are assembled, be care of placement tolerance.

