

# D-Link DWL-2100AP

## Supported Versions

H/W Ver.	S/N	OpenWrt Version Supported	Model Specific Notes
A2	-	backfire-10.03.1-rc1 [ <a href="https://forum.openwrt.org/viewtopic.php?id=27470">https://forum.openwrt.org/viewtopic.php?id=27470</a> ] & trunk [ <a href="http://downloads.openwrt.org/snapshots/trunk/atheros/">http://downloads.openwrt.org/snapshots/trunk/atheros/</a> ]	-
A3	-	-	-
A4	-	backfire-10.03.1-rc1 [ <a href="https://forum.openwrt.org/viewtopic.php?id=27470">https://forum.openwrt.org/viewtopic.php?id=27470</a> ] & trunk [ <a href="http://downloads.openwrt.org/snapshots/trunk/atheros/">http://downloads.openwrt.org/snapshots/trunk/atheros/</a> ]	-
A5	-	-	-

## Hardware Highlights

CPU	Ram	Flash	Network	USB	Serial	JTag
Atheros AR2313A @180MHz?	16MiB	4MiB	1	No	Yes	Yes

## Hardware

## Info

<b>Architecture:</b> MIPS 4Kc
<b>Vendor:</b> D-Link
<b>Bootloader:</b> (VxWorks)
<b>Wireless System-On-Chip:</b> Atheros AR2313A
<b>CPU Speed:</b> 180/240 MHz
<b>Flash-Chip:</b> AMD AM29LV320DB [ <a href="http://www.amd.com/us-en/assets/content_type/white_papers_and_tech_docs/23579c6.pdf">http://www.amd.com/us-en/assets/content_type/white_papers_and_tech_docs/23579c6.pdf</a> ] (A2) / Atmel AT49BV322A [ <a href="http://www.atmel.com/dyn/resources/prod_documents/doc3308.pdf">http://www.atmel.com/dyn/resources/prod_documents/doc3308.pdf</a> ] (A2, A3) / Spansion S29GL032M [ <a href="http://www.spansion.com/Support/Datasheets/s29gl-m_00_b8_e.pdf">http://www.spansion.com/Support/Datasheets/s29gl-m_00_b8_e.pdf</a> ] (A4) / Spansion S29AL032D90TFI04 [ <a href="http://www.spansion.com/Pages/Default.aspx">http://www.spansion.com/Pages/Default.aspx</a> ] (A4) / Macronix MX29LV320D [ <a href="http://datasheet.octopart.com/MX29LV320DBTI-70G-Macronix-datasheet-8325138.pdf">http://datasheet.octopart.com/MX29LV320DBTI-70G-Macronix-datasheet-8325138.pdf</a> ] (A5)
<b>Flash size:</b> 4 MiB
<b>RAM:</b> 16 MiB
<b>Wireless:</b> Atheros AR2112A
<b>Ethernet:</b> IC+ IP101 [ <a href="http://www.icplus.com.tw/pp-IP101.html">http://www.icplus.com.tw/pp-IP101.html</a> ] (A2) / IC+ IP101A [ <a href="http://www.icplus.com.tw/pp-IP101A.html">http://www.icplus.com.tw/pp-IP101A.html</a> ] (A2/A3/A4/A5)
<b>USB:</b> No
<b>Serial:</b> Yes [ <a href="http://wiki.openwrt.org/toh/d-link/dwl-2100ap#serial">http://wiki.openwrt.org/toh/d-link/dwl-2100ap#serial</a> ] 9600-8N1
<b>JTAG:</b> <u>Yes</u>

Same board uses in the Alpha Networks WAP-D19.


DWL-2100 A5 uses two antennas: printed on board (to right of LED "Wlan") and external.

## Opening the case


**Note:** This will void your warranty!

- To remove the cover loosen the two screws in the bottom cover and carefully lift the top cover at the back and move it towards the front (three clamps there).
- There are two screws holding the PCB to the bottom cover.

*Main PCB H/W Versions: A1, A2, A3*



*Main PCB H/W Versions: A4, a5*



## Serial

→ [port.serial](#).

Serial console represent hardware interface between router onboard serial port and PC. It is usually used to see bootprocess and interact boot loader. This is possible only if opening the case and attaching a TTL line converter cable. Then you can stop the boot process by sending `ESC` on bootup until you get a boot prompt and change the bootloader enviroment settings.



The serial communication signals on the 2100AP are ranging from 0 to 3.3V. These **must not** be connected directly to a RS232 cable, which operates at much broader voltage range (-12 to +12V). An appropriate level coupler must be built for this purpose. There are many such circuits on the net, and the simplest ones might use a common MAX 3232 chip.

Rev. A1, A2, A3


JP1 (12-pin, without headers, not for A4) is the serial port. It's wired very similarly to the serial port in the [Netgear WPN824](#) (also AR2313) and [Netgear WGT624](#) (AR2312)

### Serial

	1	JP1
VCC -	[ ]	( ) - VCC
RX -	( )	( )
	( )	( )
	( )	( )
TX -	( )	( )
	( )	( )

For GND use JTAG connector. See picture below.






**Rev. A2 only:** Some resistors (R264, R273, R275) are missing, so the serial port won't work. *I've bridged them with solder (since I don't have access to SMT equipment), and it seems like it's working. This is not needed for rev. A3.*

*Solder bridges at R275, R273 and R264 for rev. A2*

Check the voltage level of the gnd pin on jp1. If it is not ground, you have to get ground from the jtag J5 pin 2. This was the case with a rev. A2





Rev. A4, A5

JTAG is J5

Serial is JP2 (TTL levels - VCC 3.3V)

**JP2**

-1-	-2-	-3-	-4-
TX	VCC	GND	RX



## Installing

The DWL-2100AP's firmware is VxWorks [<http://www.windriver.com/products/vxworks/>] rtos with its own boot loader. Factory boot loader can load via TFTP and execute a MIPS elf executable. MIPS elf executable can be a OpenWrt ramdisk or modified bootloader.

## Ramdisk Network Boot

We can test OpenWrt without making any changes to flash. This way you can safely play with OpenWrt and preserve the original firmware in flash. If you backup the settings and config you made in OpenWrt and you need them later back, you can easily restore your saved backup.



You need a tftp server with openwrt-atheros-vmlinux.elf [<http://downloads.openwrt.org/backfire/10.03.1-rc6/atheros/openwrt-atheros-vmlinux.elf>] boot image in it's root folder.

Wait for the bootup and press ESC until you get a boot prompt.

```
$ae(1,0)hai:openwrt-atheros-vmlinux.elf h=192.168.1.254 e=192.168.1.20:0xffffffff00 f=0x80
```

where:

- hai is the hostname of the computer running tftp (not needed to be correct)
- h= sets the host computer ip adress
- e= sets the network adress and mask of the ap
- f= sets the flags to tftp boot and run

Original settings we get using command p to print settings):

```

ar531x rev 0x00005850 firmware startup...
SDRAM TEST...PASSED

WAP-G02A Boot Procedure                                V1.0
-----
Start ..Boot.B12..

theros AR5001AP default version 3.0.0.43A

1
[Boot]: ?

?                - print this list
@                - boot (load and go)
p                - print boot params
c                - change boot params
e                - print fatal exception
v                - print version
B                - change board data
S                - show board data
n netif          - print network interface device address
$dev(0,procnum)host:/file h=# e=# b=# g=# u=usr [pw=passwd] f=#
                  tn=targetname s=script o=other
boot device: tffs=drive,removable      file name: /tffs0/vxWorks
Boot flags:
  0x02 - load local system symbols
  0x04 - don't autoboot
  0x08 - quick autoboot (no countdown)
  0x20 - disable login security
  0x40 - use bootp to get boot parameters
  0x80 - use tftp to get boot image
  0x100 - use proxy arp

available boot devices:Enhanced Network Devices
a1 tffs
[Boot]: p

boot device      : tffs:
unit number     : 0
processor number : 0
file name       : /fl/APIMG1
inet on ethernet (e) : 192.168.1.20:0xffffffff00
flags (f)       : 0x0
other (o)       : ae

```

Changed settings (use command `c` to change settings):

```

[Boot]: p

boot device      : ae
unit number     : 1
processor number : 0
host name       : hai
file name       : openwrt-atheros-vmlinux.elf
inet on ethernet (e) : 192.168.1.20:0xffffffff00
host inet (h)   : 192.168.1.254
flags (f)       : 0x80
other (o)       : ae

```

## Bootloader replacement

By replacing the stock loader with modified Redboot we can install OpenWrt permanently. Replacing the loader is tricky because you need to get a version tailored for your device (correct hw. revision and flash type) - see in the forum and below! Here is a forum thread [<https://forum.openwrt.org/viewtopic.php?id=6357&p=1>] where RedBoot loader was discussed.

Vendor	Type	Loader
AMD	AM29LV320DB	Redboot [ <a href="http://rgghost.net/22011231">http://rgghost.net/22011231</a> ]
Atmel	AT49BV322A	-
Spansion	S29GL032D	Redboot [ <a href="http://rgghost.net/22011231">http://rgghost.net/22011231</a> ]
Spansion	S29GL032M	-
Macronix	MX29LV320D	-

Compiled RedBoot, need file "BootLoader Redboot con support Lzma (molto più veloce) per OpenWRT sul 2100AP" [<http://xoomer.virgilio.it/ramponis/Pages/flash.htm>]

## Install RedBoot using serial console

This is a experimental way to flash using only serial interface. RAM version of custom build RedBoot loader is needed from wich we can burn the permanent ROM version.



You need a TFTP server with both `redboot.img` (RAM version) and `redboot.bin` (ROM version) for your flash chip in it's root folder.

- Plug the AP and press ESC until you are prompted to [boot] in terminal window.
- Send `p` and write all lines from terminal output (to restore if needed), then with `c` change settings:

```
boot device      : ael
unit number     : 0
processor number : 0
file name       : redboot.img
inet on ethernet (e) : 192.168.1.20:ffffff00 //this is AP IP address
host inet (h)    : 192.168.1.254          //this is tftpd server IP address
gateway inet (g) :
flags (f)       : 0x80
other (o)       : ae
```

- Reboot AP, redboot RAM version have to load,
- Install redboot into ROM with next commands:

```
fis init -f
load -r -b ${FREEMEMLO} redboot.bin -h 192.168.1.254 -m tftp
fis create RedBoot
reset
```

- After AP reboot, redboot ROM version have to load and we are ready to install OpenWRT.



## Install RedBoot - jtag method

The safest way to change the boot loader is by using both j-tag and serial interface. If something gets borked, you can re-install the original firmware.

Connect JTAG cable and run `urjtag`. At prompt write *jtag*

```
jtag> cable WIGGLER PPDEV /dev/parport0 #this is for linux
jtag> cable WIGGLER parallel 0x378 #this is for Windows world
jtag> detect
jtag> include atheros/ar2312/ar2312
jtag> poke 0x58400000 0x000e3ce1
jtag> detectflash 0x1fc00000
jtag> flashmem 0x1fc00000 {path to file}/redboot(lzma).bin
```

## Install OpenWRT

	DWL-2100AP is supported from Backfire 10.03.1-rc1 [ <a href="http://downloads.openwrt.org/backfire/10.03.1-rc1/atheros/">http://downloads.openwrt.org/backfire/10.03.1-rc1/atheros/</a> ] on. *** (Rev. A2 tested [ <a href="https://forum.openwrt.org/viewtopic.php?pid=122738#p122738">https://forum.openwrt.org/viewtopic.php?pid=122738#p122738</a> ]) and trunk branch is working out of the box too.
	You need a redboot loader for your flash chip installed and a TFTP server with <code>openwrt-atheros-vmlinux.lzma</code> (kernel) and <code>openwrt-atheros-root.squashfs</code> (root file system) in it's root folder.

Next step is set loader environment up:

```
fconfig boot_script true
fconfig boot_script_timeout 2
fconfig
Run script at boot: true
Boot script:
..
Enter script, terminate with empty line
>> fis load -l linux
>> go
>>
Boot script timeout (1000ms resolution): 2
Use BOOTP for network configuration: false
Gateway IP address: 192.168.1.254
Local IP address: 192.168.1.1
Local IP address mask: 255.255.255.0
Default server IP address: 192.168.1.254
Console baud rate: 9600
DNS server IP address: 192.168.1.254
GDB connection port: 9000
Force console for special debug messages: false
Network debug at boot time: false
Update RedBoot non-volatile configuration - continue (y/n)? y
reset
```

After AP reboot and we are ready for OpenWRT install. *in this example ap is @192.168.1.1 & tftp server is @192.168.1.254*

```
fis init -f
load -r -b 0x80041000 openwrt-atheros-vmlinux.lzma
fis create -r 0x80041000 linux
load -r -b 0x80041000 openwrt-atheros-root.squashfs
fis create -r 0x80041000 -e 0x0 rootfs
reset
```

## Recovery Board Config


Connect JTAG cable, run urjtag

```
jtag> cable WIGGLER PPDEV /dev/parport0
jtag> detect
jtag> include atheros/ar2312/ar2312
jtag> poke 0x58400000 0x000e3ce1
jtag> detectflash 0x1FFF0000
jtag> flashmem 0x1FFF0000 {path to file}/eeprom_dwl2100hw4_3FFF0000-3FFF0800.bin
```

Here [<ftp://188.134.16.241/openwrt/DWL2100AP-A4/>] is `eeprom_dwl2100hw4_3FFF0000-3FFF0800.bin`

## JTAG



**WIGGLER JTAG cable for D-Link DWL-2100AP**edit by <http://skyprox.net.ru>Cf. [old Wiki page](#)See [port.jtag](#) for more JTAG details.

## Other Info

Cf. [old Wiki page](#)

### ■ CategoryModel

[Back to top](#)

toh/d-link/dwl-2100ap.txt · Last modified: 2013/11/24 08:30 by grumbler\_eburg



This text is licensed under a Creative Commons Attribution-ShareAlike 3.0 Unported License.