
Teseo-V Evaluation Board

Introduction

The **EVB-T5** evaluation board is a complete standalone evaluation platform for Teseo-V STA8100GA GNSS Receiver IC.

The EVB-T5 board is a complete standalone evaluation platform for Teseo-V STA8100GA GNSS Multi Band Receiver with STA5635A RF Front-End IC solution.

Teseo-V embeds the high performance ARM Cortex-M7 microprocessor with RF front-end able to support different bands (L1, L2 and L5), UART communication interfaces.

The STA5635A is a fully integrated RF front-end, able to support different bands (L2 and L5) with a programmable IF Bandwidth (7 or 13 MHz).

The EVB-T5 is designed for top performance Teseo-V GNSS IC.

1 Features

The EVB-T5 has the following features:

- USB Power Supply
- Internal backup battery placing (battery not provided)
- Push buttons to switch ON and OFF
- Reset button
- Boot button
- UART by USB connector
- ODO/CAN connector
- Leds:
 - PPS output LED
 - Power output LED
 - Antenna powered LED
- ST ASM330LHH MEMS

2 EVB-T5 general presentation

The EVB-T5 kit is composed of several elements:

- EVB-T5 Evaluation Board
- USB cable
- EVB-T5 Quick starting guide

3 Interfaces


The EVB-T5 offers different interfaces to the user:

- ON/OFF button
- Reset button
- Boot button
- μ USB use for interface with UART of Teseo-V
- Supply by USB (5 V)
- GNSS antenna input
- LED indicators

3.1 Power by USB

The micro USB connector (highlighted in pink, see [Figure 1](#)) allows supplying the board.

Figure 1. USB power input



In the [Table 1](#) below, the USB pin description:

Table 1. USB "J301" pin description

Pin	Connector signal	Comment
1	5 V USB	USB +5 V power supply
2	USB_DM	Differential Serial Data -
3	USB_DP	Differential Serial Data +
4	Not Connected	-
5	GND	Signal Ground

3.2 ON/OFF switch

When button (see [Figure 2](#)) is lifted, if the user presses the ON/OFF switch the board turns ON and the power LED turn on too.

When ON/OFF switch is lifted, VBAT is connected to GND, the board is switched OFF.


Figure 2. ON/OFF switch



3.3 Reset

The reset button (see [Figure 3](#)) is present on the front panel of the case, it resets the Teseo-V solution.

Figure 3. Reset button



3.4 Boot

A boot button (see [Figure 4](#)) is present on the front panel of the case, it's used during the Programming procedure.

Figure 4. Boot button



3.5 LED indicators

The EVB-T5 offers three LED Indicators as shown below:


- The PWR Red LED (see [Figure 5](#)) indicator shows whether the unit is ON (led is turned on) or OFF (led is turned off).

Figure 5. Power LED indicator




- The PPS Green LED (see [Figure 6](#)) indicator blinking every second indicates that Teseo-V is up and running.

Figure 6. PPS LED indicator




- The Antenna Power Led (see [Figure 7](#)) indicates if the antenna is powered (led on) or not powered (led off).

Figure 7. Antenna LED indicator


3.6 UART by USB

UART interface (see [Figure 8](#)) is provided via USB connector.

Figure 8. USB/UART connector


UART interface is used to trace NMEA messages and for upload binary file on system.

Before using UART/USB bridge, the user needs to install the VCP driver. It can be downloaded from Silabs web page (silabs.com).

The Virtual COM Port (VCP) device drivers allow the UART2USB device on EVB-T5 to appear to the PC's application software as a standard COM port. Application software running on the PC accesses the device as it would access a standard hardware COM port configured as shown in [Table 2](#). However, actual data transfer between the PC and the device is performed over the USB interface

Table 2. UART configuration

Baud rate	Data Bits	Stop Bits	Parity	Handshake
460800	8	1	none	none

Take care that on Windows10 the Universal Serial Driver has to be removed before installing the Silabs VCP driver.

3.7 ODO/CAN interface

The 4-pin connector (J500) provides CAN/ODO bus signals as shown in [Figure 9](#).

Figure 9. ODO/CAN connector


The signals CAN, ODO and REAR are muxed with I²C (use for MEMs) and MMC signals (see [Section 4.8 GPIOs](#) for muxing description).

The CAN Physical Layer Device (U503) is part of the evaluation board, thus a direct connection to a physical CAN bus is possible. CAN is configured in High speed 1 MHz.

ODO/REAR signal use VIO power supply, by default VIO is at 3.3 V. If Teseo-V is powered at 1.8 V please change VIO to 1.8 V (see [Section 4.8 GPIOs](#)).

Table 3. ODO/CAN "J500" pin description

Pin	Connector signal	Comment
1	REAR	Max. 15 V
2	ODO	Active tied to ground
3	CAN H	Connects to CAN line
4	CAN L	Connects to CAN line

This header allows connection of an external Odometer signal and/or CAN bus to the EVB-T5. The EVB-T5 offers interconnection to a CAN bus and/or to Odometer Pulses and a "reverse gear indication". These signals can be applied using connector J500. User can or cannot connect the 120 Ω ended of CAN Bus using the connector J501 as described in [Table 4](#)


Table 4. 120 Ω ended configuration

Connector J501	
Open (switch not fitted)	120 Ω ended disconnected
Closed (switch fitted)	120 Ω ended connected

3.8 GNSS input antenna

GNSS input (see [Figure 10](#)) is available through a SMA female connector.

Figure 10. GNSS SMA connector



Passive or active antenna can be used on EVB-T5. The DC power supply for active antenna is 3.3 V with current limitation in case of short circuit.

Note: Please use DC blocker for passive or simulator connected to EVB-T5.

3.9 MMC/SD_Interface

The EVB-T5 offers a "Micro-SD Card Connector" which can be used to record GPS/GLONASS Logs if an appropriate firmware is installed.

Figure 11. MMC/SD interface



The SD/MMC signals are muxed with REAR and ODO signals (see [Section 4.8 GPIOs](#) for muxing description). SD/MMC connector is described in [Table 5](#):

Table 5. MMC/SD "J404" pin description

Pin	Connector signal	Comment
1	Data 2	SD card Data Line (Bit 2)
2	Data 3	SD card Data Line (Bit 3)
3	CMD	Command Strobe
4	3.3 V	3.3 V Power Supply
5	CLK	SD Card Clock
6	GND	Signal Ground
7	Data 0	SD card Data Line (Bit 0)
8	Data 1	SD card Data Line (Bit 1)
A	SD_DETECT	Card Detect Signal (when inserted)
B	GND	Signal Ground

Note: Please choose at least a micro SD card class 4 to support baud rate of signal.

4 Internal function

4.1 ST ASM330LHH MEMS sensor

The EVB-T5 has the LSM6DSR (or the AMS330LHH for the automotive grade version) on board, it is a system-in-package featuring a 3D digital accelerometer and a 3D digital gyroscope with an extended full-scale range for the gyroscope, up to 4000 dps, and high stability in temperature. The device is interfaced through I²C.

4.2 Extra IMU sensor

The EVB-T5 has a DIL24 connector (J502 + J503) that allows to use new sensors release.

The connector J502 is described in [Table 6](#).

The connector J503 is described in [Table 7](#).

Table 6. Core Module Connector "J502" pin description

Pin	Connector signal	Comment
1	Power Supply	3.3 V
2	Power Supply	3.3 V
3	N.C.	Not Connected
4	N.C.	Not Connected
5	N.C.	Not Connected
6	N.C.	Not Connected
7	N.C.	Not Connected
8	N.C.	Not Connected
9	N.C.	Not Connected
10	N.C.	Not Connected
11	N.C.	Not Connected
12	N.C.	Not Connected

Table 7. Core Module Connector "J503" pin description

Pin	Connector signal	Comment
1	N.C.	Not Connected
2	N.C.	Not Connected
3	N.U.	Not Connected
4	SDO_SDA	I ² C Data
5	I ² C_SCL	I ² C Colck
6	N.C.	Not Connected
7	N.C.	Not Connected
8	N.C.	Not Connected
9	N.C.	Not Connected
10	N.C.	Not Connected
11	N.C.	Not Connected
12	GND	Ground

4.3 PPS

The PPS is driven by the GNSS SW and provides a Pulse Per Second and is powered by 3.3 V domain.

The EVB-T5 offers two ways to route the PPS signal:

- To use the LED indicator, as described in [Section 3.5 LED indicators](#) (selection is done by resistor).
- To use the SMA connector, selection is done by resistor R305 not mounted by default. (Ex. Ref SMA cable: MULTICOMP - R-632G7210100CB).

4.4 Wakeup

The EVB-T5 offers a push button on WAKE_UP signal for some test.

When Teseo V is in standby the WAKE_UP pin permits to exit the standby mode.

4.5 Standby_N

The EVB-T5 offers a jumper to change mode of the board. When the standby is active the power down for the internal voltage regulators is activated, the isolation always between region and switchable region is activated, and the reset to the switchable region is activated. Output notification of standby status is given through the pin STANDBY_OUT (level signal, active low).

Table 8. Teseo-V mode configuration

Connector J302	
Open (switch not fitted)	Teseo-V in normal mode
Closed (switch fitted)	Teseo-V in standby mode

4.6 Antenna power supply

For short circuit protection, the antenna has its switch on the power supply for current limitation. Power supply is switched off by software by GPIO ANT_EN. Power supply for antenna can have two values 5 V or 3.3 V.

Voltage selection can be done following the configuration in [Table 9](#).

Table 9. Antenna voltage selection description

Voltage	J306	J314
3.3 V	Open (switch not fitted)	Closed (switch fitted)
5 V	Closed (switch fitted)	Open (switch not fitted)

4.7 I/O Voltage

On EVB-T5 the I/O Voltage can be selected. EVB-T5 supports VIO at 1.8 V or 3.3 V. Selection can be done using the connector J505 as described in [Table 10](#).

Table 10. I/O Voltage "J505" configuration

VIO	Jumper Position
1.8 V	[1:2]
3.3 V (default)	[2:3]

4.8 GPIOs

The EVB-T5 provides five GPIOs. User can select which signal can be routed on a GPIO using a specific switch.

4.8.1 GPIO-0

Table 11. GPIO-0 "J313" configuration

Signal	Jumper Position
JTAG TRSTn	[2:3]
PPS_OUT (default)	[1:2]

4.8.2 GPIO-5

Table 12. GPIO-5 "J301" configuration

Signal	Jumper Position
CAN0 TX configuration	[2:3]
I²C SCL configuration (default)	[1:2]

4.8.3 GPIO-6

Table 13. GPIO-6 "J312" configuration

Signal	Jumper Position
CAN0 RX configuration	[2:3]
I²C SDA configuration (default)	[1:2]

4.8.4 GPIO-28

Table 14. GPIO-28 "J308" configuration

Signal	Jumper Position
MMC_DAT0 configuration	[2:3]
ODO configuration (default)	[1:2]

4.8.5 GPIO-29

Table 15. GPIO-29 "J307" configuration

Signal	Jumper Position
MMC_DAT1 configuration	[2:3]
REAR configuration (default)	[1:2]

4.9 Power enable

On the EVB-T5 the 3.3 V and 1.1 V power supply are on switchable domain, the EVB-T5 offers the possibility to force power switchable always on, always off or drive by STDBY_OUT using jumpers J600 and J601 (see [Table 16](#)).

Table 16. Power enabled jumpers configuration

Voltage	J600 position	J601 position
Power enable	[1:2]	Open (switch not fitted)
Power disable	[2:3]	Open (switch not fitted)
From STDBY_OUT	Open (switch not fitted)	Closed (switch fitted)

4.10 Current measurement

The EVB-T5 offers the possibility to measure current consumption on three input voltages. Removal jumpers on the following headers can permit to do the current measurement:

Table 17. Current measurement

Header	Signal	Voltage
J309	VCC (pin 25 MOD-T5)	3.3 V
J310	VBAT (pin 25 MOD-T5)	3.3 V
J311	EXT_VCC (pin 25 MOD-T5)	1.2 V or 1.8 V


4.11 Reference documents

- Teseo Suite – Data brief (DB3224, DocID030398)

5 Board general view

The EVB-T5 Evaluation Board is shown in Figure 12.

Figure 12. Internal board view




5.1 Default jumper configuration

Table 18. Default jumper configuration

Jumper	Position
J301	[1:2]
J304	[2:3]
J305	[2:3]
J307	[2:3]
J308	[2:3]
J312	[1:2]
J313	[1:2]
J314	[1:2]
J505	[1:2]
J600	[1:2]
J302	Open
J306	Open
J311	Open
J501	Open
J601	Open
J309	Closed
J310	Closed
J400	Closed

5.2 Block diagram overview

Figure 13. Block diagram



Revision history

Table 19. Document revision history

Date	Version	Changes
14-Feb-2020	1	Initial release.

Contents

1	Features.....	2
2	EVB-T5 general presentation.....	3
3	Interfaces	4
3.1	Power by USB	4
3.2	ON/OFF switch	4
3.3	Reset	5
3.4	Boot.....	5
3.5	LED indicators	5
3.6	UART by USB	6
3.7	ODO/CAN interface	6
3.8	GNSS input antenna.....	7
3.9	MMC/SD_Interface	8
4	Internal function	9
4.1	ST ASM330LHH MEMS sensor	9
4.2	Extra IMU sensor.....	9
4.3	PPS.....	10
4.4	Wakeup	10
4.5	Standby_N.....	10
4.6	Antenna power supply	11
4.7	I/O Voltage	11
4.8	GPIOs.....	11
4.8.1	GPIO-0	11
4.8.2	GPIO-5	11
4.8.3	GPIO-6	11
4.8.4	GPIO-28	11
4.8.5	GPIO-29	12
4.9	Power enable.....	12
4.10	Current measurement.....	12
4.11	Reference documents.....	12

5	Board general view	13
5.1	Default jumper configuration	13
5.2	Block diagram overview	13
	Revision history	15

List of tables

Table 1.	USB "J301" pin description	4
Table 2.	UART configuration	6
Table 3.	ODO/CAN "J500" pin description	7
Table 4.	120 Ω ended configuration	7
Table 5.	MMC/SD "J404" pin description	8
Table 6.	Core Module Connector "J502" pin description	9
Table 7.	Core Module Connector "J503" pin description	10
Table 8.	Teseo-V mode configuration	10
Table 9.	Antenna voltage selection description	11
Table 10.	I/O Voltage "J505" configuration	11
Table 11.	GPIO-0 "J313" configuration	11
Table 12.	GPIO-5 "J301" configuration	11
Table 13.	GPIO-6 "J312" configuration	11
Table 14.	GPIO-28 "J308" configuration	12
Table 15.	GPIO-29 "J307" configuration	12
Table 16.	Power enabled jumpers configuration	12
Table 17.	Current measuremet	12
Table 18.	Default jumper configuration	13
Table 19.	Document revision history	15

List of figures

Figure 1.	USB power input.	4
Figure 2.	ON/OFF switch.	4
Figure 3.	Reset button	5
Figure 4.	Boot button	5
Figure 5.	Power LED indicator	5
Figure 6.	PPS LED indicator	5
Figure 7.	Antenna LED indicator.	6
Figure 8.	USB/UART connector	6
Figure 9.	ODO/CAN connector.	6
Figure 10.	GNSS SMA connector.	7
Figure 11.	MMC/SD interface.	8
Figure 12.	Internal board view	13
Figure 13.	Block diagram	14

IMPORTANT NOTICE – PLEASE READ CAREFULLY

STMicroelectronics NV and its subsidiaries ("ST") reserve the right to make changes, corrections, enhancements, modifications, and improvements to ST products and/or to this document at any time without notice. Purchasers should obtain the latest relevant information on ST products before placing orders. ST products are sold pursuant to ST's terms and conditions of sale in place at the time of order acknowledgement.

Purchasers are solely responsible for the choice, selection, and use of ST products and ST assumes no liability for application assistance or the design of Purchasers' products.

No license, express or implied, to any intellectual property right is granted by ST herein.

Resale of ST products with provisions different from the information set forth herein shall void any warranty granted by ST for such product.

ST and the ST logo are trademarks of ST. For additional information about ST trademarks, please refer to www.st.com/trademarks. All other product or service names are the property of their respective owners.

Information in this document supersedes and replaces information previously supplied in any prior versions of this document.

© 2020 STMicroelectronics – All rights reserved